# Screening for Environmental Hazards at Sites with Contaminated Soil and Groundwater

Volume 2: Background Documentation for the Development of Tier 1 Environmental Action Levels

### **Appendix 6**

Prepared by:

Hawai'i Department of Health Environmental Management Division 2385 Waimano Home Road Pearl City, Hawai'i 96782

Spring 2024

#### **Contacts**:

Roger Brewer Hawai'i Department of Health

Environmental Management Division

Hazard Evaluation and Emergency Response

Telephone: 1-808-586-4249

E-mail: roger.brewer@doh.hawaii.gov

http://hawaii.gov/health/environmental/hazard/index.html

#### OR

Roxanne Kwan Hawai'i Department of Health Environmental Management Division Solid and Hazard Waste Branch Telephone: 1-808-586-4226

E-mail: roxanne.kwan@doh.hawaii.gov

#### DISCLAIMER

This document, Evaluation of Environmental Hazards at Sites with Contaminated Soil and Groundwater (Spring 2024), is a technical report prepared by staff of the Hawai'i Department of Health (HDOH), Environmental Management Division. The document updates and replaces the Summer 2017 edition of the same document. A summary of the Spring 2024 updates is provided in Appendix 9.

The document provides guidance for identification and evaluation of environmental hazards associated with contaminated soil and groundwater. The Environmental Action Levels (EALs) presented in this document and the accompanying text are specifically *not* intended to serve as: 1) a stand-alone decision making tool, 2) guidance for the preparation of baseline environmental risk assessments, 3) a rule to determine if a waste is hazardous under the state or federal regulations, or 4) a rule to determine when the release of hazardous substances must be reported to the HDOH.

The information presented in this document is not final action. HDOH reserves the right to change this information at any time without public notice. This document is not intended, nor can it be relied upon, to create any rights enforceable by any party in litigation in areas associated with HDOH. HDOH may elect to follow the information provided herein or act at a variance with the information, based on an analysis of site-specific circumstances.

This document will be periodically updated. Please send comments, edits, etc. in writing to the above contact. This document is not copyrighted. Copies may be freely made and distributed. It is cautioned, however, that reference to the action levels presented in this document without adequate review of the accompanying narrative could result in misinterpretation and misuse of the information. Comments and suggestions for updates are welcome at any time.

Hawai'i DOH
Spring 2024
Appendix 6

## VOLUME 2: BACKGROUND DOCUMENTATION FOR THE DEVELOPMENT OF TIER 1 SOIL AND GROUNDWATER ACTION LEVELS

#### **APPENDICES**

- 1 DEVELOPMENT OF TIER 1 LOOKUP TABLES
- 2 SUMMARY OF HUMAN HEALTH RISK-BASED EQUATIONS AND DEFAULT INPUT PARAMETER VALUES; USEPA REGIONAL SCREENING LEVELS USER'S GUIDE (MAY 2016)
- 3 RELEVANT PORTIONS OF *USER'S GUIDE FOR THE JOHNSON AND ETTINGER* (1991) MODEL FOR SUBSURFACE VAPOR INTRUSION INTO BUILDINGS; SENSITIVITY ANALYSIS OF *JOHNSON AND ETTINGER* (1991) MODEL
- 4 EXAMPLE PRINTOUTS OF VAPOR INTRUSION MODELS
- 5 DEVELOPMENT OF SOIL LEACHING SCREENING LEVELS
- 6 DEVELOPMENT OF CARBON RANGE AND TOTAL PETROLEUM HYDROCARBON RISK-BASED ACTION LEVELS
- 7 DETERMINATION OF GROUNDWATER UTILITY (HDOH 1995)
- 8 SUPPLEMENTAL HDOH TECHNICAL GUIDANCE DOCUMENTS
- 9 UPDATES TO 2011 EHE GUIDANCE DOCUMENT

#### GLOSSARY OF TERMS

AWQC: Aquatic Water Quality Criteria

CCC: Criterion for Continuous Concentration

CCM: Criterion for Maximum Concentration

EPA: Environmental Protection Agency

ESL: Environmental Screening Level

FVC: Final Chronic Value

HIDOH: Hawai'i Department of Health

HH: Human Health-consumption of aquatic organisms

LOEL: Lowest-Observed-Effects Level

MADEP: Massachusetts Department of Environmental Protection

MCL: Maximum Concentration Level

MOEE: Ontario Ministry of Environment and Energy

MTBE: Methyl tert-Butyl Ethylene

PCE: Tetrachloroethylene

PRG: Preliminary Remediation Goals RBSL: Risk-Based Screening Level

RSL: Regional Screening Level

RWQCB: Regional Water Quality Control Board

TPH: Total Petroleum Hydrocarbons

USEPA: U.S. Environmental Protection Agency

USDOE: U.S. Department of Energy

Hawai'i DOH Spring 2024

## **APPENDIX 6**

## DEVELOPMENT OF CARBON RANGE AND TOTAL PETROLEUM HYDROCARBON RISK-BASED ACTION LEVELS

- Chemistry and Toxicity of Petroleum Fuels (HDOH 2024)
- JP-5 Water-Fuel Study Laboratory Report (HIDOH 2023b)
- Chemistry and Toxicity of Petroleum Vapors (Brewer et al (2013)
- Common TPH questions (HDOH 2012)
- 2002 Massachusetts VPH-EPH Guidance
- Overview of gasoline composition (NEIWPCC, 2003)
- Use of TPH Action Levels (HDOH 2024) + Forensic Drinking Water Characterization (Newfields 2024)

# HDOH Laboratory Study of the Chemistry and Toxicity of Petroleum Fuels -Summary Text and Tables-

#### **Updates**

October 7, 2024: Appendix 6. Fuel Study Data Summary

#### **Diesel**

Table D. Dermal absorption factors weighted for the default carbon range makeup of dissolved-phase diesel. "TPH (diesel) Undegraded" dermal absorption factors "t\*" and "KP" corrected to values used in TPH action level model (identical to gasoline). TPH action levels not affected.

#### **Methods**

#### 1.0 Introduction

A detailed laboratory study of the benzene, toluene, ethylbenzene, xylene, methylnaphthalene and naphthalene (BTEXMN) and carbon range makeup of several gasolines, middle distillates and heavy oils was carried out by Newfields Environmental (Newfields 2022) on behalf of the Hawaii Department of Health (HDOH). A copy of the report is included as an attachment to this appendix. Descriptive summaries of the data are provided in Section 6 of Appendix 1. Detailed summaries for each fuel type are provided in Tables 1-5 below. The results are used in subsequent, detailed tables to describe calculation of weighted, Total Petroleum Hydrocarbon (TPH) toxicity factors for gasoline, diesel and Bunker C (Fuel Oil #6). The resulting toxicity factors are utilized to calculate risk-based action levels for TPH associated with gasolines, middle distillate fuels and residual fuels in Appendix 1 of the EHE guidance.

The reported concentrations of BTEXMN and carbon ranges in fuels initially reported by the laboratory do not sum to 100% (Table 1). It is possible that a portion of the error is related to the presence of non-hydrocarbon-related organic matter in the samples or laboratory artifacts. Newfields Environmental advised, however, that the majority of the missing mass is in large part due to limitations of carbon range lab methods to test neat fuel. The "Percent Unaccounted Carbon Range Mass" is noted at the bottom of the table. BTEXMN data reported by laboratory is assumed to be reasonably accurate given lower anticipated error in the analytical method employed. The relative proportion (but not the reported concentration) of carbon ranges is also assumed to be reasonably accurate.

Individual carbon range data are adjusted upwards in Table 2 to generate a total hydrocarbon concentration of 1,000,000 mg/kg or 100% as follows:

Adjusted Carbon Range Concentration = Initially Reported Concentration + (Initially Reported Concentration x Percent Unaccounted Carbon Range Mass).

This provides a more accurate estimate of the relative proportion of BTEXMN to carbon range compounds in a fuel. Note that this adjustment does not affect the weighted toxicity of the carbon range mixture as a whole since the relative proportion of carbon range groupings does not change.

#### 2.0 Predicted Makeup of Dissolved-Phase Petroleum Fuels in Water

The carbon range and BTEXMN makeup of dissolved-phase fuel in water that is in contact with fresh product can be estimated based on the weight percent and effective solubility of compounds in the parent fuel mixture. The effective solubility of individual components of a fuel is calculated in accordance with Raoult's Law as (after O'Reilly et al. 2001):

$$C_i = x_i \times S_i$$
 Eq 1)

where:

 $C_i$  = Effective solubility of the compound;

 $x_i = Mole$  fraction; and

 $S_i$  = Pure component solubility.

The mole fraction reflects the ratio of the number of moles of one component of a solution to the total number of moles representing all of the components, in this case TPH carbon ranges and BTEXMN, and is calculated as

$$x_i = \begin{bmatrix} \frac{w_i \times 0.01}{MW_i} \\ \frac{1}{MW_{ave}} \end{bmatrix}$$
 Eq 2)

where:

w<sub>i</sub> =Weight percent of the constituent in the mixture (converted to a fraction);

MW<sub>i</sub> = Average molecular weight of the constituent; and

MW<sub>ave</sub> = Average molecular weight of the mixture.

The equation assumes that the total mass of the fuel is equal to one mole.

Equations 1 and 2 can be simplified to:

$$C_i = \left(\frac{w_i \times 0.01}{MW_i} \times MW_{ave}\right) \times S_i.$$
 Eq 3).

Physiochemical constants for BTEXMN and carbon range compounds, including molecular weights, are provided in Table 7. Default molecular weights assigned to individual fuel types are provided in the footnotes to Table A for each fuel in attached summary tables. This equation can be used to calculate effective solubilities for BTEXMN and carbon ranges based on published data for various fuel types. The effective solubilities are assumed to reflect the relative makeup of dissolved-phase hydrocarbons in water that is in direct contact with fresh product.

#### 3.0 Calculation of Weighted Toxicity Factors

Weighted Harmonic Means

Selected toxicity factors for BTEXMN and individual carbon ranges compounds are noted in Table 6. The harmonic mean weighted to the relative proportion of targeted compounds in a mixture is used to calculate weighted toxicity factors for dissolved-phase mixtures (ORDEQ 2003). Use of the harmonic mean rather than arithmetic average biases the results to the more toxic component of the mixture and is conservative. Weighted toxicity factors for non-degraded compounds consider only the non-BTEXMN carbon range fraction of the mixture. Remaining BTEXMN compounds are assumed to be tested for and assessed separately. The weighted toxicity of degraded mixtures is, in contrast, based on the relative proportion of the combined carbon range and BTEXMN compounds in the original mixture.

Weighted Toxicity Factors

Weighted, oral Reference Doses (RfDs) are calculated as:

Weighted RfD<sub>oral</sub> (mg/kg-day) = 
$$\frac{1}{\left[\frac{(\% Fraction A)}{Fraction A RfDoral} + \frac{(\% Fraction B)}{Fraction B RfD oral} + etc.\right]}$$
 Eq 4)

where:

% Fraction "X" = Percent makeup of the subject carbon range fraction +/- BTEXMN relative to the total concentration of measured carbon ranges;

HDOH Appendix 6

Fraction "X" Toxicity Factor = Toxicity factor assigned to subject carbon range fraction +/-BTEXMN.

Weighted toxicity factors for dermal exposure are calculated using a similar approach:

Weighted RfD<sub>dermal</sub> (mg/kg-day) = 
$$\frac{1}{\left[\frac{(\% Fraction A)}{Fraction A RfD dermal} + \frac{(\% Fraction B)}{Fraction B RfD dermal} + etc.\right]}$$
 Eq 5).

Dermal toxicity factors for non-degraded mixtures focus on more soluble and less volatile, C13+ aromatic compounds. Calculation of weighted, dermal toxicity factors for degraded mixtures again requires consideration of combined, original carbon range and BTEXMN mixture.

Weighted Reference Concentrations (RfCs) applicable to the inhalation exposure focus on volatile aromatic and aliphatic carbon ranges but were otherwise calculated in a similar manner:

Weighted RfC (
$$\mu$$
g/m<sup>3</sup>) = 
$$\frac{1}{\left[\frac{(\% Fraction A)}{Fraction A RfC} + \frac{(\% Fraction B)}{Fraction B RfC} + etc.\right]}}$$
 Eq 6).

Inhalation toxicity factors for non-degraded compounds focus on the relative makeup of volatile, C5-C12 aliphatic and C9-C12 aromatic carbon ranges in the dissolved-phase mixture. Inhalation toxicity factors are again not calculated for since degraded carbon range and BTEXMN compounds are assumed to be of low volatility.

#### References

ATSDR, 1995, Toxicological Profile for Gasoline: Agency for Toxic Substances and Disease Registry, June 1995.

CountryMark, 2021, No. 6 Fuel Oil, Material Safety Data Sheet: Countrymark Refining and Logistics, LLC, December 2012.

Gustafson, J.B., Tell, J.G. and D. Orem, 1997. Selection of Representative TPH Fractions Based on Fate and Transport Considerations: Total Petroleum Hydrocarbon Working Group Series; Association for Environmental Health and Sciences: Amherst, MA, USA, Volume 3.ISBN 1-884-940-12-9.

IARC, 1989, IARC Monographs on the Evaluation of Carcinogenic Risks to Humans: International Agency for Research on Cancer, No. 45., Lyon, France. https://www.ncbi.nlm.nih.gov/books/NBK531265/

Newfields, 2022, Supplemental Analytical Data in Support of Hawaii Department of Health Fuel Study: Newfields Environmental, October 28, 2022.

NRC, 1996, Permissible Exposure Levels for Selected Military Fuel Vapors: National Research Council, Subcommittee on Permissible Exposure Levels for Military Fuels, National Academies Press, Washington, D.C.

ORDEQ, 2003, Risk-Based Decision Making for the Remediation of Petroleum- Contaminated Sites: Oregon Department of Environmental Quality, Environmental Cleanup and Tanks Program, September 2003.

O'Reilly, K.T., McGaw, R.I and W.G. Rixey, 2001, Predicting the Effect of Hydrocarbon and Hydrocarbon-Impacted Soil on Groundwater: American Petroleum Institute, September 2001, Bulletin No. 14.

USEPA, 2023, Regional Screening Levels: U.S. Environmental Protection Agency, November 2023, prepared by Oak Ridge National Laboratories, https://www.epa.gov/risk/regional-screening-levels-rsls-generic-tables

## **Fuel Study Data Summary**

Table 1. Unadjusted fuel makeup data reported for fuel samples (Newfields 2022).

Tuore 1. Chaagastea 14		•		GASC	OLINE 8										
	GASO	DLINE 8	37	(Du	plicate)		GASO	DLINE 9	)1	GASO	OLINE 9	3	HEAT	ING FUI	EL
Analytes	mg/kg	Flag	RL	mg/kg	Flag	RL	mg/kg	Flag	RL	mg/kg	Flag	RL	mg/kg	Flag	RL
Benzene	9,120	D		9,230	D		8,770	D		8,810	D		31	JD	
Toluene	50,200	D		49,400	D		47,600	D		50,200	D		110	D	
Ethylbenzene	11,800	D		11,600	D		10,600	D		11,300	D		344	D	
Xylenes	63,200			62,100			57,100			60,100			2,347		
1-Methylnapthalene	488	D		577	D		473	D		407	D		1,280	D	
2-Methylnapthalene	1,040	D		1,250	D		1,010	D		882	D		2,180	D	
Naphthalene	1,850	D		2,090	D		1,790	D		1,540	D		790	D	
Total BTEXMN:	137,698			136,247			127,343			133,239			7,082		
C5-C6 Aliphatics	170,700		94	163,393		94	190,941		98	183,440		88		U	98
>C6-C8 Aliphatics	180,170		94	175,110		94	179,301		98	172,496		88	1,059		98
>C8-C10 Aliphatics	36,595		3,130	42,871		3,130	38,359		3,210	33,345		2,930	23,794		2,940
>C10-C12 Aliphatics	11,737		3,130	13,428		3,130	11,464		3,210	9,562		2,930	80,983		2,940
>C12-C16 Aliphatics	2,667	J	3,130	2,843	J	3,130	2,275	J	3,210	2,069	J	2,930	203,122		2,940
>C16-C21 Aliphatics		U	3,130		U	3,130		U	3,210		U	2,930	166,328		2,940
>C21-C32 Aliphatics		U	3,130		U	3,130		U	3,210		U	2,930	33,481		2,940
>C8-C10 Aromatics	73,977		3,130	74,732		3,130	62,778		3,210	65,763		2,930	6,507		2,940
>C10-C12 Aromatics	26,981		3,130	27,755		3,130	22,066		3,210	24,006		2,930	30,293		2,940
>C12-C16 Aromatics	4,315		3,130	4,564		3,130	3,524		3,210	3,847		2,930	111,016		2,940
>C16-C21 Aromatics		U	3,130		U	3,130		U	3,210		U	2,930	82,640		2,940
>C21-C32 Aromatics		U	3,130		U	3,130		U	3,210		U	2,930	15,036		2,940
<sup>1</sup> Total Carbon Ranges:	507,143			504,696			510,709			494,527			754,259		
Total BTEXMN + Carbon Ranges:	644,841			640,943			638,052			627,766			761,342		
<b>Unaccounted Mass:</b>	355,159			359,057			361,948			372,234			238,658		
<sup>1</sup> Percent Unaccounted Mass for Total Data:	36%			36%			36%			37%			24%		
<sup>2</sup> Percent Unaccounted Carbon Range Mass:	70%			71%			71%			75%			32%		

Table 1 (cont.). Unadjusted fuel makeup data reported for fuel samples (Newfields 2022).

, , , ,	ROAI	) DIESE	EL		JP-5			JP-8		BU	NKER (		WASTE	OIL (A	UTO)
Analytes	mg/kg	Flag	RL	mg/kg	Flag	RL	mg/kg	Flag	RL	mg/kg	Flag	RL	mg/kg	Flag	RL
Benzene	90	JD		40	JD		129	JD		11	JBD		11	В	
Toluene	674	D		252	D		3,070	D		8.3	JD		248		
Ethylbenzene	1,600	D		492	D		5,400	D		5.5	JD		161		
Xylenes	11,630			2,495			36,900			35			988		
1-Methylnapthalene	896	D		4,810	D		4,680	D		913	D		506		
2-Methylnapthalene	1,650	D		6,900	D		7,550	D		1,620	D		945		
Naphthalene	560	D		3,490	D		4,050	D		1,120	D		386		
Total BTEXMN:	17,100			18,479			61,779			3,713			3,245		
C5-C6 Aliphatics	553		91	378		200	3,250		200		U	37	110		9.9
>C6-C8 Aliphatics	4,410		91	3,134		200	29,433		200		U	37	494		9.9
>C8-C10 Aliphatics	31,373		2,950	60,460		1,650	151,534		1,650		U	3,190		U	2,950
>C10-C12 Aliphatics	61,092		2,950	278,612		1,650	180,422		1,650	14,228		3,190		U	2,950
>C12-C16 Aliphatics	196,045		2,950	315,662		1,650	234,688		1,650	51,074		3,190	1,822	J	2,950
>C16-C21 Aliphatics	212,713		2,950	2,264		1,650	20,794		1,650	68,425		3,190	9,434		2,950
>C21-C32 Aliphatics	35,117		2,950		U	1,650		U	1,650	182,967		3,190	652,672		2,950
>C8-C10 Aromatics	22,417		2,950	7,506		1,650	30,291		1,650		U	3,190	2,177	J	2,950
>C10-C12 Aromatics	42,287		2,950	55,836		1,650	39,115		1,650	6,891		3,190	3,629		2,950
>C12-C16 Aromatics	110,031		2,950	90,500		1,650	73,316		1,650	30,159		3,190	4,970		2,950
>C16-C21 Aromatics	75,319		2,950	1,696		1,650	5,797		1,650	37,074		3,190	6,738		2,950
>C21-C32 Aromatics	12,839		2,950		U	1,650		U	1,650	84,564		3,190	60,655		2,950
<sup>1</sup> Total Carbon Ranges:	804,196			816,049			768,640			475,383			742,702		
Total BTEXMN + Carbon Ranges:	821,296			834,527			830,419			479,096			745,947		
<b>Unaccounted Mass:</b>	178,704			165,473			169,581			520,904			254,053		
<sup>1</sup> Percent Unaccounted Mass for Total Data:	18%			17%			17%			52%			25%		
<sup>2</sup> Percent Unaccounted Carbon Range Mass:	22%			20%			22%			110%			34%		

Laboratory Data Flags: D = Sample Diluted; J = Concentration below the Method Reporting Limit (RL); U = Not detected.

- 1. Percent unaccounted mass necessary for sum of BTEXMN and total carbon range data to be 1,000,000 mg/kg.
- 2. Percent unaccounted mass attributable to carbon range data error only assuming that BTEXMN data are accurate. Values used to adjust carbon range data in Table 2.

Table 2. <sup>1</sup>Adjustment of fuel makeup data to account for unreported carbon range mass (refer to Table 1).

Tuote 2. Trajustment of I	GASOLINE 87	GASOLINE 87	GASOLINE 91	GASOLINE 93	HEATING FUEL
Analytes	(mg/kg)	(Dup) (mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)
Benzene	9,120	9,230	8,770	8,810	31
Toluene	50,200	49,400	47,600	50,200	110
Ethylbenzene	11,800	11,600	10,600	11,300	344
Xylenes	63,200	62,100	57,100	60,100	2,347
1-Methylnapthalene	488	577	473	407	1,280
2-Methylnapthalene	1,040	1,250	1,010	882	2,180
Naphthalene	1,850	2,090	1,790	1,540	790
Total BTEXMN:	137,698	136,247	127,343	133,239	7,082
C5-C6 Aliphatics	290,244	279,636	326,264	321,517	ND (<98)
>C6-C8 Aliphatics	306,346	299,689	306,375	302,334	1,394
>C8-C10 Aliphatics	62,223	73,371	65,545	58,444	31,323
>C10-C12 Aliphatics	19,957	22,982	19,589	16,759	106,607
>C12-C16 Aliphatics	4,534	4,866	3,888	3,627	267,393
>C16-C21 Aliphatics	ND (<3,130)	ND (<3,130)	ND (<3,210)	ND (<2,930)	218,956
>C21-C32 Aliphatics	ND (<3,130)	ND (<3,130)	ND (<3,210)	ND (<2,930)	44,075
>C8-C10 Aromatics	125,785	127,898	107,270	115,263	8,566
>C10-C12 Aromatics	45,876	47,500	37,705	42,075	39,878
>C12-C16 Aromatics	7,337	7,811	6,021	6,742	146,143
>C16-C21 Aromatics	ND (<3,130)	ND (<3,130)	ND (<3,210)	ND (<2,930)	108,788
>C21-C32 Aromatics	ND (<3,130)	ND (<3,130)	ND (<3,210)	ND (<2,930)	19,794
<sup>1</sup> Total Carbon Ranges:	862,302	863,753	872,657	866,761	992,918
Total BTEXMN + Carbon Ranges:	1,000,000	1,000,000	1,000,000	1,000,000	1,000,000

<sup>1.</sup> Raw data noted in Table 1 adjusted in consultation with Newfields Environmental to generate a total hydrocarbon concentration of 1,000,000 mg/kg for each sample. BTEXMN data reported by laboratory assumed accurate. Unaccounted mass assumed to be related to error in reported concentration of carbon ranges. Relative proportion of carbon ranges assumed to be reasonably accurate. Individual carbon range data adjusted upwards based on the calculated "Percent Unaccounted Carbon Range Mass" to normalize data to 1,000,000 mg/kg (100%) total mass (Adjusted Carbon Range Concentration = Initially Reported Concentration + (Initially Reported Concentration x Percent Unaccounted Carbon Range Mass).

Table 2 (cont.). <sup>1</sup>Adjustment of fuel makeup data to account for unreported carbon range mass (refer to Table 1).

	ROAD DIESEL	JP-5	JP-8	BUNKER C	WASTE OIL (AUTO)
Analytes	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)	(mg/kg)
Benzene	90	40	129	11	11
Toluene	674	252	3,070	8.3	248
Ethylbenzene	1,600	492	5,400	5.5	161
Xylenes	11,630	2,495	36,900	35	988
1-Methylnapthalene	896	4,810	4,680	913	506
2-Methylnapthalene	1,650	6,900	7,550	1,620	945
Naphthalene	560	3,490	4,050	1,120	386
Total BTEXMN:	17,100	18,479	61,779	3,713	3,245
C5-C6 Aliphatics	676	455	3,967	ND (<37)	148
>C6-C8 Aliphatics	5,390	3,769	35,926	ND (<37)	663
>C8-C10 Aliphatics	38,344	72,720	184,966	ND (<3,190)	ND (<2,950)
>C10-C12 Aliphatics	74,668	335,107	220,228	29,818	ND (<2,950)
>C12-C16 Aliphatics	239,609	379,670	286,465	107,040	2,445
>C16-C21 Aliphatics	259,981	2,724	25,382	143,402	12,661
>C21-C32 Aliphatics	42,921	ND (<1,650)	ND (<1,650)	383,455	875,929
>C8-C10 Aromatics	27,399	9,028	36,974	ND (<3,190)	2,922
>C10-C12 Aromatics	51,684	67,158	47,745	14,442	4,870
>C12-C16 Aromatics	134,481	108,851	89,492	63,205	6,671
>C16-C21 Aromatics	92,056	2,040	7,076	77,699	9,043
>C21-C32 Aromatics	15,692	ND (<1,650)	ND (<1,650)	177,227	81,403
<sup>1</sup> Total Carbon Ranges:	982,900	981,522	938,221	996,287	996,755
Total BTEXMN + Carbon Ranges:	1,000,000	1,000,000	1,000,000	1,000,000	1,000,000

<sup>1.</sup> Raw data noted in Table 1 adjusted in consultation with Newfields Environmental to generate a total hydrocarbon concentration of 1,000,000 mg/kg for each sample. BTEXMN data reported by laboratory assumed accurate. Unaccounted mass assumed to be related to error in reported concentration of carbon ranges. Relative proportion of carbon ranges assumed to be reasonably accurate. Individual carbon range data adjusted upwards based on the calculated "Percent Unaccounted Carbon Range Mass" to normalize data to 1,000,000 mg/kg (100%) total mass (Adjusted Carbon Range Concentration = Initially Reported Concentration + (Initially Reported Concentration x Percent Unaccounted Carbon Range Mass).

Table 3. Default BTEXMN and carbon range makeup of petroleum fuels (refer to Table 2).

Analytes	<sup>1</sup> Gasoline	<sup>2</sup> Diesel	Bunker C
Benzene	0.90%	0.01%	0.00%
Toluene	4.9%	0.07%	0.00%
Ethylbenzene	1.1%	0.16%	0.00%
Xylenes	6.1%	1.2%	0.00%
1-Methylnapthalene	0.05%	0.09%	0.09%
2-Methylnapthalene	0.10%	0.17%	0.16%
Naphthalene	0.18%	0.06%	0.11%
Total BTEXMN:	13%	1.7%	0.37%
C5-C6 Aliphatics	30%	0.07%	-
>C6-C8 Aliphatics	30%	0.54%	-
>C8-C10 Aliphatics	6.5%	3.8%	-
>C10-C12 Aliphatics	2.0%	7.5%	3.0%
>C12-C16 Aliphatics	0.42%	24%	11%
>C16-C21 Aliphatics	-	26%	14%
>C21-C32 Aliphatics	ı	4.3%	38%
>C8-C10 Aromatics	12%	2.7%	-
>C10-C12 Aromatics	4.3%	5.2%	1.4%
>C12-C16 Aromatics	0.70%	13%	6.3%
>C16-C21 Aromatics	-	9.2%	7.8%
>C21-C32 Aromatics	-	1.6%	18%
<sup>1</sup> Total Carbon			
Ranges:	87%	98.3%	99.6%
Total BTEXMN	100%	100%	100%
+ Carbon Ranges:	100 /0	100 /0	100 /0

<sup>1.</sup> Average gasoline composition of types tested.

<sup>2.</sup> Diesel #1.

Table 4. Selected, default BTEXMN and toxicity-based, carbon range makeup of gasolines, diesel and Bunker C (refer to Table 3).

Analytes	¹Gasolines	<sup>2</sup> Middle Distillates	<sup>3</sup> Residual Fuels
Benzene	0.90%	0.01%	0.00%
Toluene	4.9%	0.07%	0.00%
Ethylbenzene	1.1%	0.16%	0.00%
Xylenes	6.1%	1.2%	0.00%
1-Methylnapthalene	0.05%	0.09%	0.09%
2-Methylnapthalene	0.10%	0.17%	0.16%
Naphthalene	0.18% 0.06%		0.11%
Total BTEXMN:	13%	1.7%	0.37%
C5-C8 Aliphatics	61%	0.61%	-
>C8-C18 Aliphatics	8.9%	61%	28%
>C18-C32 Aliphatics	-	4.3%	38%
>C8-C32 Aromatics	17%	32%	33%
<sup>1</sup> Total Carbon Ranges:	87%	98.3%	99.6%
Total BTEXMN + Carbon Ranges:	100%	100%	100%

- 1. Based on average composition of gasolines.
- 2. Based on composition of diesel.
- 3. Based on composition of Bunker C.

Table 5. Default carbon range makeup of petroleum fuels used to develop TPH soil EALs for gasolines, middle distillates and residual fuels (refer to Table 4).

Analytes	Gasolines	Middle Distillates	Residual Fuels
C5-C8 Aliphatics	70%	0.62%	-
>C8-C18 Aliphatics	10%	62%	28%
>C18-C32 Aliphatics	-	4.4%	38%
>C8-C32 Aromatics	20%	33%	33%
Total Carbon Ranges:	100%	100%	100%

Table 6. Selected physiochemical constants and toxicity factors for BTEXMN and TPH carbon ranges.

	¹Chemical/	Molecular	<sup>2</sup> Vapor Pressure	Solubility in Water	Henry's Constant	Partition Coeff, k <sub>oc</sub>	Coet (cr	usion fficient n²/s)
	Carbon Range	Weight	(mmHg)	(µg/L)	(unitless)	(cm <sup>3</sup> /g)	air	water
	Benzene	78	95	1,790	0.23	146	0.09	1.0E-05
	Toluene	92	28	526	0.27	234	0.08	9.2E-06
	Ethylbenzene	106	9.6	169	0.32	446	0.07	8.5E-06
	Xylenes (total)	106	8.0	106	0.27	383	0.07	8.5E-06
1-	-Methylnaphthalene	142	0.067	25.8	0.021	2,528	0.053	7.8E-06
2-	-Methylnaphthalene	142	0.055	24.6	0.021	2,478	0.052	7.8E-06
	Naphthalene	128	0.085	31	0.018	1,544	0.06	8.4E-06
segu	C5-C8 Aliphatics	93	76	11,000	54	2,265	0.08	1 x 10 <sup>-5</sup>
Volatile Carbon Ranges	>C8-C12 Aliphatics	120	2.2	51,000	0.33	1,778	0.07	1 x 10 <sup>-5</sup>
Carb	C9-C10 Aromatics	170	0.11	10	4,900	680,000	0.07	5 x 10 <sup>-6</sup>
ile	>C12-C18 Aliphatics	280	0.0008	0.0015	110	4.0 x 10 <sup>8</sup>	-	-
Nonvolatile Carbon Ranges	>C18-C36 Aliphatics	120	2.2	51,000	0.33	1,778	0.07	1 x 10 <sup>-5</sup>
No Carb	>C10-C22 Aromatics	150	0.024	5,800	0.03	5,000	0.06	1 x 10 <sup>-5</sup>

<sup>1.</sup> BTEXMN constants from USEPA (2023). Solubility based on a temperature of 25°C. Carbon range constants from Massachusetts Department of Environmental Protection (MADEP 2002) except constants from C19-C36 aliphatics (Gustafson et al., 1997; based on EC>16-35 aliphatics in Table 7 of document).

<sup>2.</sup> Carbon range vapor pressures converted from atmospheres (1atm = 760 mmHg).

Table 7. <sup>1</sup>Toxicity factors selected for BTEXMN and targeted carbon ranges.

Chemical/ Carbon Range	RfD <sub>0ral</sub> (mg/kg-day)	RfD <sub>Dermal</sub> (mg/kg-day)	RfC <sub>lnh</sub> (μg/m³)
Benzene	0.004	0.004	0.03
Toluene	0.08	0.08	5
Ethylbenzene	0.1	0.1	1
Xylenes (total)	0.2	0.2	0.1
1-Methylnaphthalene	0.07	0.07	0.28
2-Methylnaphthalene	0.004	0.004	0.016
Naphthalene	0.02	0.02	0.003
C6-C8 aliphatics	0.005	0.005	400
C9-C18 aliphatics	0.01	0.01	100
C19+ aliphatics	3.0	3.0	nv
C9+ aromatics	0.01	0.01	60

<sup>1.</sup> Toxicity factors for BTEXMN from USEPA Regional Screening Level guidance (USEPA 2023). Toxicity factors for carbon ranges selected from USEPA PPRTV guidance (USEPA 2022).

## **GASOLINE**

Table A. Effective solubility and predicted relative makeup of dissolved-phase gasoline.

	•			•	<sup>4</sup> Predicted		<sup>6</sup> Predicted
					Relative BTEXMN	5Predicted	Relative Carbon
		¹Pure			+ Carbon Range	Relative Carbon	Range Makeup of
		Component		<sup>3</sup> Effective	Makeup of	Range Makeup of	Volatile
Chemical/	<sup>1</sup> Molecular	Solubility	<sup>2</sup> Weight %	Solubility	Dissolved-Phase	Dissolved-Phase	Dissolved-Phase
Carbon Range	Weight	(mg/L)	in Fuel	(mg/L)	Hydrocarbons	Hydrocarbons	Hydrocarbons
Benzene	78	1790	0.90%	22	25%		
Toluene	92	526	4.9%	30	34%		
Ethylbenzene	106	169	1.1%	2.0	2.2%		
Xylenes	106	178	6.1%	11	12%		
1-Methylnaphthalene	142	25.8	0.05%	0.01	0.01%		
2-Methylnaphthalene	142	24.6	0.10%	0.02	0.02%		
Naphthalene	128	31	0.18%	0.05	0.05%		
C5-C6 Aliphatics	81	36	30%	15	16%	60%	60%
>C6-C8 Aliphatics	100	5.4	30%	1.8	2.0%	7.3%	7.3%
>C8-C10 Aliphatics	130	0.43	6.5%	0.02	0.03%	0.10%	0.10%
>C10-C12 Aliphatics	160	0.034	2.0%	0.000	0.001%	0.00%	0.00%
>C12-C16 Aliphatics	200	0.00076	0.42%	0.000002	0.000002%	0.00%	
>C16-C21 Aliphatics	270	0.0000025	-	-	-	-	
>C21-C32 Aliphatics	400	1.5E-11	-	-	-	-	
>C8-C10 Aromatics	120	65	12%	7.0	7.7%	29%	29%
>C10-C12 Aromatics	130	25	4.3%	0.9	1.0%	3.7%	3.7%
>C12-C16 Aromatics	150	5.8	0.70%	0.03	0.03%	0.12%	
>C16-C21 Aromatics	190	0.65	-	-	-	-	
>C21-C32 Aromatics	240	0.0066	-		-	0.00%	
		Sum BTEXMN:	13%	66	100%	100%	100%
	Sum	Carbon Ranges:	87%	24			
Su	m BTEXMN +	Carbon Ranges:	100%	90			

#### Table A (cont.). Effective solubility and predicted relative makeup of dissolved-phase gasoline.

- 1. BTEXMN constants from USEPA (2023). Solubility based on a temperature of 25°C. Carbon range constants from Massachusetts Department of Environmental Protection (MADEP 2002) except constants from C19-C36 Aliphatics (Gustafson et al., 1997; based on EC>16-35 aliphatics in Table 7).
- 2. Based on average composition of gasolines reported by Newfields (2022).
- 3. Effective Solubility = Compound Solubility x [(Compound Weight % in Fuel x (Molecular Weight Fuel/Molecular Weight Compound)). Assumes average molecular weight for gasoline of 108 (ATSDR 1995).
- 4. Predicted makeup of dissolved-phase hydrocarbons = (Compound Effective Solubility/Sum Total Effective Solubilities).
- 5. Reflects predicted makeup of all dissolved-phase carbon ranges.
- 6. Reflects predicted makeup of volatile dissolved-phase carbon ranges.

Table B. <sup>1</sup>Predicted relative makeup of dissolved-phase gasoline in terms of toxicity-based carbon ranges.

Chemical/ Carbon Range	Relative Weight Percent Makeup of Neat Fuel	Predicted Makeup of Dissolved-Phase Hydrocarbons (mg/L)	Predicted Relative Makeup of Dissolved-Phase Hydrocarbons
Total BTEXMN:	13%	66	73%
Total Carbon Ranges:	87%	24	27%
Benzene	0.90%	22	25%
Toluene	4.9%	30	34%
Ethylbenzene	1.1%	2.0	2.2%
Xylenes	6.1%	11	12%
1-Methylnaphthalene	0.05%	0.01	0.01%
2-Methylnaphthalene	0.10%	0.02	0.02%
Naphthalene	0.18%	0.05	0.05%
C5-C8 Aliphatics	61%	16	18%
>C8-C18 Aliphatics	8.9%	0.02	0.03%
>C18-C32 Aliphatics	0.00%	0.00	0.00%
>C8 Aromatics	17%	8	8.8%

Sum: 100% 90 100%

#### Notes

1. Refer to Table A.

Table C. Relative makeup of dissolved-phase gasoline with respect to specific media and exposure pathways.

Chemical/ Carbon Range	<sup>1</sup> Relative Carbon Range Makeup of Dissolved-Phase Hydrocarbons (ingestion)	<sup>2</sup> Relative Carbon Range Makeup of Dissolved-Phase Hydrocarbons (dermal)	<sup>3</sup> Relative Carbon Range Makeup of Volatile Dissolved-Phase Hydrocarbons (inhalation)	<sup>4</sup> Relative CR+BTEXMN Makeup of Dissolved-Phase Hydrocarbons (ingestion)	<sup>5</sup> Relative CR+BTEXMN Makeup of Dissolved-Phase Hydrocarbons (dermal)
Total BTEXMN:				73%	89%
<b>Total Carbon Ranges:</b>				27%	11%
Benzene				25%	30%
Toluene				34%	41%
Ethylbenzene				2.2%	2.6%
Xylenes				12%	15%
1-Methylnaphthalene				0.01%	0.01%
2-Methylnaphthalene				0.02%	0.03%
Naphthalene				0.05%	0.06%
C5-C8 Aliphatics	67%		68%	18%	
>C8-C18 Aliphatics	0.10%		0.10%	0.03%	
>C18-C32 Aliphatics	0.00%	0.00%		0.00%	0.00%
>C8 Aromatics	32%	100%	32%	8.8%	11%
Sum:	100%	100%	100%	100%	100%

<sup>1.</sup> Relative makeup of dissolved-phase carbon ranges used for derivation of oral TPH toxicity factor for non-degraded TPH noted in Table E.

<sup>2.</sup> Relative makeup of dissolved-phase carbon ranges used to derive dermal uptake factor values in Table D and weighted dermal toxicity factor for non-degraded TPH noted in Table E (volatile aliphatic compounds excluded).

<sup>3.</sup> Relative makeup of dissolved-phase, volatile carbon range compounds used to derive weighted inhalation toxicity factor for non-degraded TPH noted in Table E.

<sup>4.</sup> Combined dissolved-phase carbon range and BTEXMN components used to derive weighted oral toxicity factor for degraded TPH noted in Table E.

<sup>5.</sup> Combined carbon range and BTEXMN components used to derive dermal uptake factor values in Table C and weighted dermal toxicity factor for degraded TPH noted in Table E.

Table D. Dermal absorption factors weighted for the default carbon range makeup of dissolved-phase gasoline.

Table D. Definal absorption factor	В	τevent	t*	KP	
Chemical	(unitless)	(hr/event)	(hr)	(cm/hr)	Basis
Benzene	0.05	0.29	0.69	0.01	USEPA (2004, 2023) default benzene values
Toluene	0.11	0.35	0.83	0.03	USEPA (2004, 2023) default toluene values
Ethylbenzene	0.20	0.41	0.99	0.05	USEPA (2004, 2023) default ethylbenzene values
Xylenes (Total)	0.20	0.41	0.99	0.05	USEPA (2004, 2023) default naphthalene values
Naphthalene	0.20	0.55	1.3	0.05	USEPA (2004, 2023) default naphthalene values
1-Methylnaphthalene	0.43	0.66	1.6	0.09	USEPA (2004, 2023) default 1-methylnaphthalene values
C6-C8 Aliphatics	0.95	0.33	1.3	0.26	USEPA (2023) default Aliphatic Low values
>C8-C12 Aliphatics	7.4	0.55	2.5	1.70	USEPA (2023) default Aliphatic Medium values
>C12-C18 Aliphatics	7.4	0.55	2.5	1.70	USEPA (2023) default Aliphatic Medium values
>C18 Aliphatics	9.8	0.95	4.3	1.96	USEPA (2023) default Aliphatic High values
>C8-C12 Aromatics	0.334	0.495	1.189	0.079	USEPA (2023) default Aromatics Medium values
>C12-C22 Aromatics	0.334	0.495	1.189	0.079	USEPA (2023) default Aromatics Medium values
TPH (JP-5) Undegraded	0.334	0.495	1.189	0.079	<sup>1</sup> Calculated based on predicted carbon range makeup of dissolved-phase, undegraded TPH
TPH (JP-5) Degraded	0.093	0.346	0.830	0.026	<sup>1</sup> Calculated based on predicted carbon range + BTEXMN makeup of dissolved-phase, degraded TPH
TPH (JP-5) 50:50 Degradation	0.145	0.407	0.977	0.039	<sup>1</sup> Calculated based on 50:50 mixture of undegraded and degraded TPH

<sup>1.</sup> Refer to Table B for a summary of the predicted carbon range and BTEXMN makeup of dissolved-phase TPH-related compounds in water that is in contact with fresh fuel.

Table E. Weighted toxicity factors calculated for TPH associated with neat and dissolved-phase gasoline.

									<sup>4</sup> 50:50 Mixture	
_	<sup>1</sup> Carbon Range	e Only (Fuel)	<sup>2</sup> Carbon R	anges Only (Dis	solved)	<sup>3</sup> Carbon Rang	ges + BTEXMN	Degrad	ed:Undegraded	Plume
	Oral/Dermal	Inhalation			Inhalation					Inhalation
	RfD	RfC	Oral RfD	Dermal RfD	RfC	Oral RfD	Dermal RfD	Oral RfD	Dermal RfD	RfC
Fuel Type	(mg/kg-day)	(mg/m³)	(mg/kg-day)	(mg/kg-day)	(mg/m³)	(mg/kg-day)	(mg/kg-day)	(mg/kg-day)	(mg/kg-day)	(mg/m³)
Gasoline	0.006	0.190	0.0060	0.010	0.140	0.009	0.011	0.007	0.010	0.140

- 1. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to carbon range makeup for gasolines (excludes BTEXMN). Based on relative carbon range makeup of fuel and fuel vapors(refer to Table 1 and Section 6 of Appendix 1).
- 2. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to dissolved-phase carbon range makeup of gasoline in water (refer to Table C; excludes BTEXMN). Undegraded BTEXMN assessed separately. Considers ingestion of drinking water, inhalation of vapors during water use and dermal contact during bathing. Volatile aliphatic compounds assumed lost during water use and not considered for dermal contact.
- 3. Oral and dermal Reference Doses (RfDs) for dissolved carbon ranges plus BTEXMN weighted with respect to makeup noted in Table C. Intended to reflect toxicity of partially oxidized and non-volatile hydrocarbons in water. Considers ingestion of drinking water and dermal contact during bathing. Degraded compounds assumed to not be significantly volatile and not available for exposure via inhalation. Degraded aliphatic compounds assumed to remain in water and be available for dermal absorption during bathing.
- 4. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to 50:50 mixture of undegraded carbon ranges and degraded mixture of nonvolatile carbon range plus BTEXMN. Includes consideration of ingestion of drinking water, inhalation of vapors during water use and dermal contact during bathing.

## **DIESEL**

Table A. Effective solubility and predicted relative makeup of dissolved-phase diesel

		¹Pure Component		<sup>3</sup> Effective	<sup>4</sup> Predicted Relative BTEXMN + Carbon Range Makeup of	<sup>5</sup> Predicted Relative Carbon Range Makeup of	<sup>6</sup> Predicted Relative Carbon Range Makeup of Volatile
Chemical/	<sup>1</sup> Molecular	Solubility	<sup>2</sup> Weight %	Solubility	Dissolved-Phase	Dissolved-Phase	Dissolved-Phase
Carbon Range	Weight	(mg/L)	in Fuel	(mg/L)	Hydrocarbons	Hydrocarbons	Hydrocarbons
Benzene	78	1790	0.01%	0.41	3.5%		
Toluene	92	526	0.07%	0.76	6.5%		
Ethylbenzene	106	169	0.16%	0.51	4.3%		
Xylenes	106	178	1.16%	3.87	33%		
1-Methylnaphthalene	142	25.8	0.09%	0.03	0.27%		
2-Methylnaphthalene	142	24.6	0.17%	0.06	0.48%		
Naphthalene	128	31	0.06%	0.03	0.23%		
C5-C6 Aliphatics	81	36	0.07%	0.06	0.50%	0.97%	1.2%
>C6-C8 Aliphatics	100	5.4	0.54%	0.1	0.49%	0.94%	1.1%
>C8-C10 Aliphatics	130	0.43	3.8%	0.03	0.21%	0.41%	0.50%
>C10-C12 Aliphatics	160	0.034	7.5%	0.003	0.03%	0.05%	0.06%
>C12-C16 Aliphatics	200	0.00076	24%	0.0002	0.002%	0.003%	0.00%
>C16-C21 Aliphatics	270	0.0000025	26%	0.000000	0.000004%	0.00%	
>C21-C32 Aliphatics	400	1.5E-11	4.29%	3.2E-13	-	0.00%	
>C8-C10 Aromatics	120	65	2.7%	2.9	25%	48%	58%
>C10-C12 Aromatics	130	25	5.2%	2.0	17%	32%	39%
>C12-C16 Aromatics	150	5.8	13%	1.03	8.7%	17%	
>C16-C21 Aromatics	190	0.65	9.2%	0.06	0.53%	1.0%	
>C21-C32 Aromatics	240	0.0066	1.6%	0.0E+00	-	0.00%	
Sum BTEXMN:		1.7%	5.7	100%	100%	100%	
Sum Carbon Ranges:			98%	6.1			
Su	Sum BTEXMN + Carbon Ranges:				]		

Table A (cont.). Effective solubility and predicted relative makeup of dissolved-phase diesel.

- 1. BTEXMN constants from USEPA (2023). Solubility based on a temperature of 25°C. Carbon range constants from Massachusetts Department of Environmental Protection (MADEP 2002) except constants from C19-C36 Aliphatics (Gustafson et al., 1997; based on EC>16-35 aliphatics in Table 7).
- 2. Based on average composition of gasolines reported by Newfields (2022).
- 3. Effective Solubility = Compound Solubility x [(Compound Weight % in Fuel x (Molecular Weight Fuel/Molecular Weight Compound)). Assumes average molecular weight for diesel of 201 (NRC 1996).
- 4. Predicted makeup of dissolved-phase hydrocarbons = (Compound Effective Solubility/Sum Total Effective Solubilities).
- 5. Reflects predicted makeup of all dissolved-phase carbon ranges.
- 6. Reflects predicted makeup of volatile dissolved-phase carbon ranges.

Table B.  $^1$ Predicted relative makeup of dissolved-phase diesel in terms of toxicity-based carbon ranges.

Chemical/ Carbon Range	Relative Weight Percent Makeup of Neat Fuel	Predicted Makeup of Dissolved-Phase Hydrocarbons (mg/L)	Predicted Relative Makeup of Dissolved-Phase Hydrocarbons
Total BTEXMN:	1.7%	5.7	48%
Total Carbon Ranges:	98%	6.1	52%
Benzene	0.01%	0.41	3.5%
Toluene	0.07%	0.76	6.5%
Ethylbenzene	0.16%	0.51	4.28%
Xylenes	1.2%	3.9	33%
1-Methylnaphthalene	0.09%	0.03	0.3%
2-Methylnaphthalene	0.17%	0.06	0.48%
Naphthalene	0.06%	0.03	0.2%
C5-C8 Aliphatics	0.61%	0.12	1.0%
>C8-C18 Aliphatics	61%	0.03	0.24%
>C18-C32 Aliphatics	4.3%	0.00	0.00%
>C8 Aromatics	32%	6.0	51%

Sum: 100% 12 100%

#### Notes

1. Refer to Table A.

Table C. Relative makeup of dissolved-phase diesel with respect to specific media and exposure pathways.

Chemical/ Carbon Range	<sup>1</sup> Relative Carbon Range Makeup of Dissolved-Phase Hydrocarbons (ingestion)	<sup>2</sup> Relative Carbon Range Makeup of Dissolved-Phase Hydrocarbons (dermal)	<sup>3</sup> Relative Carbon Range Makeup of Volatile Dissolved-Phase Hydrocarbons (inhalation)	<sup>4</sup> Relative CR+BTEXMN Makeup of Dissolved-Phase Hydrocarbons (ingestion)	<sup>5</sup> Relative CR+BTEXMN Makeup of Dissolved-Phase Hydrocarbons (dermal)
Total BTEXMN:				48%	49%
Total Carbon Ranges:				52%	51%
Benzene				3.5%	3.5%
Toluene				6.5%	6.5%
Ethylbenzene				4.3%	4.3%
Xylenes				33%	33%
1-Methylnaphthalene				0.27%	0.28%
2-Methylnaphthalene				0.48%	0.49%
Naphthalene				0.23%	0.23%
C5-C8 Aliphatics	1.9%		2.3%	1.0%	
>C8-C18 Aliphatics	0.46%		0.56%	0.24%	
>C18-C32 Aliphatics	0.00%	0.00%		0.00%	0.00%
>C8 Aromatics	98%	100%	97%	51%	51%
Sum:	100%	100%	100%	100%	100%

<sup>1.</sup> Relative makeup of dissolved-phase carbon ranges used for derivation of oral TPH toxicity factor for non-degraded TPH noted in Table E.

<sup>2.</sup> Relative makeup of dissolved-phase carbon ranges used to derive dermal uptake factor values in Table D and weighted dermal toxicity factor for non-degraded TPH noted in Table E (volatile aliphatic compounds excluded).

<sup>3.</sup> Relative makeup of dissolved-phase, volatile carbon range compounds used to derive weighted inhalation toxicity factor for non-degraded TPH noted in Table E.

<sup>4.</sup> Combined dissolved-phase carbon range and BTEXMN components used to derive weighted oral toxicity factor for degraded TPH noted in Table E.

<sup>5.</sup> Combined carbon range and BTEXMN components used to derive dermal uptake factor values in Table C and weighted dermal toxicity factor for degraded TPH noted in Table E.

Table D. Dermal absorption factors weighted for the default carbon range makeup of dissolved-phase diesel.

	В	Tevent	t*	KP	
Chemical	(unitless)	(hr/event)	(hr)	(cm/hr)	Basis
Benzene	0.05	0.29	0.69	0.01	USEPA (2004, 2023) default benzene values
Toluene	0.11	0.35	0.83	0.03	USEPA (2004, 2023) default toluene values
Ethylbenzene	0.20	0.41	0.99	0.05	USEPA (2004, 2023) default ethylbenzene values
Xylenes (Total)	0.20	0.41	0.99	0.05	USEPA (2004, 2023) default naphthalene values
Naphthalene	0.20	0.55	1.3	0.05	USEPA (2004, 2023) default naphthalene values
1-Methylnaphthalene	0.43	0.66	1.6	0.09	USEPA (2004, 2023) default 1-methylnaphthalene values
C6-C8 Aliphatics	0.95	0.33	1.3	0.26	USEPA (2023) default Aliphatic Low values
>C8-C12 Aliphatics	7.4	0.55	2.5	1.70	USEPA (2023) default Aliphatic Medium values
>C12-C18 Aliphatics	7.4	0.55	2.5	1.70	USEPA (2023) default Aliphatic Medium values
>C18 Aliphatics	9.8	0.95	4.3	1.96	USEPA (2023) default Aliphatic High values
>C8-C12 Aromatics	0.334	0.495	1.189	0.079	USEPA (2023) default Aromatics Medium values
>C12-C22 Aromatics	0.334	0.495	1.189	0.079	USEPA (2023) default Aromatics Medium values
TPH (diesel) Undegraded	0.334	0.495	0.189	0.079	<sup>1</sup> Calculated based on predicted carbon range makeup of dissolved-phase, undegraded TPH
TPH (diesel) Degraded	0.212	0.440	1.057	0.054	<sup>1</sup> Calculated based on predicted carbon range + BTEXMN makeup of dissolved-phase, degraded TPH
TPH (diesel) 50:50 Degradation	0.259	0.466	0.675	0.097	<sup>1</sup> Calculated based on 50:50 mixture of undegraded and degraded TPH

<sup>1.</sup> Refer to Table B for a summary of the predicted carbon range and BTEXMN makeup of dissolved-phase TPH-related compounds in water that is in contact with fresh fuel.

Table E. Weighted toxicity factors calculated for TPH associated with neat and dissolved-phase diesel.

		<sup>1</sup> Carbon Range Only (Fuel)		<sup>2</sup> Carbon Ranges Only (Dissolved)			<sup>3</sup> Carbon Ranges + BTEXMN		<sup>4</sup> 50:50 Mixture Degraded:Undegraded Plume		
	a 1.70	Oral/Dermal RfD	Inhalation RfC	Oral RfD	Dermal RfD	Inhalation RfC	Oral RfD	Dermal RfD	Oral RfD	Dermal RfD	Inhalation RfC
H	Tuel Type	(mg/kg-day)	(mg/m <sup>3</sup> )	(mg/kg-day)	(mg/kg-day)	(mg/m <sup>3</sup> )	(mg/kg-day)	(mg/kg-day)	(mg/kg-day)	(mg/kg-day)	(mg/m <sup>3</sup> )
Dies	el	0.010	0.123	0.010	0.010	0.061	0.015	0.015	0.012	0.012	0.061

- 1. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to carbon range makeup for diesel (excludes BTEXMN). Based on relative carbon range makeup of fuel and fuel vapors(refer to Table 1 and Section 6 of Appendix 1).
- 2. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to dissolved-phase carbon range makeup of diesel in water (refer to Table C; excludes BTEXMN). Undegraded BTEXMN assessed separately. Considers ingestion of drinking water, inhalation of vapors during water use and dermal contact during bathing. Volatile aliphatic compounds assumed lost during water use and not considered for dermal contact.
- 3. Oral and dermal Reference Doses (RfDs) for dissolved carbon ranges plus BTEXMN weighted with respect to makeup noted in Table C. Intended to reflect toxicity of partially oxidized and non-volatile hydrocarbons in water. Considers ingestion of drinking water and dermal contact during bathing. Degraded compounds assumed to not be significantly volatile and not available for exposure via inhalation. Degraded aliphatic compounds assumed to remain in water and be available for dermal absorption during bathing.
- 4. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to 50:50 mixture of undegraded carbon ranges and degraded mixture of nonvolatile carbon range plus BTEXMN. Includes consideration of ingestion of drinking water, inhalation of vapors during water use and dermal contact during bathing.

## **BUNKER C**

Table A. Effective solubility and predicted relative makeup of dissolved-phase Bunker C.

Table A. Effective so			•	•	<sup>4</sup> Predicted Relative BTEXMN	<sup>5</sup> Predicted	<sup>6</sup> Predicted Relative Carbon
		¹Pure			+ Carbon Range	Relative Carbon	Range Makeup of
		Component	•	<sup>3</sup> Effective	Makeup of	Range Makeup of	Volatile
Chemical/	<sup>1</sup> Molecular	Solubility	<sup>2</sup> Weight %	Solubility	Dissolved-Phase	Dissolved-Phase	Dissolved-Phase
Carbon Range	Weight	(mg/L)	in Fuel	(mg/L)	Hydrocarbons	Hydrocarbons	Hydrocarbons
Benzene	78	1790	0.001%	0.17	3.9%		
Toluene	92	526	0.001%	0.03	0.72%		
Ethylbenzene	106	169	0.001%	0.01	0.13%		
Xylenes	106	178	0.004%	0.04	0.90%		
1-Methylnaphthalene	142	25.8	0.09%	0.11	2.5%		
2-Methylnaphthalene	142	24.6	0.16%	0.18	4.3%		
Naphthalene	128	31	0.11%	0.18	4.1%		
C5-C6 Aliphatics	81	36	-	-	-		
>C6-C8 Aliphatics	100	5.4	-	-	-		
>C8-C10 Aliphatics	130	0.43	-	-	-		
>C10-C12 Aliphatics	160	0.034	3.0%	0.004	0.10%	0.12%	0.23%
>C12-C16 Aliphatics	200	0.00076	11%	0.0003	0.006%	0.01%	
>C16-C21 Aliphatics	270	0.0000025	14%	0.0	0.00002%	0.00%	
>C21-C32 Aliphatics	400	1.5E-11	38%	9.3E-12	0.0000000002%	0.00%	
>C8-C10 Aromatics	120	65	-	-	-		0.00%
>C10-C12 Aromatics	130	25	1.4%	1.8	42%	51%	99.8%
>C12-C16 Aromatics	150	5.8	6.3%	1.59	37%	44%	
>C16-C21 Aromatics	190	0.65	7.8%	0.2	4.0%	4.8%	
>C21-C32 Aromatics	240	0.0066	18%	-	-	0.09%	
Sum BTEXMN:			0.37%	0.71	100%	100%	100%
	Carbon Ranges:	100%	3.6	]			
Su	m BTEXMN +	Carbon Ranges:	100%	4.3			

Table A (cont.). Effective solubility and predicted relative makeup of dissolved-phase Bunker C.

#### Notes

- 1. BTEXMN constants from USEPA (2023). Solubility based on a temperature of 25°C. Carbon range constants from Massachusetts Department of Environmental Protection (MADEP 2002) except constants from C19-C36 Aliphatics (Gustafson et al., 1997; based on EC>16-35 aliphatics in Table 7).
- 2. Based on average composition of gasolines reported by Newfields (2022).
- 3. Effective Solubility = Compound Solubility x [(Compound Weight % in Fuel x (Molecular Weight Fuel/Molecular Weight Compound)). Assumes average molecular weight for Bunker C of 600 (IARC 1989, CountryMark 2021).
- 4. Predicted makeup of dissolved-phase hydrocarbons = (Compound Effective Solubility/Sum Total Effective Solubilities).
- 5. Reflects predicted makeup of all dissolved-phase carbon ranges.
- 6. Reflects predicted makeup of volatile dissolved-phase carbon ranges.

Table B.  $^{1}\text{Predicted}$  relative makeup of dissolved-phase Bunker C in terms

of toxicity-based carbon ranges.

Chemical/	Relative Weight Percent Makeup	Predicted Makeup of Dissolved-Phase Hydrocarbons	Predicted Relative Makeup of Dissolved-Phase
Carbon Range	of Neat Fuel	(mg/L)	Hydrocarbons
Total BTEXMN:	0.37%	0.71	17%
Total Carbon Ranges:	99.63%	3.6	83%
Benzene	0.00%	0.17	3.9%
Toluene	0.00%	0.03	0.72%
Ethylbenzene	0.00%	0.01	0.13%
Xylenes	0.00%	0.04	1.0%
1-Methylnaphthalene	0.09%	0.11	2.5%
2-Methylnaphthalene	0.16%	0.18	4.3%
Naphthalene	0.11%	0.18	4.1%
C5-C8 Aliphatics	0.00%	0.00	0.00%
>C8-C18 Aliphatics	28%	0.00	0.00%
>C18-C32 Aliphatics	38%	0.00	0.00%
>C8 Aromatics	33%	3.6	83%

100% 4.3 100% Sum:

# Notes

1. Refer to Table A.

Table C. Relative makeup of dissolved-phase Bunker C with respect to specific media and exposure pathways.

Chemical/ Carbon Range	<sup>1</sup> Relative Carbon Range Makeup of Dissolved- Phase Hydrocarbons (ingestion)	<sup>2</sup> Relative Carbon Range Makeup of Dissolved- Phase Hydrocarbons (dermal)	<sup>3</sup> Relative Carbon Range Makeup of Volatile Dissolved-Phase Hydrocarbons (inhalation)	<sup>4</sup> Relative CR+BTEXMN Makeup of Dissolved-Phase Hydrocarbons (ingestion)	<sup>5</sup> Relative CR+BTEXMN Makeup of Dissolved-Phase Hydrocarbons (dermal)
Total BTEXMN:	, ,	Ì	Ì	17%	17%
Total Carbon Ranges:				83%	83%
Benzene				3.9%	3.9%
Toluene				0.72%	0.72%
Ethylbenzene				0.13%	0.13%
Xylenes				0.90%	0.90%
1-Methylnaphthalene				2.5%	2.5%
2-Methylnaphthalene				4.3%	4.3%
Naphthalene				4.1%	4.1%
C5-C8 Aliphatics	0.00%		0.00%	0.00%	
>C8-C18 Aliphatics	0.12%		0.23%	0.10%	
>C18-C32 Aliphatics	0.00%	0.0%		0.00%	0.00%
>C8 Aromatics	99.88%	100%	100%	83%	83%
Sum:	100%	100%	100%	100%	100%

#### Notes

- 1. Relative makeup of dissolved-phase carbon ranges used for derivation of oral TPH toxicity factor for non-degraded TPH noted in Table E.
- 2. Relative makeup of dissolved-phase carbon ranges used to derive dermal uptake factor values in Table D and weighted dermal toxicity factor for non-degraded TPH noted in Table E (volatile aliphatic compounds excluded).
- 3. Relative makeup of dissolved-phase, volatile carbon range compounds used to derive weighted inhalation toxicity factor for nondegraded TPH noted in Table E.
- 4. Combined dissolved-phase carbon range and BTEXMN components used to derive weighted oral toxicity factor for degraded TPH noted in Table E.
- 5. Combined carbon range and BTEXMN components used to derive dermal uptake factor values in Table C and weighted dermal toxicity factor for degraded TPH noted in Table E.

Table D. Dermal absorption factors weighted for the default carbon range makeup of dissolved-phase Bunker C.

Tuole B. Bermar accorption factor	В	Tevent	t*	KP	
Chemical	(unitless)	(hr/event)	(hr)	(cm/hr)	Basis
Benzene	0.05	0.29	0.69	0.01	USEPA (2004, 2023) default benzene values
Toluene	0.11	0.35	0.83	0.03	USEPA (2004, 2023) default toluene values
Ethylbenzene	0.20	0.41	0.99	0.05	USEPA (2004, 2023) default ethylbenzene values
Xylenes (Total)	0.20	0.41	0.99	0.05	USEPA (2004, 2023) default naphthalene values
Naphthalene	0.20	0.55	1.3	0.05	USEPA (2004, 2023) default naphthalene values
1-Methylnaphthalene	0.43	0.66	1.6	0.09	USEPA (2004, 2023) default 1-methylnaphthalene values
C6-C8 Aliphatics	0.95	0.33	1.3	0.26	USEPA (2023) default Aliphatic Low values
>C8-C12 Aliphatics	7.4	0.55	2.5	1.70	USEPA (2023) default Aliphatic Medium values
>C12-C18 Aliphatics	7.4	0.55	2.5	1.70	USEPA (2023) default Aliphatic Medium values
>C18 Aliphatics	9.8	0.95	4.3	1.96	USEPA (2023) default Aliphatic High values
>C8-C12 Aromatics	0.334	0.495	1.189	0.079	USEPA (2023) default Aromatics Medium values
>C12-C22 Aromatics	0.334	0.495	1.189	0.079	USEPA (2023) default Aromatics Medium values
TPH (Bunker C) Undegraded	0.334	0.495	1.189	0.079	<sup>1</sup> Calculated based on predicted carbon range makeup of dissolved-phase, undegraded TPH
TPH (Bunker C) Degraded	0.267	0.490	1.175	0.066	<sup>1</sup> Calculated based on predicted carbon range + BTEXMN makeup of dissolved-phase, degraded TPH
TPH (Bunker C) 50:50 Degradation	0.297	0.493	1.182	0.072	<sup>1</sup> Calculated based on 50:50 mixture of undegraded and degraded TPH

# Notes:

<sup>1.</sup> Refer to Table B for a summary of the predicted carbon range and BTEXMN makeup of dissolved-phase TPH-related compounds in water that is in contact with fresh fuel.

Table E. Weighted toxicity factors calculated for TPH associated with neat and dissolved-phase Bunker C.

	¹Carbon Range	e Only (Fuel)	²Carbon R	anges Only (Dis	solved)	³Carbon Rang	es + BTEXMN	<sup>4</sup> 50:50 Mixture Degraded:Undegraded Plume		
Fuel Type	Oral/Dermal RfD (mg/kg-day)	Inhalation RfC (mg/m³)	Oral RfD (mg/kg-day)	Dermal RfD (mg/kg-day)	Inhalation RfC (mg/m³)	Oral RfD (mg/kg-day)	Dermal RfD (mg/kg-day)	Oral RfD (mg/kg-day)	Dermal RfD (mg/kg-day)	Inhalation RfC (mg/m³)
Bunker C	0.016	0.123	0.0100	0.0100	0.0601	0.0094	0.0094	0.0097	0.0097	0.0601

#### **Notes**

- 1. Oral and dermal Reference Doses (RfDs) weighted with respect to carbon range makeup for Bunker C (excludes BTEXMN). Based on relative carbon range makeup of fuel and fuel vapors (refer to Table 1 and Section 6 of Appendix 1). Inhalation Reference Concentration (RfC) assumed identical to diesel vapors.
- 2. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to dissolved-phase carbon range makeup of Bunker C in water (refer to Table C; excludes BTEXMN). Undegraded BTEXMN assessed separately. Considers ingestion of drinking water, inhalation of vapors during water use and dermal contact during bathing. Volatile aliphatic compounds assumed lost during water use and not considered for dermal contact.
- 3. Oral and dermal Reference Doses (RfDs) for dissolved carbon ranges plus BTEXMN weighted with respect to makeup noted in Table C. Intended to reflect toxicity of partially oxidized and non-volatile hydrocarbons in water. Considers ingestion of drinking water and dermal contact during bathing. Degraded compounds assumed to not be significantly volatile and not available for exposure via inhalation. Degraded aliphatic compounds assumed to remain in water and be available for dermal absorption during bathing.
- 4. Oral and dermal Reference Doses (RfDs) and inhalation Reference Concentration (RfC) weighted with respect to 50:50 mixture of undegraded carbon ranges and degraded mixture of nonvolatile carbon range plus BTEXMN. Includes consideration of ingestion of drinking water, inhalation of vapors during water use and dermal contact during bathing.

# **Fuel Study Laboratory Report (Newfields 2022)**



October 28th, 2022

Roger Brewer Hawaii Department of Health 919 Ala Moana Boulevard Honolulu, HI 96813

Cc: Eric M. Jensen Tetra Tech, Inc. Honolulu, HI 96813

Dr. Brewer,

This memo provides supplemental analytical data in support of the fuel study conducted by Alpha Analytical and NewFields Environmental Forensics on behalf of the Hawaii Department of Health. The fuel variants considered in this study were obtained from NewFields' forensic reference material library. More information on the reference fuels can be provided upon request. This study included the analysis of the following fuel variants:

Fuel Category	Fuel Variant			
	E10 87 Octane			
Gasolines	E10 91 Octane			
	E10 93 Octane			
	Heating Fuel			
Middle Distillates	Road Diesel			
Middle Distillates	JP-5			
	JP-8			
Residual Fuels	Waste Oil (auto)			
Residual Fuels	Bunker C			

Alpha Analytical tested the fuel samples for volatile petroleum hydrocarbons (VPH) by Massachusetts Department of Environmental Protection (MADEP) VPH Method 2.1, and volatile paraffins, isoparaffins, aromatics, naphthenes and olefins (PIANO) by a modification of EPA Method 8260D. Using open column chromatography, the fuel samples were separated into aliphatic (F1), and aromatic (F2) fractions. The aliphatic, aromatic, and the whole extracts were then analyzed for total petroleum hydrocarbons (TPH C<sub>9</sub>-C<sub>44</sub>) by EPA Method 8015D. The Alpha data can be found attached to this report. Newfields, using Agilent's EnviroQuant<sup>TM</sup> data processing software further analyzed the VPH (C<sub>5</sub>-C<sub>8</sub>), and TPH (C<sub>8</sub>-C<sub>32</sub>) raw data to generate concentrations for the following carbon ranges from the aliphatic, aromatic and combined extracts:

Carbon Range									
C5-C6 Aliphatics	>C8-C10 Aromatics	>C8-C10 Combined							
>C6-C8 Aliphatics	>C10-C12 Aromatics	>C10-C12 Combined							
>C8-C10 Aliphatics	>C12-C16 Aromatics	>C12-C16 Combined							
>C10-C12 Aliphatics	>C16-C21 Aromatics	>C16-C21 Combined							
>C12-C16 Aliphatics	>C21-C32 Aromatics	>C21-C32 Combined							
>C16-C21 Aliphatics									
>C21-C32 Aliphatics									

This report includes carbon range concentrations (mg/kgoil), flame ionization detector (FID) chromatograms (aliphatic, aromatic, and combined extracts), and the detailed raw data quantitation reports that record the integration of each carbon range. I am available to discuss this data further at your convenience.

Sincerely.

Eric Litman, M.S. Senior Consultant

NewFields Environmental Forensics


# Attached:

Attachment A: Carbon Range Data Report

Attachment B: FID Chromatograms - Whole Extract Attachment C: FID Chromatograms Aliphatic Fraction Attachment D: FID Chromatograms Aromatic Fraction

Attachment E: FID Chromatograms VPH Attachment F: Quantitation Raw Data Reports

Attachment G: Alpha Analytical Data Package L2240634





Project Name: Hawaii DOH - Fuel Study

		Duplicate		
Client ID	GASOLINE 87	GASOLINE 87	GASOLINE 91	<b>GASOLINE 93</b>
Matrix	OIL	OIL	OIL	OIL
Reference Method	VPH/8015D(M)	VPH/8015D(M)	VPH/8015D(M)	VPH/8015D(M)
Batch ID	WG1676301	WG1676301	WG1676301	WG1676301
Date Collected	7/26/2022	7/26/2022	7/26/2022	7/26/2022
Date Received	7/29/2022	7/29/2022	7/29/2022	7/29/2022
Date Prepped	8/17/2022	8/17/2022	8/17/2022	8/17/2022
Date Analyzed	8/18/2022	8/18/2022	8/18/2022	8/18/2022
Sample Size(wet)	0.1054	0.1054	0.1027	0.1125
% Solid	100	100	100	100
File ID	f1708172220	f1708172220	f1708172224	f1708172226
Lab ID Combined:	L2240634-01	WG1676301-4	L2240634-04	L2240634-07
Lab ID F1:	L2240634-02	WG1676456-4	L2240634-05	L2240634-08
Lab ID F2:	L2240634-03	WG1676458-4	L2240634-06	L2240634-09
Units	mg/kg	mg/kg	mg/kg	mg/kg

Fraction	Analytes	Result	Q	RL									
Aliphatic	C5-C6 Aliphatics	23,395		22,500	23,910		22,500	23,948		21,900	16,578	J	21,400
Aliphatic	>C6-C8 Aliphatics	40,765		22,500	35,492		22,500	34,839		21,900	22,557		21,400
Aliphatic	>C8-C10 Aliphatics	36,595		3,130	42,871		3,130	38,359		3,210	33,345		2,930
Aliphatic	>C10-C12 Aliphatics	11,737		3,130	13,428		3,130	11,464		3,210	9,562		2,930
Aliphatic	>C12-C16 Aliphatics	2,667	J	3,130	2,843	J	3,130	2,275	J	3,210	2,069	J	2,930
Aliphatic	>C16-C21 Aliphatics		U	3,130		U	3,130		U	3,210		U	2,930
Aliphatic	>C21-C32 Aliphatics		U	3,130		U	3,130		U	3,210		U	2,930
Aromatic	>C8-C10 Aromatics	73,977		3,130	74,732		3,130	62,778		3,210	65,763		2,930
Aromatic	>C10-C12 Aromatics	26,981		3,130	27,755		3,130	22,066		3,210	24,006		2,930
Aromatic	>C12-C16 Aromatics	4,315		3,130	4,564		3,130	3,524		3,210	3,847		2,930
Aromatic	>C16-C21 Aromatics		U	3,130		U	3,130		U	3,210		U	2,930
Aromatic	>C21-C32 Aromatics		U	3,130		U	3,130		U	3,210		U	2,930
Combined	>C8-C10 Combined	182,369		6,260	173,957		6,260	163,348		6,430	163,372		5,870
Combined	>C10-C12 Combined	56,742		6,260	53,742		6,260	46,601		6,430	47,722		5,870
Combined	>C12-C16 Combined	10,283		6,260	9,868		6,260	8,099		6,430	8,118		5,870
Combined	>C16-C21 Combined		U	6,260		U	6,260		U	6,430		U	5,870
Combined	>C21-C32 Combined		U	6,260		U	6,260		U	6,430		U	5,870



Project Name: Hawaii DOH - Fı

Client ID	HEATING FUEL	ROAD DIESEL	JP-5	JP-8
Matrix	OIL	OIL	OIL	OIL
Reference Method	VPH/8015D(M)	VPH/8015D(M)	VPH/8015D(M)	VPH/8015D(M)
Batch ID	WG1676301	WG1676301	WG1676301	WG1676301
Date Collected	7/26/2022	7/26/2022	7/26/2022	7/26/2022
Date Received	7/29/2022	7/29/2022	7/29/2022	7/29/2022
Date Prepped	8/17/2022	8/17/2022	8/17/2022	8/17/2022
Date Analyzed	8/18/2022	8/18/2022	8/18/2022	8/18/2022
Sample Size(wet)	0.1122	0.1118	0.02	0.02
% Solid	100	100	100	100
File ID	f1708172228	f1708172230	f1708172232	f1708172240
Lab ID Combined:	L2240634-10	L2240634-13	L2240634-16	L2240634-19
Lab ID F1:	L2240634-11	L2240634-14	L2240634-17	L2240634-20
Lab ID F2:	L2240634-12	L2240634-15	L2240634-18	L2240634-21
Units	mg/kg	mg/kg	mg/kg	mg/kg

Fraction	Analytes	Result	Q	RL									
Aliphatic	C5-C6 Aliphatics		U	8,550		U	5,990		U	1,650		U	1,650
Aliphatic	>C6-C8 Aliphatics	1,526	J	8,550	1,406	J	5,990		U	1,650	780	J	1,650
Aliphatic	>C8-C10 Aliphatics	23,794		2,940	31,373		2,950	60,460		1,650	151,534		1,650
Aliphatic	>C10-C12 Aliphatics	80,983		2,940	61,092		2,950	278,612		1,650	180,422		1,650
Aliphatic	>C12-C16 Aliphatics	203,122		2,940	196,045		2,950	315,662		1,650	234,688		1,650
Aliphatic	>C16-C21 Aliphatics	166,328		2,940	212,713		2,950	2,264		1,650	20,794		1,650
Aliphatic	>C21-C32 Aliphatics	33,481		2,940	35,117		2,950		U	1,650		U	1,650
Aromatic	>C8-C10 Aromatics	6,507		2,940	22,417		2,950	7,506		1,650	30,291		1,650
Aromatic	>C10-C12 Aromatics	30,293		2,940	42,287		2,950	55,836		1,650	39,115		1,650
Aromatic	>C12-C16 Aromatics	111,016		2,940	110,031		2,950	90,500		1,650	73,316		1,650
Aromatic	>C16-C21 Aromatics	82,640		2,940	75,319		2,950	1,696		1,650	5,797		1,650
Aromatic	>C21-C32 Aromatics	15,036		2,940	12,839		2,950		U	1,650		U	1,650
Combined	>C8-C10 Combined	49,868		5,880	84,424		5,900	106,536		6,600	285,428		6,600
Combined	>C10-C12 Combined	152,064		5,880	137,585		5,900	440,808		6,600	295,541		6,600
Combined	>C12-C16 Combined	357,797		5,880	363,823		5,900	460,178		6,600	364,544		6,600
Combined	>C16-C21 Combined	263,613		5,880	317,428		5,900		U	6,600	29,586		6,600
Combined	>C21-C32 Combined	56,726		5,880	52,789		5,900		U	6,600		U	6,600



Project Name: Hawaii DOH - Fı

Client ID	BUNKER C	WASTE OIL (AUTO)
Matrix	OIL	OIL
Reference Method	VPH/8015D(M)	VPH/8015D(M)
Batch ID	WG1676301	WG1682983
Date Collected	7/26/2022	7/26/2022
Date Received	7/29/2022	7/29/2022
Date Prepped	8/17/2022	9/2/2022
Date Analyzed	8/18/2022	9/7/2022
Sample Size(wet)	0.1035	0.1119
% Solid	100	100
File ID	f1708172244	f1709062236
Lab ID Combined:	L2240634-25	L2240634-32
Lab ID F1:	L2240634-26	L2240634-33
Lab ID F2:	L2240634-27	L2240634-34
Units	mg/kg	mg/kg

Fraction	Analytes	Result	Q	RL	Result	Q	RL
Aliphatic	C5-C6 Aliphatics		U	855		U	248
Aliphatic	>C6-C8 Aliphatics		U	855	597		248
Aliphatic	>C8-C10 Aliphatics		U	3,190		U	2,950
Aliphatic	>C10-C12 Aliphatics	14,228		3,190		U	2,950
Aliphatic	>C12-C16 Aliphatics	51,074		3,190	1,822	J	2,950
Aliphatic	>C16-C21 Aliphatics	68,425		3,190	9,434		2,950
Aliphatic	>C21-C32 Aliphatics	182,967		3,190	652,672		2,950
Aromatic	>C8-C10 Aromatics		U	3,190	2,177	J	2,950
Aromatic	>C10-C12 Aromatics	6,891		3,190	3,629		2,950
Aromatic	>C12-C16 Aromatics	30,159		3,190	4,970		2,950
Aromatic	>C16-C21 Aromatics	37,074		3,190	6,738		2,950
Aromatic	>C21-C32 Aromatics	84,564		3,190	60,655		2,950
Combined	>C8-C10 Combined		U	12,800	3,762	J	5,900
Combined	>C10-C12 Combined	59,346		12,800	5,203	J	5,900
Combined	>C12-C16 Combined	189,840		12,800	7,246		5,900
Combined	>C16-C21 Combined	222,386		12,800	15,089		5,900
Combined	>C21-C32 Combined	568,242		12,800	622,151		5,900

Attachment B: FID Chromatograms - Whole Extract

... Study\L2240634\TPH\NF TPH\f1708172220.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 1:41 am using AcqMethod FID17A.M

Sample Name: L2240634-01,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract GASOLINE 87 L2240634-01 Product



... Study\L2240634\TPH\NF TPH\f1708172222.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 3:10 am using AcqMethod FID17A.M

Sample Name: WG1676301-4,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract
GASOLINE 87 Duplicate
L2240634-01
Product



... Study\L2240634\TPH\NF TPH\f1708172224.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 4:40 am using AcqMethod FID17A.M

Sample Name: L2240634-04,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract GASOLINE 91 L2240634-04 Product



... Study\L2240634\TPH\NF TPH\f1708172226.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 6:10 am using AcqMethod FID17A.M

Sample Name: L2240634-07,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract GASOLINE 93 L2240634-07 Product



... Study\L2240634\TPH\NF TPH\f1708172228.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 7:40 am using AcqMethod FID17A.M

Sample Name: L2240634-10,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract HEATING FUEL L2240634-10 Product



... Study\L2240634\TPH\NF TPH\f1708172230.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 9:10 am using AcqMethod FID17A.M

Sample Name: L2240634-13,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract ROAD DIESEL L2240634-13 Product



... Study\L2240634\TPH\NF TPH\f1708172232.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 10:41 am using AcqMethod FID17A.M

Sample Name: L2240634-16,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract JP-5 L2240634-16 Product



... Study\L2240634\TPH\NF TPH\f1708172240.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 16:46 pm using AcqMethod FID17A.M

Sample Name: L2240634-19,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract JP-8 L2240634-19 Product



... Study\L2240634\TPH\NF TPH\f1708172244.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 19:48 pm using AcqMethod FID17A.M

Sample Name: L2240634-25,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract BUNKER C L2240634-25 Product



... Study\L2240634\TPH\NF TPH\f1709062236.D


Operator : FID17:WR Instrument : FID17

Acquired : 07 Sep 2022 16:05 pm using AcqMethod FID17A.M

Sample Name: 12240634-32,42,,

Misc Info : WG1684077, WG1682983, ICAL18753

Whole Extract WASTE OIL (AUTO) L2240634-32 Product



... Study\L2240634\TPH\NF TPH\f1708172212.D


Operator : FID17:WR Instrument : FID17

Acquired : 17 Aug 2022 19:40 pm using AcqMethod FID17A.M

Sample Name: WG1676301-1,42,,

Misc Info : WG1676467, WG1676301, ICAL18753

Whole Extract Method Blank



... Study\L2240634\TPH\NF TPH\f1708172210.D


Operator : FID17:WR Instrument : FID17

Acquired : 17 Aug 2022 18:10 pm using AcqMethod FID17A.M

Sample Name: IB1708172201F

Misc Info :

Whote Extract Instrument Blank



... Study\L2240634\TPH\NF TPH\f1708172238.D


Operator : FID17:WR Instrument : FID17

Acquired : 18 Aug 2022 15:14 pm using AcqMethod FID17A.M

Sample Name: IB1708172202F

Misc Info :

Whote Extract Instrument Blank



Attachment C: FID Chromatograms Aliphatic Fraction	

... Study\L2240634\TPH\NF TPH\f1708172260.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 7:48 am using AcqMethod FID17A.M

Sample Name: L2240634-02,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic GASOLINE 87 F1 L2240634-02 Product



... Study\L2240634\TPH\NF TPH\f1708172262.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 9:18 am using AcqMethod FID17A.M

Sample Name: WG1676456-4,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic GASOLINE 87 F1 Duplicate L2240634-02 Product



... Study\L2240634\TPH\NF TPH\f1708172264.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 10:49 am using AcqMethod FID17A.M

Sample Name: L2240634-05,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic GASOLINE 91 F1 L2240634-05 Product



... Study\L2240634\TPH\NF TPH\f1708172266.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 12:21 pm using AcqMethod FID17A.M

Sample Name: L2240634-08,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic GASOLINE 93 F1 L2240634-08 Product



... Study\L2240634\TPH\NF TPH\f1708172268.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 13:52 pm using AcqMethod FID17A.M

Sample Name: L2240634-11,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic HEATING FUEL F1 L2240634-11 Product



... Study\L2240634\TPH\NF TPH\f1708172270.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 15:24 pm using AcqMethod FID17A.M

Sample Name: L2240634-14,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic ROAD DIESEL F1 L2240634-14 Product



... Study\L2240634\TPH\NF TPH\f1708172278.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 21:29 pm using AcqMethod FID17A.M

Sample Name: L2240634-17,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic JP-5 L2240634-17 Product



... Study\L2240634\TPH\NF TPH\f1708172280.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 23:00 pm using AcqMethod FID17A.M

Sample Name: L2240634-20,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic JP-8 L2240634-20 Product



... Study\L2240634\TPH\NF TPH\f1708172284.D


Operator : FID17:WR Instrument : FID17

Acquired : 20 Aug 2022 2:01 am using AcqMethod FID17A.M

Sample Name: L2240634-26,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic BUNKER C L2240634-26 Product



... Study\L2240634\TPH\NF TPH\f1709062244.D


Operator : FID17:WR Instrument : FID17

Acquired : 07 Sep 2022 22:05 pm using AcqMethod FID17A.M

Sample Name: 12240634-33,42,,

Misc Info : WG1684077, WG1682989, ICAL18753

F1-Aliphatic WASTE OIL (AUTO) F1 L2240634-33 Product



... Study\L2240634\TPH\NF TPH\f1708172252.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 1:49 am using AcqMethod FID17A.M

Sample Name: WG1676456-1,42,,

Misc Info : WG1676467, WG1676456, ICAL18753

F1-Aliphatic Method Blank



... Study\L2240634\TPH\NF TPH\f1708172250.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 0:19 am using AcqMethod FID17A.M

Sample Name: IB1708172203F

Misc Info :

F1-Aliphatic Instrument Blank



... Study\L2240634\TPH\NF TPH\f1708172276.D


Operator : FID17:WR Instrument : FID17

Acquired : 19 Aug 2022 19:58 pm using AcqMethod FID17A.M

Sample Name: IB1708172204F

Misc Info :

F1-Aliphatic Instrument Blank



Attachment D: FID Chromatograms Aromatic Fraction

... Study\L2240634\TPH\Alpha TPH\f1708242224.D


Operator : FID17:WR Instrument : FID17

Acquired : 25 Aug 2022 19:02 pm using AcqMethod FID17A.M

Sample Name: L2240634-03,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic GASOLINE 87 F2 L2240634-03 Product



... Study\L2240634\TPH\Alpha TPH\f1708242226.D


Operator : FID17:WR Instrument : FID17

Acquired : 25 Aug 2022 20:32 pm using AcqMethod FID17A.M

Sample Name: WG1676458-4,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic GASOLINE 87 F2 Duplicate L2240634-03 Product



... Study\L2240634\TPH\Alpha TPH\f1708242228.D


Operator : FID17:WR Instrument : FID17

Acquired : 25 Aug 2022 22:03 pm using AcqMethod FID17A.M

Sample Name: L2240634-06,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic GASOLINE 91 F2 L2240634-06 Product



... Study\L2240634\TPH\Alpha TPH\f1708242230.D


Operator : FID17:WR Instrument : FID17

Acquired : 25 Aug 2022 23:34 pm using AcqMethod FID17A.M

Sample Name: L2240634-09,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic GASOLINE 93 F2 L2240634-09 Product



... Study\L2240634\TPH\Alpha TPH\f1708242232.D


Operator : FID17:WR Instrument : FID17

Acquired : 26 Aug 2022 1:04 am using AcqMethod FID17A.M

Sample Name: L2240634-12,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic HEATING FUEL F2 L2240634-12 Product



... Study\L2240634\TPH\Alpha TPH\f1708242234.D


Operator : FID17:WR Instrument : FID17

Acquired : 26 Aug 2022 2:34 am using AcqMethod FID17A.M

Sample Name: L2240634-15,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic ROAD DIESEL F2 L2240634-15 Product



... Study\L2240634\TPH\Alpha TPH\f1708242236.D


Operator : FID17:WR Instrument : FID17

Acquired : 26 Aug 2022 4:05 am using AcqMethod FID17A.M

Sample Name: L2240634-18,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic JP-5 F2 L2240634-18 Product



... Study\L2240634\TPH\Alpha TPH\f1708242238.D


Operator : FID17:WR Instrument : FID17

Acquired : 26 Aug 2022 5:35 am using AcqMethod FID17A.M

Sample Name: L2240634-21,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic JP-8 F2 L2240634-21 Product



... Study\L2240634\TPH\Alpha TPH\f1708242240.D


Operator : FID17:WR Instrument : FID17

Acquired : 26 Aug 2022 7:05 am using AcqMethod FID17A.M

Sample Name: L2240634-27,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic BUNKER C F2 L2240634-27 Product



... Study\L2240634\TPH\Alpha TPH\f1709062240.D


Operator : FID17:WR Instrument : FID17

Acquired : 07 Sep 2022 19:05 pm using AcqMethod FID17A.M

Sample Name: 12240634-34,42,,

Misc Info : WG1684077, WG1682993, ICAL18753

F2-Aromatic WASTE OIL (AUTO) F2 L2240634-34 Product



... Study\L2240634\TPH\Alpha TPH\f1708242212.D


Operator : FID17:WR Instrument : FID17

Acquired : 25 Aug 2022 9:53 am using AcqMethod FID17A.M

Sample Name: WG1676458-1,42,,

Misc Info : WG1679263, WG1676458, ICAL18753

F2-Aromatic Method Blank



... Study\L2240634\TPH\Alpha TPH\f1708242220.D


Operator : FID17:WR Instrument : FID17

Acquired : 25 Aug 2022 15:59 pm using AcqMethod FID17A.M

Sample Name: IB1708242202F

Misc Info :

F2-Aromatic Instrument Blank



# Attachment E: VPH Chromatograms and Quantification Reports

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A05.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 11:00 am

Operator: PVPH:BAD

Sample: WG1684889-4,41,10,1,0.100,, Misc: WG1684889,ICAL19300,VPH-50

ALS Vial: 5 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 09:08:53 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

System Monitoring Compounds

8) s 2,5-Dibromotoluene-FID 22.455 10942410 270.693 Spiked Amount 250.000 Recovery = 108.28%

**Target Compounds** 

9) A1 C5-C8 Aliphatics 5.404f 30443172 270.398 m 10) A2 C5 - C6 Aliphatics 5.626f 9158246 81.344 11) A2 > C6 - C8 Aliphatics 7.578f 4966763 44.115 m 12) A1 > C8-C10 Aliphatics 13.678 1462338 11.735 13) A2 C8 - C10 Aliphatics 13.678 1419622 11.392 m 14) A2 > C10 - C12 Aliphatics 18.050f 3457053 27.742 m

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A05.D

Signal(s): FID2B.ch

Acq On : 2 Sep 2022 11:00 am

Operator: PVPH:BAD

Sample: WG1684889-4,41,10,1,0.100,, Misc: WG1684889,ICAL19300,VPH-50

ALS Vial: 5 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 09:08:53 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A21.D

Signal(s): FID2B.ch

Acq On : 2 Sep 2022 7:24 pm

Operator: PVPH:BAD

Sample : I2240634-01d,41,10,1.11,0.0002,,w : WG1684889,ICAL19300,VPH-50

ALS Vial: 21 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 20 12:41:34 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase: Signal Info :

Compound

R.T.

Response Conc Units

## **System Monitoring Compounds**

**Target Compounds** 

304347979 2703.231 11.330f m 9) A1 C5-C8 Aliphatics 5.656f 60440510 536.835 10) A2 C5 - C6 Aliphatics 9.189 121166480 1076.206 11.330f 255768658 2052.512 11) A2 > C6 - C8 Aliphatics m 12) A1 > C8-C10 Aliphatics 11.330f 13) A2 C8 - C10 Aliphatics 11.330f m 254301055 2040.735 m 14) A2 > C10 - C12 Aliphatics 15.830 74746720 599.833 m

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A21.D

Signal(s): FID2B.ch

Acq On : 2 Sep 2022 7:24 pm

Operator: PVPH:BAD

Sample : I2240634-01d,41,10,1.11,0.0002,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 21 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 20 12:41:34 2022

Quant Method : C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





#12 > C8-C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.041 min Response: 255768658 Conc: 2052.51 m

#13 C8 - C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.044 min Response: 254301055 Conc: 2040.73 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 74746720 Conc: 599.83 m

15.00

Time

16.00

17.00

18.00

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A23.D

Signal(s): FID2B.ch

Acq On : 2 Sep 2022 8:24 pm

Operator: PVPH:BAD

Sample : WG1684889-6,41,10,1.11,0.0002,,w : WG1684889,ICAL19300,VPH-50

ALS Vial: 23 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 13:35:50 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase: Signal Info:

Compound

R.T.

Response Conc Units

# System Monitoring Compounds

**Target Compounds** 

300192561 2666.323 11.330f m 9) A1 C5-C8 Aliphatics 5.655f 61735358 548.336 10) A2 C5 - C6 Aliphatics 11) A2 > C6 - C8 Aliphatics 9.189 107967308 958.970 12) A1 > C8-C10 Aliphatics 11.330f 251296740 2016.626 m m 13) A2 C8 - C10 Aliphatics 11.330f 250868515 2013.189 m m

14) A2 > C10 - C12 Aliphatics 15.830 70683996 567.230

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A23.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 8:24 pm

Operator: PVPH:BAD

Sample: WG1684889-6,41,10,1.11,0.0002,,w Misc: WG1684889,ICAL19300,VPH-50

ALS Vial: 23 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 13:35:50 2022

Quant Method : C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





#12 > C8-C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.041 min Response: 251296740 Conc: 2016.63 m

#13 C8 - C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.044 min Response: 250868515 Conc: 2013.19 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 70683996 Conc: 567.23 m

15.00

Time

16.00

17.00

18.00

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A25.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 9:23 pm

Operator: PVPH:BAD

Sample : I2240634-04d,41,10,1.14,0.0002,,w Misc: WG1684889,ICAL19300,VPH-50

ALS Vial: 25 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 11:02:10 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj.: Signal Phase: Signal Info:

Compound R.T. Response Conc Units

## System Monitoring Compounds

Target Compounds

9) A1 C5-C8 Aliphatics	11.330f	310179084 2755.023	m
10) A2 C5 - C6 Aliphatics	5.655f	63527232 564.251	m
11) A2 > C6 - C8 Aliphatics	9.189	109378360 971.503	m
12) A1 > C8-C10 Aliphatics	11.330f	255951261 2053.977	m
13) A2 C8 - C10 Aliphatics	11.330f	253222488 2032.079	m
14) A2 > C10 - C12 Aliphatics	15.830	67246649 539.646	m

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A25.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 9:23 pm

Operator: PVPH:BAD

Sample : l2240634-04d,41,10,1.14,0.0002,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 25 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 11:02:10 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





#12 > C8-C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.041 min Response: 255951261 Conc: 2053.98 m

#13 C8 - C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.044 min Response: 253222488 Conc: 2032.08 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 67246649 Conc: 539.65 m

15.00

Time

16.00

17.00

18.00

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A27.D

Signal(s): FID2B.ch

Acq On : 2 Sep 2022 10:23 pm

Operator: PVPH:BAD

Sample : I2240634-07d,41,10,1.17,0.0002,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 27 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 26 17:03:23 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

## System Monitoring Compounds

**Target Compounds** 

9) A1 C5-C8 Aliphatics 11.330f 235266727 2089.649 m 10) A2 C5 - C6 Aliphatics 5.655f 45220918 401.654 m 11) A2 > C6 - C8 Aliphatics 9.189 78082300 693.530 m 12) A1 > C8-C10 Aliphatics 11.330f 212562718 1705.790 m 13) A2 C8 - C10 Aliphatics 11.330f 212907744 1708.559 m 14) A2 > C10 - C12 Aliphatics 15.830 54931074 440.815 m

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A27.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 10:23 pm

Operator: PVPH:BAD

Sample : l2240634-07d,41,10,1.17,0.0002,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 27 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 26 17:03:23 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





15.00

Time

18.00

17.00

#12 > C8-C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.041 min Response: 212562718 Conc: 1705.79 m

#13 C8 - C10 Aliphatics

R.T.: 11.330 min Delta R.T.: -2.044 min Response: 212907744 Conc: 1708.56 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 54931074 Conc: 440.82 m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A29.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 11:23 pm

Operator: PVPH:BAD

Sample : l2240634-10d,41,10,1.17,0.0005,,z Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 29 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 11:44:02 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Compound

R.T. Response Conc Units

#### System Monitoring Compounds

**Target Compounds** 

9) A1 C5-C8 Aliphatics 12.138f 38324948 340.404 m 2454292 21.799 5.656f 10) A2 C5 - C6 Aliphatics 10108723 89.786 11) A2 > C6 - C8 Aliphatics 10.887f 12) A1 > C8-C10 Aliphatics 14.689f 176571573 1416.965 m 13) A2 C8 - C10 Aliphatics 14.689f 164212163 1317.782 m 14) A2 > C10 - C12 Aliphatics 15.830 338492923 2716.364

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A29.D Signal(s): FID2B.ch

Acq On : 2 Sep 2022 11:23 pm

Operator: PVPH:BAD

Sample : I2240634-10d,41,10,1.17,0.0005,,z Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 29 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 11:44:02 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A


.09152022.m

Quant Title: VPH ALIPHATIC


QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration

Integrator: ChemStation



Page: 2





15.00

17.00

18.00

#### #12 > C8-C10 Aliphatics

R.T.: 14.689 min Delta R.T.: 1.318 min Response: 176571573 Conc: 1416.97 m

#13 C8 - C10 Aliphatics

R.T.: 14.689 min Delta R.T.: 1.315 min Response: 164212163 Conc: 1317.78 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 338492923 Conc: 2716.36 m

Time

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A31.D

Signal(s): FID2B.ch

Acq On : 3 Sep 2022 12:23 am

Operator: PVPH:BAD

Sample : 12240634-13d,41,10,1.67,0.0005,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 31 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 14:57:20 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj.: Signal Phase: Signal Info :

Compound

R.T. Response Conc Units

#### **System Monitoring Compounds**

**Target Compounds** 

9) A1 C5-C8 Aliphatics	11.330f	41789542 371.176 r	n
10) A2 C5 - C6 Aliphatics	5.654f	1574382 13.984 m	
11) A2 > C6 - C8 Aliphatics	9.937	13911422 123.562	m
12) A1 > C8-C10 Aliphatics	13.373	179764104 1442.585	m
13) A2 C8 - C10 Aliphatics	13.373	181295100 1454.871	m
14) A2 > C10 - C12 Aliphatics	15.830	354633889 2845.893	m

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A31.D

Signal(s): FID2B.ch

Acq On : 3 Sep 2022 12:23 am

Operator: PVPH:BAD

Sample : I2240634-13d,41,10,1.67,0.0005,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 31 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 14:57:20 2022

Quant Method : C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A


.09152022.m

Quant Title: VPH ALIPHATIC


QLast Update : Fri Sep 16 09:02:50 2022


Response via: Initial Calibration

Integrator: ChemStation



Page: 2





#12 > C8-C10 Aliphatics

R.T.: 13.373 min Delta R.T.: 0.002 min Response: 179764104 Conc: 1442.58 m

#13 C8 - C10 Aliphatics

R.T.: 13.373 min Delta R.T.: 0.000 min Response: 181295100 Conc: 1454.87 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 354633889 Conc: 2845.89 m

15.00

Time

16.00

17.00

18.00

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A33.D

Signal(s): FID2B.ch

Acq On : 3 Sep 2022 1:23 am

Operator: PVPH:BAD

Sample : I2240634-25d,41,10,1.17,0.005,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 33 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 11:46:04 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Compound

R.T. Response Conc Units

System Monitoring Compounds

8) s 2,5-Dibromotoluene-FID 22.355f 18998220 469.977 Spiked Amount 250.000 Recovery = 187.99%

Target Compounds

9) A1 C5-C8 Aliphatics 12.140f 10589513 94.056 m
10) A2 C5 - C6 Aliphatics 6.777 1817701 16.145 m
11) A2 > C6 - C8 Aliphatics 10.888f 3040048 27.002 m
12) A1 > C8-C10 Aliphatics 14.688f 45405379 364.373 m
13) A2 C8 - C10 Aliphatics 14.688f 40299446 323.398 m
14) A2 > C10 - C12 Aliphatics 18.042f 628687699 5045.142 m

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A33.D

Signal(s): FID2B.ch

Acq On : 3 Sep 2022 1:23 am

Operator: PVPH:BAD

Sample : I2240634-25d,41,10,1.17,0.005,,w Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 33 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 11:46:04 2022

Quant Method : C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update : Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





15.00

Time

17.00

18.00

#### #12 > C8-C10 Aliphatics

R.T.: 14.688 min Delta R.T.: 1.317 min Response: 45405379 Conc: 364.37 m

#13 C8 - C10 Aliphatics

R.T.: 14.688 min Delta R.T.: 1.314 min Response: 40299446 Conc: 323.40 m

#14 > C10 - C12 Aliphatics

R.T.: 18.042 min Delta R.T.: 2.212 min Response: 628687699 Conc: 5045.14 m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220902A35.D

Signal(s): FID2B.ch

Acq On : 3 Sep 2022 2:22 am

Operator: PVPH:BAD

Sample : I2240634-32d,41,10,1.01,0.02,,z Misc: WG1684889,ICAL19300,VPH-50

ALS Vial: 35 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 11:48:01 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase: Signal Info:

Compound

R.T. Response Conc Units

## System Monitoring Compounds

**Target Compounds** 

9) A1	C5-C8 Aliphatics	11.329f	286089755 2541.061	m
1Ó) A2	C5 - C6 Aliphatics	6.851	22433507 199.255	m
11) A2	> C6 - C8 Aliphatics	8.907	138597802 1231.031	m
12) A1	> C8-C10 Aliphatics	13.373	352626722 2829.786	m
13) A2	C8 - C10 Aliphatics	13.373	458724925 3681.211	m

14) A2 > C10 - C12 Aliphatics 15.830 702543749 5637.827

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220902A35.D

Signal(s): FID2B.ch

Acq On : 3 Sep 2022 2:22 am

Operator: PVPH:BAD

Sample : I2240634-32d,41,10,1.01,0.02,,z Misc : WG1684889,ICAL19300,VPH-50

ALS Vial: 35 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 11:48:01 2022

Quant Method : C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A


.09152022.m

Quant Title: VPH ALIPHATIC


QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration

Integrator: ChemStation



Page: 2





#### #12 > C8-C10 Aliphatics

R.T.: 13.373 min Delta R.T.: 0.002 min Response: 352626722 Conc: 2829.79 m

#13 C8 - C10 Aliphatics

R.T.: 13.373 min Delta R.T.: -0.001 min Response: 458724925 Conc: 3681.21 m

#14 > C10 - C12 Aliphatics

R.T.: 15.830 min Delta R.T.: 0.000 min Response: 702543749 Conc: 5637.83 m

15.00

Time

16.00

17.00

18.00

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220908A07.D Signal(s): FID2B.ch

Acq On : 8 Sep 2022 12:54 pm

Operator: PVPH:BAD

Sample : I2240634-30d,41,10,0.51,0.05,,w Misc : WG1685081,ICAL19300,VPH-50

ALS Vial: 7 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 15:06:12 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via: Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

**System Monitoring Compounds** 

8) s 2,5-Dibromotoluene-FID 22.452 21754166 538.153 Spiked Amount 250.000 Recovery = 215.26%

**Target Compounds** 

9) A1 C5-C8 Aliphatics 12.148f 95472227 847.988 m
10) A2 C5 - C6 Aliphatics 5.645f 5590013 49.651 m
11) A2 > C6 - C8 Aliphatics 10.887f 26673691 236.917 m
12) A1 > C8-C10 Aliphatics 14.689f 556275720 4464.044 m
13) A2 C8 - C10 Aliphatics 14.689f 507962715 4076.338 m
14) A2 > C10 - C12 Aliphatics 16.426 1840868984 14772.748 m

(f)=RT Delta > 1/2 Window (m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220908A07.D

Signal(s): FID2B.ch

Acq On : 8 Sep 2022 12:54 pm

Operator: PVPH:BAD

Sample : I2240634-30d,41,10,0.51,0.05,,w Misc : WG1685081,ICAL19300,VPH-50

ALS Vial: 7 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 15:06:12 2022

Quant Method : C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A


.09152022.m

Quant Title: VPH ALIPHATIC


QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration

Integrator: ChemStation



Page: 2





15.00

Time

18.00

17.00

#### #12 > C8-C10 Aliphatics

R.T.: 14.689 min Delta R.T.: 1.318 min Response: 556275720 Conc: 4464.04 m

#13 C8 - C10 Aliphatics

R.T.: 14.689 min Delta R.T.: 1.315 min Response: 507962715 Conc: 4076.34 m

#14 > C10 - C12 Aliphatics

R.T.: 16.426 min Delta R.T.: 0.596 min Response: 1840868984 Conc: 14772.75 m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Data

Data File: P220908A09.D

Signal(s): FID2B.ch

Acq On : 8 Sep 2022 1:53 pm

Operator: PVPH:BAD

Sample : I2240634-31d,41,10,0.50,0.05,,w Misc: : WG1685081,ICAL19300,VPH-50

ALS Vial: 9 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 15:19:25 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF Ali

.09152022.m

Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022

Response via : Initial Calibration

Integrator: ChemStation

Volume Inj.: Signal Phase: Signal Info :

> R.T. Response Conc Units Compound

System Monitoring Compounds

8) s 2,5-Dibromotoluene-FID 22.453 16252552 402.054 Recovery = 160.82%Spiked Amount 250.000

12.142f 724538586 6435.381 10) A2 C5 - C6 Aliphatics 5.648f 6007100 51 11) A2 > C6 - C8 Aliphatics 10.887f 219533316 1949.904 m 12) A1 > C8-C10 Aliphatics 13.373 1699941144 13641.819 13) A2 C8 - C10 Aliphatics 13.373 1616382725 12971.273 m m 14) A2 > C10 - C12 Aliphatics 15.829 1095003172 8787.266 m

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\Aliphatic Da

Data File: P220908A09.D Signal(s): FID2B.ch

Acq On : 8 Sep 2022 1:53 pm

Operator: PVPH:BAD

Sample : I2240634-31d,41,10,0.50,0.05,,w Misc : WG1685081,ICAL19300,VPH-50

ALS Vial: 9 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Sep 16 15:19:25 2022

Quant Method: C:\Projects\Aquiver Hawaii\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\VPH\NF Data\NF A

.09152022.m


Quant Title: VPH ALIPHATIC

QLast Update: Fri Sep 16 09:02:50 2022


Response via: Initial Calibration


Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :



Page: 2





15.00

Time

17.00

#12 > C8-C10 Aliphatics

R.T.: 13.373 min Delta R.T.: 0.002 min Response: 1699941144 Conc: 13641.82 m

#13 C8 - C10 Aliphatics

R.T.: 13.373 min Delta R.T.: -0.001 min Response: 1616382725 Conc: 12971.27 m

#14 > C10 - C12 Aliphatics

R.T.: 15.829 min
Delta R.T.: 0.000 min
Response: 1095003172
Conc: 8787.27 m

18.00

Attachment F: TPH Quantitation Raw Data Reports

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172212.D Signal(s): FID1A.CH

Acq On : 17 Aug 2022 19:40 pm

Operator: FID17:WR

Sample: WG1676301-1,42,,

Misc : WG1676467,WG1676301,ICAL18753

ALS Vial: 6 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:37:45 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.266 59394365 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.290 63504659 51.145 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 102.29% 3) s d50-Tetracosane 35.019 49108277 50.020 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 100.04%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.072 1364421 1.219 ug/mLm 5) h > C10 to C12 Aliphatics 11.977 1105234 0.988 ug/mlm 6) h > C12 to C16 Aliphatics 16.687 2063524 1.844 UG/MLm 7) h > C16 to C21 Aliphatics 28.293 17976833 16.065 UG/MLm 8) h > C21 to C32 Aliphatics 32.798 27247290 24.350 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window (m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172212.D Signal(s): FID1A.CH

Acq On : 17 Aug 2022 19:40 pm

Operator : FID17:WR

Sample: WG1676301-1,42,,

Misc : WG1676467,WG1676301,ICAL18753

ALS Vial: 6 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:37:45 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172220.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 1:41 am

Operator: FID17:WR Sample: L2240634-01,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 10 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:45:45 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH\

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.263 62914638 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.289 67077447 50.999 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 102.00% 3) s d50-Tetracosane 35.024 51803250 49.813 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 99.63%

Target Compounds

 4) h
 > C8 to C10 Aliphatics
 7.072
 1140268388
 961.985 ug/mLm

 5) h
 > C10 to C12 Aliphatics
 11.977
 354604380
 299.161 ug/mlm

 6) h
 > C12 to C16 Aliphatics
 16.687
 65383861
 55.161 UG/MLm

 7) h
 > C16 to C21 Aliphatics
 28.293
 16180616
 13.651 UG/MLm

 8) h
 > C21 to C32 Aliphatics
 32.798
 29067199
 24.522 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window (m)=manual int.

Page: 1

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172220.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 1:41 am

Operator: FID17:WR Sample: L2240634-01,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 10 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:45:45 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172222.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 3:10 am

Operator: FID17:WR

Sample: WG1676301-4,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 11 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:51:17 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) | 5-alpha-androstane 30.266 60681820 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.288 64853135 51.122 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 102.24% 3) s d50-Tetracosane 35.022 50427755 50.274 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 100.55%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.072 1049161063 917.691 ug/mLm 5) h > C10 to C12 Aliphatics 11.977 323945728 283.352 ug/mlm 6) h > C12 to C16 Aliphatics 16.687 60603128 53.009 UG/MLm 7) h > C16 to C21 Aliphatics 28.293 15274127 13.360 UG/MLm 8) h > C21 to C32 Aliphatics 32.798 28156051 24.628 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window (m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172222.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 3:10 am

Operator: FID17:WR

Sample: WG1676301-4,42,,

Misc : WG1676467,WG1676301,ICAL18753

ALS Vial: 11 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:51:17 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update : Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172224.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 4:40 am

Operator: FID17:WR Sample: L2240634-04,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 12 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 17:33:14 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.265 62919262 50.000 ug/mLm

**System Monitoring Compounds** 

2) s ortho-terphenyl 28.291 67286922 51.155 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 102.31% 3) s d50-Tetracosane 35.020 52130181 50.124 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 100.25%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.072 995389305 839.696 ug/mLm 5) h > C10 to C12 Aliphatics 11.977 283823166 239.429 ug/mlm 6) h > C12 to C16 Aliphatics 16.687 50448201 42.557 UG/MLm 7) h > C16 to C21 Aliphatics 28.293 13104180 11.055 UG/MLm 8) h > C21 to C32 Aliphatics 32.798 28029786 23.646 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window (m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172224.D

Signal(s): FID1A.CH

Acq On : 18 Aug 2022 4:40 am

Operator: FID17:WR Sample: L2240634-04,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 12 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 17:33:14 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172226.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 6:10 am

Operator: FID17:WR

Sample : L2240634-07,42,,

Misc : WG1676467,WG1676301,ICAL18753

ALS Vial: 13 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 17:43:31 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.265 66306484 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.292 71426738 51.528 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 103.06% 3) s d50-Tetracosane 35.022 55360507 50.510 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 101.02%

**Target Compounds** 

 4) h
 C8 to C10 Aliphatics
 7.072
 1149074725
 919.825 ug/mLm

 5) h
 C10 to C12 Aliphatics
 11.977
 335489692
 268.557 ug/mlm

 6) h
 C12 to C16 Aliphatics
 16.687
 58193772
 46.584 UG/MLm

 7) h
 C16 to C21 Aliphatics
 28.293
 14679873
 11.751 UG/MLm

 8) h
 C21 to C32 Aliphatics
 32.798
 27942125
 22.367 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172226.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 6:10 am

Operator: FID17:WR Sample: L2240634-07,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 13 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 17:43:31 2022


Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped





### #1 5-alpha-androstane

R.T.: 30.265 min

Delta R.T.: -0.005 min

Response: 66306484

Conc: 50.00 ug/mL m

### #2 ortho-terphenyl


R.T.: 28.292 min
Delta R.T.: 0.000 min
Response: 71426738
Conc: 51.53 ug/mL m

#### #3 d50-Tetracosane

R.T.: 35.022 min
Delta R.T.: -0.017 min
Response: 55360507
Conc: 50.51 ug/mL m

#### #4 > C8 to C10 Aliphatics

R.T.: 7.072 min
Delta R.T.: 0.000 min
Response: 1149074725
Conc: 919.82 ug/mL m



Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172228.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 7:40 am

Operator: FID17:WR

Sample : L2240634-10,42,,

Misc: : WG1676467,WG1676301,ICAL18753

ALS Vial: 14 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 17:52:47 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.278 62079088 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.300 65512801 50.480 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 100.96% 3) s d50-Tetracosane 35.022 50542749 49.255 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 98.51%

**Target Compounds** 

 4) h
 > C8 to C10 Aliphatics
 7.072
 328285868 280.685 ug/mLm

 5) h
 > C10 to C12 Aliphatics
 11.977
 997894203 853.202 ug/mlm

 6) h
 > C12 to C16 Aliphatics
 16.687
 2348760899 2008.197 UG/MLm

 7) h
 > C16 to C21 Aliphatics
 28.293
 1732349970 1481.164 UG/MLm

 8) h
 > C21 to C32 Aliphatics
 32.798
 394378981 337.195 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172228.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 7:40 am

Operator: FID17:WR

Sample : L2240634-10,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 14 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 17:52:47 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update : Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







#5 > C10 to C12 Aliphatics

R.T.: 11.977 min Delta R.T.: 0.000 min Response: 997894203 Conc: 853.20 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.687 min
Delta R.T.: 0.000 min
Response: 2348760899
Conc: 2008.20 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.293 min Delta R.T.: 0.000 min Response: 1732349970 Conc: 1481.16 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.798 min
Delta R.T.: 0.000 min
Response: 394378981
Conc: 337.20 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172230.D Signal(s): FID1A.CH

Acg On : 18 Aug 2022 9:10 am

Operator: FID17:WR

Sample : L2240634-13,42,,

Misc: : WG1676467,WG1676301,ICAL18753

ALS Vial: 15 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:00:55 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.280 61549067 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.301 65613942 50.993 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 101.99% 3) s d50-Tetracosane 35.020 51390182 50.512 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 101.02%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.072 548329739 472.861 ug/mLm 5) h > C10 to C12 Aliphatics 11.977 891993370 769.224 ug/mlm 6) h > C12 to C16 Aliphatics 16.687 2359478728 2034.733 UG/MLm 7) h > C16 to C21 Aliphatics 28.293 2060299682 1776.732 UG/MLm 8) h > C21 to C32 Aliphatics 32.798 364368418 314.219 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172230.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 9:10 am

Operator: FID17:WR

Sample : L2240634-13,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 15 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:00:55 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update : Fri Sep 23 15:53:13 2022


Response via : Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#5 > C10 to C12 Aliphatics

R.T.: 11.977 min Delta R.T.: 0.000 min Response: 891993370 Conc: 769.22 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.687 min
Delta R.T.: 0.000 min
Response: 2359478728
Conc: 2034.73 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.293 min
Delta R.T.: 0.000 min
Response: 2060299682
Conc: 1776.73 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.798 min Delta R.T.: 0.000 min Response: 364368418 Conc: 314.22 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172232.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 10:41 am

Operator: FID17:WR Sample: L2240634-16,42,,

Misc : WG1676467,WG1676301,ICAL18753

ALS Vial: 16 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:23:44 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.261 65118623 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.287 69523879 51.070 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 102.14% 3) s d50-Tetracosane 35.020 54760510 50.874 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 101.75%

**Target Compounds** 

(f)=RT Delta > 1/2 Window

4) h > C8 to C10 Aliphatics 7.072 654593826 533.556 ug/mLm 5) h > C10 to C12 Aliphatics 11.977 2704146725 2204.134 ug/mlm 6) h > C12 to C16 Aliphatics 16.687 2823958271 2301.792 UG/MLm 7) h > C16 to C21 Aliphatics 28.293 31709527 25.846 UG/MLm 8) h > C21 to C32 Aliphatics 32.798 28077442 22.886 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172232.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 10:41 am

Operator: FID17:WR Sample: L2240634-16,42,,

Misc : WG1676467,WG1676301,ICAL18753

ALS Vial: 16 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:23:44 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172240.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 16:46 pm

Operator: FID17:WR

Sample : L2240634-19,42,,

Misc: : WG1676467, WG1676301, ICAL 18753

ALS Vial: 20 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:38:30 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.261 69177027 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.289 73601155 50.893 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 101.79% 3) s d50-Tetracosane 35.017 56914459 49.773 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 99.55%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.072 1860931675 1427.846 ug/mLm 5) h > C10 to C12 Aliphatics 11.977 1926067589 1477.823 ug/mlm 6) h > C12 to C16 Aliphatics 16.687 2376840066 1823.690 UG/MLm 7) h > C16 to C21 Aliphatics 28.293 194138497 148.958 UG/MLm 8) h > C21 to C32 Aliphatics 32.798 24985414 19.171 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172240.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 16:46 pm

Operator: FID17:WR Sample: L2240634-19,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 20 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:38:30 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :





### #1 5-alpha-androstane

R.T.: 30.261 min
Delta R.T.: -0.008 min
Response: 69177027
Conc: 50.00 ug/mL m

### #2 ortho-terphenyl


R.T.: 28.289 min
Delta R.T.: -0.003 min
Response: 73601155
Conc: 50.89 ug/mL m

#### #3 d50-Tetracosane

R.T.: 35.017 min Delta R.T.: -0.022 min Response: 56914459 Conc: 49.77 ug/mL m

### #4 > C8 to C10 Aliphatics

R.T.: 7.072 min Delta R.T.: 0.000 min Response: 1860931675 Conc: 1427.85 ug/mL m



Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172244.D Signal(s): FID1A.CH

Acq On : 18 Aug 2022 19:48 pm

Operator: FID17:WR Sample: L2240634-25,42,,

Misc: : WG1676467,WG1676301,ICAL18753

ALS Vial: 22 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:47:29 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH\

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) | 5-alpha-androstane 30.270 69299970 50.000 ug/mLm

**System Monitoring Compounds** 

2) s ortho-terphenyl 28.294 73139576 50.485 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 100.97% 3) s d50-Tetracosane 35.024 60804744 53.081 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 106.16%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.072 12357325 9.465 ug/mLm
5) h > C10 to C12 Aliphatics 11.977 200670480 153.696 ug/mlm
6) h > C12 to C16 Aliphatics 16.687 642632413 492.201 UG/MLm
7) h > C16 to C21 Aliphatics 28.293 752619422 576.442 UG/MLm
8) h > C21 to C32 Aliphatics 32.798 1935070135 1482.097 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

File :C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range


... Study\L2240634\TPH\NF TPH\f1708172244.D

Operator : FID17:WR Instrument : FID17

Acquired: 18 Aug 2022 19:48 pm using AcqMethod FID17A.M

Sample Name: L2240634-25,42,,

Misc Info: WG1676467, WG1676301, ICAL18753



Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172244.D

Signal(s): FID1A.CH

Acq On : 18 Aug 2022 19:48 pm

Operator: FID17:WR

Sample : L2240634-25,42,,

Misc: WG1676467,WG1676301,ICAL18753

ALS Vial: 22 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 18:47:29 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







#5 > C10 to C12 Aliphatics

R.T.: 11.977 min Delta R.T.: 0.000 min Response: 200670480 Conc: 153.70 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.687 min
Delta R.T.: 0.000 min
Response: 642632413
Conc: 492.20 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.293 min Delta R.T.: 0.000 min Response: 752619422 Conc: 576.44 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.798 min
Delta R.T.: 0.000 min
Response: 1935070135
Conc: 1482.10 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1709062236.D Signal(s): FID1A.CH

Acq On : 07 Sep 2022 16:05 pm

Operator: FID17:WR Sample: 12240634-32,42,,

Misc : WG1684077,WG1682983,ICAL18753

ALS Vial: 18 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 19:21:04 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Sun Oct 23 18:48:52 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.083 74106757 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.113 70607308 45.575 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 91.15% 3) s d50-Tetracosane 34.865 57756883 47.150 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 94.30%

**Target Compounds** 

(f)=RT Delta > 1/2 Window

4) h > C8 to C10 Aliphatics 7.029 30357146 21.743 ug/mLm 5) h > C10 to C12 Aliphatics 11.903 40921226 29.309 ug/mlm 6) h > C12 to C16 Aliphatics 16.584 57780945 41.385 UG/MLm 7) h > C16 to C21 Aliphatics 28.119 119151760 85.341 UG/MLm 8) h > C21 to C32 Aliphatics 32.596 4873232031 3490.376 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1709062236.D

Signal(s): FID1A.CH

Acq On : 07 Sep 2022 16:05 pm

Operator: FID17:WR Sample: I2240634-32,42,,

Misc: WG1684077,WG1682983,ICAL18753

ALS Vial: 18 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 19:21:04 2022


Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Sun Oct 23 18:48:52 2022

Response via : Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172252.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 1:49 am

Operator: FID17:WR

Sample: WG1676456-1,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 26 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 17:12:14 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.257 60790287 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.017 49093075 48.857 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 97.71%

Target Compounds

4) n	> C8 to C10 Aliphatics	7.069	2/4814/8 4	23.995 ug/mLm
5) h	> C10 to C12 Aliphatics	11.972	7681627	6.707 ug/mlm
6) h	> C12 to C16 Aliphatics	16.680	2006465	1.752 UG/MLm
7) h	> C16 to C21 Aliphatics	28.281	4168073	3.639 UG/MLm
8) h	> C21 to C32 Aliphatics	32.785	23445315	20.471 UG/MLm
9) h	> C8 to C10 Aromatics	7.069	27566135	24.069 UG/MLm
10) h	> C10 to C12 Aromatics	11.972	6721338	5.869 UG/MLm
11) h	> C12 to C16 Aromatics	16.680	2039906	1.781 UG/MLm
12) h	> C16 to C21 Aromatics	28.281	4238839	3.701 UG/MLm
13) h	> C21 to C32 Aromatics	32.785	23633302	2 20.635 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172252.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 1:49 am

Operator : FID17:WR

Sample: WG1676456-1,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 26 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 17:12:14 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration


Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped


Volume Inj. : Signal Phase : Signal Info :











#13 > C21 to C32 Aromatics

R.T.: 32.785 min Delta R.T.: 0.000 min Response: 23633302 Conc: 20.63 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172260.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 7:48 am

Operator: FID17:WR Sample: L2240634-02,42,,

Misc: WG1676467, WG1676456, ICAL18753

ALS Vial: 30 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 17:20:14 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound	R.T.	Response	Conc Units		

Internal Standards

1) | 5-alpha-androstane 30.253 61167035 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.010 48645471 48.113 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 96.23%

**Target Compounds** 

4) h	> C8 to C10 Aliphatics	7.069	446712270 387.635 ug/mLm	
5) h	> C10 to C12 Aliphatics	11.972	142759669 123.880 ug/mlm	
6) h	> C12 to C16 Aliphatics	16.680	33496124 29.066 UG/MLm	
	> C16 to C21 Aliphatics	28.281	11600857 10.067 UG/MLm	
-: .	> C21 to C32 Aliphatics	32.785	23860579 20.705 UG/MLm	

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172260.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 7:48 am

Operator: FID17:WR Sample: L2240634-02,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 30 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 21 17:20:14 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172262.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 9:18 am

Operator: FID17:WR

Sample: WG1676456-4,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 31 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 16:45:43 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound	R.T.	Response	Conc Units
town of Chandordo			4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-

Internal Standards

1) | 5-alpha-androstane 30.253 63639014 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.010 51158551 48.633 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 97.27%

**Target Compounds** 

4) h	> C8 to C10 Aliphatics	7.069	543985759 453.709 u	ıg/mLm
5) h	> C10 to C12 Aliphatics	11.972	169891397 141.697	ug/mlm
6) h	> C12 to C16 Aliphatics	16.680	37038170 30.892 l	JG/MLm
7) h	> C16 to C21 Aliphatics	28.281	11079278 9.241 U	G/MLm
8) h	> C21 to C32 Aliphatics	32.785	25033312 20.879 U	JG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172262.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 9:18 am

Operator: FID17:WR

Sample : WG1676456-4,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 31 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 16:45:43 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172264.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 10:49 am

Operator: FID17:WR Sample: L2240634-05,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 32 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 16:55:34 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH\C

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound	R.T.	Response	Conc Units		

#### Internal Standards

1) I 5-alpha-androstane 30.253 66028062 50.000 ug/mLm

#### **System Monitoring Compounds**

3) s d50-Tetracosane 35.009 50960795 46.692 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 93.38%

#### **Target Compounds**

4) h	> C8 to C10 Aliphatics	7.069	492283944 395.731 ug/mLm
5) h	> C10 to C12 Aliphatics	11.972	146658507 117.894 ug/mlm
6) h	> C12 to C16 Aliphatics	16.680	30173126 24.255 UG/MLm
7) h	> C16 to C21 Aliphatics	28.281	9278829 7.459 UG/MLm
,	> C21 to C32 Aliphatics	32.785	23160922 18.618 UG/MLm

# SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172264.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 10:49 am

Operator: FID17:WR Sample: L2240634-05,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 32 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 16:55:34 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172266.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 12:21 pm

Operator: FID17:WR Sample: L2240634-08,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 33 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:03:41 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units
-----Internal Standards

System Monitoring Compounds

3) s d50-Tetracosane 35.010 50818704 48.278 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 96.56%

1) | 5-alpha-androstane 30.252 63680700 50.000 ug/mLm

**Target Compounds** 

 4) h
 > C8 to C10 Aliphatics
 7.069
 452285967
 376.980 ug/mLm

 5) h
 > C10 to C12 Aliphatics
 11.972
 129249544
 107.729 ug/mlm

 6) h
 > C12 to C16 Aliphatics
 16.680
 29034071
 24.200 UG/MLm

 7) h
 > C16 to C21 Aliphatics
 28.281
 9145590
 7.623 UG/MLm

 8) h
 > C21 to C32 Aliphatics
 32.785
 23869912
 19.896 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172266.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 12:21 pm

Operator: FID17:WR Sample: L2240634-08,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 33 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:03:41 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172268.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 13:52 pm

Operator: FID17:WR Sample: L2240634-11,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 34 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:13:08 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) | 5-alpha-androstane 30.275 68769343 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.013 55198276 48.559 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 97.12%

**Target Compounds** 

 4) h
 > C8 to C10 Aliphatics
 7.069
 348108102
 268.678 ug/mLm

 5) h
 > C10 to C12 Aliphatics
 11.972
 1177427463
 908.766 ug/mlm

 6) h
 > C12 to C16 Aliphatics
 16.680
 2953853288
 2279.854 UG/MLm

 7) h
 > C16 to C21 Aliphatics
 28.281
 2420916324
 1868.520 UG/MLm

 8) h
 > C21 to C32 Aliphatics
 32.785
 505923626
 390.484 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172268.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 13:52 pm

Operator: FID17:WR Sample: L2240634-11,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 34 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:13:08 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#5 > C10 to C12 Aliphatics

R.T.: 11.972 min Delta R.T.: 0.000 min Response: 1177427463 Conc: 908.77 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.680 min Delta R.T.: 0.000 min Response: 2953853288 Conc: 2279.85 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.281 min
Delta R.T.: 0.000 min
Response: 2420916324
Conc: 1868.52 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.785 min
Delta R.T.: 0.000 min
Response: 505923626
Conc: 390.48 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172270.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 15:24 pm

Operator: FID17:WR Sample: L2240634-14,42,,

Misc: : WG1676467, WG1676456, ICAL 18753

ALS Vial: 35 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:25:54 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH\C

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound	R.T.	Response	Conc Units		

#### Internal Standards

1) I 5-alpha-androstane 30.280 71347060 50.000 ug/mLm

## System Monitoring Compounds

3) s d50-Tetracosane 35.011 55068639 46.694 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 93.39%

#### **Target Compounds**

_	> C8 to C10 Aliphatics	7.069	473685715 352.393 ug/mLm
5) h	> C10 to C12 Aliphatics	11.972	918284796 683.147 ug/mlm
6) h	> C12 to C16 Aliphatics	16.680	2947264608 2192.583 UG/MLm
7) h	> C16 to C21 Aliphatics	28.281	3199675265 2380.361 UG/MLm
	> C21 to C32 Aliphatics	32.785	546954534 406.900 UG/MLm

## SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172270.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 15:24 pm

Operator: FID17:WR Sample: L2240634-14,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 35 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:25:54 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#5 > C10 to C12 Aliphatics

R.T.: 11.972 min Delta R.T.: 0.000 min Response: 918284796 Conc: 683.15 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.680 min
Delta R.T.: 0.000 min
Response: 2947264608
Conc: 2192.58 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.281 min
Delta R.T.: 0.000 min
Response: 3199675265
Conc: 2380.36 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.785 min
Delta R.T.: 0.000 min
Response: 546954534
Conc: 406.90 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172278.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 21:29 pm

Operator: FID17:WR Sample: L2240634-17,42,,

Misc: : WG1676467, WG1676456, ICAL18753

ALS Vial: 39 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:45:02 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.250 66264060 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.008 51828863 47.318 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 94.64%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.069 1510386093 1209.826 ug/mLm 5) h > C10 to C12 Aliphatics 11.972 6956599866 5572.267 ug/mlm 6) h > C12 to C16 Aliphatics 16.680 7882540532 6313.949 UG/MLm 7) h > C16 to C21 Aliphatics 28.281 57722154 46.236 UG/MLm 8) h > C21 to C32 Aliphatics 32.785 23221356 18.600 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172278.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 21:29 pm

Operator: FID17:WR Sample: L2240634-17,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 39 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:45:02 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#5 > C10 to C12 Aliphatics

R.T.: 11.972 min Delta R.T.: 0.000 min Response: 6956599866 Conc: 5572.27 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.680 min
Delta R.T.: 0.000 min
Response: 7882540532
Conc: 6313.95 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.281 min
Delta R.T.: 0.000 min
Response: 57722154
Conc: 46.24 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.785 min
Delta R.T.: 0.000 min
Response: 23221356
Conc: 18.60 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172280.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 23:00 pm

Operator: FID17:WR Sample: L2240634-20,42,,

Misc : WG1676467,WG1676456,ICAL18753

ALS Vial: 40 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:53:55 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.250 61578399 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.005 48822991 47.966 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 95.93%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.069 3516785025 3031.310 ug/mLm 5) h > C10 to C12 Aliphatics 11.972 4186414087 3608.500 ug/mlm 6) h > C12 to C16 Aliphatics 16.680 5446394917 4694.547 UG/MLm 7) h > C16 to C21 Aliphatics 28.281 483664196 416.897 UG/MLm 8) h > C21 to C32 Aliphatics 32.785 26062216 22.464 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172280.D Signal(s): FID1A.CH

Acq On : 19 Aug 2022 23:00 pm

Operator: FID17:WR Sample: L2240634-20,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 40 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 17:53:55 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update : Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#5 > C10 to C12 Aliphatics

R.T.: 11.972 min Delta R.T.: 0.000 min Response: 4186414087 Conc: 3608.50 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.680 min
Delta R.T.: 0.000 min
Response: 5446394917
Conc: 4694.55 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.281 min Delta R.T.: 0.000 min Response: 483664196 Conc: 416.90 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.785 min Delta R.T.: 0.000 min Response: 26062216 Conc: 22.46 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172284.D Signal(s): FID1A.CH

Acq On : 20 Aug 2022 2:01 am

Operator: FID17:WR Sample: L2240634-26,42,,

Misc: : WG1676467, WG1676456, ICAL18753

ALS Vial: 42 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 18:04:39 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.261 82004497 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 35.017 67152910 49.541 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 99.08%

**Target Compounds** 

 4) h
 > C8 to C10 Aliphatics
 7.069
 32202572
 20.843 ug/mLm

 5) h
 > C10 to C12 Aliphatics
 11.972
 227632553
 147.336 ug/mlm

 6) h
 > C12 to C16 Aliphatics
 16.680
 817697244
 529.258 UG/MLm

 7) h
 > C16 to C21 Aliphatics
 28.281
 1095318580
 708.950 UG/MLm

 8) h
 > C21 to C32 Aliphatics
 32.785
 2940194047
 1903.055 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708172284.D Signal(s): FID1A.CH

Acq On : 20 Aug 2022 2:01 am

Operator: FID17:WR Sample: L2240634-26,42,,

Misc: WG1676467,WG1676456,ICAL18753

ALS Vial: 42 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 18:04:39 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







#5 > C10 to C12 Aliphatics

R.T.: 11.972 min Delta R.T.: 0.000 min Response: 227632553 Conc: 147.34 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.680 min Delta R.T.: 0.000 min Response: 817697244 Conc: 529.26 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.281 min
Delta R.T.: 0.000 min
Response: 1095318580
Conc: 708.95 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.785 min Delta R.T.: 0.000 min Response: 2940194047 Conc: 1903.05 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1709062244.D Signal(s): FID1A.CH

Acq On : 07 Sep 2022 22:05 pm

Operator: FID17:WR Sample: 12240634-33,42,,

Misc : WG1684077,WG1682989,ICAL18753

ALS Vial: 22 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 18:31:24 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units
----Internal Standards
1) I 5-alpha-androstane 30.077 60427121 50.000 ug/mLm

System Monitoring Compounds

3) s d50-Tetracosane 34.875 56293433 56.359 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 112.72%

**Target Compounds** 

4) h > C8 to C10 Aliphatics 7.042 11334302 9.956 ug/mLm 5) h > C10 to C12 Aliphatics 11.919 11462659 10.069 ug/mlm 6) h > C12 to C16 Aliphatics 16.606 24386921 21.421 UG/MLm 7) h > C16 to C21 Aliphatics 28.155 121462692 106.690 UG/MLm 8) h > C21 to C32 Aliphatics 32.639 8327772379 7314.925 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1709062244.D Signal(s): FID1A.CH

Acq On : 07 Sep 2022 22:05 pm

Operator: FID17:WR Sample: I2240634-33,42,,

Misc: WG1684077,WG1682989,ICAL18753

ALS Vial: 22 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 18:31:24 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







#5 > C10 to C12 Aliphatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 11462659 Conc: 10.07 ug/ml m

#6 > C12 to C16 Aliphatics

R.T.: 16.606 min Delta R.T.: 0.000 min Response: 24386921 Conc: 21.42 UG/ML m

#7 > C16 to C21 Aliphatics

R.T.: 28.155 min Delta R.T.: 0.000 min Response: 121462692 Conc: 106.69 UG/ML m

#8 > C21 to C32 Aliphatics

R.T.: 32.639 min
Delta R.T.: 0.000 min
Response: 8327772379
Conc: 7314.92 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242212.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 9:53 am

Operator: FID17:WR

Sample: WG1676458-1,42,,

Misc : WG1679263,WG1676458,ICAL18753

ALS Vial: 6 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 18:54:38 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH\

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.131 64228646 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.163 62124248 46.267 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 92.53%

Target Compounds

4) h	> C8 to C10 Aliphatics	7.043	6387733 5.279 ug/mLm
5) h	> C10 to C12 Aliphatics	11.928	8442061 6.976 ug/mlm
6) h	> C12 to C16 Aliphatics	16.619	21575818 17.830 ÚG/MLm
7) h	> C16 to C21 Aliphatics	28.177	22492390 18.587 UG/MLm
8) h	> C21 to C32 Aliphatics	32.664	57886459 47.837 UG/MLm
9) h	> C8 to C10 Aromatics	7.043	6301191 5.207 UG/MLm
10) h	> C10 to C12 Aromatics	11.928	8032661 6.638 UG/MLm
11) h	> C12 to C16 Aromatics	16.619	21433732 17.713 UG/MLm
12) h	> C16 to C21 Aromatics	28.177	22711550 18.769 UG/MLm
13) h	> C21 to C32 Aromatics	32.664	58236843 48.126 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242212.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 9:53 am

Operator: FID17:WR

Sample: WG1676458-1,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 6 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 18:54:38 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration


Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped











#13 > C21 to C32 Aromatics

R.T.: 32.664 min
Delta R.T.: 0.000 min
Response: 58236843
Conc: 48.13 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242224.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 19:02 pm

Operator: FID17:WR Sample: L2240634-03,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 12 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 20:49:02 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.122 68685134 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.156 65980584 45.951 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 91.90%

**Target Compounds** 

9) h > C8 to C10 Aromatics 7.038 1010230151 780.675 UG/MLm 10) h > C10 to C12 Aromatics 11.919 368352040 284.651 UG/MLm 11) h > C12 to C16 Aromatics 16.606 60241628 46.553 UG/MLm 12) h > C16 to C21 Aromatics 28.155 13343626 10.312 UG/MLm 13) h > C21 to C32 Aromatics 32.639 26472456 20.457 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window (m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242224.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 19:02 pm

Operator: FID17:WR Sample: L2240634-03,42,,

Misc : WG1679263,WG1676458,ICAL18753

ALS Vial: 12 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 20:49:02 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242226.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 20:32 pm

Operator: FID17:WR

Sample: WG1676458-4,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 13 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 20:59:55 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

System Monitoring Compounds

2) s ortho-terphenyl 28.158 70270710 45.189 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 90.38%

**Target Compounds** 

9) h > C8 to C10 Aromatics 7.038 1105087659 788.548 UG/MLm 10) h > C10 to C12 Aromatics 11.919 410311734 292.783 UG/MLm 11) h > C12 to C16 Aromatics 16.606 68801366 49.094 UG/MLm 12) h > C16 to C21 Aromatics 28.155 14710868 10.497 UG/MLm 13) h > C21 to C32 Aromatics 32.639 25715230 18.349 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242226.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 20:32 pm

Operator: FID17:WR

Sample: WG1676458-4,42,,

Misc: : WG1679263,WG1676458,ICAL18753

ALS Vial: 13 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 20:59:55 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







#10 > C10 to C12 Aromatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 410311734 Conc: 292.78 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min Delta R.T.: 0.000 min Response: 68801366 Conc: 49.09 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min
Delta R.T.: 0.000 min
Response: 14710868
Conc: 10.50 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min
Delta R.T.: 0.000 min
Response: 25715230
Conc: 18.35 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242228.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 22:03 pm

Operator: FID17:WR

Sample : L2240634-06,42,,

Misc : WG1679263,WG1676458,ICAL18753

ALS Vial: 14 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 21:04:57 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH\

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.124 70581674 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.156 66111087 44.805 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 89.61%

**Target Compounds** 

9) h > C8 to C10 Aromatics 7.038 858582569 645.659 UG/MLm 10) h > C10 to C12 Aromatics 11.919 301708080 226.886 UG/MLm 11) h > C12 to C16 Aromatics 16.606 49508773 37.231 UG/MLm 12) h > C16 to C21 Aromatics 28.155 12195381 9.171 UG/MLm 13) h > C21 to C32 Aromatics 32.639 26623554 20.021 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242228.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 22:03 pm

Operator: FID17:WR Sample: L2240634-06,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 14 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 21:04:57 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration


Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :



Page: 2





#10 > C10 to C12 Aromatics

R.T.: 11.919 min
Delta R.T.: 0.000 min
Response: 301708080
Conc: 226.89 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min
Delta R.T.: 0.000 min
Response: 49508773
Conc: 37.23 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min
Delta R.T.: 0.000 min
Response: 12195381
Conc: 9.17 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min
Delta R.T.: 0.000 min
Response: 26623554
Conc: 20.02 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242230.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 23:34 pm

Operator: FID17:WR Sample: L2240634-09,42,,

Misc: : WG1679263, WG1676458, ICAL18753

ALS Vial: 15 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 21:11:20 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.122 72636985 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.154 69326264 45.654 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 91.31%

Target Compounds

9) h > C8 to C10 Aromatics 7.038 1013690776 740.731 UG/MLm 10) h > C10 to C12 Aromatics 11.919 369937163 270.323 UG/MLm 11) h > C12 to C16 Aromatics 16.606 60609790 44.289 UG/MLm 12) h > C16 to C21 Aromatics 28.155 14743870 10.774 UG/MLm 13) h > C21 to C32 Aromatics 32.639 26522518 19.381 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242230.D Signal(s): FID1A.CH

Acq On : 25 Aug 2022 23:34 pm

Operator: FID17:WR Sample: L2240634-09,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 15 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 22 21:11:20 2022


Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped







#10 > C10 to C12 Aromatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 369937163 Conc: 270.32 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min Delta R.T.: 0.000 min Response: 60609790 Conc: 44.29 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min
Delta R.T.: 0.000 min
Response: 14743870
Conc: 10.77 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min Delta R.T.: 0.000 min Response: 26522518 Conc: 19.38 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242232.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 1:04 am

Operator: FID17:WR Sample: L2240634-12,42,,

Misc: : WG1679263, WG1676458, ICAL18753

ALS Vial: 16 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 27 13:27:44 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) | 5-alpha-androstane 30.133 75161742 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.166 74758755 47.578 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 95.16%

**Target Compounds** 

9) h > C8 to C10 Aromatics 7.038 104636851 73.893 UG/MLm 10) h > C10 to C12 Aromatics 11.919 481655372 340.136 UG/MLm 11) h > C12 to C16 Aromatics 16.606 1765221219 1246.566 UG/MLm 12) h > C16 to C21 Aromatics 28.155 1314202337 928.065 UG/MLm 13) h > C21 to C32 Aromatics 32.639 255262767 180.262 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242232.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 1:04 am

Operator: FID17:WR Sample: L2240634-12,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 16 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 27 13:27:44 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration


Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :



Page: 2





#10 > C10 to C12 Aromatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 481655372 Conc: 340.14 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min
Delta R.T.: 0.000 min
Response: 1765221219
Conc: 1246.57 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min Delta R.T.: 0.000 min Response: 1314202337 Conc: 928.06 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min Delta R.T.: 0.000 min Response: 255262767 Conc: 180.26 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242234.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 2:34 am

Operator: FID17:WR Sample : L2240634-15,42,,

Misc: WG1679263, WG1676458, ICAL18753

ALS Vial: 17 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 27 13:34:52 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj.: Signal Phase: Signal Info :

Compound R.T.

Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.133 72014007 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.163 61848218 41.082 ug/mLm

Spiked Amount 50,000 Range 50 - 130 Recovery = 82.16%

**Target Compounds** 

9) h > C8 to C10 Aromatics 7.038 10) h > C10 to C12 Aromatics 11.919 641781980 473.024 UG/MLm

341284260 251.543 UG/MLm

11) h > C12 to C16 Aromatics 16.606 1670378414 1231.150 UG/MLm

1143684784 842.951 UG/MLm

12) h > C16 to C21 Aromatics 28.155 13) h > C21 to C32 Aromatics 32.639

211111953 155.600 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242234.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 2:34 am

Operator: FID17:WR Sample: L2240634-15,42,,

Misc: : WG1679263,WG1676458,ICAL18753

ALS Vial: 17 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 27 13:34:52 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration


Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :



Page: 2





#10 > C10 to C12 Aromatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 641781980 Conc: 473.02 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min Delta R.T.: 0.000 min Response: 1670378414 Conc: 1231.15 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min
Delta R.T.: 0.000 min
Response: 1143684784
Conc: 842.95 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min Delta R.T.: 0.000 min Response: 211111953 Conc: 155.60 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242236.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 4:05 am

Operator: FID17:WR Sample : L2240634-18,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 18 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 15:49:40 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj.: Signal Phase: Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.121 60909812 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.160 71948260 56.503 ug/mLm

Spiked Amount 50.000 Range 50 - 130 Recovery = 113.01%

Target Compounds

9) h > C8 to C10 Aromatics 7.038 173518306 151.207 UG/MLm 10) h > C10 to C12 Aromatics 11.919 1281830918 1117.008 UG/MLm

11) h > C12 to C16 Aromatics 16.606 2078425171 1811.174 UG/MLm

12) h > C16 to C21 Aromatics 28.155 40151719 34.989 UG/MLm

13) h > C21 to C32 Aromatics 32.639

35406944 30.854 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242236.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 4:05 am

Operator: FID17:WR Sample: L2240634-18,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 18 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 15:49:40 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#### #10 > C10 to C12 Aromatics

R.T.: 11.919 min
Delta R.T.: 0.000 min
Response: 1281830918
Conc: 1117.01 UG/ML m

#### #11 > C12 to C16 Aromatics

R.T.: 16.606 min

Delta R.T.: 0.000 min

Response: 2078425171

Conc: 1811.17 UG/ML m

# #12 > C16 to C21 Aromatics

R.T.: 28.155 min
Delta R.T.: 0.000 min
Response: 40151719
Conc: 34.99 UG/ML m

#### #13 > C21 to C32 Aromatics

R.T.: 32.639 min
Delta R.T.: 0.000 min
Response: 35406944
Conc: 30.85 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242238.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 5:35 am

Operator: FID17:WR Sample : L2240634-21,42,,

Misc : WG1679263, WG1676458, ICAL18753

ALS Vial: 19 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 15:56:29 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase: Signal Info:

Compound R.T.

Response Conc Units

Internal Standards

1) I 5-alpha-androstane

30.122 67563072 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.155 63783057 45.158 ug/mLm

Spiked Amount 50.000 Range 50 - 130 Recovery = 90.32%

**Target Compounds** 

9) h > C8 to C10 Aromatics 10) h > C10 to C12 Aromatics 11.919

7.038

772399920 606.800 UG/MLm 996145040 782.575 UG/MLm

11) h > C12 to C16 Aromatics 16.606 1867860170 1467.398 UG/MLm

12) h > C16 to C21 Aromatics 28.155

148792599 116.892 UG/MLm

13) h > C21 to C32 Aromatics

32.639

26988282 21.202 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242238.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 5:35 am

Operator: FID17:WR Sample: L2240634-21,42,,

Misc : WG1679263,WG1676458,ICAL18753

ALS Vial: 19 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 15:56:29 2022

Quant Method : C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#10 > C10 to C12 Aromatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 996145040 Conc: 782.58 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min Delta R.T.: 0.000 min Response: 1867860170 Conc: 1467.40 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min

Delta R.T.: 0.000 min

Response: 148792599

Conc: 116.89 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min
Delta R.T.: 0.000 min
Response: 26988282
Conc: 21.20 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242240.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 7:05 am

Operator: FID17:WR Sample: L2240634-27,42,,

Misc: : WG1679263, WG1676458, ICAL18753

ALS Vial: 20 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:11:48 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Fri Sep 23 15:53:13 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.126 71294132 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.160 69721607 46.779 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 93.56%

**Target Compounds** 

9) h > C8 to C10 Aromatics 7.038 8607615 6.408 UG/MLm 10) h > C10 to C12 Aromatics 11.919 96151579 71.584 UG/MLm 11) h > C12 to C16 Aromatics 16.606 420653648 313.173 UG/MLm 12) h > C16 to C21 Aromatics 28.155 516620976 384.619 UG/MLm 13) h > C21 to C32 Aromatics 32.639 1191979219 887.417 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1708242240.D Signal(s): FID1A.CH

Acq On : 26 Aug 2022 7:05 am

Operator: FID17:WR Sample: L2240634-27,42,,

Misc: WG1679263,WG1676458,ICAL18753

ALS Vial: 20 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 23 16:11:48 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Fri Sep 23 15:53:13 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#10 > C10 to C12 Aromatics

R.T.: 11.919 min Delta R.T.: 0.000 min Response: 96151579 Conc: 71.58 UG/ML m

#11 > C12 to C16 Aromatics

R.T.: 16.606 min

Delta R.T.: 0.000 min

Response: 420653648

Conc: 313.17 UG/ML m

#12 > C16 to C21 Aromatics

R.T.: 28.155 min Delta R.T.: 0.000 min Response: 516620976 Conc: 384.62 UG/ML m

#13 > C21 to C32 Aromatics

R.T.: 32.639 min Delta R.T.: 0.000 min Response: 1191979219 Conc: 887.42 UG/ML m

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1709062240.D Signal(s): FID1A.CH

Acq On : 07 Sep 2022 19:05 pm

Operator: FID17:WR Sample: 12240634-34,42,,

Misc : WG1684077,WG1682993,ICAL18753

ALS Vial: 20 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 26 14:32:01 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH (

Quant Title: FID Forensics

QLast Update: Sun Oct 23 16:14:30 2022

Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase: Signal Info:

Compound R.T. Response Conc Units

Internal Standards

1) I 5-alpha-androstane 30.078 56950357 50.000 ug/mLm

System Monitoring Compounds

2) s ortho-terphenyl 28.115 61888011 51.982 ug/mLm Spiked Amount 50.000 Range 50 - 130 Recovery = 103.96%

**Target Compounds** 

7.028 27220310 25.369 UG/MLm 9) h > C8 to C10 Aromatics 10) h > C10 to C12 Aromatics 11.901 43832716 40.852 UG/MLm 60866518 56.728 UG/MLm 11) h > C12 to C16 Aromatics 16.582 82212863 76.622 UG/MLm 12) h > C16 to C21 Aromatics 28.115 13) h > C21 to C32 Aromatics 32.591 741457907 691.040 UG/MLm

SemiQuant Compounds - Not Calibrated on this Instrument

(f)=RT Delta > 1/2 Window

(m)=manual int.

Data Path: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\

Data File: f1709062240.D Signal(s): FID1A.CH

Acq On : 07 Sep 2022 19:05 pm

Operator: FID17:WR Sample: 12240634-34,42,,

Misc : WG1684077,WG1682993,ICAL18753

ALS Vial: 20 Sample Multiplier: 1

Integration File: autoint1.e

Quant Time: Oct 26 14:32:01 2022

Quant Method: C:\Projects\Hawaii DOH\2. Laboratory Data\Alpha\Carbon Range Study\L2240634\TPH\NF TPH\NF TPH


Quant Title: FID Forensics


QLast Update: Sun Oct 23 16:14:30 2022


Response via: Initial Calibration

Integrator: ChemStation 6890 Scale Mode: Large solvent peaks clipped

Volume Inj. : Signal Phase : Signal Info :







#### #10 > C10 to C12 Aromatics

R.T.: 11.901 min
Delta R.T.: 0.000 min
Response: 43832716
Conc: 40.85 UG/ML m

#### #11 > C12 to C16 Aromatics

R.T.: 16.582 min
Delta R.T.: 0.000 min
Response: 60866518
Conc: 56.73 UG/ML m

#### #12 > C16 to C21 Aromatics

R.T.: 28.115 min
Delta R.T.: 0.000 min
Response: 82212863
Conc: 76.62 UG/ML m

### #13 > C21 to C32 Aromatics

R.T.: 32.591 min Delta R.T.: 0.000 min Response: 741457907 Conc: 691.04 UG/ML m



#### ANALYTICAL REPORT

Lab Number: L2240634

Client: NewFields

300 Ledgewood Place

Suite 305

Rockland, MA 02370

ATTN: Eric Litman
Phone: (781) 681-5040

Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified Report Date: 09/08/22

The original project report/data package is held by Alpha Analytical. This report/data package is paginated and should be reproduced only in its entirety. Alpha Analytical holds no responsibility for results and/or data that are not consistent with the original.

Certifications & Approvals: MA (M-MA030), NH NELAP (2062), CT (PH-0141), DoD (L2474), FL (E87814), IL (200081), LA (85084), ME (MA00030), MD (350), NJ (MA015), NY (11627), NC (685), OH (CL106), PA (68-02089), RI (LAO00299), TX (T104704419), VT (VT-0015), VA (460194), WA (C954), US Army Corps of Engineers, USDA (Permit #P330-17-00150), USFWS (Permit #206964).

320 Forbes Boulevard, Mansfield, MA 02048-1806 508-822-9300 (Fax) 508-822-3288 800-624-9220 - www.alphalab.com



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

 Lab Number:
 L2240634

 Report Date:
 09/08/22

Alpha Sample ID	Client ID	Matrix	Sample Location	Collection Date/Time	Receive Date
L2240634-01	GASOLINE 87	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-02	GASOLINE 87 F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-03	GASOLINE 87 F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-04	GASOLINE 91	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-05	GASOLINE 91 F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-06	GASOLINE 91 F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-07	GASOLINE 93	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-08	GASOLINE 93 F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-09	GASOLINE 93 F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-10	HEATING FUEL	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-11	HEATING FUEL F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-12	HEATING FUEL F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-13	ROAD DIESEL	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-14	ROAD DIESEL F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-15	ROAD DIESEL F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-16	JP-5	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-17	JP-5 F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-18	JP-5 F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-19	JP-8	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-20	JP-8 F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-21	JP-8 F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-22	ASPHALT 1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-23	ASPHALT 1 F1	OIL	Not Specified	07/26/22 00:00	07/29/22
P. 2946694124	ASPHALT 1 F2	OIL	Not Specified	07/26/22 00:00	07/29/22



Alpha			Sample	Serial_No:( <b>Collection</b>	09082217:24
Sample ID	Client ID	Matrix	Location	Date/Time	Receive Date
L2240634-25	BUNKER C	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-26	BUNKER C F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-27	BUNKER C F2	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-28	JP-5 MEOH (0.5 MG/ML)	OIL	Not Specified	08/08/22 00:00	08/08/22
L2240634-29	JP-8 MEOH (0.5 MG/ML)	OIL	Not Specified	08/08/22 00:00	08/08/22
L2240634-30	JP-5 MEOH (20 MG/ML)	OIL	Not Specified	08/17/22 12:15	08/17/22
L2240634-31	JP-8 MEOH (20 MG/ML)	OIL	Not Specified	08/17/22 12:15	08/17/22
L2240634-32	WASTE OIL (AUTO)	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-33	WASTE OIL (AUTO) F1	OIL	Not Specified	07/26/22 00:00	07/29/22
L2240634-34	WASTE OIL (AUTO) F2	OIL	Not Specified	07/26/22 00:00	07/29/22



Project Name:HAWAII DOH - FINGERPRINTINGLab Number:L2240634Project Number:Not SpecifiedReport Date:09/08/22

#### **Case Narrative**

The samples were received in accordance with the Chain of Custody and no significant deviations were encountered during the preparation or analysis unless otherwise noted. Sample Receipt, Container Information, and the Chain of Custody are located at the back of the report.

Results contained within this report relate only to the samples submitted under this Alpha Lab Number and meet NELAP requirements for all NELAP accredited parameters unless otherwise noted in the following narrative. The data presented in this report is organized by parameter (i.e. VOC, SVOC, etc.). Sample specific Quality Control data (i.e. Surrogate Spike Recovery) is reported at the end of the target analyte list for each individual sample, followed by the Laboratory Batch Quality Control at the end of each parameter. Tentatively Identified Compounds (TICs), if requested, are reported for compounds identified to be present and are not part of the method/program Target Compound List, even if only a subset of the TCL are being reported. If a sample was re-analyzed or re-extracted due to a required quality control corrective action and if both sets of data are reported, the Laboratory ID of the re-analysis or re-extraction is designated with an "R" or "RE", respectively.

When multiple Batch Quality Control elements are reported (e.g. more than one LCS), the associated samples for each element are noted in the grey shaded header line of each data table. Any Laboratory Batch, Sample Specific % recovery or RPD value that is outside the listed Acceptance Criteria is bolded in the report. In reference to questions H (CAM) or 4 (RCP) when "NO" is checked, the performance criteria for CAM and RCP methods allow for some quality control failures to occur and still be within method compliance. In these instances, the specific failure is not narrated but noted in the associated QC Outlier Summary Report, located directly after the Case Narrative. QC information is also incorporated in the Data Usability Assessment table (Format 11) of our Data Merger tool, where it can be reviewed in conjunction with the sample result, associated regulatory criteria and any associated data usability implications.

Soil/sediments, solids and tissues are reported on a dry weight basis unless otherwise noted. Definitions of all data qualifiers and acronyms used in this report are provided in the Glossary located at the back of the report.

HOLD POLICY - For samples submitted on hold, Alpha's policy is to hold samples (with the exception of Air canisters) free of charge for 21 calendar days from the date the project is completed. After 21 calendar days, we will dispose of all samples submitted including those put on hold unless you have contacted your Alpha Project Manager and made arrangements for Alpha to continue to hold the samples. Air canisters will be disposed after 3 business days from the date the project is completed.

Please contact Project Management at 800-624-9220 with any questions.	



Project Name:HAWAII DOH - FINGERPRINTINGLab Number:L2240634Project Number:Not SpecifiedReport Date:09/08/22

#### Case Narrative (continued)

#### Report Submission

All non-detect (ND) or estimated concentrations (J-qualified) have been quantitated to the limit noted in the MDL column.

#### Volatile Organics

L2240634-01D, -04D, -07D, -10D, -13D, -25D, -30D, and -31D: The samples have elevated detection limits due to the dilution required by the elevated concentrations of target compounds in the samples.

L2240634-01D2, -04D2, -07D2, -13D2, -30D2, and -31D2: The samples were re-analyzed on dilution in order to quantitate the results within the calibration range. The result(s) should be considered estimated, and are qualified with an E flag, for any compound(s) that exceeded the calibration range in the initial analysis. The re-analysis was performed only for the compound(s) that exceeded the calibration range.

The WG1671854-6 Method Blank, associated with L2240634-01D2, -01D, -04D2, -04D, -07D2, -07D, -10D, -13D2, -22, and -25D, has concentrations below the reporting limits and "J" qualified. Associated field sample results are "B" qualified if the concentrations are less than 10x the concentrations in the blank. The WG1677380-6 Method Blank, associated with L2240634-30D2, -30D, -31D2, -31D, and -32, has concentrations below the reporting limits and "J" qualified. Associated field sample results are "B" qualified if the concentrations in the blank.

#### Petroleum Hydrocarbon Quantitation

The WG1676458-1 Method Blank, associated with L2240634-03, -06, -09, -12, -15, -18, -21, and -27, has a concentration above the reporting limit for TPH (C9-C44). Associated field sample results are "B" qualified if the concentrations are less than 10x the concentration in the blank.

#### VPH

L2240634-01D, -04D, -07D, -10D, -13D, -25D, -30D, -31D, and -32D: The sample has elevated detection limits due to the dilution required by the elevated concentrations of target compounds in the sample. L2240634-01D, -04D, -07D, -10D, and -13D: The surrogate recoveries are below the acceptance criteria for



Project Name:HAWAII DOH - FINGERPRINTINGLab Number:L2240634Project Number:Not SpecifiedReport Date:09/08/22

#### **Case Narrative (continued)**

2,5-dibromotoluene-pid (0%) and 2,5-dibromotoluene-fid (0%) due to the dilution required to quantitate the sample. Re-extraction was not required; therefore, the results of the original analysis are reported.

L2240634-25D: The surrogate recoveries are outside the acceptance criteria for 2,5-dibromotoluene-pid (0%) and 2,5-dibromotoluene-fid (0%); however, the sample was not re-analyzed due to coelution with an unresolved complex mixture (UCM). A copy of the chromatogram is included as an attachment to this report. The results are not considered to be biased.

L2240634-32D: The surrogate recovery is outside the acceptance criteria for 2,5-dibromotoluene-fid (14%); however, the sample was not re-analyzed due to coelution with an obvious interference. A copy of the chromatogram is included as an attachment to this report.

WG1684889-6: The sample has elevated detection limits due to the dilution required by the elevated concentrations of target compounds in the sample.

WG1684889-6: The surrogate recoveries are below the acceptance criteria for 2,5-dibromotoluene-pid (0%) and 2,5-dibromotoluene-fid (0%) due to the dilution required to quantitate the sample. Re-extraction was not required; therefore, the results of the original analysis are reported.

I, the undersigned, attest under the pains and penalties of perjury that, to the best of my knowledge and belief and based upon my personal inquiry of those responsible for providing the information contained in this analytical report, such information is accurate and complete. This certificate of analysis is not complete unless this page accompanies any and all pages of this report.

Authorized Signature:

Luxen & Med Susan O' Neil

Title: Technical Director/Representative Date: 09/08/22



# **ORGANICS**



# **VOLATILES**



09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-01 D2 Date Collected: 07/26/22 00:00

Client ID: GASOLINE 87 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/04/22 02:47

Analyst: RY

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
PIANO Volatile Organics by GC/MS - Mansfield Lab								
Isopentane	37900		mg/kg	1890	703.	200		
Pentane	30300		mg/kg	1890	588.	200		
2-Methylpentane	26800		mg/kg	1890	607.	200		
3-Methylpentane	17800		mg/kg	1890	366.	200		
n-Hexane	26700		mg/kg	1890	550.	200		
Methylcyclopentane	18800		mg/kg	1890	573.	200		
Cyclohexane	12700		mg/kg	1890	544.	200		
2-Methylhexane	14500		mg/kg	1890	440.	200		
3-Methylhexane	14800		mg/kg	1890	496.	200		
Isooctane	14900		mg/kg	1890	441.	200		
Heptane	18700		mg/kg	1890	518.	200		
Methylcyclohexane	14300		mg/kg	1890	402.	200		
Toluene	50200		mg/kg	1890	273.	200		
Ethylbenzene	11800		mg/kg	1890	204.	200		
p/m-Xylene	46400		mg/kg	3770	531.	200		
o-Xylene	16800		mg/kg	1890	290.	200		
1-Methyl-3-Ethylbenzene	11900		mg/kg	1890	302.	200		
1,2,4-Trimethylbenzene	19200		mg/kg	1890	413.	200		

Surrogate	% Recovery	Acceptance Qualifier Criteria	
Dibromofluoromethane	124	70-130	
Toluene-d8	112	70-130	
4-Bromofluorobenzene	96	70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-01 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 87 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M) Analytical Date: 08/03/22 22:03

Analyst: RY

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Superstane   S8500   E   mg/kg   94	.3 29.2	10
1-Pentene         2220         mg/kg         94           2-Methyl-1-Butene         5550         mg/kg         94           Pentane         43500         E         mg/kg         94           trans-2-Pentene         6310         mg/kg         94           cis-2-Pentene         3660         mg/kg         94           Tertiary Butanol         ND         mg/kg         11           Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methyl pentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           1-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 29.2	
1-Pentene         2220         mg/kg         94           2-Methyl-1-Butene         5550         mg/kg         94           Pentane         43500         E         mg/kg         94           trans-2-Pentene         6310         mg/kg         94           cis-2-Pentene         3660         mg/kg         94           Tertiary Butanol         ND         mg/kg         11           Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methyl pentane         35800         E         mg/kg         94           3-Methyl tert butyl ether         ND         mg/kg         94           1-Hexene         820         mg/kg         94           1-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94		
Pentane         43500         E         mg/kg         94           trans-2-Pentene         6310         mg/kg         94           cis-2-Pentene         3660         mg/kg         94           Tertiary Butanol         ND         mg/kg         11           Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           1-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	0.1.0	10
Pentane         43500         E         mg/kg         94           trans-2-Pentene         6310         mg/kg         94           cis-2-Pentene         3660         mg/kg         94           Tertiary Butanol         ND         mg/kg         11           Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           1-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 31.0	10
cis-2-Pentene         3660         mg/kg         94           Tertiary Butanol         ND         mg/kg         11           Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 29.4	10
Tertiary Butanol         ND         mg/kg         11           Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 33.2	10
Cyclopentane         4880         mg/kg         94           2,3-Dimethylbutane         7760         mg/kg         94           2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 24.7	10
2,3-Dimethylbutane         7760         mg/kg         94           2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           n-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	80 382.	10
2-Methylpentane         35800         E         mg/kg         94           Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           n-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 24.5	10
Methyl tert butyl ether         ND         mg/kg         94           3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           n-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 38.9	10
3-Methylpentane         22700         E         mg/kg         94           1-Hexene         820         mg/kg         94           n-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 30.4	10
1-Hexene         820         mg/kg         94           n-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 29.4	10
n-Hexane         33300         E         mg/kg         94           Isopropyl Ether         ND         mg/kg         94	.3 18.3	10
Isopropyl Ether ND mg/kg 94	.3 27.1	10
1.15	.3 27.5	10
Ethyl-Tert-Butyl-Ether ND mg/kg 94	.3 25.9	10
, ,	.3 24.6	10
2,2-Dimethylpentane 1230 mg/kg 94	.3 24.4	10
Methylcyclopentane 22200 E mg/kg 94	.3 28.7	10
2,4-Dimethylpentane 4700 mg/kg 94	.3 24.8	10
1,2-Dichloroethane ND mg/kg 94	.3 28.6	10
Cyclohexane 14600 E mg/kg 94	.3 27.2	10
2-Methylhexane 16200 E mg/kg 94	.3 22.0	10
Benzene 9120 mg/kg 94	.3 20.4	10
2,3-Dimethylpentane 7000 mg/kg 94	.3 23.9	10
Thiophene ND mg/kg 94	.3 24.5	10
3-Methylhexane 15900 E mg/kg 94	.3 24.8	10
Tertiary-Amyl Methyl Ether ND mg/kg 94	.3 25.0	10
1-Heptene/1,2-DMCP (trans) 8560 mg/kg 18	39 57.8	10



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-01 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 87 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS -	Mansfield Lab					
logostono	15100	E		94.3	22.0	10
Isooctane Heptane	19000	E	mg/kg	94.3	25.9	10
Methylcyclohexane	14900	E	mg/kg	94.3	20.1	10
	3420	E	mg/kg	94.3	22.6	
2,5-Dimethylhexane			mg/kg			10
2,4-Dimethylhexane	3390		mg/kg	94.3	22.3	10
2,2,3-Trimethylpentane	1010		mg/kg	94.3	23.6	10
2,3,4-Trimethylpentane	7030		mg/kg	94.3	21.6	10
2,3,3-Trimethylpentane	7790		mg/kg	94.3	20.6	10
2,3-Dimethylhexane	2140		mg/kg	94.3	22.8	10
2-Methylheptane	8310		mg/kg	94.3	21.8	10
3-Methylheptane	6270		mg/kg	94.3	28.3	10
3-Ethylhexane	1610		mg/kg	94.3	24.1	10
Toluene	54500	E	mg/kg	94.3	13.6	10
2-Methylthiophene	ND		mg/kg	94.3	14.0	10
3-Methylthiophene	ND		mg/kg	94.3	14.5	10
1-Octene	ND		mg/kg	236	14.4	10
Octane	9010		mg/kg	94.3	20.0	10
1,2-Dibromoethane	ND		mg/kg	94.3	15.1	10
Ethylbenzene	12400	E	mg/kg	94.3	10.2	10
2-Ethylthiophene	ND		mg/kg	94.3	10.3	10
p/m-Xylene	47000	Е	mg/kg	189	26.5	10
1-Nonene	ND		mg/kg	236	9.77	10
Nonane (C9)	3940		mg/kg	94.3	20.6	10
Styrene	16.2	J	mg/kg	94.3	13.1	10
o-Xylene	17600	E	mg/kg	94.3	14.5	10
Isopropylbenzene	1000		mg/kg	94.3	15.8	10
n-Propylbenzene	3720		mg/kg	94.3	17.8	10
1-Methyl-3-Ethylbenzene	11200	E	mg/kg	94.3	15.1	10
1-Methyl-4-Ethylbenzene	5210		mg/kg	94.3	17.2	10
1,3,5-Trimethylbenzene	5520		mg/kg	94.3	17.9	10
1-Decene	ND		mg/kg	94.3	13.1	10
1-Methyl-2-Ethylbenzene	4020		mg/kg	94.3	19.3	10
Decane (C10)	2190		mg/kg	94.3	14.4	10
1,2,4-Trimethylbenzene	17900	E	mg/kg	94.3	20.6	10
sec-Butylbenzene	338		mg/kg	94.3	19.1	10
1-Methyl-3-Isopropylbenzene	536		mg/kg	94.3	17.7	10
1-Methyl-4-Isopropylbenzene	179		mg/kg	94.3	21.6	10
71 -17	•••		9''\9			<u> </u>



09/08/22

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

L2240634-01

**GASOLINE 87** 

Not Specified

D

**SAMPLE RESULTS** 

Date Collected: 07/26/22 00:00

Date Received: 07/29/22

Report Date:

Field Prep: Not Specified

Sample Depth:

Sample Location:

Lab ID:

Client ID:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC/MS - Mansfield Lab							
1-Methyl-2-Isopropylbenzene	38.6	J	mg/kg	94.3	25.9	10	
Indane	1870		mg/kg	94.3	21.8	10	
1-Methyl-3-N-Propylbenzene	2200		mg/kg	94.3	20.8	10	
1-Methyl-4-N-Propylbenzene	1040		mg/kg	94.3	22.1	10	
n-Butylbenzene	717		mg/kg	94.3	23.6	10	
1,2-Dimethyl-4-Ethylbenzene	2190		mg/kg	94.3	22.9	10	
1,2-Diethylbenzene	158		mg/kg	94.3	21.8	10	
1-Methyl-2-N-Propylbenzene	779		mg/kg	94.3	19.2	10	
1,4-Dimethyl-2-Ethylbenzene	1550		mg/kg	94.3	21.0	10	
Undecane	758		mg/kg	94.3	33.3	10	
1,3-Dimethyl-4-Ethylbenzene	1300		mg/kg	94.3	20.2	10	
1,3-Dimethyl-5-Ethylbenzene	2430		mg/kg	94.3	22.9	10	
1,3-Dimethyl-2-Ethylbenzene	166		mg/kg	94.3	22.4	10	
1,2-Dimethyl-3-Ethylbenzene	511		mg/kg	94.3	20.5	10	
1,2,4,5-Tetramethylbenzene	1220		mg/kg	94.3	21.3	10	
N-Pentylbenzene	91.9	J	mg/kg	94.3	18.7	10	
Dodecane (C12)	341		mg/kg	236	41.4	10	
Naphthalene	1850		mg/kg	94.3	39.3	10	
Benzothiophene	ND		mg/kg	94.3	49.8	10	
MMT	ND		mg/kg	236	60.6	10	
Tridecane	181	J	mg/kg	236	61.1	10	
2-Methylnaphthalene	1040		mg/kg	236	62.3	10	
1-Methylnaphthalene	488		mg/kg	236	69.2	10	

Surrogate	% Recovery	Acceptance Qualifier Criteria	
Dibromofluoromethane	127	70-130	
Toluene-d8	115	70-130	
4-Bromofluorobenzene	92	70-130	



09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-04 D2 Date Collected: 07/26/22 00:00

Client ID: GASOLINE 91 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/04/22 05:09

Analyst: RY

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor			
PIANO Volatile Organics by GC/	PIANO Volatile Organics by GC/MS - Mansfield Lab								
Isopentane	49400		mg/kg	1960	732.	200			
Pentane	36900		mg/kg	1960	612.	200			
2-Methylpentane	29300		mg/kg	1960	632.	200			
3-Methylpentane	18700		mg/kg	1960	381.	200			
n-Hexane	27500		mg/kg	1960	572.	200			
Methylcyclopentane	19400		mg/kg	1960	597.	200			
Cyclohexane	12600		mg/kg	1960	567.	200			
2-Methylhexane	14200		mg/kg	1960	458.	200			
3-Methylhexane	14200		mg/kg	1960	517.	200			
Isooctane	14400		mg/kg	1960	459.	200			
Heptane	17800		mg/kg	1960	539.	200			
Methylcyclohexane	13600		mg/kg	1960	418.	200			
Toluene	47600		mg/kg	1960	284.	200			
Ethylbenzene	10600		mg/kg	1960	212.	200			
p/m-Xylene	42100		mg/kg	3930	553.	200			
o-Xylene	15000		mg/kg	1960	302.	200			
1-Methyl-3-Ethylbenzene	10300		mg/kg	1960	315.	200			
1,2,4-Trimethylbenzene	16700		mg/kg	1960	430.	200			

Surrogate	% Recovery	Acceptance Qualifier Criteria	
Dibromofluoromethane	121	70-130	
Toluene-d8	112	70-130	
4-Bromofluorobenzene	96	70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-04 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 91 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M) Analytical Date: 08/04/22 00:25

Analyst: RY

Percent Solids: Results reported on an 'AS RECEIVED' basis.

1-Pentene	Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
1-Pentene   2120	PIANO Volatile Organics by GC/MS	S - Mansfield Lab					
2-Methyl-1-Butene         5360         mg/kg         98.2         32.3         10           Pentane         40600         E         mg/kg         98.2         30.6         10           trans-2-Pentene         6050         mg/kg         98.2         34.6         10           cis-2-Pentene         3320         mg/kg         98.2         25.7         10           Tertiary Butanol         ND         mg/kg         98.2         25.5         10           Cyclopentane         4660         mg/kg         98.2         25.5         10           2-Joinethylbutane         6950         mg/kg         98.2         31.6         10           2-Methylpentane         31700         E         mg/kg         98.2         31.6         10           2-Methylpentane         23000         E         mg/kg         98.2         28.2         10           1-Hexane         681         mg/kg         98.2         28.6         10           1-Hexane         681         mg/kg         98.2         28.6         10           1-Hexane         180         mg/kg         98.2         28.6         10           Ebryl-Tert-Butyl-Ether         ND         mg/kg	Isopentane	56800	E	mg/kg	98.2	36.6	10
Pentane         40600         E         mg/kg         88.2         30.6         10           trans-2-Pentene         6050         mg/kg         98.2         34.6         10           cis-2-Pentene         3320         mg/kg         98.2         25.7         10           Tertiary Butanol         ND         mg/kg         98.2         25.5         10           Cyclopentane         4660         mg/kg         98.2         25.5         10           23-Dimethylbutane         6950         mg/kg         98.2         31.6         10           2-Methylpentane         31700         E         mg/kg         98.2         31.6         10           3-Methyl tert butyl ether         ND         mg/kg         98.2         30.6         10           3-Methylpentane         20300         E         mg/kg         98.2         28.2         10           1-Hexane         681         mg/kg         98.2         28.6         10           1-Hexane         70         mg/kg         98.2         28.6         10           1-Hexane         10         mg/kg         98.2         27.0         10           1-Hexane         ND         mg/kg	1-Pentene	2120		mg/kg	98.2	30.4	10
trans-2-Pentene         6050         mg/kg         98.2         34.6         10           cis-2-Pentene         3320         mg/kg         98.2         25.7         10           Tertiary Butanol         ND         mg/kg         1230         398.         10           Cyclopentane         4660         mg/kg         98.2         25.5         10           2.3-Dimethylbutane         6950         mg/kg         98.2         40.5         10           2-Methylpentane         31700         E         mg/kg         98.2         31.6         10           Methyl tert butyl ether         ND         mg/kg         98.2         30.6         10           3-Methylpentane         20300         E         mg/kg         98.2         30.6         10           1-Hexane         681         mg/kg         98.2         28.2         10           1-Hexane         29900         E         mg/kg         98.2         22.2         10           1-Hexane         29900         E         mg/kg         98.2         25.6         10           1-Stopptyl Ether         ND         mg/kg         98.2         25.6         10           2,2-Dimethylpentane	2-Methyl-1-Butene	5360		mg/kg	98.2	32.3	10
Section   Sect	Pentane	40600	E	mg/kg	98.2	30.6	10
Tertiary Butanol         ND         mg/kg         1230         398.         10           Cyclopentane         4660         mg/kg         98.2         25.5         10           2,3-Dimethylbutane         6950         mg/kg         98.2         40.5         10           2-Methylpentane         31700         E         mg/kg         98.2         31.6         10           Methyl tert butyl ether         ND         mg/kg         98.2         30.6         10           3-Methylpentane         20300         E         mg/kg         98.2         28.2         10           1-Hexene         681         mg/kg         98.2         28.2         10           n-Hexane         29900         E         mg/kg         98.2         28.6         10           Isopropyl Ether         ND         mg/kg         98.2         27.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         98.2         25.6         10           2,2-Dimethylpentane         1120         mg/kg         98.2         25.4         10           Methylocyclopentane         4470         mg/kg         98.2         25.8         10           1,2-Dichloroethane	trans-2-Pentene	6050		mg/kg	98.2	34.6	10
Cyclopentane         4660         mg/kg         98.2         25.5         10           2,3-Dimethylbutane         6950         mg/kg         98.2         40.5         10           2-Methylpentane         31700         E         mg/kg         98.2         31.6         10           Methyl tert butyl ether         ND         mg/kg         98.2         30.6         10           3-Methylpentane         20300         E         mg/kg         98.2         19.0         10           1-Hexene         681         mg/kg         98.2         28.2         10           n-Hexane         29900         E         mg/kg         98.2         28.6         10           Isopropyl Ether         ND         mg/kg         98.2         28.6         10           Isopropyl Ether         ND         mg/kg         98.2         25.6         10           2,2-Dimethylpentane         1120         mg/kg         98.2         25.6         10           2,2-Dimethylpentane         4470         mg/kg         98.2         25.8         10           Methylcyclopentane         4470         mg/kg         98.2         25.8         10           1,2-Dichloroethane         <	cis-2-Pentene	3320		mg/kg	98.2	25.7	10
2,3-Dimethylbutane 6950 mg/kg 98.2 40.5 10  2-Methylpentane 31700 E mg/kg 98.2 31.6 10  Methyl tert butyl ether ND mg/kg 98.2 30.6 10  3-Methylpentane 20300 E mg/kg 98.2 19.0 10  1-Hexane 681 mg/kg 98.2 28.2 10  n-Hexane 29900 E mg/kg 98.2 28.6 10  Isopropyl Ether ND mg/kg 98.2 27.0 10  Ethyl-Tert-Butyl-Ether ND mg/kg 98.2 25.6 10  2,2-Dimethylpentane 1120 mg/kg 98.2 25.4 10  Methylcyclopentane 20300 E mg/kg 98.2 25.4 10  Methylcyclopentane 1120 mg/kg 98.2 25.4 10  Methylcyclopentane 4470 mg/kg 98.2 25.8 10  1,2-Dichloroethane ND mg/kg 98.2 25.8 10  Cyclohexane 14500 E mg/kg 98.2 29.7 10  Cyclohexane 16200 E mg/kg 98.2 22.9 10  Benzene 8770 mg/kg 98.2 21.3 10  Ethyl-Tert-Butyl-Ether 16200 E mg/kg 98.2 22.9 10  Benzene 8770 mg/kg 98.2 24.9 10  Thiophene 21.2 J mg/kg 98.2 25.5 10  3-Methylpexane 16100 E mg/kg 98.2 25.8 10  Tertiary-Amyl Methyl Ether ND mg/kg 98.2 25.8 10	Tertiary Butanol	ND		mg/kg	1230	398.	10
2-Methylpentane         31700         E         mg/kg         98.2         31.6         10           Methyl tert butyl ether         ND         mg/kg         98.2         30.6         10           3-Methylpentane         20300         E         mg/kg         98.2         19.0         10           1-Hexene         681         mg/kg         98.2         28.2         10           n-Hexane         29900         E         mg/kg         98.2         28.6         10           Isopropyl Ether         ND         mg/kg         98.2         27.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         98.2         25.6         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         98.2         25.6         10           2,2-Dimethylpentane         1120         mg/kg         98.2         25.4         10           Methylcyclopentane         20300         E         mg/kg         98.2         25.8         10           2,4-Dimethylpentane         4470         mg/kg         98.2         25.8         10           Cyclohexane         14500         E         mg/kg         98.2         28.4         10 <t< td=""><td>Cyclopentane</td><td>4660</td><td></td><td>mg/kg</td><td>98.2</td><td>25.5</td><td>10</td></t<>	Cyclopentane	4660		mg/kg	98.2	25.5	10
Methyl tert butyl ether         ND         mg/kg         98.2         30.6         10           3-Methylpentane         20300         E         mg/kg         98.2         19.0         10           1-Hexene         681         mg/kg         98.2         28.2         10           n-Hexane         29900         E         mg/kg         98.2         28.6         10           stopropyl Ether         ND         mg/kg         98.2         27.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         98.2         25.6         10           2,2-Dimethylpentane         1120         mg/kg         98.2         25.6         10           Methylcyclopentane         20300         E         mg/kg         98.2         25.8         10           Methylpentane         4470         mg/kg         98.2         25.8         10           1,2-Dichloroethane         ND         mg/kg         98.2         29.7         10           Cyclohexane         14500         E         mg/kg         98.2         28.4         10           2-Methylhexane         16200         E         mg/kg         98.2         21.3         10	2,3-Dimethylbutane	6950		mg/kg	98.2	40.5	10
3-Methylpentane         20300         E         mg/kg         98.2         19.0         10           1-Hexene         681         mg/kg         98.2         28.2         10           n-Hexane         29900         E         mg/kg         98.2         28.6         10           Isopropyl Ether         ND         mg/kg         98.2         27.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         98.2         25.6         10           2,2-Dimethylpentane         1120         mg/kg         98.2         25.4         10           Methylcyclopentane         20300         E         mg/kg         98.2         29.8         10           2,4-Dimethylpentane         4470         mg/kg         98.2         25.8         10           1,2-Dichloroethane         ND         mg/kg         98.2         29.7         10           Cyclohexane         14500         E         mg/kg         98.2         28.4         10           2-Methylhexane         16200         E         mg/kg         98.2         22.9         10           Benzene         8770         mg/kg         98.2         24.9         10           2,3-	2-Methylpentane	31700	Е	mg/kg	98.2	31.6	10
1-Hexene 681 mg/kg 98.2 28.6 10 n-Hexane 29900 E mg/kg 98.2 28.6 10 Isopropyl Ether ND mg/kg 98.2 27.0 10 Ethyl-Tert-Butyl-Ether ND mg/kg 98.2 25.6 10 2,2-Dimethylpentane 1120 mg/kg 98.2 25.4 10 Methylcyclopentane 20300 E mg/kg 98.2 25.4 10 2,4-Dimethylpentane 4470 mg/kg 98.2 25.8 10 1,2-Dichloroethane ND mg/kg 98.2 25.8 10 1,2-Dichloroethane ND mg/kg 98.2 29.7 10 Cyclohexane 14500 E mg/kg 98.2 29.7 10 Cyclohexane 16200 E mg/kg 98.2 22.9 10 Benzene 8770 mg/kg 98.2 22.9 10 Benzene 8770 mg/kg 98.2 21.3 10 2,3-Dimethylpentane 6240 mg/kg 98.2 24.9 10 Thiophene 21.2 J mg/kg 98.2 25.5 10 3-Methylhexane 16100 E mg/kg 98.2 25.8 10 Tertiary-Amyl Methyl Ether ND mg/kg 98.2 25.8 10	Methyl tert butyl ether	ND		mg/kg	98.2	30.6	10
ND   mg/kg   98.2   28.6   10	3-Methylpentane	20300	E	mg/kg	98.2	19.0	10
Sopropy  Ether	1-Hexene	681		mg/kg	98.2	28.2	10
Ethyl-Tert-Butyl-Ether	n-Hexane	29900	Е	mg/kg	98.2	28.6	10
2,2-Dimethylpentane       1120       mg/kg       98.2       25.4       10         Methylcyclopentane       20300       E       mg/kg       98.2       29.8       10         2,4-Dimethylpentane       4470       mg/kg       98.2       25.8       10         1,2-Dichloroethane       ND       mg/kg       98.2       29.7       10         Cyclohexane       14500       E       mg/kg       98.2       28.4       10         2-Methylhexane       16200       E       mg/kg       98.2       22.9       10         Benzene       8770       mg/kg       98.2       21.3       10         2,3-Dimethylpentane       6240       mg/kg       98.2       24.9       10         Thiophene       21.2       J       mg/kg       98.2       25.5       10         3-Methylhexane       16100       E       mg/kg       98.2       25.8       10         Tertiary-Amyl Methyl Ether       ND       mg/kg       98.2       26.0       10	Isopropyl Ether	ND		mg/kg	98.2	27.0	10
Methylcyclopentane       20300       E       mg/kg       98.2       29.8       10         2,4-Dimethylpentane       4470       mg/kg       98.2       25.8       10         1,2-Dichloroethane       ND       mg/kg       98.2       29.7       10         Cyclohexane       14500       E       mg/kg       98.2       28.4       10         2-Methylhexane       16200       E       mg/kg       98.2       22.9       10         Benzene       8770       mg/kg       98.2       21.3       10         2,3-Dimethylpentane       6240       mg/kg       98.2       24.9       10         Thiophene       21.2       J       mg/kg       98.2       25.5       10         3-Methylhexane       16100       E       mg/kg       98.2       25.8       10         Tertiary-Amyl Methyl Ether       ND       mg/kg       98.2       26.0       10	Ethyl-Tert-Butyl-Ether	ND		mg/kg	98.2	25.6	10
2,4-Dimethylpentane 4470 mg/kg 98.2 25.8 10  1,2-Dichloroethane ND mg/kg 98.2 29.7 10  Cyclohexane 14500 E mg/kg 98.2 28.4 10  2-Methylhexane 16200 E mg/kg 98.2 22.9 10  Benzene 8770 mg/kg 98.2 21.3 10  2,3-Dimethylpentane 6240 mg/kg 98.2 24.9 10  Thiophene 21.2 J mg/kg 98.2 25.5 10  3-Methylhexane 16100 E mg/kg 98.2 25.8 10  Tertiary-Amyl Methyl Ether ND mg/kg 98.2 26.0 10	2,2-Dimethylpentane	1120		mg/kg	98.2	25.4	10
1,2-Dichloroethane         ND         mg/kg         98.2         29.7         10           Cyclohexane         14500         E         mg/kg         98.2         28.4         10           2-Methylhexane         16200         E         mg/kg         98.2         22.9         10           Benzene         8770         mg/kg         98.2         21.3         10           2,3-Dimethylpentane         6240         mg/kg         98.2         24.9         10           Thiophene         21.2         J         mg/kg         98.2         25.5         10           3-Methylhexane         16100         E         mg/kg         98.2         25.8         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         98.2         26.0         10	Methylcyclopentane	20300	Е	mg/kg	98.2	29.8	10
Cyclohexane         14500         E         mg/kg         98.2         28.4         10           2-Methylhexane         16200         E         mg/kg         98.2         22.9         10           Benzene         8770         mg/kg         98.2         21.3         10           2,3-Dimethylpentane         6240         mg/kg         98.2         24.9         10           Thiophene         21.2         J         mg/kg         98.2         25.5         10           3-Methylhexane         16100         E         mg/kg         98.2         25.8         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         98.2         26.0         10	2,4-Dimethylpentane	4470		mg/kg	98.2	25.8	10
2-Methylhexane 16200 E mg/kg 98.2 22.9 10  Benzene 8770 mg/kg 98.2 21.3 10  2,3-Dimethylpentane 6240 mg/kg 98.2 24.9 10  Thiophene 21.2 J mg/kg 98.2 25.5 10  3-Methylhexane 16100 E mg/kg 98.2 25.8 10  Tertiary-Amyl Methyl Ether ND mg/kg 98.2 26.0 10	1,2-Dichloroethane	ND		mg/kg	98.2	29.7	10
Benzene         8770         mg/kg         98.2         21.3         10           2,3-Dimethylpentane         6240         mg/kg         98.2         24.9         10           Thiophene         21.2         J         mg/kg         98.2         25.5         10           3-Methylhexane         16100         E         mg/kg         98.2         25.8         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         98.2         26.0         10	Cyclohexane	14500	Е	mg/kg	98.2	28.4	10
2,3-Dimethylpentane       6240       mg/kg       98.2       24.9       10         Thiophene       21.2       J       mg/kg       98.2       25.5       10         3-Methylhexane       16100       E       mg/kg       98.2       25.8       10         Tertiary-Amyl Methyl Ether       ND       mg/kg       98.2       26.0       10	2-Methylhexane	16200	E	mg/kg	98.2	22.9	10
Thiophene         21.2         J         mg/kg         98.2         25.5         10           3-Methylhexane         16100         E         mg/kg         98.2         25.8         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         98.2         26.0         10	Benzene	8770		mg/kg	98.2	21.3	10
3-Methylhexane 16100 E mg/kg 98.2 25.8 10  Tertiary-Amyl Methyl Ether ND mg/kg 98.2 26.0 10	2,3-Dimethylpentane	6240		mg/kg	98.2	24.9	10
Tertiary-Amyl Methyl Ether ND mg/kg 98.2 26.0 10	Thiophene	21.2	J	mg/kg	98.2	25.5	10
	3-Methylhexane	16100	Е	mg/kg	98.2	25.8	10
1-Heptene/1,2-DMCP (trans) 7960 mg/kg 196 60.2 10	Tertiary-Amyl Methyl Ether	ND		mg/kg	98.2	26.0	10
	1-Heptene/1,2-DMCP (trans)	7960		mg/kg	196	60.2	10



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-04 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 91 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC/MS - Mansfield Lab							
Isooctane	15800	E	mg/kg	98.2	23.0	10	
Heptane	20100	E	mg/kg	98.2	27.0	10	
Methylcyclohexane	16600	E	mg/kg	98.2	20.9	10	
2,5-Dimethylhexane	3670		mg/kg	98.2	23.5	10	
2,4-Dimethylhexane	3770		mg/kg	98.2	23.2	10	
2,2,3-Trimethylpentane	1050		mg/kg	98.2	24.6	10	
2,3,4-Trimethylpentane	7220		mg/kg	98.2	22.5	10	
2,3,3-Trimethylpentane	8190		mg/kg	98.2	21.5	10	
2,3-Dimethylhexane	2420		mg/kg	98.2	23.8	10	
2-Methylheptane	8760		mg/kg	98.2	22.7	10	
3-Methylheptane	6940		mg/kg	98.2	29.5	10	
3-Ethylhexane	1520		mg/kg	98.2	25.1	10	
Toluene	52500	Е	mg/kg	98.2	14.2	10	
2-Methylthiophene	ND		mg/kg	98.2	14.6	10	
3-Methylthiophene	ND		mg/kg	98.2	15.1	10	
1-Octene	ND		mg/kg	246	15.0	10	
Octane	9750		mg/kg	98.2	20.8	10	
1,2-Dibromoethane	ND		mg/kg	98.2	15.7	10	
Ethylbenzene	12500	E	mg/kg	98.2	10.6	10	
2-Ethylthiophene	ND		mg/kg	98.2	10.8	10	
p/m-Xylene	48000	Е	mg/kg	196	27.6	10	
1-Nonene	ND		mg/kg	246	10.2	10	
Nonane (C9)	4570		mg/kg	98.2	21.5	10	
Styrene	17.1	J	mg/kg	98.2	13.6	10	
o-Xylene	17600	Е	mg/kg	98.2	15.1	10	
Isopropylbenzene	1080		mg/kg	98.2	16.4	10	
n-Propylbenzene	4100		mg/kg	98.2	18.5	10	
1-Methyl-3-Ethylbenzene	12400	Е	mg/kg	98.2	15.7	10	
1-Methyl-4-Ethylbenzene	5750		mg/kg	98.2	17.9	10	
1,3,5-Trimethylbenzene	6120		mg/kg	98.2	18.7	10	
1-Decene	ND		mg/kg	98.2	13.6	10	
1-Methyl-2-Ethylbenzene	4330		mg/kg	98.2	20.1	10	
Decane (C10)	2540		mg/kg	98.2	15.0	10	
1,2,4-Trimethylbenzene	19500	E	mg/kg	98.2	21.5	10	
sec-Butylbenzene	384		mg/kg	98.2	19.9	10	
1-Methyl-3-Isopropylbenzene	608		mg/kg	98.2	18.5	10	
1-Methyl-4-Isopropylbenzene	206		mg/kg	98.2	22.5	10	



09/08/22

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

L2240634-04

**GASOLINE 91** 

Not Specified

D

**SAMPLE RESULTS** 

Date Collected: 07/26/22 00:00

Date Received: 07/29/22

Report Date:

Field Prep: Not Specified

Sample Depth:

Sample Location:

Lab ID:

Client ID:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC/MS - Mansfield Lab							
1-Methyl-2-Isopropylbenzene	42.0	J	mg/kg	98.2	27.0	10	
Indane	1950		mg/kg	98.2	22.7	10	
1-Methyl-3-N-Propylbenzene	2530		mg/kg	98.2	21.7	10	
1-Methyl-4-N-Propylbenzene	1200		mg/kg	98.2	23.0	10	
n-Butylbenzene	840		mg/kg	98.2	24.5	10	
1,2-Dimethyl-4-Ethylbenzene	2490		mg/kg	98.2	23.9	10	
1,2-Diethylbenzene	180		mg/kg	98.2	22.7	10	
1-Methyl-2-N-Propylbenzene	877		mg/kg	98.2	20.0	10	
1,4-Dimethyl-2-Ethylbenzene	1730		mg/kg	98.2	21.9	10	
Undecane	821		mg/kg	98.2	34.7	10	
1,3-Dimethyl-4-Ethylbenzene	1460		mg/kg	98.2	21.0	10	
1,3-Dimethyl-5-Ethylbenzene	2730		mg/kg	98.2	23.9	10	
1,3-Dimethyl-2-Ethylbenzene	203		mg/kg	98.2	23.3	10	
1,2-Dimethyl-3-Ethylbenzene	562		mg/kg	98.2	21.4	10	
1,2,4,5-Tetramethylbenzene	1390		mg/kg	98.2	22.2	10	
N-Pentylbenzene	99.9		mg/kg	98.2	19.4	10	
Dodecane (C12)	354		mg/kg	246	43.1	10	
Naphthalene	1790		mg/kg	98.2	41.0	10	
Benzothiophene	ND		mg/kg	98.2	51.9	10	
MMT	ND		mg/kg	246	63.1	10	
Tridecane	220	J	mg/kg	246	63.7	10	
2-Methylnaphthalene	1010		mg/kg	246	64.9	10	
1-Methylnaphthalene	473		mg/kg	246	72.0	10	

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	122		70-130	
Toluene-d8	113		70-130	
4-Bromofluorobenzene	97		70-130	



09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-07 D2 Date Collected: 07/26/22 00:00

Client ID: GASOLINE 93 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/04/22 23:43

Analyst: RY

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC/MS	6 - Mansfield Lab						
Isopentane	44400		mg/kg	1760	658.	200	
Pentane	32900		mg/kg	1760	550.	200	
2-Methylpentane	27700		mg/kg	1760	568.	200	
3-Methylpentane	17800		mg/kg	1760	342.	200	
n-Hexane	26300		mg/kg	1760	514.	200	
Methylcyclopentane	18600		mg/kg	1760	536.	200	
Cyclohexane	12400		mg/kg	1760	509.	200	
2-Methylhexane	14100		mg/kg	1760	411.	200	
Benzene	8810		mg/kg	1760	382.	200	
3-Methylhexane	14100		mg/kg	1760	464.	200	
Isooctane	14100		mg/kg	1760	413.	200	
Heptane	18100		mg/kg	1760	485.	200	
Methylcyclohexane	13900		mg/kg	1760	376.	200	
2-Methylheptane	8070		mg/kg	1760	409.	200	
Toluene	50200		mg/kg	1760	255.	200	
Octane	8740		mg/kg	1760	373.	200	
Ethylbenzene	11300		mg/kg	1760	190.	200	
p/m-Xylene	44200		mg/kg	3530	497.	200	
o-Xylene	15900		mg/kg	1760	271.	200	
1-Methyl-3-Ethylbenzene	10700		mg/kg	1760	283.	200	
1,2,4-Trimethylbenzene	17300		mg/kg	1760	386.	200	

Surrogate	% Recovery		ptance iteria
Dibromofluoromethane	122	7	70-130
Toluene-d8	113	7	70-130
4-Bromofluorobenzene	95	ī	70-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-07 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 93 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/04/22 16:33

Analyst: RY

Plano Volatile Organics by GC/MS - Mansfield Lab	Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
1-Pentene	PIANO Volatile Organics by GC/N	MS - Mansfield Lab					
2-Methyl-1-Butene         6330         mg/kg         88.3         29.0         10           Pentane         50800         E         mg/kg         88.3         27.5         10           trans-2-Pentene         7230         mg/kg         88.3         31.1         10           cis-2-Pentene         4470         mg/kg         88.3         23.1         10           Tertiary Butanol         ND         mg/kg         88.3         23.1         10           Cyclopentane         5320         mg/kg         88.3         22.9         10           2-3-Dimethylbutane         8280         mg/kg         88.3         22.9         10           2-4Methylpentane         38200         E         mg/kg         88.3         28.4         10           2-4Methylpentane         38200         E         mg/kg         88.3         27.5         10           3-4Methylpentane         23900         E         mg/kg         88.3         27.5         10           1-Hexene         ND         mg/kg         88.3         25.7         10           1-Hexene         ND         mg/kg         88.3         24.2         10           1-Hexene         ND	Isopentane	72400	E	mg/kg	88.3	32.9	10
Pentane         50800         E         mg/kg         88.3         27.5         10           trans-2-Pentane         7230         mg/kg         88.3         31.1         10           cis-2-Pentane         4470         mg/kg         88.3         23.1         10           Tertiary Butanol         ND         mg/kg         88.3         23.1         10           Cyclopentane         5320         mg/kg         88.3         22.9         10           2-Jemethylbutane         8280         mg/kg         88.3         36.4         10           2-Methylpentane         38200         E         mg/kg         88.3         28.4         10           Methyl tert butyl ether         ND         mg/kg         88.3         27.5         10           3-Methylpentane         23900         E         mg/kg         88.3         27.5         10           1-Hexane         ND         mg/kg         88.3         25.3         10           1-Hexane         ND         mg/kg         88.3         25.7         10           Isopropyl Ether         ND         mg/kg         88.3         22.2         10           Ethyl-Tert-Butyl-Ether         ND <t< td=""><td>1-Pentene</td><td>2710</td><td></td><td>mg/kg</td><td>88.3</td><td>27.3</td><td>10</td></t<>	1-Pentene	2710		mg/kg	88.3	27.3	10
trans-2-Pentene         7230         mg/kg         88.3         31.1         10           cis-2-Pentene         4470         mg/kg         88.3         23.1         10           Tertiary Butanol         ND         mg/kg         1100         357.         10           Cyclopentane         5320         mg/kg         88.3         22.9         10           2.3-Dimethylbutane         8280         mg/kg         88.3         36.4         10           2-Methylpentane         38200         E         mg/kg         88.3         27.5         10           Methyl tert butyl ether         ND         mg/kg         88.3         27.5         10           3-Methylpentane         23900         E         mg/kg         88.3         27.5         10           3-Methylpentane         34800         E         mg/kg         88.3         25.7         10           1-Hexane         34800         E         mg/kg         88.3         25.7         10           1-Pethylpentane         1260         mg/kg         88.3         25.7         10           Methylcyclopentane         23000         E         mg/kg         88.3         25.5         10	2-Methyl-1-Butene	6330		mg/kg	88.3	29.0	10
Cis-2-Pentene	Pentane	50800	E	mg/kg	88.3	27.5	10
Tertiary Butanol         ND         mg/kg         1100         357.         10           Cyclopentane         5320         mg/kg         88.3         22.9         10           2,3-Dimethylbutane         8280         mg/kg         88.3         36.4         10           2-Methylpentane         38200         E         mg/kg         88.3         28.4         10           Methyl tert butyl ether         ND         mg/kg         88.3         27.5         10           3-Methylpentane         23900         E         mg/kg         88.3         27.5         10           1-Hexene         ND         mg/kg         88.3         25.3         10           1-Hexene         ND         mg/kg         88.3         25.7         10           1-Hexene         ND         mg/kg         88.3         25.7         10           Isopropyl Ether         ND         mg/kg         88.3         24.2         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         88.3         22.8         10           Ethyl-Tert-Butyl-Ether         1260         mg/kg         88.3         22.8         10           Wethylvcyl-Copentane         1260         mg/	trans-2-Pentene	7230		mg/kg	88.3	31.1	10
Cyclopentane         5320         mg/kg         88.3         22.9         10           2,3-Dimethylbutane         8280         mg/kg         88.3         36.4         10           2-Methylpentane         38200         E         mg/kg         88.3         28.4         10           Methyl tert butyl ether         ND         mg/kg         88.3         27.5         10           3-Methylpentane         23900         E         mg/kg         88.3         27.5         10           1-Hexene         ND         mg/kg         88.3         25.3         10           1-Hexene         ND         mg/kg         88.3         25.3         10           1-Hexene         ND         mg/kg         88.3         25.7         10           Isopropyl Ether         ND         mg/kg         88.3         24.2         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         88.3         23.0         10           2,2-Dimethylpentane         1260         mg/kg         88.3         22.8         10           Methylcyclopentane         4760         mg/kg         88.3         23.2         10           1,2-Dichloroethane         ND         mg/kg<	cis-2-Pentene	4470		mg/kg	88.3	23.1	10
2,3-Dimethylbutane 8280 mg/kg 88.3 36.4 10 2-Methylpentane 38200 E mg/kg 88.3 28.4 10 Methyl tent butyl ether ND mg/kg 88.3 27.5 10 3-Methylpentane 23900 E mg/kg 88.3 17.1 10 1-Hexene ND mg/kg 88.3 25.3 10 n-Hexane 34800 E mg/kg 88.3 25.7 10 Isopropyl Ether ND mg/kg 88.3 25.7 10 Ethyl-Tert-Butyl-Ether ND mg/kg 88.3 24.2 10 Ethyl-Tert-Butyl-Ether ND mg/kg 88.3 23.0 10 2,2-Dimethylpentane 1260 mg/kg 88.3 22.8 10 Methylcyclopentane 23000 E mg/kg 88.3 22.8 10 Methylcyclopentane 23000 E mg/kg 88.3 23.0 10 2,4-Dimethylpentane 4760 mg/kg 88.3 23.2 10 1,2-Dichloroethane ND mg/kg 88.3 25.5 10 Cyclohexane 14400 E mg/kg 88.3 25.5 10 2-Methylhexane 16600 E mg/kg 88.3 25.5 10 Enzene 9320 E mg/kg 88.3 20.6 10 Enzene 9320 E mg/kg 8	Tertiary Butanol	ND		mg/kg	1100	357.	10
2-Methylpentane         38200         E         mg/kg         88.3         28.4         10           Methyl tert butyl ether         ND         mg/kg         88.3         27.5         10           3-Methylpentane         23900         E         mg/kg         88.3         17.1         10           1-Hexene         ND         mg/kg         88.3         25.3         10           n-Hexane         34800         E         mg/kg         88.3         25.7         10           Isopropyl Ether         ND         mg/kg         88.3         24.2         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         88.3         23.0         10           2,2-Dimethylpentane         1260         mg/kg         88.3         22.8         10           Methylcyclopentane         23000         E         mg/kg         88.3         26.8         10           4,4-Dimethylpentane         4760         mg/kg         88.3         23.2         10           1,2-Dichloroethane         ND         mg/kg         88.3         25.5         10           Cyclohexane         14400         E         mg/kg         88.3         25.5         10	Cyclopentane	5320		mg/kg	88.3	22.9	10
Methyl tert butyl ether         ND         mg/kg         88.3         27.5         10           3-Methylpentane         23900         E         mg/kg         88.3         17.1         10           1-Hexene         ND         mg/kg         88.3         25.3         10           n-Hexane         34800         E         mg/kg         88.3         25.7         10           sopropyl Ether         ND         mg/kg         88.3         24.2         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         88.3         23.0         10           2,2-Dimethylpentane         1260         mg/kg         88.3         22.8         10           Methylcyclopentane         23000         E         mg/kg         88.3         23.2         10           Methylcyclopentane         4760         mg/kg         88.3         23.2         10           1,2-Dichloroethane         ND         mg/kg         88.3         25.5         10           Cyclohexane         14400         E         mg/kg         88.3         25.5         10           2-Methylhexane         16600         E         mg/kg         88.3         19.1         10	2,3-Dimethylbutane	8280		mg/kg	88.3	36.4	10
3-Methylpentane 23900 E mg/kg 88.3 17.1 10  1-Hexene ND mg/kg 88.3 25.3 10  1-Hexane 34800 E mg/kg 88.3 25.7 10  Isopropyl Ether ND mg/kg 88.3 24.2 10  Ethyl-Tert-Butyl-Ether ND mg/kg 88.3 23.0 10  2,2-Dimethylpentane 1260 mg/kg 88.3 22.8 10  Methylcyclopentane 23000 E mg/kg 88.3 26.8 10  2,4-Dimethylpentane 4760 mg/kg 88.3 23.2 10  1,2-Dichloroethane ND mg/kg 88.3 23.2 10  1,2-Dichloroethane ND mg/kg 88.3 25.5 10  Cyclohexane 14400 E mg/kg 88.3 25.5 10  Cyclohexane 16600 E mg/kg 88.3 20.6 10  Benzene 9320 E mg/kg 88.3 20.6 10  Benzene 9320 E mg/kg 88.3 20.6 10  Benzene 9320 E mg/kg 88.3 20.6 10  Thiophene 15.5 J mg/kg 88.3 22.3 10  Thiophene 15.5 J mg/kg 88.3 22.9 10  Thiophene 15.5 J mg/kg 88.3 23.2 10  Tertiary-Amyl Methyl Ether ND mg/kg 88.3 23.2 10	2-Methylpentane	38200	Е	mg/kg	88.3	28.4	10
1-Hexene         ND         mg/kg         88.3         25.3         10           n-Hexane         34800         E         mg/kg         88.3         25.7         10           Isopropyl Ether         ND         mg/kg         88.3         24.2         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         88.3         23.0         10           2,2-Dimethylpentane         1260         mg/kg         88.3         22.8         10           Methylcyclopentane         23000         E         mg/kg         88.3         26.8         10           2,4-Dimethylpentane         4760         mg/kg         88.3         23.2         10           1,2-Dichloroethane         ND         mg/kg         88.3         26.7         10           Cyclohexane         14400         E         mg/kg         88.3         25.5         10           2-Methylhexane         16600         E         mg/kg         88.3         20.6         10           Benzene         9320         E         mg/kg         88.3         22.3         10           2,3-Dimethylpentane         ND         mg/kg         88.3         22.3         10           Thio	Methyl tert butyl ether	ND		mg/kg	88.3	27.5	10
ND   mg/kg   88.3   25.7   10	3-Methylpentane	23900	Е	mg/kg	88.3	17.1	10
Sopropy  Ether	1-Hexene	ND		mg/kg	88.3	25.3	10
Ethyl-Tert-Butyl-Ether         ND         mg/kg         88.3         23.0         10           2,2-Dimethylpentane         1260         mg/kg         88.3         22.8         10           Methylcyclopentane         23000         E         mg/kg         88.3         26.8         10           2,4-Dimethylpentane         4760         mg/kg         88.3         23.2         10           1,2-Dichloroethane         ND         mg/kg         88.3         26.7         10           Cyclohexane         14400         E         mg/kg         88.3         25.5         10           2-Methylhexane         16600         E         mg/kg         88.3         20.6         10           Benzene         9320         E         mg/kg         88.3         19.1         10           2,3-Dimethylpentane         ND         mg/kg         88.3         22.3         10           Thiophene         15.5         J         mg/kg         88.3         22.9         10           3-Methylhexane         16100         E         mg/kg         88.3         23.2         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         88.3         23.4         10 </td <td>n-Hexane</td> <td>34800</td> <td>Е</td> <td>mg/kg</td> <td>88.3</td> <td>25.7</td> <td>10</td>	n-Hexane	34800	Е	mg/kg	88.3	25.7	10
2,2-Dimethylpentane       1260       mg/kg       88.3       22.8       10         Methylcyclopentane       23000       E       mg/kg       88.3       26.8       10         2,4-Dimethylpentane       4760       mg/kg       88.3       23.2       10         1,2-Dichloroethane       ND       mg/kg       88.3       26.7       10         Cyclohexane       14400       E       mg/kg       88.3       25.5       10         2-Methylhexane       16600       E       mg/kg       88.3       20.6       10         Benzene       9320       E       mg/kg       88.3       19.1       10         2,3-Dimethylpentane       ND       mg/kg       88.3       22.3       10         Thiophene       15.5       J       mg/kg       88.3       22.9       10         3-Methylhexane       16100       E       mg/kg       88.3       23.2       10         Tertiary-Amyl Methyl Ether       ND       mg/kg       88.3       23.4       10	Isopropyl Ether	ND		mg/kg	88.3	24.2	10
Methylcyclopentane         23000         E         mg/kg         88.3         26.8         10           2,4-Dimethylpentane         4760         mg/kg         88.3         23.2         10           1,2-Dichloroethane         ND         mg/kg         88.3         26.7         10           Cyclohexane         14400         E         mg/kg         88.3         25.5         10           2-Methylhexane         16600         E         mg/kg         88.3         20.6         10           Benzene         9320         E         mg/kg         88.3         19.1         10           2,3-Dimethylpentane         ND         mg/kg         88.3         22.3         10           Thiophene         15.5         J         mg/kg         88.3         22.9         10           3-Methylhexane         16100         E         mg/kg         88.3         23.2         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         88.3         23.4         10	Ethyl-Tert-Butyl-Ether	ND		mg/kg	88.3	23.0	10
2,4-Dimethylpentane       4760       mg/kg       88.3       23.2       10         1,2-Dichloroethane       ND       mg/kg       88.3       26.7       10         Cyclohexane       14400       E       mg/kg       88.3       25.5       10         2-Methylhexane       16600       E       mg/kg       88.3       20.6       10         Benzene       9320       E       mg/kg       88.3       19.1       10         2,3-Dimethylpentane       ND       mg/kg       88.3       22.3       10         Thiophene       15.5       J       mg/kg       88.3       22.9       10         3-Methylhexane       16100       E       mg/kg       88.3       23.2       10         Tertiary-Amyl Methyl Ether       ND       mg/kg       88.3       23.4       10	2,2-Dimethylpentane	1260		mg/kg	88.3	22.8	10
1,2-Dichloroethane         ND         mg/kg         88.3         26.7         10           Cyclohexane         14400         E         mg/kg         88.3         25.5         10           2-Methylhexane         16600         E         mg/kg         88.3         20.6         10           Benzene         9320         E         mg/kg         88.3         19.1         10           2,3-Dimethylpentane         ND         mg/kg         88.3         22.3         10           Thiophene         15.5         J         mg/kg         88.3         22.9         10           3-Methylhexane         16100         E         mg/kg         88.3         23.2         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         88.3         23.4         10	Methylcyclopentane	23000	Е	mg/kg	88.3	26.8	10
Cyclohexane         14400         E         mg/kg         88.3         25.5         10           2-Methylhexane         16600         E         mg/kg         88.3         20.6         10           Benzene         9320         E         mg/kg         88.3         19.1         10           2,3-Dimethylpentane         ND         mg/kg         88.3         22.3         10           Thiophene         15.5         J         mg/kg         88.3         22.9         10           3-Methylhexane         16100         E         mg/kg         88.3         23.2         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         88.3         23.4         10	2,4-Dimethylpentane	4760		mg/kg	88.3	23.2	10
2-Methylhexane 16600 E mg/kg 88.3 20.6 10  Benzene 9320 E mg/kg 88.3 19.1 10  2,3-Dimethylpentane ND mg/kg 88.3 22.3 10  Thiophene 15.5 J mg/kg 88.3 22.9 10  3-Methylhexane 16100 E mg/kg 88.3 23.2 10  Tertiary-Amyl Methyl Ether ND mg/kg 88.3 23.4 10	1,2-Dichloroethane	ND		mg/kg	88.3	26.7	10
Benzene         9320         E         mg/kg         88.3         19.1         10           2,3-Dimethylpentane         ND         mg/kg         88.3         22.3         10           Thiophene         15.5         J         mg/kg         88.3         22.9         10           3-Methylhexane         16100         E         mg/kg         88.3         23.2         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         88.3         23.4         10	Cyclohexane	14400	Е	mg/kg	88.3	25.5	10
2,3-Dimethylpentane       ND       mg/kg       88.3       22.3       10         Thiophene       15.5       J       mg/kg       88.3       22.9       10         3-Methylhexane       16100       E       mg/kg       88.3       23.2       10         Tertiary-Amyl Methyl Ether       ND       mg/kg       88.3       23.4       10	2-Methylhexane	16600	E	mg/kg	88.3	20.6	10
Thiophene         15.5         J         mg/kg         88.3         22.9         10           3-Methylhexane         16100         E         mg/kg         88.3         23.2         10           Tertiary-Amyl Methyl Ether         ND         mg/kg         88.3         23.4         10	Benzene	9320	Е	mg/kg	88.3	19.1	10
3-Methylhexane 16100 E mg/kg 88.3 23.2 10  Tertiary-Amyl Methyl Ether ND mg/kg 88.3 23.4 10	2,3-Dimethylpentane	ND		mg/kg	88.3	22.3	10
Tertiary-Amyl Methyl Ether ND mg/kg 88.3 23.4 10	Thiophene	15.5	J	mg/kg	88.3	22.9	10
	3-Methylhexane	16100	Е	mg/kg	88.3	23.2	10
1-Heptene/1,2-DMCP (trans) 8870 mg/kg 176 54.1 10	Tertiary-Amyl Methyl Ether	ND		mg/kg	88.3	23.4	10
	1-Heptene/1,2-DMCP (trans)	8870		mg/kg	176	54.1	10



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-07 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 93 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
PIANO Volatile Organics by GC/MS - Mansfield Lab								
Innertone	15400	_		00.2	20.6	10		
Isooctane		E E	mg/kg	88.3	20.6	10		
Heptane	20000		mg/kg	88.3	24.2	10		
Methylcyclohexane	15200	E	mg/kg	88.3	18.8	10		
2,5-Dimethylhexane	3860		mg/kg	88.3	21.1	10		
2,4-Dimethylhexane	3530		mg/kg	88.3	20.8	10		
2,2,3-Trimethylpentane	1060		mg/kg	88.3	22.1	10		
2,3,4-Trimethylpentane	7760		mg/kg	88.3	20.2	10		
2,3,3-Trimethylpentane	8560		mg/kg	88.3	19.3	10		
2,3-Dimethylhexane	2150		mg/kg	88.3	21.4	10		
2-Methylheptane	9960	E	mg/kg	88.3	20.4	10		
3-Methylheptane	6700		mg/kg	88.3	26.5	10		
3-Ethylhexane	1860		mg/kg	88.3	22.5	10		
Toluene	53900	E	mg/kg	88.3	12.8	10		
2-Methylthiophene	ND		mg/kg	88.3	13.1	10		
3-Methylthiophene	ND		mg/kg	88.3	13.6	10		
1-Octene	ND		mg/kg	221	13.5	10		
Octane	9940	E	mg/kg	88.3	18.7	10		
1,2-Dibromoethane	ND		mg/kg	88.3	14.1	10		
Ethylbenzene	12200	E	mg/kg	88.3	9.53	10		
2-Ethylthiophene	ND		mg/kg	88.3	9.66	10		
p/m-Xylene	44900	Е	mg/kg	176	24.8	10		
1-Nonene	ND		mg/kg	221	9.14	10		
Nonane (C9)	4510		mg/kg	88.3	19.3	10		
Styrene	17.3	J	mg/kg	88.3	12.2	10		
o-Xylene	16500	E	mg/kg	88.3	13.6	10		
Isopropylbenzene	1000		mg/kg	88.3	14.7	10		
n-Propylbenzene	3760		mg/kg	88.3	16.6	10		
1-Methyl-3-Ethylbenzene	11200	E	mg/kg	88.3	14.1	10		
1-Methyl-4-Ethylbenzene	5200		mg/kg	88.3	16.1	10		
1,3,5-Trimethylbenzene	5500		mg/kg	88.3	16.8	10		
1-Decene	ND		mg/kg	88.3	12.2	10		
1-Methyl-2-Ethylbenzene	3890		mg/kg	88.3	18.0	10		
Decane (C10)	2420		mg/kg	88.3	13.5	10		
1,2,4-Trimethylbenzene	17500	E	mg/kg	88.3	19.3	10		
sec-Butylbenzene	345		mg/kg	88.3	17.8	10		
1-Methyl-3-Isopropylbenzene	543		mg/kg	88.3	16.6	10		
1-Methyl-4-Isopropylbenzene	186		mg/kg	88.3	20.2	10		
7 1 17			<b>ت</b> ا و و					



09/08/22

**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified

L2240634-07

**GASOLINE 93** 

Not Specified

D

**SAMPLE RESULTS** 

Date Collected: 07/26/22 00:00

Date Received: 07/29/22

Report Date:

Field Prep: Not Specified

Sample Depth:

Sample Location:

Lab ID:

Client ID:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
PIANO Volatile Organics by GC/MS - Mansfield Lab								
1-Methyl-2-Isopropylbenzene	39.3	J	mg/kg	88.3	24.2	10		
Indane	1730		mg/kg	88.3	20.4	10		
1-Methyl-3-N-Propylbenzene	2260		mg/kg	88.3	19.5	10		
1-Methyl-4-N-Propylbenzene	1080		mg/kg	88.3	20.7	10		
n-Butylbenzene	752		mg/kg	88.3	22.0	10		
1,2-Dimethyl-4-Ethylbenzene	2220		mg/kg	88.3	21.5	10		
1,2-Diethylbenzene	164		mg/kg	88.3	20.4	10		
1-Methyl-2-N-Propylbenzene	792		mg/kg	88.3	18.0	10		
1,4-Dimethyl-2-Ethylbenzene	1540		mg/kg	88.3	19.7	10		
Undecane	752		mg/kg	88.3	31.2	10		
1,3-Dimethyl-4-Ethylbenzene	1290		mg/kg	88.3	18.9	10		
1,3-Dimethyl-5-Ethylbenzene	2410		mg/kg	88.3	21.5	10		
1,3-Dimethyl-2-Ethylbenzene	173		mg/kg	88.3	20.9	10		
1,2-Dimethyl-3-Ethylbenzene	496		mg/kg	88.3	19.2	10		
1,2,4,5-Tetramethylbenzene	1200		mg/kg	88.3	19.9	10		
N-Pentylbenzene	89.4		mg/kg	88.3	17.4	10		
Dodecane (C12)	318		mg/kg	221	38.7	10		
Naphthalene	1540		mg/kg	88.3	36.8	10		
Benzothiophene	ND		mg/kg	88.3	46.6	10		
MMT	ND		mg/kg	221	56.7	10		
Tridecane	190	J	mg/kg	221	57.2	10		
2-Methylnaphthalene	882		mg/kg	221	58.3	10		
1-Methylnaphthalene	407		mg/kg	221	64.7	10		

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	119		70-130	
Toluene-d8	114		70-130	
4-Bromofluorobenzene	90		70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-10 D Date Collected: 07/26/22 00:00

Client ID: Date Received: 07/29/22
Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M) Analytical Date: 08/04/22 17:44

Analyst: RY

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS -	Mansfield Lab					
Isopentane	18.3	J	mg/kg	97.8	36.5	10
1-Pentene	ND		mg/kg	97.8	30.3	10
2-Methyl-1-Butene	ND		mg/kg	97.8	32.1	10
Pentane	ND		mg/kg	97.8	30.5	10
trans-2-Pentene	ND		mg/kg	97.8	34.5	10
cis-2-Pentene	ND		mg/kg	97.8	25.6	10
Tertiary Butanol	ND		mg/kg	1220	396.	10
Cyclopentane	ND		mg/kg	97.8	25.4	10
2,3-Dimethylbutane	ND		mg/kg	97.8	40.4	10
2-Methylpentane	16.2	J	mg/kg	97.8	31.5	10
Methyl tert butyl ether	ND		mg/kg	97.8	30.5	10
3-Methylpentane	7.58	J	mg/kg	97.8	19.0	10
1-Hexene	ND		mg/kg	97.8	28.1	10
n-Hexane	21.7	JB	mg/kg	97.8	28.5	10
Isopropyl Ether	ND		mg/kg	97.8	26.9	10
Ethyl-Tert-Butyl-Ether	ND		mg/kg	97.8	25.5	10
2,2-Dimethylpentane	ND		mg/kg	97.8	25.3	10
Methylcyclopentane	8.56	J	mg/kg	97.8	29.7	10
2,4-Dimethylpentane	ND		mg/kg	97.8	25.7	10
1,2-Dichloroethane	ND		mg/kg	97.8	29.6	10
Cyclohexane	ND		mg/kg	97.8	28.2	10
2-Methylhexane	ND		mg/kg	97.8	22.8	10
Benzene	31.4	J	mg/kg	97.8	21.2	10
2,3-Dimethylpentane	ND		mg/kg	97.8	24.8	10
Thiophene	ND		mg/kg	97.8	25.4	10
3-Methylhexane	ND		mg/kg	97.8	25.8	10
Tertiary-Amyl Methyl Ether	ND		mg/kg	97.8	25.9	10
1-Heptene/1,2-DMCP (trans)	ND		mg/kg	196	60.0	10



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-10 D Date Collected: 07/26/22 00:00

Client ID: Date Received: 07/29/22
Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor			
PIANO Volatile Organics by GC/MS -	PIANO Volatile Organics by GC/MS - Mansfield Lab								
Innectons	4.55	J	m a/l.a	97.8	22.9	10			
Isooctane Heptane	26.8	J	mg/kg	97.8	26.9	10			
Methylcyclohexane	50.3	J	mg/kg	97.8	20.9	10			
	ND	J	mg/kg	97.8	23.4	10			
2,5-Dimethylhexane			mg/kg						
2,4-Dimethylhexane	ND		mg/kg	97.8	23.1	10			
2,2,3-Trimethylpentane	ND		mg/kg	97.8	24.5	10			
2,3,4-Trimethylpentane	ND		mg/kg	97.8	22.4	10			
2,3,3-Trimethylpentane	ND		mg/kg	97.8	21.4	10			
2,3-Dimethylhexane	18.4	J	mg/kg	97.8	23.7	10			
2-Methylheptane	139		mg/kg	97.8	22.6	10			
3-Methylheptane	154		mg/kg	97.8	29.4	10			
3-Ethylhexane	ND		mg/kg	97.8	25.0	10			
Toluene	110		mg/kg	97.8	14.2	10			
2-Methylthiophene	ND		mg/kg	97.8	14.6	10			
3-Methylthiophene	ND		mg/kg	97.8	15.1	10			
1-Octene	ND		mg/kg	245	14.9	10			
Octane	657		mg/kg	97.8	20.7	10			
1,2-Dibromoethane	ND		mg/kg	97.8	15.6	10			
Ethylbenzene	344		mg/kg	97.8	10.6	10			
2-Ethylthiophene	ND		mg/kg	97.8	10.7	10			
p/m-Xylene	1540		mg/kg	196	27.5	10			
1-Nonene	ND		mg/kg	245	10.1	10			
Nonane (C9)	3840		mg/kg	97.8	21.4	10			
Styrene	ND		mg/kg	97.8	13.6	10			
o-Xylene	807		mg/kg	97.8	15.0	10			
Isopropylbenzene	220		mg/kg	97.8	16.3	10			
n-Propylbenzene	630		mg/kg	97.8	18.4	10			
1-Methyl-3-Ethylbenzene	2000		mg/kg	97.8	15.7	10			
1-Methyl-4-Ethylbenzene	916		mg/kg	97.8	17.8	10			
1,3,5-Trimethylbenzene	1230		mg/kg	97.8	18.6	10			
1-Decene	ND		mg/kg	97.8	13.6	10			
1-Methyl-2-Ethylbenzene	1020		mg/kg	97.8	20.0	10			
Decane (C10)	8030		mg/kg	97.8	14.9	10			
1,2,4-Trimethylbenzene	4110		mg/kg	97.8	21.4	10			
sec-Butylbenzene	415		mg/kg	97.8	19.8	10			
1-Methyl-3-Isopropylbenzene	568		mg/kg	97.8	18.4	10			
1-Methyl-4-Isopropylbenzene	324		mg/kg	97.8	22.4	10			
, , , , , , ,			···•						



09/08/22

**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified

**SAMPLE RESULTS** 

Date Collected: 07/26/22 00:00

Report Date:

Lab ID: L2240634-10 D

Date Received: 07/29/22 Client ID: **HEATING FUEL** Sample Location: Field Prep: Not Specified Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
PIANO Volatile Organics by GC/MS - Mansfield Lab								
1-Methyl-2-Isopropylbenzene	71.3	J	mg/kg	97.8	26.8	10		
Indane	671		mg/kg	97.8	22.6	10		
1-Methyl-3-N-Propylbenzene	1440		mg/kg	97.8	21.6	10		
1-Methyl-4-N-Propylbenzene	687		mg/kg	97.8	23.0	10		
n-Butylbenzene	632		mg/kg	97.8	24.4	10		
1,2-Dimethyl-4-Ethylbenzene	1210		mg/kg	97.8	23.8	10		
1,2-Diethylbenzene	223		mg/kg	97.8	22.6	10		
1-Methyl-2-N-Propylbenzene	898		mg/kg	97.8	19.9	10		
1,4-Dimethyl-2-Ethylbenzene	1040		mg/kg	97.8	21.8	10		
Undecane	7310		mg/kg	97.8	34.5	10		
1,3-Dimethyl-4-Ethylbenzene	1060		mg/kg	97.8	20.9	10		
1,3-Dimethyl-5-Ethylbenzene	1430		mg/kg	97.8	23.8	10		
1,3-Dimethyl-2-Ethylbenzene	217		mg/kg	97.8	23.2	10		
1,2-Dimethyl-3-Ethylbenzene	514		mg/kg	97.8	21.3	10		
1,2,4,5-Tetramethylbenzene	774		mg/kg	97.8	22.1	10		
N-Pentylbenzene	882		mg/kg	97.8	19.4	10		
Dodecane (C12)	6580		mg/kg	245	42.9	10		
Naphthalene	790		mg/kg	97.8	40.8	10		
Benzothiophene	ND		mg/kg	97.8	51.7	10		
MMT	ND		mg/kg	245	62.8	10		
Tridecane	6630		mg/kg	245	63.4	10		
2-Methylnaphthalene	2180		mg/kg	245	64.6	10		
1-Methylnaphthalene	1280		mg/kg	245	71.8	10		

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	118		70-130	
Toluene-d8	109		70-130	
4-Bromofluorobenzene	100		70-130	



09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-13 D2 Date Collected: 07/26/22 00:00

Client ID: ROAD DIESEL Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/05/22 02:06

Analyst: RY

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC/MS	Mansfield Lab						
1,2,4-Trimethylbenzene	9340		mg/kg	1820	399.	200	
Surrogate			% Recovery	Qualifier	Accept Crite		
Dibromofluoromethane			100		70-	130	
Toluene-d8			112		70-	130	
4-Bromofluorobenzene			94		70-	130	

09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-13 D Date Collected: 07/26/22 00:00

Client ID: ROAD DIESEL Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/04/22 18:56

Analyst: RY

Plano Volatile Organics by GC/MS - Mansfield Lab	Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
1-Pentene   ND	PIANO Volatile Organics by GC/MS	S - Mansfield Lab					
1-Pentene   ND	Isopentane	121		ma/ka	91.2	34.0	10
Pentiane         90.3         J         mg/kg         91.2         28.4         10           trans-2-Pentene         ND         mg/kg         91.2         32.1         10           cis-2-Pentene         ND         mg/kg         91.2         23.9         10           Tertiary Butanol         ND         mg/kg         1140         369.         10           Cydopentane         23.2         J         mg/kg         91.2         23.6         10           2,3-Dimethylbutane         22.4         J         mg/kg         91.2         23.6         10           2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         ND         mg/kg         91.2         28.4         10           3-Methylpentane         ND         mg/kg         91.2         26.6         10           1-Hexene         ND         mg/kg         91.2         26.6         10           1-Hexene         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg	1-Pentene	ND			91.2	28.2	10
Pentane         90.3         J         mg/kg         91.2         28.4         10           trans-2-Pentene         ND         mg/kg         91.2         32.1         10           cis-2-Pentene         ND         mg/kg         91.2         23.9         10           Tentiary Butanol         ND         mg/kg         1140         369.         10           Cyclopentane         23.2         J         mg/kg         91.2         23.6         10           2,3-Dimethylbutane         22.4         J         mg/kg         91.2         23.6         10           2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         28.4         10           1-Hexene         ND         mg/kg         91.2         26.6         10           1-Hexene         ND         mg/kg         91.2         25.0         10           1-Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.6         10           Methylcyclopentane <td< td=""><td>2-Methyl-1-Butene</td><td>ND</td><td></td><td>mg/kg</td><td>91.2</td><td>29.9</td><td>10</td></td<>	2-Methyl-1-Butene	ND		mg/kg	91.2	29.9	10
cis-2-Pentene         ND         mg/kg         91.2         23.9         10           Tertiary Butanol         ND         mg/kg         1140         369.         10           Cyclopentane         23.2         J         mg/kg         91.2         23.6         10           2,3-Dimethylbutane         22.4         J         mg/kg         91.2         23.6         10           2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         28.4         10           3-Methylpentane         ND         mg/kg         91.2         26.2         10           1-Hexene         ND         mg/kg         91.2         26.2         10           1-Hexene         ND         mg/kg         91.2         26.6         10           1-Hexene         ND         mg/kg         91.2         25.0         10           1-Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.6         10           2,-Dimethylpentane         ND <td< td=""><td>Pentane</td><td>90.3</td><td>J</td><td></td><td>91.2</td><td>28.4</td><td>10</td></td<>	Pentane	90.3	J		91.2	28.4	10
Tertiary Butanol         ND         mg/kg         1140         369.         10           Cyclopentane         23.2         J         mg/kg         91.2         23.6         10           2,3-Dimethylbutane         22.4         J         mg/kg         91.2         23.6         10           2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         26.2         10           1-Hexene         ND         mg/kg         91.2         26.2         10           n-Hexane         130         mg/kg         91.2         26.6         10           Isopropyl Ether         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.6         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           2,4-Dimethylpentane <td>trans-2-Pentene</td> <td>ND</td> <td></td> <td>mg/kg</td> <td>91.2</td> <td>32.1</td> <td>10</td>	trans-2-Pentene	ND		mg/kg	91.2	32.1	10
Cyclopentane         23.2         J         mg/kg         91.2         23.6         10           2,3-Dimethylbutane         22.4         J         mg/kg         91.2         37.6         10           2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         26.2         10           1-Hexene         ND         mg/kg         91.2         26.2         10           n-Hexane         130         mg/kg         91.2         26.6         10           Isopropyl Ether         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         157         mg/kg         91.2         23.9         10           1,2-Dichloroethane         ND         mg/kg         91.2         27.6         10           Cyclohexane         296	cis-2-Pentene	ND		mg/kg	91.2	23.9	10
2,3-Dimethylbutane         22.4         J         mg/kg         91.2         37.6         10           2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         26.2         10           1-Hexene         ND         mg/kg         91.2         26.2         10           1-Hexene         ND         mg/kg         91.2         26.6         10           1-Hexene         ND         mg/kg         91.2         25.0         10           Isopropyl Ether         ND         mg/kg         91.2         23.8         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         ND         mg/kg         91.2         27.7         10           2,4-Dimethylpentane         ND         mg/kg         91.2         27.6         10           Cyclohexane         296         mg/kg	Tertiary Butanol	ND		mg/kg	1140	369.	10
2-Methylpentane         92.6         mg/kg         91.2         29.3         10           Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         28.4         10           1-Hexene         ND         mg/kg         91.2         26.2         10           1-Hexane         130         mg/kg         91.2         26.6         10           Isopropyl Ether         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         157         mg/kg         91.2         27.7         10           2,4-Dimethylpentane         ND         mg/kg         91.2         27.6         10           1,2-Dichloroethane         ND         mg/kg         91.2         26.3         10           Cyclohexane         296         mg/kg         91.2         26.3         10           2-Methylhexane         124         mg/kg         91	Cyclopentane	23.2	J	mg/kg	91.2	23.6	10
Methyl tert butyl ether         ND         mg/kg         91.2         28.4         10           3-Methylpentane         73.7         J         mg/kg         91.2         17.7         10           1-Hexene         ND         mg/kg         91.2         26.2         10           n-Hexane         130         mg/kg         91.2         26.6         10           Isopropyl Ether         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         157         mg/kg         91.2         27.7         10           2,4-Dimethylpentane         ND         mg/kg         91.2         23.9         10           1,2-Dichloroethane         ND         mg/kg         91.2         27.6         10           Cyclohexane         296         mg/kg         91.2         26.3         10           2-Methylhexane         124         mg/kg         91.2         21.2         10           Benzene         90.0         J         mg/kg	2,3-Dimethylbutane	22.4	J	mg/kg	91.2	37.6	10
3-Methylpentane 73.7 J mg/kg 91.2 17.7 10 1-Hexene ND mg/kg 91.2 26.2 10 n-Hexane 130 mg/kg 91.2 26.6 10 Isopropyl Ether ND mg/kg 91.2 25.0 10 Ethyl-Tert-Butyl-Ether ND mg/kg 91.2 23.8 10 2,2-Dimethylpentane ND mg/kg 91.2 23.6 10 Methylcyclopentane 157 mg/kg 91.2 23.6 10 Methylcyclopentane ND mg/kg 91.2 23.6 10  Methylcyclopentane ND mg/kg 91.2 27.7 10 2,4-Dimethylpentane ND mg/kg 91.2 27.7 10 1,2-Dichloroethane ND mg/kg 91.2 23.9 10 1,2-Dichloroethane ND mg/kg 91.2 27.6 10 Cyclohexane 296 mg/kg 91.2 27.6 10 Cyclohexane 296 mg/kg 91.2 26.3 10 Ethyl-Tert-Butyl-Ether ND mg/kg 91.2 26.3 10 Cyclohexane 296 mg/kg 91.2 26.3 10 2-Methylhexane 124 mg/kg 91.2 21.2 10 Benzene 90.0 J mg/kg 91.2 21.2 10 Thiophene ND mg/kg 91.2 23.1 10 Thiophene ND mg/kg 91.2 23.7 10 3-Methylhexane 163 mg/kg 91.2 23.7 10	2-Methylpentane	92.6		mg/kg	91.2	29.3	10
1-Hexene         ND         mg/kg         91.2         26.2         10           n-Hexane         130         mg/kg         91.2         26.6         10           Isopropyl Ether         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         157         mg/kg         91.2         27.7         10           2,4-Dimethylpentane         ND         mg/kg         91.2         23.9         10           1,2-Dichloroethane         ND         mg/kg         91.2         27.6         10           Cyclohexane         296         mg/kg         91.2         26.3         10           2-Methylhexane         124         mg/kg         91.2         21.2         10           Benzene         90.0         J         mg/kg         91.2         23.1         10           2,3-Dimethylpentane         58.7         J         mg/kg         91.2         23.1         10           Thiophene         ND         mg/kg         9	Methyl tert butyl ether	ND		mg/kg	91.2	28.4	10
n-Hexane         130         mg/kg         91.2         26.6         10           Isopropyl Ether         ND         mg/kg         91.2         25.0         10           Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         157         mg/kg         91.2         27.7         10           2,4-Dimethylpentane         ND         mg/kg         91.2         23.9         10           1,2-Dichloroethane         ND         mg/kg         91.2         27.6         10           Cyclohexane         296         mg/kg         91.2         26.3         10           2-Methylhexane         124         mg/kg         91.2         21.2         10           Benzene         90.0         J         mg/kg         91.2         23.1         10           2,3-Dimethylpentane         58.7         J         mg/kg         91.2         23.1         10           Thiophene         ND         mg/kg         91.2         23.7         10           3-Methylpexane         163         mg/kg	3-Methylpentane	73.7	J	mg/kg	91.2	17.7	10
Isopropyl Ether   ND   mg/kg   91.2   25.0   10	1-Hexene	ND		mg/kg	91.2	26.2	10
Ethyl-Tert-Butyl-Ether         ND         mg/kg         91.2         23.8         10           2,2-Dimethylpentane         ND         mg/kg         91.2         23.6         10           Methylcyclopentane         157         mg/kg         91.2         27.7         10           2,4-Dimethylpentane         ND         mg/kg         91.2         23.9         10           1,2-Dichloroethane         ND         mg/kg         91.2         27.6         10           Cyclohexane         296         mg/kg         91.2         26.3         10           2-Methylhexane         124         mg/kg         91.2         21.2         10           Benzene         90.0         J         mg/kg         91.2         23.1         10           2,3-Dimethylpentane         58.7         J         mg/kg         91.2         23.1         10           Thiophene         ND         mg/kg         91.2         23.7         10           3-Methylhexane         163         mg/kg         91.2         24.0         10	n-Hexane	130		mg/kg	91.2	26.6	10
2,2-Dimethylpentane       ND       mg/kg       91.2       23.6       10         Methylcyclopentane       157       mg/kg       91.2       27.7       10         2,4-Dimethylpentane       ND       mg/kg       91.2       23.9       10         1,2-Dichloroethane       ND       mg/kg       91.2       27.6       10         Cyclohexane       296       mg/kg       91.2       26.3       10         2-Methylhexane       124       mg/kg       91.2       21.2       10         Benzene       90.0       J       mg/kg       91.2       19.7       10         2,3-Dimethylpentane       58.7       J       mg/kg       91.2       23.1       10         Thiophene       ND       mg/kg       91.2       23.7       10         3-Methylhexane       163       mg/kg       91.2       24.0       10	Isopropyl Ether	ND		mg/kg	91.2	25.0	10
Methylcyclopentane       157       mg/kg       91.2       27.7       10         2,4-Dimethylpentane       ND       mg/kg       91.2       23.9       10         1,2-Dichloroethane       ND       mg/kg       91.2       27.6       10         Cyclohexane       296       mg/kg       91.2       26.3       10         2-Methylhexane       124       mg/kg       91.2       21.2       10         Benzene       90.0       J       mg/kg       91.2       19.7       10         2,3-Dimethylpentane       58.7       J       mg/kg       91.2       23.1       10         Thiophene       ND       mg/kg       91.2       23.7       10         3-Methylhexane       163       mg/kg       91.2       24.0       10	Ethyl-Tert-Butyl-Ether	ND		mg/kg	91.2	23.8	10
2,4-Dimethylpentane       ND       mg/kg       91.2       23.9       10         1,2-Dichloroethane       ND       mg/kg       91.2       27.6       10         Cyclohexane       296       mg/kg       91.2       26.3       10         2-Methylhexane       124       mg/kg       91.2       21.2       10         Benzene       90.0       J       mg/kg       91.2       19.7       10         2,3-Dimethylpentane       58.7       J       mg/kg       91.2       23.1       10         Thiophene       ND       mg/kg       91.2       23.7       10         3-Methylhexane       163       mg/kg       91.2       24.0       10	2,2-Dimethylpentane	ND		mg/kg	91.2	23.6	10
1,2-Dichloroethane     ND     mg/kg     91.2     27.6     10       Cyclohexane     296     mg/kg     91.2     26.3     10       2-Methylhexane     124     mg/kg     91.2     21.2     10       Benzene     90.0     J     mg/kg     91.2     19.7     10       2,3-Dimethylpentane     58.7     J     mg/kg     91.2     23.1     10       Thiophene     ND     mg/kg     91.2     23.7     10       3-Methylhexane     163     mg/kg     91.2     24.0     10	Methylcyclopentane	157		mg/kg	91.2	27.7	10
Cyclohexane         296         mg/kg         91.2         26.3         10           2-Methylhexane         124         mg/kg         91.2         21.2         10           Benzene         90.0         J         mg/kg         91.2         19.7         10           2,3-Dimethylpentane         58.7         J         mg/kg         91.2         23.1         10           Thiophene         ND         mg/kg         91.2         23.7         10           3-Methylhexane         163         mg/kg         91.2         24.0         10	2,4-Dimethylpentane	ND		mg/kg	91.2	23.9	10
2-Methylhexane     124     mg/kg     91.2     21.2     10       Benzene     90.0     J     mg/kg     91.2     19.7     10       2,3-Dimethylpentane     58.7     J     mg/kg     91.2     23.1     10       Thiophene     ND     mg/kg     91.2     23.7     10       3-Methylhexane     163     mg/kg     91.2     24.0     10	1,2-Dichloroethane	ND		mg/kg	91.2	27.6	10
Benzene         90.0         J         mg/kg         91.2         19.7         10           2,3-Dimethylpentane         58.7         J         mg/kg         91.2         23.1         10           Thiophene         ND         mg/kg         91.2         23.7         10           3-Methylhexane         163         mg/kg         91.2         24.0         10	Cyclohexane	296		mg/kg	91.2	26.3	10
2,3-Dimethylpentane       58.7       J       mg/kg       91.2       23.1       10         Thiophene       ND       mg/kg       91.2       23.7       10         3-Methylhexane       163       mg/kg       91.2       24.0       10	2-Methylhexane	124		mg/kg	91.2	21.2	10
Thiophene         ND         mg/kg         91.2         23.7         10           3-Methylhexane         163         mg/kg         91.2         24.0         10	Benzene	90.0	J	mg/kg	91.2	19.7	10
3-Methylhexane 163 mg/kg 91.2 24.0 10	2,3-Dimethylpentane	58.7	J	mg/kg	91.2	23.1	10
	Thiophene	ND		mg/kg	91.2	23.7	10
	3-Methylhexane	163		mg/kg	91.2	24.0	10
Tertiary-Amyl Methyl Ether ND mg/kg 91.2 24.1 10	Tertiary-Amyl Methyl Ether	ND		mg/kg	91.2	24.1	10
1-Heptene/1,2-DMCP (trans) 163 J mg/kg 182 55.9 10	1-Heptene/1,2-DMCP (trans)	163	J	mg/kg	182	55.9	10



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-13 D Date Collected: 07/26/22 00:00

Client ID: ROAD DIESEL Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - M	/lansfield Lab					
Isooctane	23.8	J	mg/kg	91.2	21.3	10
Heptane	330	•	mg/kg	91.2	25.0	10
Methylcyclohexane	1050		mg/kg	91.2	19.4	10
2,5-Dimethylhexane	43.0	J	mg/kg	91.2	21.8	10
2,4-Dimethylhexane	57.6	J	mg/kg	91.2	21.5	10
2,2,3-Trimethylpentane	ND	•	mg/kg	91.2	22.8	10
2,3,4-Trimethylpentane	21.6	J	mg/kg	91.2	20.9	10
2,3,3-Trimethylpentane	18.7	J	mg/kg	91.2	20.0	10
2,3-Dimethylhexane	57.4	J	mg/kg	91.2	22.1	10
2-Methylheptane	420	<u> </u>	mg/kg	91.2	21.1	10
3-Methylheptane	340		mg/kg	91.2	27.4	10
3-Ethylhexane	76.3	J		91.2	23.3	10
Toluene	674	J	mg/kg	91.2	13.2	10
2-Methylthiophene	ND		mg/kg	91.2	13.6	10
3-Methylthiophene	ND		mg/kg	91.2	14.0	10
	ND		mg/kg	228		10
1-Octene			mg/kg		13.9	
Octane	1010 ND		mg/kg	91.2	19.3	10
1,2-Dibromoethane			mg/kg		14.6	
Ethylbenzene	1600		mg/kg	91.2	9.84	10
2-Ethylthiophene	ND		mg/kg	91.2	9.98	10
p/m-Xylene	7880		mg/kg	182	25.6	10
1-Nonene	ND		mg/kg	228	9.44	10
Nonane (C9)	3770		mg/kg	91.2	19.9	10
Styrene	ND		mg/kg	91.2	12.6	10
o-Xylene	3750		mg/kg	91.2	14.0	10
Isopropylbenzene	364		mg/kg	91.2	15.2	10
n-Propylbenzene	1510		mg/kg	91.2	17.2	10
1-Methyl-3-Ethylbenzene	6570		mg/kg	91.2	14.6	10
1-Methyl-4-Ethylbenzene	2640		mg/kg	91.2	16.6	10
1,3,5-Trimethylbenzene	3260		mg/kg	91.2	17.3	10
1-Decene	ND		mg/kg	91.2	12.7	10
1-Methyl-2-Ethylbenzene	2150		mg/kg	91.2	18.6	10
Decane (C10)	5360		mg/kg	91.2	13.9	10
1,2,4-Trimethylbenzene	11100	Е	mg/kg	91.2	19.9	10
sec-Butylbenzene	382		mg/kg	91.2	18.4	10
1-Methyl-3-Isopropylbenzene	650		mg/kg	91.2	17.1	10
1-Methyl-4-Isopropylbenzene	281		mg/kg	91.2	20.9	10



09/08/22

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

L2240634-13

**SAMPLE RESULTS** 

Date Collected: 07/26/22 00:00

Report Date:

Client ID: ROAD DIESEL Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

D

Sample Depth:

Lab ID:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - M	Mansfield Lab					
1-Methyl-2-Isopropylbenzene	60.7	J	mg/kg	91.2	25.0	10
Indane	2010		mg/kg	91.2	21.1	10
1-Methyl-3-N-Propylbenzene	2450		mg/kg	91.2	20.1	10
1-Methyl-4-N-Propylbenzene	1060		mg/kg	91.2	21.4	10
n-Butylbenzene	812		mg/kg	91.2	22.8	10
1,2-Dimethyl-4-Ethylbenzene	2500		mg/kg	91.2	22.2	10
1,2-Diethylbenzene	216		mg/kg	91.2	21.1	10
1-Methyl-2-N-Propylbenzene	884		mg/kg	91.2	18.6	10
1,4-Dimethyl-2-Ethylbenzene	1920		mg/kg	91.2	20.3	10
Undecane	5260		mg/kg	91.2	32.2	10
1,3-Dimethyl-4-Ethylbenzene	1610		mg/kg	91.2	19.5	10
1,3-Dimethyl-5-Ethylbenzene	2820		mg/kg	91.2	22.2	10
1,3-Dimethyl-2-Ethylbenzene	221		mg/kg	91.2	21.6	10
1,2-Dimethyl-3-Ethylbenzene	696		mg/kg	91.2	19.8	10
1,2,4,5-Tetramethylbenzene	1580		mg/kg	91.2	20.6	10
N-Pentylbenzene	476		mg/kg	91.2	18.0	10
Dodecane (C12)	5520		mg/kg	228	40.0	10
Naphthalene	560		mg/kg	91.2	38.0	10
Benzothiophene	ND		mg/kg	91.2	48.1	10
MMT	ND		mg/kg	228	58.6	10
Tridecane	6510		mg/kg	228	59.1	10
2-Methylnaphthalene	1650		mg/kg	228	60.2	10
1-Methylnaphthalene	896		mg/kg	228	66.9	10

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	121		70-130	
Toluene-d8	112		70-130	
4-Bromofluorobenzene	96		70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-25 D Date Collected: 07/26/22 00:00

Client ID: BUNKER C Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/05/22 14:03

Analyst: RY

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - Ma	nsfield Lab					
Isopentane	ND		mg/kg	36.7	13.7	4
1-Pentene	ND		mg/kg	36.7	11.3	4
2-Methyl-1-Butene	ND		mg/kg	36.7	12.0	4
Pentane	ND		mg/kg	36.7	11.4	4
trans-2-Pentene	ND		mg/kg	36.7	12.9	4
cis-2-Pentene	ND		mg/kg	36.7	9.60	4
Tertiary Butanol	ND		mg/kg	458	148.	4
Cyclopentane	ND		mg/kg	36.7	9.51	4
2,3-Dimethylbutane	ND		mg/kg	36.7	15.1	4
2-Methylpentane	ND		mg/kg	36.7	11.8	4
Methyl tert butyl ether	ND		mg/kg	36.7	11.4	4
3-Methylpentane	ND		mg/kg	36.7	7.11	4
1-Hexene	ND		mg/kg	36.7	10.5	4
n-Hexane	6.82	JB	mg/kg	36.7	10.7	4
Isopropyl Ether	ND		mg/kg	36.7	10.1	4
Ethyl-Tert-Butyl-Ether	ND		mg/kg	36.7	9.56	4
2,2-Dimethylpentane	ND		mg/kg	36.7	9.49	4
Methylcyclopentane	ND		mg/kg	36.7	11.1	4
2,4-Dimethylpentane	ND		mg/kg	36.7	9.63	4
1,2-Dichloroethane	ND		mg/kg	36.7	11.1	4
Cyclohexane	ND		mg/kg	36.7	10.6	4
2-Methylhexane	ND		mg/kg	36.7	8.54	4
Benzene	11.3	JB	mg/kg	36.7	7.94	4
2,3-Dimethylpentane	ND		mg/kg	36.7	9.28	4
Thiophene	ND		mg/kg	36.7	9.52	4
3-Methylhexane	ND		mg/kg	36.7	9.65	4
Tertiary-Amyl Methyl Ether	ND		mg/kg	36.7	9.70	4
1-Heptene/1,2-DMCP (trans)	ND		mg/kg	73.3	22.5	4



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-25 D Date Collected: 07/26/22 00:00

Client ID: BUNKER C Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - I	Mansfield Lab					
Isooctane	ND		m a/l.a	36.7	8.57	4
Heptane	ND		mg/kg	36.7	10.1	4
Methylcyclohexane	ND		mg/kg	36.7	7.80	4
2,5-Dimethylhexane	ND		mg/kg	36.7	8.77	4
<u>·</u>	ND		mg/kg	36.7		4
2,4-Dimethylhexane			mg/kg		8.65	
2,2,3-Trimethylpentane	ND		mg/kg	36.7	9.18	4
2,3,4-Trimethylpentane	ND		mg/kg	36.7	8.41	4
2,3,3-Trimethylpentane	ND		mg/kg	36.7	8.03	4
2,3-Dimethylhexane	ND		mg/kg	36.7	8.88	4
2-Methylheptane	ND		mg/kg	36.7	8.49	4
3-Methylheptane	ND		mg/kg	36.7	11.0	4
3-Ethylhexane	ND		mg/kg	36.7	9.36	4
Toluene	8.27	J	mg/kg	36.7	5.30	4
2-Methylthiophene	ND		mg/kg	36.7	5.46	4
3-Methylthiophene	ND		mg/kg	36.7	5.65	4
1-Octene	ND		mg/kg	91.6	5.60	4
Octane	6.16	J	mg/kg	36.7	7.76	4
1,2-Dibromoethane	ND		mg/kg	36.7	5.86	4
Ethylbenzene	5.52	J	mg/kg	36.7	3.96	4
2-Ethylthiophene	ND		mg/kg	36.7	4.01	4
p/m-Xylene	23.0	J	mg/kg	73.3	10.3	4
1-Nonene	ND		mg/kg	91.6	3.80	4
Nonane (C9)	25.2	J	mg/kg	36.7	8.02	4
Styrene	ND		mg/kg	36.7	5.09	4
o-Xylene	12.2	J	mg/kg	36.7	5.63	4
Isopropylbenzene	3.41	J	mg/kg	36.7	6.12	4
n-Propylbenzene	12.0	J	mg/kg	36.7	6.92	4
1-Methyl-3-Ethylbenzene	45.9		mg/kg	36.7	5.88	4
1-Methyl-4-Ethylbenzene	22.1	J	mg/kg	36.7	6.67	4
1,3,5-Trimethylbenzene	39.7		mg/kg	36.7	6.97	4
1-Decene	ND		mg/kg	36.7	5.09	4
1-Methyl-2-Ethylbenzene	31.4	J	mg/kg	36.7	7.50	4
Decane (C10)	246		mg/kg	36.7	5.60	4
1,2,4-Trimethylbenzene	206		mg/kg	36.7	8.02	4
sec-Butylbenzene	14.4	J	mg/kg	36.7	7.42	4
1-Methyl-3-Isopropylbenzene	24.7	J	mg/kg	36.7	6.89	4
1-Methyl-4-Isopropylbenzene	14.0	J	mg/kg	36.7	8.40	4
,		-	9''\9			



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-25 D Date Collected: 07/26/22 00:00

Client ID: BUNKER C Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS	6 - Mansfield Lab					
1-Methyl-2-Isopropylbenzene	3.68	J	mg/kg	36.7	10.0	4
Indane	66.3		mg/kg	36.7	8.48	4
1-Methyl-3-N-Propylbenzene	141		mg/kg	36.7	8.09	4
1-Methyl-4-N-Propylbenzene	70.2			36.7	8.60	4
n-Butylbenzene	58.3		mg/kg	36.7	9.15	4
•			mg/kg			
1,2-Dimethyl-4-Ethylbenzene	170		mg/kg	36.7	8.92	4
1,2-Diethylbenzene	19.6	J	mg/kg	36.7	8.47	4
1-Methyl-2-N-Propylbenzene	82.2		mg/kg	36.7	7.46	4
1,4-Dimethyl-2-Ethylbenzene	174		mg/kg	36.7	8.18	4
Undecane	833		mg/kg	36.7	12.9	4
1,3-Dimethyl-4-Ethylbenzene	176		mg/kg	36.7	7.85	4
1,3-Dimethyl-5-Ethylbenzene	297		mg/kg	36.7	8.91	4
1,3-Dimethyl-2-Ethylbenzene	44.6		mg/kg	36.7	8.69	4
1,2-Dimethyl-3-Ethylbenzene	102		mg/kg	36.7	7.98	4
1,2,4,5-Tetramethylbenzene	204		mg/kg	36.7	8.28	4
N-Pentylbenzene	115		mg/kg	36.7	7.25	4
Dodecane (C12)	765		mg/kg	91.6	16.1	4
Naphthalene	1120		mg/kg	36.7	15.3	4
Benzothiophene	ND		mg/kg	36.7	19.4	4
MMT	ND		mg/kg	91.6	23.6	4
Tridecane	736		mg/kg	91.6	23.8	4
2-Methylnaphthalene	1620		mg/kg	91.6	24.2	4
1-Methylnaphthalene	913		mg/kg	91.6	26.9	4

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	121		70-130	
Toluene-d8	111		70-130	
4-Bromofluorobenzene	94		70-130	



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

Report Date: **Project Number:** Not Specified 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-30 D2 Date Collected: 08/17/22 12:15

JP-5 MEOH (20 MG/ML) Date Received: 08/17/22 Client ID: Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M) 08/20/22 12:00 Analytical Date:

Analyst: RY

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC	C/MS - Mansfield Lab						
Decane (C10)	2480000		mg/kg	33300	5090	80	
Undecane	3040000		mg/kg	33300	11800	80	
Dodecane (C12)	2140000		mg/kg	83300	14600	80	
Tridecane	1850000		mg/kg	83300	21600	80	

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	114		70-130	
Toluene-d8	109		70-130	
4-Bromofluorobenzene	97		70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-30 D Date Collected: 08/17/22 12:15

Client ID: JP-5 MEOH (20 MG/ML) Date Received: 08/17/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/19/22 17:04

Analyst: RY

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - Ma	nsfield Lab					
Isopentane	ND		mg/kg	8330	3100	20
1-Pentene	ND		mg/kg	8330	2580	20
2-Methyl-1-Butene	ND		mg/kg	8330	2740	20
Pentane	ND		mg/kg	8330	2600	20
trans-2-Pentene	ND		mg/kg	8330	2940	20
cis-2-Pentene	ND		mg/kg	8330	2180	20
Tertiary Butanol	ND		mg/kg	104000	33800	20
Cyclopentane	ND		mg/kg	8330	2160	20
2,3-Dimethylbutane	ND		mg/kg	8330	3440	20
2-Methylpentane	ND		mg/kg	8330	2680	20
Methyl tert butyl ether	ND		mg/kg	8330	2590	20
3-Methylpentane	ND		mg/kg	8330	1620	20
1-Hexene	ND		mg/kg	8330	2390	20
n-Hexane	1390	J	mg/kg	8330	2430	20
Isopropyl Ether	ND		mg/kg	8330	2290	20
Ethyl-Tert-Butyl-Ether	ND		mg/kg	8330	2170	20
2,2-Dimethylpentane	ND		mg/kg	8330	2160	20
Methylcyclopentane	ND		mg/kg	8330	2530	20
2,4-Dimethylpentane	ND		mg/kg	8330	2190	20
1,2-Dichloroethane	ND		mg/kg	8330	2520	20
Cyclohexane	996	J	mg/kg	8330	2400	20
2-Methylhexane	ND		mg/kg	8330	1940	20
Benzene	1640	J	mg/kg	8330	1800	20
2,3-Dimethylpentane	ND		mg/kg	8330	2110	20
Thiophene	ND		mg/kg	8330	2160	20
3-Methylhexane	1900	J	mg/kg	8330	2190	20
Tertiary-Amyl Methyl Ether	ND		mg/kg	8330	2200	20
1-Heptene/1,2-DMCP (trans)	3680	J	mg/kg	16700	5110	20



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-30 D Date Collected: 08/17/22 12:15

Client ID: JP-5 MEOH (20 MG/ML) Date Received: 08/17/22 Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/M	IS - Mansfield Lab					
Isooctane	ND		mg/kg	8330	1950	20
Heptane	8810		mg/kg	8330	2290	20
Methylcyclohexane	19100		mg/kg	8330	1770	20
2,5-Dimethylhexane	892	J	mg/kg	8330	1990	20
2,4-Dimethylhexane	1140	J	mg/kg	8330	1970	20
2,2,3-Trimethylpentane	ND		mg/kg	8330	2080	20
2,3,4-Trimethylpentane	ND		mg/kg	8330	1910	20
2,3,3-Trimethylpentane	ND		mg/kg	8330	1820	20
2,3-Dimethylhexane	2090	J	mg/kg	8330	2020	20
2-Methylheptane	19200		mg/kg	8330	1930	20
3-Methylheptane	14400		mg/kg	8330	2500	20
3-Ethylhexane	1950	J	mg/kg	8330	2130	20
Toluene	10500		mg/kg	8330	1200	20
2-Methylthiophene	ND		mg/kg	8330	1240	20
3-Methylthiophene	ND		mg/kg	8330	1280	20
1-Octene	ND		mg/kg	20800	1270	20
Octane	71000		mg/kg	8330	1760	20
1,2-Dibromoethane	ND		mg/kg	8330	1330	20
Ethylbenzene	20500		mg/kg	8330	900.	20
2-Ethylthiophene	ND		mg/kg	8330	912.	20
p/m-Xylene	69900		mg/kg	16700	2340	20
1-Nonene	ND		mg/kg	20800	863.	20
Nonane (C9)	333000		mg/kg	8330	1820	20
Styrene	ND		mg/kg	8330	1160	20
o-Xylene	33900		mg/kg	8330	1280	20
Isopropylbenzene	14500		mg/kg	8330	1390	20
n-Propylbenzene	33700		mg/kg	8330	1570	20
1-Methyl-3-Ethylbenzene	84100		mg/kg	8330	1340	20
1-Methyl-4-Ethylbenzene	41100		mg/kg	8330	1520	20
1,3,5-Trimethylbenzene	76800		mg/kg	8330	1580	20
1-Decene	ND		mg/kg	8330	1160	20
1-Methyl-2-Ethylbenzene	44600		mg/kg	8330	1700	20
Decane (C10)	1560000	E	mg/kg	8330	1270	20
1,2,4-Trimethylbenzene	302000		mg/kg	8330	1820	20
sec-Butylbenzene	38300		mg/kg	8330	1690	20
1-Methyl-3-Isopropylbenzene	63500		mg/kg	8330	1570	20
1-Methyl-4-Isopropylbenzene	50800		mg/kg	8330	1910	20



09/08/22

**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified

L2240634-30

**SAMPLE RESULTS** 

Date Collected: 08/17/22 12:15

Report Date:

JP-5 MEOH (20 MG/ML) Date Received: 08/17/22 Client ID:

Sample Location: Not Specified Field Prep: Not Specified

D

Sample Depth:

Lab ID:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - Ma	nsfield Lab					
1-Methyl-2-Isopropylbenzene	9750		mg/kg	8330	2290	20
Indane	15800		mg/kg	8330	1930	20
1-Methyl-3-N-Propylbenzene	164000		mg/kg	8330	1840	20
1-Methyl-4-N-Propylbenzene	73400		mg/kg	8330	1960	20
n-Butylbenzene	77000		mg/kg	8330	2080	20
1,2-Dimethyl-4-Ethylbenzene	134000		mg/kg	8330	2030	20
1,2-Diethylbenzene	18300		mg/kg	8330	1920	20
1-Methyl-2-N-Propylbenzene	78100		mg/kg	8330	1700	20
1,4-Dimethyl-2-Ethylbenzene	95700		mg/kg	8330	1860	20
Undecane	2040000	E	mg/kg	8330	2940	20
1,3-Dimethyl-4-Ethylbenzene	108000		mg/kg	8330	1780	20
1,3-Dimethyl-5-Ethylbenzene	155000		mg/kg	8330	2030	20
1,3-Dimethyl-2-Ethylbenzene	20000		mg/kg	8330	1980	20
1,2-Dimethyl-3-Ethylbenzene	62700		mg/kg	8330	1820	20
1,2,4,5-Tetramethylbenzene	86500		mg/kg	8330	1880	20
N-Pentylbenzene	27500		mg/kg	8330	1650	20
Dodecane (C12)	1890000	E	mg/kg	20800	3660	20
Naphthalene	145000		mg/kg	8330	3470	20
Benzothiophene	ND		mg/kg	8330	4400	20
MMT	ND		mg/kg	20800	5350	20
Tridecane	2100000	E	mg/kg	20800	5400	20
2-Methylnaphthalene	287000		mg/kg	20800	5500	20
1-Methylnaphthalene	200000		mg/kg	20800	6110	20

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	126		70-130	
Toluene-d8	113		70-130	
4-Bromofluorobenzene	91		70-130	



09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-31 D2 Date Collected: 08/17/22 12:15

Client ID: JP-8 MEOH (20 MG/ML) Date Received: 08/17/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M)
Analytical Date: 08/20/22 13:13

Analyst: RY

Parameter	Result	Qualifier Units RL		RL	MDL	Dilution Factor	
PIANO Volatile Organics by GC/MS - Mansfield Lab							
Names (CO)	70000			47400	2000	00	
Nonane (C9)	790000		mg/kg	17400	3800	80	
Decane (C10)	718000		mg/kg	17400	2650	80	
Undecane	552000		mg/kg	17400	6140	80	
Dodecane (C12)	444000		mg/kg	43500	7630	80	
Tridecane	403000		mg/kg	43500	11300	80	

Surrogate	% Recovery	Acceptance Qualifier Criteria	
Dibromofluoromethane	115	70-130	
Toluene-d8	109	70-130	
4-Bromofluorobenzene	96	70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-31 D Date Collected: 08/17/22 12:15

Client ID: JP-8 MEOH (20 MG/ML) Date Received: 08/17/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M) Analytical Date: 08/19/22 18:15

Analyst: RY

PIANO Volatile Organics by GC/MS - Mansfield  Isopentane 1-Pentene 2-Methyl-1-Butene Pentane trans-2-Pentene cis-2-Pentene Tertiary Butanol	ND N		mg/kg mg/kg mg/kg mg/kg mg/kg mg/kg mg/kg mg/kg	4350 4350 4350 4350 4350 4350 54300 4350	1620 1340 1430 1350 1530 1140 17600	20 20 20 20 20 20 20 20 20
1-Pentene 2-Methyl-1-Butene Pentane trans-2-Pentene cis-2-Pentene	ND		mg/kg mg/kg mg/kg mg/kg mg/kg mg/kg	4350 4350 4350 4350 4350 54300 4350	1340 1430 1350 1530 1140 17600	20 20 20 20 20 20 20
2-Methyl-1-Butene Pentane trans-2-Pentene cis-2-Pentene	ND		mg/kg mg/kg mg/kg mg/kg mg/kg	4350 4350 4350 4350 54300 4350	1430 1350 1530 1140 17600	20 20 20 20 20 20
Pentane trans-2-Pentene cis-2-Pentene	ND ND ND ND ND ND ND ND		mg/kg mg/kg mg/kg mg/kg mg/kg	4350 4350 4350 54300 4350	1350 1530 1140 17600	20 20 20 20
trans-2-Pentene cis-2-Pentene	ND ND ND ND ND		mg/kg mg/kg mg/kg mg/kg	4350 4350 54300 4350	1530 1140 17600	20 20 20
cis-2-Pentene	ND ND ND		mg/kg mg/kg mg/kg	4350 54300 4350	1140 17600	20 20
	ND ND ND		mg/kg mg/kg	54300 4350	17600	20
Tertiany Butanol	ND ND		mg/kg	4350		
remary Butanor	ND				1130	20
Cyclopentane			ma/ka			
2,3-Dimethylbutane	1630		mg/ng	4350	1790	20
2-Methylpentane		J	mg/kg	4350	1400	20
Methyl tert butyl ether	ND		mg/kg	4350	1350	20
3-Methylpentane	1130	J	mg/kg	4350	843.	20
1-Hexene	ND		mg/kg	4350	1250	20
n-Hexane	2500	J	mg/kg	4350	1270	20
Isopropyl Ether	ND		mg/kg	4350	1190	20
Ethyl-Tert-Butyl-Ether	ND		mg/kg	4350	1130	20
2,2-Dimethylpentane	ND		mg/kg	4350	1120	20
Methylcyclopentane	5650		mg/kg	4350	1320	20
2,4-Dimethylpentane	965	J	mg/kg	4350	1140	20
1,2-Dichloroethane	ND		mg/kg	4350	1320	20
Cyclohexane	7060		mg/kg	4350	1250	20
2-Methylhexane	12700		mg/kg	4350	1010	20
Benzene	2810	J	mg/kg	4350	941.	20
2,3-Dimethylpentane	3790	J	mg/kg	4350	1100	20
Thiophene	ND		mg/kg	4350	1130	20
3-Methylhexane 1	12700		mg/kg	4350	1140	20
Tertiary-Amyl Methyl Ether	ND		mg/kg	4350	1150	20
1-Heptene/1,2-DMCP (trans)	13400		mg/kg	8700	2660	20



09/08/22

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified

**SAMPLE RESULTS** 

Date Collected: 08/17/22 12:15

Report Date:

Lab ID: L2240634-31 D JP-8 MEOH (20 MG/ML) Client ID: Date Received: 08/17/22

Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS -	Mansfield Lab					
lacastana	ND			4250	1020	20
Isoacane			mg/kg	4350	1020	20
Heptane	27900		mg/kg	4350	1190	20
Methylcyclohexane	114000		mg/kg	4350	926.	20
2,5-Dimethylhexane	9680		mg/kg	4350	1040	20
2,4-Dimethylhexane	13800		mg/kg	4350	1030	20
2,2,3-Trimethylpentane	ND		mg/kg	4350	1090	20
2,3,4-Trimethylpentane	1310	J	mg/kg	4350	997.	20
2,3,3-Trimethylpentane	670	J	mg/kg	4350	952.	20
2,3-Dimethylhexane	11100		mg/kg	4350	1050	20
2-Methylheptane	85700		mg/kg	4350	1010	20
3-Methylheptane	66400		mg/kg	4350	1310	20
3-Ethylhexane	13600		mg/kg	4350	1110	20
Toluene	66800		mg/kg	4350	629.	20
2-Methylthiophene	ND		mg/kg	4350	647.	20
3-Methylthiophene	ND		mg/kg	4350	670.	20
1-Octene	ND		mg/kg	10900	664.	20
Octane	304000		mg/kg	4350	920.	20
1,2-Dibromoethane	ND		mg/kg	4350	695.	20
Ethylbenzene	117000		mg/kg	4350	469.	20
2-Ethylthiophene	ND		mg/kg	4350	476.	20
p/m-Xylene	575000		mg/kg	8700	1220	20
1-Nonene	ND		mg/kg	10900	450.	20
Nonane (C9)	848000	Е	mg/kg	4350	951.	20
Styrene	ND		mg/kg	4350	603.	20
o-Xylene	229000		mg/kg	4350	668.	20
Isopropylbenzene	32800		mg/kg	4350	726.	20
n-Propylbenzene	86700		mg/kg	4350	820.	20
1-Methyl-3-Ethylbenzene	211000		mg/kg	4350	697.	20
1-Methyl-4-Ethylbenzene	94300		mg/kg	4350	791.	20
1,3,5-Trimethylbenzene	151000		mg/kg	4350	826.	20
1-Decene	ND		mg/kg	4350	604.	20
1-Methyl-2-Ethylbenzene	78100		mg/kg	4350	889.	20
Decane (C10)	754000	E	mg/kg	4350	664.	20
1,2,4-Trimethylbenzene	347000		mg/kg	4350	951.	20
sec-Butylbenzene	20100		mg/kg	4350	880.	20
1-Methyl-3-Isopropylbenzene	32100		mg/kg	4350	818.	20
1-Methyl-4-Isopropylbenzene	22100		mg/kg	4350	997.	20



09/08/22

**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified

**SAMPLE RESULTS** 

Date Collected: 08/17/22 12:15

Report Date:

Lab ID: L2240634-31 D JP-8 MEOH (20 MG/ML) Date Received: 08/17/22 Client ID:

Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS -	Mansfield Lab					
1-Methyl-2-Isopropylbenzene	5000		mg/kg	4350	1190	20
Indane	61800		mg/kg	4350	1010	20
1-Methyl-3-N-Propylbenzene	79600		mg/kg	4350	959.	20
1-Methyl-4-N-Propylbenzene	37900		mg/kg	4350	1020	20
n-Butylbenzene	46600		mg/kg	4350	1080	20
1,2-Dimethyl-4-Ethylbenzene	66800		mg/kg	4350	1060	20
1,2-Diethylbenzene	7870		mg/kg	4350	1000	20
1-Methyl-2-N-Propylbenzene	35500		mg/kg	4350	885.	20
1,4-Dimethyl-2-Ethylbenzene	39300		mg/kg	4350	969.	20
Undecane	530000	E	mg/kg	4350	1530	20
1,3-Dimethyl-4-Ethylbenzene	42400		mg/kg	4350	930.	20
1,3-Dimethyl-5-Ethylbenzene	60200		mg/kg	4350	1060	20
1,3-Dimethyl-2-Ethylbenzene	9450		mg/kg	4350	1030	20
1,2-Dimethyl-3-Ethylbenzene	20000		mg/kg	4350	947.	20
1,2,4,5-Tetramethylbenzene	30000		mg/kg	4350	982.	20
N-Pentylbenzene	37300		mg/kg	4350	860.	20
Dodecane (C12)	480000	Е	mg/kg	10900	1910	20
Naphthalene	88000		mg/kg	4350	1810	20
Benzothiophene	ND		mg/kg	4350	2300	20
MMT	ND		mg/kg	10900	2790	20
Tridecane	494000	E	mg/kg	10900	2820	20
2-Methylnaphthalene	164000		mg/kg	10900	2870	20
1-Methylnaphthalene	102000		mg/kg	10900	3190	20

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	121		70-130	
Toluene-d8	112		70-130	
4-Bromofluorobenzene	94		70-130	



09/08/22

Report Date:

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

**SAMPLE RESULTS** 

Lab ID: L2240634-32 Date Collected: 07/26/22 00:00

Client ID: WASTE OIL (AUTO) Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 1,8260B(M) Analytical Date: 08/20/22 10:48

Analyst: RY

PIANO Volatile Organics by GC/MS - Mansf Isopentane 1-Pentene 2-Methyl-1-Butene Pentane trans-2-Pentene	7.62 ND ND 4.83 0.928	J	mg/kg mg/kg	9.92 9.92	3.70 3.07	1
1-Pentene 2-Methyl-1-Butene Pentane	ND ND 4.83		mg/kg			1
2-Methyl-1-Butene Pentane	ND 4.83			9.92	3.07	
Pentane	4.83				5.07	1
			mg/kg	9.92	3.26	1
trans-2-Pentene	0.928	J	mg/kg	9.92	3.09	1
		J	mg/kg	9.92	3.49	1
cis-2-Pentene	ND		mg/kg	9.92	2.60	1
Tertiary Butanol	ND		mg/kg	124	40.2	1
Cyclopentane	1.88	J	mg/kg	9.92	2.57	1
2,3-Dimethylbutane	5.14	J	mg/kg	9.92	4.09	1
2-Methylpentane	19.8		mg/kg	9.92	3.19	1
Methyl tert butyl ether	28.9		mg/kg	9.92	3.09	1
3-Methylpentane	17.1		mg/kg	9.92	1.92	1
1-Hexene	ND		mg/kg	9.92	2.85	1
n-Hexane	23.8		mg/kg	9.92	2.89	1
Isopropyl Ether	ND		mg/kg	9.92	2.72	1
Ethyl-Tert-Butyl-Ether	ND		mg/kg	9.92	2.59	1
2,2-Dimethylpentane	1.93	J	mg/kg	9.92	2.57	1
Methylcyclopentane	22.0		mg/kg	9.92	3.02	1
2,4-Dimethylpentane	5.18	J	mg/kg	9.92	2.60	1
1,2-Dichloroethane	ND		mg/kg	9.92	3.00	1
Cyclohexane	18.0		mg/kg	9.92	2.86	1
2-Methylhexane	39.6		mg/kg	9.92	2.31	1
Benzene	11.2	В	mg/kg	9.92	2.15	1
2,3-Dimethylpentane	14.3		mg/kg	9.92	2.51	1
Thiophene	ND		mg/kg	9.92	2.58	1
3-Methylhexane	44.4		mg/kg	9.92	2.61	1
Tertiary-Amyl Methyl Ether	24.5		mg/kg	9.92	2.63	1
1-Heptene/1,2-DMCP (trans)	14.1	J	mg/kg	19.8	6.08	1



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-32 Date Collected: 07/26/22 00:00

Client ID: WASTE OIL (AUTO) Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - I	Mansfield Lab					
lanatana	F 04		//	0.00	2.22	4
Isoaca	5.61	J	mg/kg	9.92	2.32	1
Heptane	51.7		mg/kg	9.92	2.72	1
Methylcyclohexane	26.8		mg/kg	9.92	2.11	1
2,5-Dimethylhexane	8.76	J	mg/kg	9.92	2.37	1
2,4-Dimethylhexane	13.2		mg/kg	9.92	2.34	1
2,2,3-Trimethylpentane	1.02	J	mg/kg	9.92	2.48	<u> </u>
2,3,4-Trimethylpentane	6.03	J	mg/kg	9.92	2.27	1
2,3,3-Trimethylpentane	6.70	J	mg/kg	9.92	2.17	1
2,3-Dimethylhexane	11.0		mg/kg	9.92	2.40	1
2-Methylheptane	49.4		mg/kg	9.92	2.30	1
3-Methylheptane	55.7		mg/kg	9.92	2.98	1
3-Ethylhexane	10.5		mg/kg	9.92	2.53	1
Toluene	248		mg/kg	9.92	1.44	1
2-Methylthiophene	ND		mg/kg	9.92	1.48	1
3-Methylthiophene	ND		mg/kg	9.92	1.53	1
1-Octene	ND		mg/kg	24.8	1.51	1
Octane	63.8		mg/kg	9.92	2.10	1
1,2-Dibromoethane	ND		mg/kg	9.92	1.59	1
Ethylbenzene	161		mg/kg	9.92	1.07	1
2-Ethylthiophene	ND		mg/kg	9.92	1.09	1
p/m-Xylene	683		mg/kg	19.8	2.79	1
1-Nonene	ND		mg/kg	24.8	1.03	1
Nonane (C9)	66.4		mg/kg	9.92	2.17	1
Styrene	2.79	J	mg/kg	9.92	1.38	1
o-Xylene	305		mg/kg	9.92	1.52	1
Isopropylbenzene	23.7		mg/kg	9.92	1.66	1
n-Propylbenzene	119		mg/kg	9.92	1.87	1
1-Methyl-3-Ethylbenzene	438		mg/kg	9.92	1.59	1
1-Methyl-4-Ethylbenzene	201		mg/kg	9.92	1.80	1
1,3,5-Trimethylbenzene	237		mg/kg	9.92	1.88	1
1-Decene	ND		mg/kg	9.92	1.38	1
1-Methyl-2-Ethylbenzene	171		mg/kg	9.92	2.03	1
Decane (C10)	42.2		mg/kg	9.92	1.51	1
1,2,4-Trimethylbenzene	880		mg/kg	9.92	2.17	1
sec-Butylbenzene	13.0		mg/kg	9.92	2.01	1
1-Methyl-3-Isopropylbenzene	25.3		mg/kg	9.92	1.86	1
1-Methyl-4-Isopropylbenzene	8.90	J	mg/kg	9.92	2.27	1
, , , , , , ,			<i>۳٬۰۰۰</i>			



09/08/22

**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified

L2240634-32

**SAMPLE RESULTS** 

Date Collected: 07/26/22 00:00

Report Date:

Client ID: Date Received: 07/29/22 WASTE OIL (AUTO)

Field Prep: Sample Location: Not Specified Not Specified

Sample Depth:

Lab ID:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
PIANO Volatile Organics by GC/MS - M	/lansfield Lab					
1-Methyl-2-Isopropylbenzene	2.33	J	mg/kg	9.92	2.72	1
Indane	150		mg/kg	9.92	2.30	1
1-Methyl-3-N-Propylbenzene	166		mg/kg	9.92	2.19	1
1-Methyl-4-N-Propylbenzene	83.0		mg/kg	9.92	2.33	1
n-Butylbenzene	57.6		mg/kg	9.92	2.48	1
1,2-Dimethyl-4-Ethylbenzene	199		mg/kg	9.92	2.41	1
1,2-Diethylbenzene	13.9		mg/kg	9.92	2.29	1
1-Methyl-2-N-Propylbenzene	59.2		mg/kg	9.92	2.02	1
1,4-Dimethyl-2-Ethylbenzene	153		mg/kg	9.92	2.21	1
Undecane	24.3		mg/kg	9.92	3.50	1
1,3-Dimethyl-4-Ethylbenzene	136		mg/kg	9.92	2.12	1
1,3-Dimethyl-5-Ethylbenzene	260		mg/kg	9.92	2.41	1
1,3-Dimethyl-2-Ethylbenzene	16.5		mg/kg	9.92	2.35	1
1,2-Dimethyl-3-Ethylbenzene	61.3		mg/kg	9.92	2.16	1
1,2,4,5-Tetramethylbenzene	179		mg/kg	9.92	2.24	1
N-Pentylbenzene	22.8		mg/kg	9.92	1.96	1
Dodecane (C12)	23.4	J	mg/kg	24.8	4.35	1
Naphthalene	386		mg/kg	9.92	4.14	1
Benzothiophene	ND		mg/kg	9.92	5.24	1
MMT	ND		mg/kg	24.8	6.37	1
Tridecane	24.9		mg/kg	24.8	6.43	1
2-Methylnaphthalene	945		mg/kg	24.8	6.55	1
1-Methylnaphthalene	506		mg/kg	24.8	7.28	1

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
Dibromofluoromethane	115		70-130	
Toluene-d8	112		70-130	
4-Bromofluorobenzene	95		70-130	



Project Number: Not Specified Report Date: 09/08/22

## Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/02/22 17:22

Section   Sect	Parameter	Result	Qualifier	Units	RL	MDL	
1-Pentene		- Mansfield	I Lab for sa	ample(s):	01,04,07,10,	13,22,25	Batch:
2-Methyl-1-Butene         ND         mg/kg         10.0         3.28           Pentane         ND         mg/kg         10.0         3.11           trans-2-Pentene         ND         mg/kg         10.0         3.52           cis-2-Pentene         ND         mg/kg         10.0         2.62           Tertiary Butanol         ND         mg/kg         10.0         2.62           Tertiary Butanol         ND         mg/kg         10.0         2.59           2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methylpentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.22           Methylpentane         ND         mg/kg         10.0         3.21           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,-Dimethylpentane         ND	Isopentane	ND		mg/kg	10.0	3.73	
Pentane         ND         mg/kg         10.0         3.11           trans-2-Pentene         ND         mg/kg         10.0         3.52           cis-2-Pentene         ND         mg/kg         10.0         2.62           Tertiary Butanol         ND         mg/kg         10.0         2.62           Cyclopentane         ND         mg/kg         10.0         2.59           2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methylpentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         3.11           3-Hexane         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND	1-Pentene	ND		mg/kg	10.0	3.09	
trans-2-Pentene         ND         mg/kg         10.0         3.52           cis-2-Pentene         ND         mg/kg         10.0         2.62           Tertiary Butanol         ND         mg/kg         125         40.5           Cyclopentane         ND         mg/kg         10.0         2.59           2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methylpentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         2.87           1-Hexane         ND         mg/kg         10.0         2.87           1-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         <	2-Methyl-1-Butene	ND		mg/kg	10.0	3.28	
cis-2-Pentene         ND         mg/kg         10.0         2.62           Tertiary Butanol         ND         mg/kg         125         40.5           Cyclopentane         ND         mg/kg         10.0         2.59           2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methylpentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.03           Cyclohexane         ND	Pentane	ND		mg/kg	10.0	3.11	
Tertiary Butanol         ND         mg/kg         125         40.5           Cyclopentane         ND         mg/kg         10.0         2.59           2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methyl pentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.87           lsopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         2.33           Benzene         1,58	trans-2-Pentene	ND		mg/kg	10.0	3.52	
Cyclopentane         ND         mg/kg         10.0         2.59           2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methyl pentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1,58	cis-2-Pentene	ND		mg/kg	10.0	2.62	
2,3-Dimethylbutane         ND         mg/kg         10.0         4.13           2-Methyl pentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methyl pentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J mg/kg         10.0         2.53           Thiophene         ND         mg/kg <t< td=""><td>Tertiary Butanol</td><td>ND</td><td></td><td>mg/kg</td><td>125</td><td>40.5</td><td></td></t<>	Tertiary Butanol	ND		mg/kg	125	40.5	
2-Methyl pentane         ND         mg/kg         10.0         3.22           Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methyl pentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         <	Cyclopentane	ND		mg/kg	10.0	2.59	
Methyl tert butyl ether         ND         mg/kg         10.0         3.11           3-Methylpentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND	2,3-Dimethylbutane	ND		mg/kg	10.0	4.13	
3-Methylpentane         ND         mg/kg         10.0         1.94           1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND </td <td>2-Methylpentane</td> <td>ND</td> <td></td> <td>mg/kg</td> <td>10.0</td> <td>3.22</td> <td></td>	2-Methylpentane	ND		mg/kg	10.0	3.22	
1-Hexene         ND         mg/kg         10.0         2.87           n-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND	Methyl tert butyl ether	ND		mg/kg	10.0	3.11	
n-Hexane         2.60         J         mg/kg         10.0         2.91           Isopropyl Ether         ND         mg/kg         10.0         2.74           Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans) <td< td=""><td>3-Methylpentane</td><td>ND</td><td></td><td>mg/kg</td><td>10.0</td><td>1.94</td><td></td></td<>	3-Methylpentane	ND		mg/kg	10.0	1.94	
Sopropyl Ether	1-Hexene	ND		mg/kg	10.0	2.87	
Ethyl-Tert-Butyl-Ether         ND         mg/kg         10.0         2.61           2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.16           2,3-Dimethylpentane         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	n-Hexane	2.60	J	mg/kg	10.0	2.91	
2,2-Dimethylpentane         ND         mg/kg         10.0         2.59           Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.16           2,3-Dimethylpentane         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	Isopropyl Ether	ND		mg/kg	10.0	2.74	
Methylcyclopentane         ND         mg/kg         10.0         3.04           2,4-Dimethylpentane         ND         mg/kg         10.0         2.62           1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.16           2,3-Dimethylpentane         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	Ethyl-Tert-Butyl-Ether	ND		mg/kg	10.0	2.61	
2,4-Dimethylpentane       ND       mg/kg       10.0       2.62         1,2-Dichloroethane       ND       mg/kg       10.0       3.03         Cyclohexane       ND       mg/kg       10.0       2.89         2-Methylhexane       ND       mg/kg       10.0       2.33         Benzene       1.58       J       mg/kg       10.0       2.16         2,3-Dimethylpentane       ND       mg/kg       10.0       2.53         Thiophene       ND       mg/kg       10.0       2.60         3-Methylhexane       ND       mg/kg       10.0       2.63         Tertiary-Amyl Methyl Ether       ND       mg/kg       10.0       2.65         1-Heptene/1,2-DMCP (trans)       ND       mg/kg       20.0       6.13	2,2-Dimethylpentane	ND		mg/kg	10.0	2.59	
1,2-Dichloroethane         ND         mg/kg         10.0         3.03           Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.16           2,3-Dimethylpentane         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	Methylcyclopentane	ND		mg/kg	10.0	3.04	
Cyclohexane         ND         mg/kg         10.0         2.89           2-Methylhexane         ND         mg/kg         10.0         2.33           Benzene         1.58         J         mg/kg         10.0         2.16           2,3-Dimethylpentane         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	2,4-Dimethylpentane	ND		mg/kg	10.0	2.62	
2-Methylhexane       ND       mg/kg       10.0       2.33         Benzene       1.58       J       mg/kg       10.0       2.16         2,3-Dimethylpentane       ND       mg/kg       10.0       2.53         Thiophene       ND       mg/kg       10.0       2.60         3-Methylhexane       ND       mg/kg       10.0       2.63         Tertiary-Amyl Methyl Ether       ND       mg/kg       10.0       2.65         1-Heptene/1,2-DMCP (trans)       ND       mg/kg       20.0       6.13	1,2-Dichloroethane	ND		mg/kg	10.0	3.03	
Benzene         1.58         J         mg/kg         10.0         2.16           2,3-Dimethylpentane         ND         mg/kg         10.0         2.53           Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	Cyclohexane	ND		mg/kg	10.0	2.89	
2,3-Dimethylpentane       ND       mg/kg       10.0       2.53         Thiophene       ND       mg/kg       10.0       2.60         3-Methylhexane       ND       mg/kg       10.0       2.63         Tertiary-Amyl Methyl Ether       ND       mg/kg       10.0       2.65         1-Heptene/1,2-DMCP (trans)       ND       mg/kg       20.0       6.13	2-Methylhexane	ND		mg/kg	10.0	2.33	
Thiophene         ND         mg/kg         10.0         2.60           3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	Benzene	1.58	J	mg/kg	10.0	2.16	
3-Methylhexane         ND         mg/kg         10.0         2.63           Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	2,3-Dimethylpentane	ND		mg/kg	10.0	2.53	
Tertiary-Amyl Methyl Ether         ND         mg/kg         10.0         2.65           1-Heptene/1,2-DMCP (trans)         ND         mg/kg         20.0         6.13	Thiophene	ND		mg/kg	10.0	2.60	
1-Heptene/1,2-DMCP (trans) ND mg/kg 20.0 6.13	3-Methylhexane	ND		mg/kg	10.0	2.63	
	Tertiary-Amyl Methyl Ether	ND		mg/kg	10.0	2.65	
Isooctane ND mg/kg 10.0 2.34	1-Heptene/1,2-DMCP (trans)	ND		mg/kg	20.0	6.13	
	Isooctane	ND		mg/kg	10.0	2.34	



Project Number: Not Specified Report Date: 09/08/22

## Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/02/22 17:22

Parameter	Result	Qualifier	Units	RL	MDL	
PIANO Volatile Organics by GC/MS WG1671854-6	- Mansfield	Lab for sa	mple(s):	01,04,07,10,1	13,22,25	Batch:
Heptane	ND		mg/kg	10.0	2.74	
Methylcyclohexane	ND		mg/kg	10.0	2.13	
2,5-Dimethylhexane	ND		mg/kg	10.0	2.39	
2,4-Dimethylhexane	ND		mg/kg	10.0	2.36	
2,2,3-Trimethylpentane	ND		mg/kg	10.0	2.50	
2,3,4-Trimethylpentane	ND		mg/kg	10.0	2.29	
2,3,3-Trimethylpentane	ND		mg/kg	10.0	2.19	
2,3-Dimethylhexane	ND		mg/kg	10.0	2.42	
2-Methylheptane	ND		mg/kg	10.0	2.32	
3-Methylheptane	ND		mg/kg	10.0	3.00	
3-Ethylhexane	ND		mg/kg	10.0	2.55	
Toluene	ND		mg/kg	10.0	1.45	
2-Methylthiophene	ND		mg/kg	10.0	1.49	
3-Methylthiophene	ND		mg/kg	10.0	1.54	
1-Octene	ND		mg/kg	25.0	1.53	
Octane	ND		mg/kg	10.0	2.12	
1,2-Dibromoethane	ND		mg/kg	10.0	1.60	
Ethylbenzene	ND		mg/kg	10.0	1.08	
2-Ethylthiophene	ND		mg/kg	10.0	1.09	
p/m-Xylene	ND		mg/kg	20.0	2.81	
1-Nonene	ND		mg/kg	25.0	1.04	
Nonane (C9)	ND		mg/kg	10.0	2.19	
Styrene	ND		mg/kg	10.0	1.39	
o-Xylene	ND		mg/kg	10.0	1.54	
Isopropylbenzene	ND		mg/kg	10.0	1.67	
n-Propylbenzene	ND		mg/kg	10.0	1.89	
1-Methyl-3-Ethylbenzene	ND		mg/kg	10.0	1.60	
1-Methyl-4-Ethylbenzene	ND		mg/kg	10.0	1.82	
1,3,5-Trimethylbenzene	ND		mg/kg	10.0	1.90	



Project Number: Not Specified Report Date: 09/08/22

## Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/02/22 17:22

Parameter	Result	Qualifier	Units	RL	MDL	
PIANO Volatile Organics by GC/MS WG1671854-6	- Mansfield	Lab for sa	imple(s):	01,04,07,10,	13,22,25	Batch:
1-Decene	ND		mg/kg	10.0	1.39	
1-Methyl-2-Ethylbenzene	ND		mg/kg	10.0	2.04	
Decane (C10)	ND		mg/kg	10.0	1.53	
1,2,4-Trimethylbenzene	ND		mg/kg	10.0	2.19	
sec-Butylbenzene	ND		mg/kg	10.0	2.02	
1-Methyl-3-Isopropylbenzene	ND		mg/kg	10.0	1.88	
1-Methyl-4-Isopropylbenzene	ND		mg/kg	10.0	2.29	
1-Methyl-2-Isopropylbenzene	ND		mg/kg	10.0	2.74	
Indane	ND		mg/kg	10.0	2.31	
1-Methyl-3-N-Propylbenzene	ND		mg/kg	10.0	2.20	
1-Methyl-4-N-Propylbenzene	ND		mg/kg	10.0	2.35	
n-Butylbenzene	ND		mg/kg	10.0	2.50	
1,2-Dimethyl-4-Ethylbenzene	ND		mg/kg	10.0	2.43	
1,2-Diethylbenzene	ND		mg/kg	10.0	2.31	
1-Methyl-2-N-Propylbenzene	ND		mg/kg	10.0	2.04	
1,4-Dimethyl-2-Ethylbenzene	ND		mg/kg	10.0	2.23	
Undecane	ND		mg/kg	10.0	3.53	
1,3-Dimethyl-4-Ethylbenzene	ND		mg/kg	10.0	2.14	
1,3-Dimethyl-5-Ethylbenzene	ND		mg/kg	10.0	2.43	
1,3-Dimethyl-2-Ethylbenzene	ND		mg/kg	10.0	2.37	
1,2-Dimethyl-3-Ethylbenzene	ND		mg/kg	10.0	2.18	
1,2,4,5-Tetramethylbenzene	ND		mg/kg	10.0	2.26	
N-Pentylbenzene	ND		mg/kg	10.0	1.98	
Dodecane (C12)	ND		mg/kg	25.0	4.39	
Naphthalene	ND		mg/kg	10.0	4.17	
Benzothiophene	ND		mg/kg	10.0	5.28	
MMT	ND		mg/kg	25.0	6.42	
Tridecane	ND		mg/kg	25.0	6.48	
2-Methylnaphthalene	0.870	J	mg/kg	25.0	6.60	



Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/02/22 17:22

Parameter	Result	Qualifier	Units	RL	MDL	
PIANO Volatile Organics by GC/MS WG1671854-6	- Mansfield	Lab for sa	ample(s):	01,04,07,10,1	3,22,25	Batch:
1-Methylnaphthalene	0.600	J	mg/kg	25.0	7.33	

		Acceptance			
Surrogate	%Recovery	Qualifier Criteria			
Dibromofluoromethane	122	70-130			
Toluene-d8	111	70-130			
4-Bromofluorobenzene	95	70-130			



Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/17/22 04:45

Parameter	Result	Qualifier	Units	RL		MDL	
PIANO Volatile Organics by GC/MS	- Mansfield	Lab for sa	ample(s):	30-32	Batch:	WG1677380-6	
Isopentane	ND		mg/kg	10.0		3.73	
1-Pentene	ND		mg/kg	10.0		3.09	
2-Methyl-1-Butene	ND		mg/kg	10.0		3.28	
Pentane	ND		mg/kg	10.0		3.11	
trans-2-Pentene	ND		mg/kg	10.0		3.52	
cis-2-Pentene	ND		mg/kg	10.0		2.62	
Tertiary Butanol	ND		mg/kg	125		40.5	
Cyclopentane	ND		mg/kg	10.0		2.59	
2,3-Dimethylbutane	ND		mg/kg	10.0		4.13	
2-Methylpentane	ND		mg/kg	10.0		3.22	
Methyl tert butyl ether	ND		mg/kg	10.0		3.11	
3-Methylpentane	ND		mg/kg	10.0		1.94	
1-Hexene	ND		mg/kg	10.0		2.87	
n-Hexane	ND		mg/kg	10.0		2.91	
Isopropyl Ether	ND		mg/kg	10.0		2.74	
Ethyl-Tert-Butyl-Ether	ND		mg/kg	10.0		2.61	
2,2-Dimethylpentane	ND		mg/kg	10.0		2.59	
Methylcyclopentane	ND		mg/kg	10.0		3.04	
2,4-Dimethylpentane	ND		mg/kg	10.0		2.62	
1,2-Dichloroethane	ND		mg/kg	10.0		3.03	
Cyclohexane	ND		mg/kg	10.0		2.89	
2-Methylhexane	ND		mg/kg	10.0		2.33	
Benzene	1.93	J	mg/kg	10.0		2.16	
2,3-Dimethylpentane	ND		mg/kg	10.0		2.53	
Thiophene	ND		mg/kg	10.0		2.60	
3-Methylhexane	ND		mg/kg	10.0		2.63	
Tertiary-Amyl Methyl Ether	ND		mg/kg	10.0		2.65	
1-Heptene/1,2-DMCP (trans)	ND		mg/kg	20.0		6.13	
Isooctane	ND		mg/kg	10.0		2.34	



Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/17/22 04:45

arameter	Result	Qualifier	Units	RL		MDL	
IANO Volatile Organics by G	C/MS - Mansfield	Lab for sa	ample(s):	30-32	Batch:	WG1677380-6	
Heptane	ND		mg/kg	10.0		2.74	
Methylcyclohexane	ND		mg/kg	10.0		2.13	
2,5-Dimethylhexane	ND		mg/kg	10.0		2.39	
2,4-Dimethylhexane	ND		mg/kg	10.0		2.36	
2,2,3-Trimethylpentane	ND		mg/kg	10.0		2.50	
2,3,4-Trimethylpentane	ND		mg/kg	10.0		2.29	
2,3,3-Trimethylpentane	ND		mg/kg	10.0		2.19	
2,3-Dimethylhexane	ND		mg/kg	10.0		2.42	
2-Methylheptane	ND		mg/kg	10.0		2.32	
3-Methylheptane	ND		mg/kg	10.0		3.00	
3-Ethylhexane	ND		mg/kg	10.0		2.55	
Toluene	0.530	J	mg/kg	10.0		1.45	
2-Methylthiophene	ND		mg/kg	10.0		1.49	
3-Methylthiophene	ND		mg/kg	10.0		1.54	
1-Octene	ND		mg/kg	25.0		1.53	
Octane	ND		mg/kg	10.0		2.12	
1,2-Dibromoethane	ND		mg/kg	10.0		1.60	
Ethylbenzene	ND		mg/kg	10.0		1.08	
2-Ethylthiophene	ND		mg/kg	10.0		1.09	
p/m-Xylene	0.680	J	mg/kg	20.0		2.81	
1-Nonene	ND		mg/kg	25.0		1.04	
Nonane (C9)	ND		mg/kg	10.0		2.19	
Styrene	ND		mg/kg	10.0		1.39	
o-Xylene	0.425	J	mg/kg	10.0		1.54	
Isopropylbenzene	ND		mg/kg	10.0		1.67	
n-Propylbenzene	ND		mg/kg	10.0		1.89	
1-Methyl-3-Ethylbenzene	ND		mg/kg	10.0		1.60	
1-Methyl-4-Ethylbenzene	ND		mg/kg	10.0		1.82	
1,3,5-Trimethylbenzene	ND		mg/kg	10.0		1.90	



Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/17/22 04:45

Parameter	Result	Qualifier	Units	RL		MDL	
PIANO Volatile Organics by GC/MS	- Mansfield	Lab for sa	ample(s):	30-32	Batch:	WG1677380-6	
1-Decene	ND		mg/kg	10.0		1.39	
1-Methyl-2-Ethylbenzene	ND		mg/kg	10.0		2.04	
Decane (C10)	1.36	J	mg/kg	10.0		1.53	
1,2,4-Trimethylbenzene	0.295	J	mg/kg	10.0		2.19	
sec-Butylbenzene	ND		mg/kg	10.0		2.02	
1-Methyl-3-Isopropylbenzene	ND		mg/kg	10.0		1.88	
1-Methyl-4-Isopropylbenzene	ND		mg/kg	10.0		2.29	
1-Methyl-2-Isopropylbenzene	ND		mg/kg	10.0		2.74	
Indane	ND		mg/kg	10.0		2.31	
1-Methyl-3-N-Propylbenzene	ND		mg/kg	10.0		2.20	
1-Methyl-4-N-Propylbenzene	ND		mg/kg	10.0		2.35	
n-Butylbenzene	ND		mg/kg	10.0		2.50	
1,2-Dimethyl-4-Ethylbenzene	ND		mg/kg	10.0		2.43	
1,2-Diethylbenzene	ND		mg/kg	10.0		2.31	
1-Methyl-2-N-Propylbenzene	ND		mg/kg	10.0		2.04	
1,4-Dimethyl-2-Ethylbenzene	ND		mg/kg	10.0		2.23	
Undecane	ND		mg/kg	10.0		3.53	
1,3-Dimethyl-4-Ethylbenzene	ND		mg/kg	10.0		2.14	
1,3-Dimethyl-5-Ethylbenzene	ND		mg/kg	10.0		2.43	
1,3-Dimethyl-2-Ethylbenzene	ND		mg/kg	10.0		2.37	
1,2-Dimethyl-3-Ethylbenzene	ND		mg/kg	10.0		2.18	
1,2,4,5-Tetramethylbenzene	ND		mg/kg	10.0		2.26	
N-Pentylbenzene	ND		mg/kg	10.0		1.98	
Dodecane (C12)	ND		mg/kg	25.0		4.39	
Naphthalene	0.750	J	mg/kg	10.0		4.17	
Benzothiophene	ND		mg/kg	10.0		5.28	
MMT	ND		mg/kg	25.0		6.42	
Tridecane	ND		mg/kg	25.0		6.48	
2-Methylnaphthalene	0.760	J	mg/kg	25.0		6.60	



Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 1,8260B(M) Analytical Date: 08/17/22 04:45

Parameter	Result	Qualifier	Units	RL	MDL
PIANO Volatile Organics by GC/MS	- Mansfield	Lab for sa	mple(s):	30-32	Batch: WG1677380-6
1-Methylnaphthalene	0.445	J	mg/kg	25.0	7.33

		Acceptance
Surrogate	%Recovery Qual	ifier Criteria
D'harandharan albara	440	70.400
Dibromofluoromethane	118	70-130
Toluene-d8	110	70-130
4-Bromofluorobenzene	95	70-130



# Lab Control Sample Analysis Batch Quality Control

**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

**Report Date:** 09/08/22

Parameter	LCS %Recovery	Qual	LCSD %Recovery Qu		Recovery Limits	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfi	eld Lab Associa	ated sample(s):	01,04,07,10,13,22,2	5 Batch:	WG1671854-3	WG16718	354-4
1-Pentene	110		118		50-130	7	30
Pentane	92		96		50-130	4	30
Tertiary Butanol	106		106		50-130	0	30
Cyclopentane	91		100		50-130	9	30
2-Methylpentane	95		102		50-130	7	30
Methyl tert butyl ether	90		94		50-130	4	30
3-Methylpentane	98		104		50-130	6	30
1-Hexene	104		109		50-130	5	30
n-Hexane	97		102		50-130	5	30
Isopropyl Ether	94		96		50-130	2	30
Ethyl-Tert-Butyl-Ether	82		74		50-130	10	30
Methylcyclopentane	102		108		50-130	6	30
2,4-Dimethylpentane	96		103		50-130	7	30
Cyclohexane	102		107		50-130	5	30
2-Methylhexane	95		101		50-130	6	30
Benzene	95		98		50-130	3	30
2,3-Dimethylpentane	97		103		50-130	6	30
3-Methylhexane	83		94		50-130	12	30
Tertiary-Amyl Methyl Ether	89		92		50-130	3	30
Isooctane	104		107		50-130	3	30
Heptane	103		109		50-130	6	30
Methylcyclohexane	102		103		50-130	1	30
2-Methylheptane	102		104		50-130	2	30



# Lab Control Sample Analysis Batch Quality Control

**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

**Report Date:** 09/08/22

Parameter	LCS %Recovery	Qual	LCSD %Recovery	Qual	%Recovery Limits	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfi	eld Lab Associa	ated sample(s):	01,04,07,10,1	3,22,25	Batch: WG1671854-3	3 WG1671	854-4
3-Methylheptane	101		103		50-130	2	30
Toluene	96		98		50-130	2	30
Octane	106		106		50-130	0	30
Ethylbenzene	96		99		50-130	3	30
p/m-Xylene	100		102		50-130	2	30
Nonane (C9)	98		97		50-130	1	30
o-Xylene	100		101		50-130	1	30
Isopropylbenzene	101		101		50-130	0	30
n-Propylbenzene	103		103		50-130	0	30
1-Methyl-3-Ethylbenzene	101		101		50-130	0	30
1-Methyl-4-Ethylbenzene	104		104		50-130	0	30
1,3,5-Trimethylbenzene	104		104		50-130	0	30
1-Decene	82		82		50-130	0	30
1-Methyl-2-Ethylbenzene	102		103		50-130	1	30
Decane (C10)	101		102		50-130	1	30
1,2,4-Trimethylbenzene	98		97		50-130	1	30
sec-Butylbenzene	106		105		50-130	1	30
1-Methyl-4-N-Propylbenzene	98		97		50-130	1	30
n-Butylbenzene	99		99		50-130	0	30
1,2-Diethylbenzene	98		97		50-130	1	30
Undecane	83		88		50-130	6	30
N-Pentylbenzene	96		97		50-130	1	30
Dodecane (C12)	91		96		50-130	5	30



# Lab Control Sample Analysis Batch Quality Control

**Project Name:** HAWAII DOH - FINGERPRINTING

Lab Number:

L2240634

Project Number: Not

Not Specified

Report Date:

09/08/22

	LCS	LCSD			%Recovery			RPD		
Parameter	%Recovery	Qual	%Recovery	Qual	Limits	RPD	Qual	Limits		

PIANO Volatile Organics by GC/MS - Mansfield Lab Associated sample(s): 01,04,07,10,13,22,25 Batch: WG1671854-3 WG1671854-4

Surrogate	LCS %Recovery Qua	LCSD I %Recovery Qual	Acceptance Criteria
Dibromofluoromethane	123	123	70-130
Toluene-d8	114	114	70-130
4-Bromofluorobenzene	94	94	70-130



## Lab Control Sample Analysis Batch Quality Control

**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

arameter	LCS %Recovery	Qual	LCSD %Recovery	%Recovery Qual Limits	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfie	eld Lab Associa	ated sample(s):	30-32 Batch	: WG1677380-3 WG167738	30-4	
1-Pentene	94		105	50-130	11	30
Pentane	75		85	50-130	13	30
Tertiary Butanol	101		98	50-130	3	30
Cyclopentane	83		92	50-130	10	30
2-Methylpentane	84		92	50-130	9	30
Methyl tert butyl ether	83		84	50-130	1	30
3-Methylpentane	86		95	50-130	10	30
1-Hexene	93		99	50-130	6	30
n-Hexane	84		92	50-130	9	30
Isopropyl Ether	88		89	50-130	1	30
Ethyl-Tert-Butyl-Ether	78		78	50-130	0	30
Methylcyclopentane	93		101	50-130	8	30
2,4-Dimethylpentane	85		93	50-130	9	30
Cyclohexane	96		102	50-130	6	30
2-Methylhexane	87		95	50-130	9	30
Benzene	92		93	50-130	1	30
2,3-Dimethylpentane	89		96	50-130	8	30
3-Methylhexane	78		85	50-130	9	30
Tertiary-Amyl Methyl Ether	84		84	50-130	0	30
Isooctane	94		100	50-130	6	30
Heptane	94		102	50-130	8	30
Methylcyclohexane	94		96	50-130	2	30
2-Methylheptane	100		104	50-130	4	30



## Lab Control Sample Analysis Batch Quality Control

**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

arameter	LCS %Recovery	Qual	LCSD %Recovery		covery mits RI	PD	Qual	RPD Limits
PIANO Volatile Organics by GC/MS - Mansfi	eld Lab Associa	ated sample(s):	30-32 Bato	ch: WG1677380-3	WG1677380-4			
3-Methylheptane	98		104	50	-130	6		30
Toluene	94		95	50	-130	1		30
Octane	101		106	50	-130	5		30
Ethylbenzene	95		97	50	-130	2		30
p/m-Xylene	100		101	50	-130	1		30
Nonane (C9)	97		101	50	-130	4		30
o-Xylene	99		101	50	-130	2		30
Isopropylbenzene	102		103	50	-130	1		30
n-Propylbenzene	105		106	50	-130	1		30
1-Methyl-3-Ethylbenzene	103		104	50	-130	1		30
1-Methyl-4-Ethylbenzene	106		108	50	-130	2		30
1,3,5-Trimethylbenzene	105		106	50	-130	1		30
1-Decene	81		86	50	-130	6		30
1-Methyl-2-Ethylbenzene	104		106	50	-130	2		30
Decane (C10)	105		110	50	-130	5		30
1,2,4-Trimethylbenzene	99		101	50	-130	2		30
sec-Butylbenzene	110		111	50	-130	1		30
1-Methyl-4-N-Propylbenzene	102		102	50	-130	0		30
n-Butylbenzene	103		104	50	-130	1		30
1,2-Diethylbenzene	102		104	50	-130	2		30
Undecane	96		105	50	-130	9		30
N-Pentylbenzene	101		103	50	-130	2		30
Dodecane (C12)	112		126	50	-130	12		30



#### Lab Control Sample Analysis Batch Quality Control

Project Name: HAWAII DOH - FINGERPRINTING

Lab Number:

L2240634

Project Number: N

Not Specified

Report Date:

09/08/22

LCS LCSD %Recovery RPD Parameter %Recovery Qual %Recovery Qual Limits RPD Qual Limits

PIANO Volatile Organics by GC/MS - Mansfield Lab Associated sample(s): 30-32 Batch: WG1677380-3 WG1677380-4

Surrogate	LCS %Recovery Qua	LCSD al %Recovery Qua	Acceptance al Criteria
Dibromofluoromethane	116	118	70-130
Toluene-d8	110	110	70-130
4-Bromofluorobenzene	96	97	70-130

Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Control Lab Number: L2240634

Parameter	Native Sample	Duplicate Sample	Units	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfield Lab Client ID: GASOLINE 87	Associated sample(s):	01,04,07,10,13,22,25	QC Batch ID:	WG1671854-7	QC Sample: L2240634-01
Isopentane	58500E	58500E	mg/kg	0	30
1-Pentene	2220	2630	mg/kg	17	30
2-Methyl-1-Butene	5550	5450	mg/kg	2	30
Pentane	43500E	43100E	mg/kg	1	30
trans-2-Pentene	6310	6150	mg/kg	3	30
cis-2-Pentene	3660	3870	mg/kg	6	30
Tertiary Butanol	ND	ND	mg/kg	NC	30
Cyclopentane	4880	4990	mg/kg	2	30
2,3-Dimethylbutane	7760	7600	mg/kg	2	30
2-Methylpentane	35800E	35400E	mg/kg	1	30
Methyl tert butyl ether	ND	ND	mg/kg	NC	30
3-Methylpentane	22700E	22400E	mg/kg	1	30
1-Hexene	820	703	mg/kg	15	30
n-Hexane	33300E	33000E	mg/kg	1	30
Isopropyl Ether	ND	ND	mg/kg	NC	30
Ethyl-Tert-Butyl-Ether	ND	ND	mg/kg	NC	30
2,2-Dimethylpentane	1230	1230	mg/kg	0	30
Methylcyclopentane	22200E	21900E	mg/kg	1	30
2,4-Dimethylpentane	4700	4510	mg/kg	4	30
1,2-Dichloroethane	ND	ND	mg/kg	NC	30
Cyclohexane	14600E	14200E	mg/kg	3	30



Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

control Lab Number: L2240634

Parameter	Native Sample	Duplicate Sample	Units	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfield Lal Client ID: GASOLINE 87	Associated sample(s):	01,04,07,10,13,22,25	QC Batch ID:	WG1671854-7	QC Sample: L2240634-01
2-Methylhexane	16200E	16200E	mg/kg	0	30
Benzene	9120	9230	mg/kg	1	30
2,3-Dimethylpentane	7000	6750	mg/kg	4	30
Thiophene	ND	ND	mg/kg	NC	30
3-Methylhexane	15900E	15900E	mg/kg	0	30
Tertiary-Amyl Methyl Ether	ND	ND	mg/kg	NC	30
1-Heptene/1,2-DMCP (trans)	8560	8780	mg/kg	3	30
Isooctane	15100E	15600E	mg/kg	3	30
Heptane	19000E	19800E	mg/kg	4	30
Methylcyclohexane	14900E	15600E	mg/kg	5	30
2,5-Dimethylhexane	3420	3920	mg/kg	14	30
2,4-Dimethylhexane	3390	3640	mg/kg	7	30
2,2,3-Trimethylpentane	1010	1120	mg/kg	10	30
2,3,4-Trimethylpentane	7030	7840	mg/kg	11	30
2,3,3-Trimethylpentane	7790	8830	mg/kg	13	30
2,3-Dimethylhexane	2140	2270	mg/kg	6	30
2-Methylheptane	8310	10300E	mg/kg	21	30
3-Methylheptane	6270	7340	mg/kg	16	30
3-Ethylhexane	1610	1730	mg/kg	7	30
Toluene	54500E	56700E	mg/kg	4	30
2-Methylthiophene	ND	ND	mg/kg	NC	30



Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Control Lab Number: L2240634

Parameter	Native Sample	Duplicate Sample	Units	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfield Lab Client ID: GASOLINE 87	Associated sample(s):	01,04,07,10,13,22,25	QC Batch ID:	WG1671854-7	QC Sample: L2240634-01
3-Methylthiophene	ND	ND	mg/kg	NC	30
1-Octene	ND	ND	mg/kg	NC	30
Octane	9010	10600E	mg/kg	16	30
1,2-Dibromoethane	ND	ND	mg/kg	NC	30
Ethylbenzene	12400E	13600E	mg/kg	9	30
2-Ethylthiophene	ND	ND	mg/kg	NC	30
p/m-Xylene	47000E	52100E	mg/kg	10	30
1-Nonene	ND	ND	mg/kg	NC	30
Nonane (C9)	3940	5100	mg/kg	26	30
Styrene	16.2J	18.8J	mg/kg	NC	30
o-Xylene	17600E	19500E	mg/kg	10	30
Isopropylbenzene	1000	1180	mg/kg	17	30
n-Propylbenzene	3720	4520	mg/kg	19	30
1-Methyl-3-Ethylbenzene	11200E	13600E	mg/kg	19	30
1-Methyl-4-Ethylbenzene	5210	6350	mg/kg	20	30
1,3,5-Trimethylbenzene	5520	6840	mg/kg	21	30
1-Decene	ND	ND	mg/kg	NC	30
1-Methyl-2-Ethylbenzene	4020	4880	mg/kg	19	30
Decane (C10)	2190	2920	mg/kg	29	30
1,2,4-Trimethylbenzene	17900E	21700E	mg/kg	19	30
sec-Butylbenzene	338	429	mg/kg	24	30



Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	Native Sample	Duplicate Sample	Units	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfield Lab Client ID: GASOLINE 87	Associated sample(s):	01,04,07,10,13,22,25	QC Batch ID:	WG1671854-7	QC Sample: L2240634-01
1-Methyl-3-Isopropylbenzene	536	684	mg/kg	24	30
1-Methyl-4-Isopropylbenzene	179	230	mg/kg	25	30
1-Methyl-2-Isopropylbenzene	38.6J	49.5J	mg/kg	NC	30
Indane	1870	2190	mg/kg	16	30
1-Methyl-3-N-Propylbenzene	2200	2860	mg/kg	26	30
1-Methyl-4-N-Propylbenzene	1040	1360	mg/kg	27	30
n-Butylbenzene	717	941	mg/kg	27	30
1,2-Dimethyl-4-Ethylbenzene	2190	2840	mg/kg	26	30
1,2-Diethylbenzene	158	202	mg/kg	24	30
1-Methyl-2-N-Propylbenzene	779	1000	mg/kg	25	30
1,4-Dimethyl-2-Ethylbenzene	1550	1970	mg/kg	24	30
Undecane	758	988	mg/kg	26	30
1,3-Dimethyl-4-Ethylbenzene	1300	1670	mg/kg	25	30
1,3-Dimethyl-5-Ethylbenzene	2430	3090	mg/kg	24	30
1,3-Dimethyl-2-Ethylbenzene	166	203	mg/kg	20	30
1,2-Dimethyl-3-Ethylbenzene	511	640	mg/kg	22	30
1,2,4,5-Tetramethylbenzene	1220	1600	mg/kg	27	30
N-Pentylbenzene	91.9J	119	mg/kg	NC	30
Dodecane (C12)	341	425	mg/kg	22	30
Naphthalene	1850	2090	mg/kg	12	30
Benzothiophene	ND	ND	mg/kg	NC	30



L2240634

## Lab Duplicate Analysis Batch Quality Control

Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Quality Control Lab Number:

Parameter	Native Sample	Duplicate Sample	Units	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Mansfield Lab Client ID: GASOLINE 87	Associated sample(s):	01,04,07,10,13,22,25	QC Batch ID:	WG1671854-7	QC Sample: L2240634-01
MMT	ND	ND	mg/kg	NC	30
Tridecane	181J	253	mg/kg	NC	30
2-Methylnaphthalene	1040	1250	mg/kg	18	30
1-Methylnaphthalene	488	577	mg/kg	17	30

			Acceptance
Surrogate	%Recovery Qualifie	er %Recovery Qua	lifier Criteria
Dibromofluoromethane	127	120	70-130
Toluene-d8	115	111	70-130
4-Bromofluorobenzene	92	95	70-130



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	Native Sample	Duplicate Sample	Units	RPD	RPD Qual Limits
PIANO Volatile Organics by GC/MS - Client ID: GASOLINE 87	Mansfield Lab Associated sample(s):	01,04,07,10,13,22,25	QC Batch ID:	WG1671854-7	QC Sample: L2240634-01
Isopentane	37900	37000	mg/kg	2	30
Pentane	30300	28500	mg/kg	6	30
2-Methylpentane	26800	25600	mg/kg	5	30
3-Methylpentane	17800	16600	mg/kg	7	30
n-Hexane	26700	24300	mg/kg	9	30
Methylcyclopentane	18800	17500	mg/kg	7	30
Cyclohexane	12700	11800	mg/kg	7	30
2-Methylhexane	14500	13200	mg/kg	9	30
3-Methylhexane	14800	13200	mg/kg	11	30
Isooctane	14900	13600	mg/kg	9	30
Heptane	18700	16900	mg/kg	10	30
Methylcyclohexane	14300	13600	mg/kg	5	30
2-Methylheptane	8310	8080	mg/kg	3	30
Toluene	50200	49400	mg/kg	2	30
Octane	9010	9270	mg/kg	3	30
Ethylbenzene	11800	11600	mg/kg	2	30
p/m-Xylene	46400	45600	mg/kg	2	30
o-Xylene	16800	16500	mg/kg	2	30
1-Methyl-3-Ethylbenzene	11900	11800	mg/kg	1	30
1,2,4-Trimethylbenzene	19200	19200	mg/kg	0	30



HAWAII DOH - FINGERPRINTING Batch Quality Control

Lab Number:

L2240634

Project Number: Not Specified

Report Date:

09/08/22

RPD Parameter Native Sample Duplicate Sample Units RPD Qual Limits

PIANO Volatile Organics by GC/MS - Mansfield Lab Associated sample(s): 01,04,07,10,13,22,25 QC Batch ID: WG1671854-7 QC Sample: L2240634-01

Client ID: GASOLINE 87

**Project Name:** 

Surrogate	%Recovery	Qualifier %Recovery	Acceptance Qualifier Criteria	
Dibromofluoromethane	124	123	70-130	
Toluene-d8	112	113	70-130	
4-Bromofluorobenzene	96	95	70-130	



#### PETROLEUM HYDROCARBONS



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-01 Date Collected: 07/26/22 00:00

Date Received: Client ID: **GASOLINE 87** 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 10:45 Analytical Method: 1,8015D(M) Analytical Date: 08/18/22 01:41

Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	169000		mg/kg	6260	57.8	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			102		:	50-130
d50-Tetracosane			100			50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number: Report Date:** Not Specified 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: L2240634-02 07/26/22 00:00

**GASOLINE 87 F1** Date Received: 07/29/22 Client ID: Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 Analytical Method: 1,8015D(M) Cleanup Method: EPA 3630(M) Analytical Date: 08/19/22 07:48 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Qualifier Units RL MDL **Dilution Factor** Result **Parameter** Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Total Petroleum Hydrocarbons (C9-C44) 34900 mg/kg 3130 28.9 1 Acceptance Criteria Surrogate Qualifier % Recovery d50-Tetracosane 96 50-130



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number: Report Date:** Not Specified 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: L2240634-03 07/26/22 00:00

**GASOLINE 87 F2** Date Received: 07/29/22 Client ID: Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

o-Terphenyl

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 Analytical Method: 1,8015D(M) Cleanup Method: EPA 3630(M) Analytical Date: 08/25/22 19:02 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Qualifier Units RL MDL **Dilution Factor** Result **Parameter** Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Total Petroleum Hydrocarbons (C9-C44) 76100 mg/kg 3130 28.9 1 Acceptance Criteria Surrogate Qualifier % Recovery



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-04 Date Collected: 07/26/22 00:00

Date Received: Client ID: **GASOLINE 91** 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 10:45 Analytical Method: 1,8015D(M) 08/18/22 04:40 Analytical Date:

Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	142000		mg/kg	6430	59.4	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			102		;	50-130
d50-Tetracosane			100			50-130



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number: Report Date:** Not Specified 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: L2240634-05 07/26/22 00:00

**GASOLINE 91 F1** Date Received: 07/29/22 Client ID: Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

d50-Tetracosane

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 Analytical Method: 1,8015D(M) Cleanup Method: EPA 3630(M) Analytical Date: 08/19/22 10:49 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Qualifier Units RL MDL **Dilution Factor** Result **Parameter** Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Total Petroleum Hydrocarbons (C9-C44) 33800 mg/kg 3210 29.7 1 Acceptance Criteria Surrogate Qualifier % Recovery

50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-06 Date Collected: 07/26/22 00:00

Client ID: GASOLINE 91 F2 Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

o-Terphenyl

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/25/22 22:03 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-FI	D - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	63500	В	mg/kg	3210	29.7	1
Surrogate			% Recovery	Qualifier		eptance riteria



09/08/22

**Report Date:** 

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

SAMPLE RESULTS

MPLE RESULTS

Lab ID: L2240634-07 Date Collected: 07/26/22 00:00

Client ID: GASOLINE 93 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil Extraction Method: EPA 3580A

Analytical Method: 1,8015D(M) Extraction Date: 08/17/22 10:45
Analytical Date: 08/18/22 06:10

Analyst: WR

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	144000		mg/kg	5870	54.2	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			103		;	50-130
d50-Tetracosane			101			50-130



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number: Report Date:** Not Specified 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: L2240634-08 07/26/22 00:00

Client ID: **GASOLINE 93 F1** Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

d50-Tetracosane

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 Analytical Method: 1,8015D(M) Cleanup Method: EPA 3630(M) Analytical Date: 08/19/22 12:21 08/18/22

Cleanup Date: Analyst: WR Results reported on an 'AS RECEIVED' basis. Percent Solids:

Qualifier Units RL MDL **Dilution Factor** Result **Parameter** Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Total Petroleum Hydrocarbons (C9-C44) 29100 mg/kg 2930 27.1 1 Acceptance Criteria Surrogate Qualifier % Recovery



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-09 Date Collected: 07/26/22 00:00

Date Received: Client ID: **GASOLINE 93 F2** 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

o-Terphenyl

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/25/22 23:34 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	67400		mg/kg	2930	27.1	1
Surrogate			% Recovery	Qualifier		eptance riteria



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified

**SAMPLE RESULTS** 

**Report Date:** 09/08/22

L2240634-10

Date Collected: 07/26/22 00:00

Date Received: Client ID: **HEATING FUEL** 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Lab ID:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 10:45 Analytical Method: 1,8015D(M) 08/18/22 07:40 Analytical Date:

Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	884000		mg/kg	5880	54.3	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			103			50-130
d50-Tetracosane			101			50-130



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: L2240634-11 07/26/22 00:00

Client ID: **HEATING FUEL F1** Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

d50-Tetracosane

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 Analytical Method: 1,8015D(M) Cleanup Method: EPA 3630(M) Analytical Date: 08/19/22 13:52 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Qualifier Units RL MDL **Dilution Factor** Result **Parameter** Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Total Petroleum Hydrocarbons (C9-C44) 511000 mg/kg 2940 27.2 1 Acceptance Criteria Surrogate Qualifier % Recovery



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-12 Date Collected: 07/26/22 00:00

Client ID: HEATING FUEL F2 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil Extraction Method: EPA 3580A

Analytical Method: 1,8015D(M) Extraction Date: 08/17/22 16:35
Analytical Date: 08/26/22 01:04 Cleanup Method: EPA 3630(M)
Analyst: WR Cleanup Date: 08/18/22

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	FID - Mansfield Lat	)				
Total Petroleum Hydrocarbons (C9-C44)	242000		mg/kg	2940	27.2	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			95			50-130



09/08/22

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

SAMPLE RESULTS

LE RESULTS

**Report Date:** 

Lab ID: L2240634-13 Date Collected: 07/26/22 00:00

Client ID: ROAD DIESEL Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil Extraction Method: EPA 3580A

Analytical Method: 1,8015D(M) Extraction Date: 08/17/22 10:45
Analytical Date: 08/18/22 09:10

Analyst: WR

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	927000		mg/kg	5900	54.5	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			102			50-130
d50-Tetracosane			100			50-130



50-130

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

SAMPLE RESULTS

Lab ID: L2240634-14 Date Collected: 07/26/22 00:00

Client ID: ROAD DIESEL F1 Date Received: 07/29/22
Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

d50-Tetracosane

Matrix: Oil Extraction Method: EPA 3580A

Analytical Method: 1,8015D(M) Extraction Date: 08/17/22 16:35
Analytical Date: 08/19/22 15:24 Cleanup Method: EPA 3630(M)
Analyst: WR Cleanup Date: 08/18/22

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Qualifier Units RL MDL **Dilution Factor** Result **Parameter** Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Total Petroleum Hydrocarbons (C9-C44) 524000 mg/kg 2950 27.3 1 Acceptance Criteria Surrogate Qualifier % Recovery



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-15 Date Collected: 07/26/22 00:00

Date Received: Client ID: **ROAD DIESEL F2** 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

o-Terphenyl

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/26/22 02:34 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-FI	D - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	260000		mg/kg	2950	27.3	1
Surrogate			% Recovery	Qualifier		eptance riteria



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-16 Date Collected: 07/26/22 00:00

Date Received: Client ID: JP-5 07/29/22

Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 10:45 Analytical Method: 1,8015D(M) Analytical Date: 08/18/22 10:41

Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	FID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	1010000		mg/kg	6600	61.0	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			102			50-130
d50-Tetracosane			102			50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: 07/26/22 00:00 L2240634-17

Client ID: JP-5 F1 Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/19/22 21:29 Cleanup Date: 08/18/22 Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-l	FID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	656000		mg/kg	1650	15.2	1
Surrogate			% Recovery	Qualifier		eptance riteria
d50-Tetracosane			94		ļ	50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: 07/26/22 00:00 L2240634-18

Client ID: JP-5 F2 Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/26/22 04:05 Cleanup Date: 08/18/22 Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	FID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	153000		mg/kg	1650	15.2	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			113		Ę	50-130



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-19 Date Collected: 07/26/22 00:00

Date Received: Client ID: JP-8 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 10:45 Analytical Method: 1,8015D(M) Analytical Date: 08/18/22 16:46

Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	914000		mg/kg	6600	61.0	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			102		;	50-130
d50-Tetracosane			100			50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: 07/26/22 00:00 L2240634-20

Client ID: JP-8 F1 Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/19/22 23:00 Cleanup Date: 08/18/22 Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-	FID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	558000		mg/kg	1650	15.2	1
Surrogate			% Recovery	Qualifier		eptance iteria
d50-Tetracosane			96		5	50-130

**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: Date Collected: 07/26/22 00:00 L2240634-21

Client ID: JP-8 F2 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/26/22 05:35 Cleanup Date: 08/18/22 Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-I	FID - Mansfield Lab	)				
Total Petroleum Hydrocarbons (C9-C44)	138000		mg/kg	1650	15.2	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			90			50-130



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-25 Date Collected: 07/26/22 00:00

Date Received: Client ID: **BUNKER C** 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 10:45 1,8015D(M) Analytical Method: Analytical Date: 08/18/22 19:48

Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	FID - Mansfield Lal	b				
Total Petroleum Hydrocarbons (C9-C44)	1270000		mg/kg	12800	118.	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			101			50-130
d50-Tetracosane			103			50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-26 Date Collected: 07/26/22 00:00

Client ID: **BUNKER C F1** Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/20/22 02:01 Cleanup Date: 08/18/22 Analyst: WR

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	FID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	385000		mg/kg	3190	29.4	1
Surrogate			% Recovery	Qualifier		eptance riteria
d50-Tetracosane			95		Ę	50-130



50-130

**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-27 Date Collected: 07/26/22 00:00

Client ID: BUNKER C F2 Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

o-Terphenyl

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 08/17/22 16:35 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 08/26/22 07:05 Cleanup Date: 08/18/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	TD - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	178000		mg/kg	3190	29.4	1
Surrogate			% Recovery	Qualifier		ptance iteria

09/08/22

**Report Date:** 

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified

SAMPLE RESULTS

Lab ID: L2240634-32 Date Collected: 07/26/22 00:00

Client ID: WASTE OIL (AUTO) Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Matrix: Oil Extraction Method: EPA 3580A

Analytical Method: 1,8015D(M) Extraction Date: 09/02/22 12:12
Analytical Date: 09/07/22 16:05

Analyst: WR

Percent Solids: Results reported on an 'AS RECEIVED' basis.

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield La	b				
Total Petroleum Hydrocarbons (C9-C44)	809000		mg/kg	5900	54.5	1
Surrogate			% Recovery	Qualifier		eptance riteria
o-Terphenyl			90		;	50-130
d50-Tetracosane			93			50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-33 Date Collected: 07/26/22 00:00

Client ID: WASTE OIL (AUTO) F1 Date Received: 07/29/22 Sample Location: Not Specified Field Prep: Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 09/02/22 15:30 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 09/07/22 22:05 Cleanup Date: 09/02/22

Analyst: WR Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-	FID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	834000		mg/kg	2950	27.2	1
Surrogate			% Recovery	Qualifier		ptance iteria
d50-Tetracosane			109		5	50-130



**Project Name:** HAWAII DOH - FINGERPRINTING Lab Number: L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-34 Date Collected: 07/26/22 00:00

Client ID: WASTE OIL (AUTO) F2 Date Received: 07/29/22 Sample Location: Field Prep: Not Specified Not Specified

Sample Depth:

Extraction Method: EPA 3580A Matrix: Oil

**Extraction Date:** 09/02/22 15:30 1,8015D(M) Analytical Method: Cleanup Method: EPA 3630(M) Analytical Date: 09/07/22 19:05 Cleanup Date: 09/02/22 Analyst: WR

Results reported on an 'AS RECEIVED' basis. Percent Solids:

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Total Petroleum Hydrocarbon by GC-F	ID - Mansfield Lab					
Total Petroleum Hydrocarbons (C9-C44)	93600		mg/kg	2950	27.2	1
Surrogate			% Recovery	Qualifier		ptance teria
o-Terphenyl			104		5	0-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis
Batch Quality Control

Analytical Method: 1,8015D(M) Extraction Method: EPA 3580A
Analytical Date: 08/17/22 19:40 Extraction Date: 08/17/22 10:45

Analyst: WR

ParameterResultQualifierUnitsRLMDLTotal Petroleum Hydrocarbon by GC-FID - Mansfield Lab for sample(s): 01,04,07,10,13,16,19,25Batch: WG1676301-1Total Petroleum Hydrocarbons (C9-C44)NDmg/kg753069.5

		Acceptance
Surrogate	%Recovery Qua	alifier Criteria
		_
o-Terphenyl	102	50-130
d50-Tetracosane	100	50-130



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number: Report Date:** Not Specified 09/08/22

> **Method Blank Analysis Batch Quality Control**

Analytical Method: 1,8015D(M) Analytical Date: 08/19/22 01:49

Analyst: WR

Extraction Method: EPA 3580A 08/17/22 16:35 **Extraction Date:** Cleanup Method: EPA 3630(M)

Cleanup Date: 08/18/22

Parameter	Result	Qualifier	Units	RL	MDL	
Total Petroleum Hydrocarbon by GC WG1676456-1	C-FID - Mans	sfield Lab f	for sample(s):	02,05,08,11	1,14,17,20,26	Batch:
Total Petroleum Hydrocarbons (C9-C44)	2110	J	mg/kg	3760	34.8	

**Acceptance** Criteria Surrogate %Recovery Qualifier d50-Tetracosane 98 50-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis
Batch Quality Control

Analytical Method: 1,8015D(M) Analytical Date: 08/25/22 09:53

Analyst: WR

Extraction Method: EPA 3580A
Extraction Date: 08/17/22 16:35
Cleanup Method: EPA 3630(M)
Cleanup Date: 08/18/22

Parameter	Result	Qualifier	Units	RL	MDL	
Total Petroleum Hydrocarbon by G0 WG1676458-1	C-FID - Mans	sfield Lab fo	or sample(s):	03,06,09,12	2,15,18,21,27	Batch:

Total Petroleum Hydrocarbons (C9-C44) 6380 mg/kg 3760 34.8

	Acceptance						
Surrogate	%Recovery Qualifier	Criteria					
o-Terphenyl	93	50-130					



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 1,8015D(M) Analytical Date: 09/06/22 22:04

Analyst: WR

Extraction Method: EPA 3580A Extraction Date: 09/02/22 12:12

Parameter	Result	Qualifier	Units	RL	MDL
Total Petroleum Hydrocarbon by GC	-FID - Man	sfield Lab f	or sample(s):	32	Batch: WG1682983-1
Total Petroleum Hydrocarbons (C9-C44)	ND		mg/kg	5900	54.5

		cceptance	ce	
Surrogate	%Recovery	Qualifier	Criteria	
o-Terphenyl	89		50-130	
d50-Tetracosane	91		50-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis
Batch Quality Control

Analytical Method: 1,8015D(M) Analytical Date: 09/07/22 01:04

Analyst: WR

Extraction Method: EPA 3580A
Extraction Date: 09/02/22 15:30
Cleanup Method: EPA 3630(M)

Cleanup Date: 09/02/22

Parameter	Result	Qualifier	Units	RL	MDL
Total Petroleum Hydrocarbon by GC	-FID - Mans	sfield Lab f	or sample(s):	33	Batch: WG1682989-1
Total Petroleum Hydrocarbons (C9-C44)	ND		mg/kg	2950	27.2

Surrogate %Recovery Qualifier Criteria

d50-Tetracosane 105 50-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis
Batch Quality Control

Analytical Method: 1,8015D(M) Analytical Date: 09/06/22 23:34

Analyst: WR

Extraction Method: EPA 3580A
Extraction Date: 09/02/22 15:30
Cleanup Method: EPA 3630(M)
Cleanup Date: 09/02/22

Parameter	Result	Qualifier	Units	RL	MDL
Total Petroleum Hydrocarbon by GC	-FID - Mans	sfield Lab f	or sample(s):	34	Batch: WG1682993-1
Total Petroleum Hydrocarbons (C9-C44)	ND		mg/kg	2950	27.2

Surrogate %Recovery Qualifier Criteria

o-Terphenyl 91 50-130



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

aramatar	LCS %Recovery	Qual %	LCSD Recovery	Qual	%Recovery Limits	RPD	Qual	RPD Limits
arameter	/øNecovery	Quai 701	Recovery	Quai	Lililis	KPU	Quai	Lillits
otal Petroleum Hydrocarbon by GC-FID -	Mansfield Lab A	ssociated sample(s	): 01,04,07	7,10,13,16,19,2	5 Batch:	WG1676301-2	WG1676301-3	3
Nonane (C9)	97		101		50-130	4		30
Decane (C10)	95		101		50-130	6		30
Dodecane (C12)	103		105		50-130	2		30
Tetradecane (C14)	99		101		50-130	2		30
Hexadecane (C16)	106		108		50-130	2		30
Octadecane (C18)	107		109		50-130	2		30
Nonadecane (C19)	101		103		50-130	2		30
Eicosane (C20)	99		102		50-130	3		30
Docosane (C22)	100		103		50-130	3		30
Tetracosane (C24)	104		107		50-130	3		30
Hexacosane (C26)	102		105		50-130	3		30
Octacosane (C28)	101		104		50-130	3		30
Triacontane (C30)	101		104		50-130	3		30
Hexatriacontane (C36)	91		94		50-130	3		30

Surrogate	LCS	LCSD	Acceptance
	%Recovery	Qual %Recovery	Qual Criteria
o-Terphenyl	103	103	50-130
d50-Tetracosane	101	102	50-130



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	LCS %Recovery		LCSD Recovery	% Qual	Recovery	, RPD	Qual	RPD Limits
	•		-					
otal Petroleum Hydrocarbon by GC-FID -	Mansfield Lab As	ssociated sample(s)	1: 02,05,08	5,11,14,17,20,26	Batch:	WG1676456-2	WG1676456-3	
Nonane (C9)	75		74		50-130	1		30
Decane (C10)	72		72		50-130	0		30
Dodecane (C12)	81		82		50-130	1		30
Tetradecane (C14)	84		86		50-130	2		30
Hexadecane (C16)	93		95		50-130	2		30
Octadecane (C18)	98		101		50-130	3		30
Nonadecane (C19)	100		103		50-130	3		30
Eicosane (C20)	100		102		50-130	2		30
Docosane (C22)	99		101		50-130	2		30
Tetracosane (C24)	103		105		50-130	2		30
Hexacosane (C26)	101		103		50-130	2		30
Octacosane (C28)	100		103		50-130	3		30
Triacontane (C30)	99		102		50-130	3		30
Hexatriacontane (C36)	90		92		50-130	2		30

Surrogate	LCS	LCSD	Acceptance
	%Recovery Qu	ual %Recovery	Qual Criteria
d50-Tetracosane	97	98	50-130



Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	LCS %Recovery	Qual	LCSD %Recovery	%Recovery Qual Limits	RPD	RPD Qual Limits
Total Petroleum Hydrocarbon by GC-FID	- Mansfield Lab Ass	sociated sampl	e(s): 32 Bato	ch: WG1682983-2 WG1682	983-3	
Nonane (C9)	88		86	50-130	2	30
Decane (C10)	88		88	50-130	0	30
Dodecane (C12)	90		91	50-130	1	30
Tetradecane (C14)	91		91	50-130	0	30
Hexadecane (C16)	94		94	50-130	0	30
Octadecane (C18)	93		93	50-130	0	30
Nonadecane (C19)	93		93	50-130	0	30
Eicosane (C20)	91		93	50-130	2	30
Docosane (C22)	92		92	50-130	0	30
Tetracosane (C24)	95		95	50-130	0	30
Hexacosane (C26)	93		93	50-130	0	30
Octacosane (C28)	96		96	50-130	0	30
Triacontane (C30)	91		92	50-130	1	30
Hexatriacontane (C36)	82		83	50-130	1	30

Surrogate	LCS	LCSD	Acceptance
	%Recovery	Qual %Recovery	Qual Criteria
o-Terphenyl	89	90	50-130
d50-Tetracosane	91	92	50-130



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	LCS %Recovery	Qual	LCSD %Recovery	%Recovery Qual Limits	RPD	RPD Qual Limits	
Total Petroleum Hydrocarbon by GC-FID -	Mansfield Lab As	sociated sampl	e(s): 33 Bato	ch: WG1682989-2 WG1682	989-3		
Nonane (C9)	82		78	50-130	5	30	
Decane (C10)	85		80	50-130	6	30	
Dodecane (C12)	89		84	50-130	6	30	
Tetradecane (C14)	92		87	50-130	6	30	
Hexadecane (C16)	102		96	50-130	6	30	
Octadecane (C18)	108		101	50-130	7	30	
Nonadecane (C19)	109		102	50-130	7	30	
Eicosane (C20)	108		102	50-130	6	30	
Docosane (C22)	107		101	50-130	6	30	
Tetracosane (C24)	110		104	50-130	6	30	
Hexacosane (C26)	107		101	50-130	6	30	
Octacosane (C28)	106		100	50-130	6	30	
Triacontane (C30)	106		100	50-130	6	30	
Hexatriacontane (C36)	97		88	50-130	10	30	

Surrogate	LCS	LCSD	Acceptance
	%Recovery Qua	al %Recovery Qua	Criteria
d50-Tetracosane	105	99	50-130



L2240634

Lab Number:

**Lab Duplicate Analysis** 

HAWAII DOH - FINGERPRINTING Batch Quality Control

Project Number: Not Specified Report Date: 09/08/22

**RPD Native Sample Duplicate Sample RPD** Limits **Parameter** Units Qual Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Associated sample(s): 01,04,07,10,13,16,19,25 QC Batch ID: WG1676301-4 QC Sample: L2240634-01 Client ID: GASOLINE 87 169000 30 Total Petroleum Hydrocarbons (C9-C44) 160000 mg/kg 5 Acceptance Surrogate %Recovery Qualifier %Recovery Qualifier Criteria o-Terphenyl 102 102 50-130 d50-Tetracosane 100 101 50-130 Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Associated sample(s): 02,05,08,11,14,17,20,26 QC Batch ID: WG1676456-4 QC Sample: L2240634-02 Client ID: GASOLINE 87 F1 30 Total Petroleum Hydrocarbons (C9-C44) 34900 40100 mg/kg 14 **Acceptance** Surrogate Criteria %Recovery Qualifier %Recovery Qualifier d50-Tetracosane 96 97 50-130 Total Petroleum Hydrocarbon by GC-FID - Mansfield Lab Associated sample(s): 03,06,09,12,15,18,21,27 QC Batch ID: WG1676458-4 QC Sample:

			Acceptance	
Surrogate	%Recovery Qualifie	r %Recovery Qualifier	Criteria	
o-Terphenyl	92	90	50-130	

78200

mg/kg

3

76100



30

L2240634-03 Client ID: GASOLINE 87 F2

Total Petroleum Hydrocarbons (C9-C44)

**Project Name:** 

L2240634

Lab Duplicate Analysis
Batch Quality Control

HAWAII DOH - FINGERPRINTING

Not Specified

**Project Name:** 

**Project Number:** 

Lab Number:

09/08/22 **Report Date:** 

Parameter N	lative Sample	Duplicate Sample	Units	RPD		PD mits
Total Petroleum Hydrocarbon by GC-FID - Mansfield La WASTE OIL (AUTO)	ab Associated sample(	s): 32 QC Batch ID:	WG1682983-4	QC Sampl	e: L2240634-3	2 Client ID:
Total Petroleum Hydrocarbons (C9-C44)	809000	813000	mg/kg	0		30
Surrogate		%Recovery Qualifie	r %Recovery		cceptance Criteria	
o-Terphenyl d50-Tetracosane		90 93	90 92		50-130 50-130	
otal Petroleum Hydrocarbon by GC-FID - Mansfield La VASTE OIL (AUTO) F1	ab Associated sample(	s): 33 QC Batch ID:	WG1682989-4	QC Sampl	e: L2240634-3	3 Client ID:
Total Petroleum Hydrocarbons (C9-C44)	834000	848000	mg/kg	2		30
Surrogate		%Recovery Qualifie	r %Recovery		cceptance Criteria	
d50-Tetracosane		109	105		50-130	
Total Petroleum Hydrocarbon by GC-FID - Mansfield La	ab Associated sample(	s): 34 QC Batch ID:	WG1682993-4	QC Sampl	e: L2240634-3	4 Client ID:

			Acceptance	
Surrogate	%Recovery	Qualifier %Recovery	Qualifier Criteria	
o-Terphenyl	104	102	50-130	_

83400

93600

mg/kg

12



30

WASTE OIL (AUTO) F2

Total Petroleum Hydrocarbons (C9-C44)

Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-01 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 87 Date Received: 07/29/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/02/22 19:24

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Satisfactory

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

9.0:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor				
Volatile Petroleum Hydrocarbons - Westborough Lab										
C5-C8 Aliphatics	124000		mg/kg	22500	22500	500				
C9-C12 Aliphatics	78900		mg/kg	22500	22500	500				
C9-C10 Aromatics	28400		mg/kg	22500	22500	500				
C5-C8 Aliphatics, Adjusted	80600		mg/kg	22500	22500	500				
C9-C12 Aliphatics, Adjusted	ND		mg/kg	22500	22500	500				

Surrogate	% Recovery	Qualifier	Acceptance Criteria
2,5-Dibromotoluene-PID	0	Q	70-130
2,5-Dibromotoluene-FID	0	Q	70-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-04 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 91 Date Received: 07/29/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/02/22 21:23

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

8.8:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor				
Volatile Petroleum Hydrocarbons - Westborough Lab										
C5-C8 Aliphatics	121000		mg/kg	21900	21900	500				
C9-C12 Aliphatics	72200		mg/kg	21900	21900	500				
C9-C10 Aromatics	27000		mg/kg	21900	21900	500				
C5-C8 Aliphatics, Adjusted	77900		mg/kg	21900	21900	500				
C9-C12 Aliphatics, Adjusted	ND		mg/kg	21900	21900	500				

2,5-Dibromotoluene-PID	Surrogate	% Recovery	Qualifier	Acceptance Criteria
			Q	70-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-07 D Date Collected: 07/26/22 00:00

Client ID: GASOLINE 93 Date Received: 07/29/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/02/22 22:23

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

8.5:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Volatile Petroleum Hydrocarbons	- Westborough Lab					
C5-C8 Aliphatics	91000		mg/kg	21400	21400	500
C9-C12 Aliphatics	57400		mg/kg	21400	21400	500
C9-C10 Aromatics	ND		mg/kg	21400	21400	500
C5-C8 Aliphatics, Adjusted	53400		mg/kg	21400	21400	500
C9-C12 Aliphatics, Adjusted	30100		mg/kg	21400	21400	500

Surrogate	% Recovery	Qualifier	Acceptance Criteria
2,5-Dibromotoluene-PID	0	Q	70-130
2,5-Dibromotoluene-FID	0	Q	70-130



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-10 D Date Collected: 07/26/22 00:00

Client ID: **HEATING FUEL** Date Received: 07/29/22 Not Specified

Field Prep: Sample Location:

Sample Depth:

Matrix: Oil

Analytical Method: 131, VPH-18-2.1 Analytical Date: 09/02/22 23:23

**BAD** Analyst:

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Restek, RTX-502.2, Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column:

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received: Satisfactory Sample Temperature upon receipt: Received on Ice Were samples received in methanol? Yes (Covering the Soil) Methanol ratio: 8.5:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
Volatile Petroleum Hydrocarbons - Westborough Lab								
C5-C8 Aliphatics	ND		mg/kg	8550	8550	200		
C9-C12 Aliphatics	110000		mg/kg	8550	8550	200		
C9-C10 Aromatics	60200		mg/kg	8550	8550	200		
C5-C8 Aliphatics, Adjusted	ND		mg/kg	8550	8550	200		
C9-C12 Aliphatics, Adjusted	48300		mg/kg	8550	8550	200		

Surrogate	% Recovery	Qualifier	Acceptance Criteria
2,5-Dibromotoluene-PID	0	Q	70-130
2,5-Dibromotoluene-FID	0	Q	70-130



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-13 D Date Collected: 07/26/22 00:00

Client ID: ROAD DIESEL Date Received: 07/29/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/03/22 00:23

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Satisfactory

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

6.0:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
Volatile Petroleum Hydrocarbons - Westborough Lab								
C5-C8 Aliphatics	ND		mg/kg	5990	5990	200		
C9-C12 Aliphatics	66700		mg/kg	5990	5990	200		
C9-C10 Aromatics	38200		mg/kg	5990	5990	200		
C5-C8 Aliphatics, Adjusted	ND		mg/kg	5990	5990	200		
C9-C12 Aliphatics, Adjusted	19600		mg/kg	5990	5990	200		

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
2,5-Dibromotoluene-PID	0	Q	70-130	
2,5-Dibromotoluene-FID	0	Q	70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-25 D Date Collected: 07/26/22 00:00

Client ID: BUNKER C Date Received: 07/29/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/03/22 01:23

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Satisfactory

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

8.5:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor		
Volatile Petroleum Hydrocarbons - Westborough Lab								
C5-C8 Aliphatics	ND		mg/kg	855	855.	20		
C9-C12 Aliphatics	21000		mg/kg	855	855.	20		
C9-C10 Aromatics	12700		mg/kg	855	855.	20		
C5-C8 Aliphatics, Adjusted	ND		mg/kg	855	855.	20		
C9-C12 Aliphatics, Adjusted	8230		mg/kg	855	855.	20		

Surrogate	% Recovery	Qualifier	Acceptance Criteria
2,5-Dibromotoluene-PID	0	Q	70-130
2,5-Dibromotoluene-FID	0	Q	70-130



**Project Name:** Lab Number: HAWAII DOH - FINGERPRINTING L2240634

**Project Number:** Not Specified **Report Date:** 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-30 D Date Collected: 08/17/22 12:15

Client ID: JP-5 MEOH (20 MG/ML) Date Received: 08/17/22 Not Specified

Field Prep: Sample Location:

Sample Depth:

Matrix: Oil

Analytical Method: 131, VPH-18-2.1 Analytical Date: 09/08/22 12:54

**BAD** Analyst:

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Restek, RTX-502.2, Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column:

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received: Satisfactory Sample Temperature upon receipt: Received on Ice Were samples received in methanol? Yes (Covering the Soil) Methanol ratio: 20.:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Volatile Petroleum Hydrocarbons	- Westborough Lab					
C5-C8 Aliphatics	340		mg/kg	196	196.	2
C9-C12 Aliphatics	11700		mg/kg	196	196.	2
C9-C10 Aromatics	5250		mg/kg	196	196.	2
C5-C8 Aliphatics, Adjusted	340		mg/kg	196	196.	2
C9-C12 Aliphatics, Adjusted	6410		mg/kg	196	196.	2

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
2,5-Dibromotoluene-PID	95	Quanto	70-130	
2,5-Dibromotoluene-FID	107		70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-31 D Date Collected: 08/17/22 12:15

Client ID: JP-8 MEOH (20 MG/ML) Date Received: 08/17/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/08/22 13:53

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

20.:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Volatile Petroleum Hydrocarbons	- Westborough Lab					
C5-C8 Aliphatics	2590		mg/kg	200	200.	2
C9-C12 Aliphatics	10900		mg/kg	200	200.	2
C9-C10 Aromatics	4040		mg/kg	200	200.	2
C5-C8 Aliphatics, Adjusted	2560		mg/kg	200	200.	2
C9-C12 Aliphatics, Adjusted	6370		mg/kg	200	200.	2

Surrogate	% Recovery	Qualifier	Acceptance Criteria	
2,5-Dibromotoluene-PID	85		70-130	
2,5-Dibromotoluene-FID	74		70-130	



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

**SAMPLE RESULTS** 

Lab ID: L2240634-32 D Date Collected: 07/26/22 00:00

Client ID: WASTE OIL (AUTO) Date Received: 07/29/22

Sample Location: Field Prep: Not Specified

Sample Depth:

Matrix: Oil

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/03/22 02:22

Analyst: BAD

Percent Solids: Results are reported on an 'AS RECEIVED' basis.

Trap: EST, Carbopack B/Carboxen 1000&1001 Analytical Column: Restek, RTX-502.2,

105m, 0.53ID, 3um

## **Quality Control Information**

Condition of sample received:

Sample Temperature upon receipt:

Were samples received in methanol?

Methanol ratio:

Satisfactory

Received on Ice

Yes (Covering the Soil)

9.9:1

Parameter	Result	Qualifier	Units	RL	MDL	Dilution Factor
Volatile Petroleum Hydrocarbons	- Westborough Lab					
C5-C8 Aliphatics	1310		mg/kg	248	248.	5
C9-C12 Aliphatics	5430		mg/kg	248	248.	5
C9-C10 Aromatics	3360		mg/kg	248	248.	5
C5-C8 Aliphatics, Adjusted	1060		mg/kg	248	248.	5
C9-C12 Aliphatics, Adjusted	1240		mg/kg	248	248.	5

	Acceptance				
Surrogate	% Recovery	Qualifier	Criteria		
2,5-Dibromotoluene-PID	83		70-130		
2,5-Dibromotoluene-FID	14	Q	70-130		



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/02/22 11:00

Analyst: BAD

Parameter	Result	Qualifier	Units	RL	MDL	
Volatile Petroleum Hydrocarbons - WG1684889-4	Westboroug	h Lab for s	ample(s):	01,04,07,10	),13,25,32	Batch:
C5-C8 Aliphatics	ND		mg/kg	50.0	50.0	
C9-C12 Aliphatics	ND		mg/kg	50.0	50.0	
C9-C10 Aromatics	ND		mg/kg	50.0	50.0	
C5-C8 Aliphatics, Adjusted	ND		mg/kg	50.0	50.0	
C9-C12 Aliphatics, Adjusted	ND		mg/kg	50.0	50.0	

		Acceptance			
Surrogate	%Recovery Qu	alifier Criteria			
2,5-Dibromotoluene-PID	105	70-130			
2,5-Dibromotoluene-FID	108	70-130			



Project Name: HAWAII DOH - FINGERPRINTING Lab Number: L2240634

Project Number: Not Specified Report Date: 09/08/22

Method Blank Analysis Batch Quality Control

Analytical Method: 131,VPH-18-2.1 Analytical Date: 09/08/22 11:54

Analyst: BAD

Parameter	Result C	Qualifier Units	RL	MDL	
Volatile Petroleum Hydrocarbons -	Westborough l	_ab for sample(s):	30-31	Batch: WG1685081-4	
C5-C8 Aliphatics	ND	mg/kg	50.0	50.0	
C9-C12 Aliphatics	ND	mg/kg	50.0	50.0	
C9-C10 Aromatics	ND	mg/kg	50.0	50.0	
C5-C8 Aliphatics, Adjusted	ND	mg/kg	50.0	50.0	
C9-C12 Aliphatics, Adjusted	ND	mg/kg	50.0	50.0	

		Acceptance		
Surrogate	%Recovery Qualif	ier Criteria		
2,5-Dibromotoluene-PID	98	70-130		
2,5-Dibromotoluene-FID	106	70-130		



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	LCS %Recovery	Qual	LCSD %Recovery	Qual	%Recovery Limits	RPD	RPD Qual Limits	
Volatile Petroleum Hydrocarbons - Westbor	ough Lab Associ	ated sample(s)	: 01,04,07,10,	13,25,32	Batch: WG1684889	9-2 WG1684	4889-3	
C5-C8 Aliphatics	100		100		70-130	0	25	
C9-C12 Aliphatics	114		116		70-130	2	25	
C9-C10 Aromatics	106		106		70-130	0	25	
Benzene	106		106		70-130	0	25	
Toluene	108		108		70-130	0	25	
Ethylbenzene	109		108		70-130	1	25	
p/m-Xylene	109		108		70-130	1	25	
o-Xylene	106		105		70-130	1	25	
Methyl tert butyl ether	98		95		70-130	3	25	
Naphthalene	102		98		70-130	4	25	
1,2,4-Trimethylbenzene	106		106		70-130	0	25	
Pentane	85		84		70-130	1	25	
2-Methylpentane	100		101		70-130	1	25	
2,2,4-Trimethylpentane	110		111		70-130	1	25	
n-Nonane	115		117		30-130	2	25	
n-Decane	113		115		70-130	2	25	
n-Butylcyclohexane	114		116		70-130	2	25	

Surrogate	LCS %Recovery Qua	LCSD al %Recovery Qual	Acceptance Criteria
2,5-Dibromotoluene-PID	109	103	70-130
2,5-Dibromotoluene-FID	109	106	70-130



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Lab Number: L2240634

Parameter	LCS %Recovery	Qual	LCSD %Recovery	%Recovery Qual Limits	RPD	RPD Qual Limits
Volatile Petroleum Hydrocarbons - Westboro	ugh Lab Assoc	iated sample(s)	: 30-31 Batch	n: WG1685081-2 WG16850	)81-3	
C5-C8 Aliphatics	94		94	70-130	0	25
C9-C12 Aliphatics	111		111	70-130	0	25
C9-C10 Aromatics	98		98	70-130	0	25
Benzene	98		97	70-130	0	25
Toluene	99		99	70-130	0	25
Ethylbenzene	100		100	70-130	0	25
p/m-Xylene	100		100	70-130	0	25
o-Xylene	98		97	70-130	0	25
Methyl tert butyl ether	88		87	70-130	1	25
Naphthalene	92		92	70-130	0	25
1,2,4-Trimethylbenzene	98		98	70-130	0	25
Pentane	80		80	70-130	0	25
2-Methylpentane	93		92	70-130	0	25
2,2,4-Trimethylpentane	105		105	70-130	0	25
n-Nonane	112		112	30-130	0	25
n-Decane	108		109	70-130	1	25
n-Butylcyclohexane	111		111	70-130	0	25

Surrogate	LCS %Recovery Qua	LCSD al %Recovery Q	Acceptance ual Criteria
2,5-Dibromotoluene-PID	96	95	70-130
2,5-Dibromotoluene-FID	103	102	70-130



L2240634

# Lab Duplicate Analysis Batch Quality Control

Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Quality Control Lab Number:

_					RPD
Parameter	Native Sample	Duplicate Sample	Units	RPD	Qual Limits
Volatile Petroleum Hydrocarbons - Westborough Lab Client ID: GASOLINE 87	Associated sample(s):	01,04,07,10,13,25,32	QC Batch ID:	WG1684889-6	G QC Sample: L2240634-0
C5-C8 Aliphatics	124000	123000	mg/kg	1	50
C9-C12 Aliphatics	78900	75700	mg/kg	4	50
C9-C10 Aromatics	28400	25900	mg/kg	9	50
C5-C8 Aliphatics, Adjusted	80600	79600	mg/kg	1	50
C9-C12 Aliphatics, Adjusted	ND	ND	mg/kg	NC	50

					Acceptance
Surrogate	%Recovery	Qualifier	%Recovery	Qualifier	Criteria
2,5-Dibromotoluene-PID	0	Q	0	Q	70-130
2,5-Dibromotoluene-FID	0	Q	0	Q	70-130



**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

**Lab Number:** L2240634 **Report Date:** 09/08/22

## Sample Receipt and Container Information

Were project specific reporting limits specified?

**Cooler Information** 

Cooler Custody Seal

N/A Absent

Container Information			Initial	Final	Temp			Frozen	
Container ID	Container Type	Cooler	рН рН			Pres	Seal	Date/Time	Analysis(*)
L2240634-01A	Vial unpreserved 20ml hard-cap	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
L2240634-01B	Vial unpreserved	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-01W	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-01X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-01Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-04A	Vial unpreserved 20ml hard-cap	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
L2240634-04B	Vial unpreserved	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-04W	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-04X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-04Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-07A	Vial unpreserved 20ml hard-cap	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
L2240634-07B	Vial unpreserved	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-07W	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-07X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-07Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-10A	Vial unpreserved 20ml hard-cap	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
L2240634-10V	Split Small Ampule	N/A	NA			Υ	Absent		A2-NFTPH(365)
L2240634-10W	Vial unpreserved	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-10X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-10Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-10Z	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-13A	Vial unpreserved 20ml hard-cap	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
L2240634-13B	Vial unpreserved	N/A	NA			Υ	Absent		VPH-18(28)



Lab Number: L2240634

**Report Date:** 09/08/22

**Project Name:** HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Container Information			Initial	Final	Temp			Frozen	
Container ID	Container Type	Cooler	рН	рН	deg C	Pres	Seal	Date/Time	Analysis(*)
L2240634-13W	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-13X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-13Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-16A	Small Ampule	N/A	NA			Υ	Absent		A2-NFTPH(365)
L2240634-16B	Small Ampule	N/A	NA			Υ	Absent		A2-NFTPH(365)
L2240634-19A	Small Ampule	N/A	NA			Υ	Absent		A2-NFTPH(365)
L2240634-19B	Small Ampule	N/A	NA			Υ	Absent		A2-NFTPH(365)
L2240634-22A	Small Ampule	N/A	NA			Υ	Absent		TS100(),HOLD-NFSHC(365)
L2240634-22W	Vial unpreserved	N/A	NA			Υ	Absent		TS100(),HOLD-NFSHC(365)
L2240634-22X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		TS100(),HOLD-NFSHC(365)
L2240634-22Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		TS100(),HOLD-NFSHC(365)
L2240634-22Z	Vial MeOH preserved split	N/A	NA			Υ	Absent		TS100(),HOLD-NFSHC(365)
L2240634-25A	Vial unpreserved 20ml hard-cap	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
L2240634-25V	Glass 60mL/2oz unpreserved	N/A	NA			Υ	Absent		A2-NFTPH(365)
L2240634-25W	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-25X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-25Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-25Z	Vial unpreserved	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-28A	Small Ampule	N/A	NA			Υ	Absent		CANCELLED()
L2240634-28B	Small Ampule	N/A	NA			Υ	Absent		CANCELLED()
L2240634-29A	Small Ampule	N/A	NA			Υ	Absent		CANCELLED()
L2240634-29B	Small Ampule	N/A	NA			Υ	Absent		CANCELLED()
L2240634-30A	Small Ampule	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-30B	Small Ampule	N/A	NA			Υ	Absent		VPH-18(28)
L2240634-30W	Vial MeOH preserved split	NA	NA			Υ	Absent		VPH-18(28)
L2240634-30X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-31A	Small Ampule	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
L2240634-31B	Small Ampule	N/A	NA			Υ	Absent		VPH-18(28)



Lab Number: L2240634

**Report Date:** 09/08/22

Project Name: HAWAII DOH - FINGERPRINTING

Project Number: Not Specified

Container Information			Initial	Final	Temp			Frozen		
	Container ID	Container Type	Cooler			deg C Pres		Seal	Date/Time	Analysis(*)
	L2240634-31W	Vial MeOH preserved split	NA	NA			Υ	Absent		VPH-18(28)
	L2240634-31X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
	L2240634-32A	Vial unpreserved	N/A	NA			Υ	Absent		A2-NFTPH(365)
	L2240634-32V	Vial unpreserved split	N/A	NA			Υ	Absent		A2-NFTPH(365),A2-NFPIANO8260(365)
	L2240634-32W	Vial unpreserved split	N/A	NA			Υ	Absent		VPH-18(28)
	L2240634-32X	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
	L2240634-32Y	Vial unpreserved 20ml hard-cap split	N/A	NA			Υ	Absent		A2-NFPIANO8260(365)
	L2240634-32Z	Vial MeOH preserved split	N/A	NA			Υ	Absent		VPH-18(28)

## **Container Comments**

L2240634-30A	Ampule placed in Glass-A.120
L2240634-30B	Ampule placed in Glass-A.120
L2240634-31A	Ampule placed in Glass-A.120
L2240634-31B	Ampule placed in Glass-A.120



### **GLOSSARY**

### Acronyms

**EMPC** 

LOQ

MS

RPD

DL - Detection Limit: This value represents the level to which target analyte concentrations are reported as estimated values, when those target analyte concentrations are quantified below the limit of quantitation (LOQ). The DL includes any adjustments from dilutions, concentrations or moisture content, where applicable. (DoD report formats only.)

from dilutions, concentrations or moisture content, where applicable. (Dod report formats only.

EDL - Estimated Detection Limit: This value represents the level to which target analyte concentrations are reported as estimated values, when those target analyte concentrations are quantified below the reporting limit (RL). The EDL includes any adjustments from dilutions, concentrations or moisture content, where applicable. The use of EDLs is specific to the analysis of PAHs using Solid-Phase Microextraction (SPME).

 Estimated Maximum Possible Concentration: The concentration that results from the signal present at the retention time of an analyte when the ions meet all of the identification criteria except the ion abundance ratio criteria. An EMPC is a worst-case estimate of the concentration.

EPA - Environmental Protection Agency.

LCS - Laboratory Control Sample: A sample matrix, free from the analytes of interest, spiked with verified known amounts of analytes or a material containing known and verified amounts of analytes.

LCSD - Laboratory Control Sample Duplicate: Refer to LCS.

LFB - Laboratory Fortified Blank: A sample matrix, free from the analytes of interest, spiked with verified known amounts of analytes or a material containing known and verified amounts of analytes.

LOD - Limit of Detection: This value represents the level to which a target analyte can reliably be detected for a specific analyte in a specific matrix by a specific method. The LOD includes any adjustments from dilutions, concentrations or moisture content, where applicable. (DoD report formats only.)

- Limit of Quantitation: The value at which an instrument can accurately measure an analyte at a specific concentration. The LOQ includes any adjustments from dilutions, concentrations or moisture content, where applicable. (DoD report formats only.)

Limit of Quantitation: The value at which an instrument can accurately measure an analyte at a specific concentration. The LOQ includes any adjustments from dilutions, concentrations or moisture content, where applicable. (DoD report formats only.)

MDL - Method Detection Limit: This value represents the level to which target analyte concentrations are reported as estimated values, when those target analyte concentrations are quantified below the reporting limit (RL). The MDL includes any adjustments from dilutions, concentrations or moisture content, where applicable.

 Matrix Spike Sample: A sample prepared by adding a known mass of target analyte to a specified amount of matrix sample for which an independent estimate of target analyte concentration is available. For Method 332.0, the spike recovery is calculated using the native concentration, including estimated values.

MSD - Matrix Spike Sample Duplicate: Refer to MS.

NA - Not Applicable.

NC - Not Calculated: Term is utilized when one or more of the results utilized in the calculation are non-detect at the parameter's reporting unit.

NDPA/DPA - N-Nitrosodiphenylamine/Diphenylamine.

NI - Not Ignitable.

NP - Non-Plastic: Term is utilized for the analysis of Atterberg Limits in soil.

NR - No Results: Term is utilized when 'No Target Compounds Requested' is reported for the analysis of Volatile or Semivolatile

Organic TIC only requests.

RL - Reporting Limit: The value at which an instrument can accurately measure an analyte at a specific concentration. The RL includes any adjustments from dilutions, concentrations or moisture content, where applicable.

- Relative Percent Difference: The results from matrix and/or matrix spike duplicates are primarily designed to assess the precision of analytical results in a given matrix and are expressed as relative percent difference (RPD). Values which are less than five times the reporting limit for any individual parameter are evaluated by utilizing the absolute difference between the values; although the RPD value will be provided in the report.

SRM - Standard Reference Material: A reference sample of a known or certified value that is of the same or similar matrix as the associated field samples.

STLP - Semi-dynamic Tank Leaching Procedure per EPA Method 1315.

TEF - Toxic Equivalency Factors: The values assigned to each dioxin and furan to evaluate their toxicity relative to 2,3,7,8-TCDD.

TEQ - Toxic Equivalent: The measure of a sample's toxicity derived by multiplying each dioxin and furan by its corresponding TEF and then summing the resulting values.

TIC - Tentatively Identified Compound: A compound that has been identified to be present and is not part of the target compound list (TCL) for the method and/or program. All TICs are qualitatively identified and reported as estimated concentrations.

Report Format: DU Report with 'J' Qualifiers



#### **Footnotes**

1 - The reference for this analyte should be considered modified since this analyte is absent from the target analyte list of the original method.

#### **Terms**

Analytical Method: Both the document from which the method originates and the analytical reference method. (Example: EPA 8260B is shown as 1,8260B.) The codes for the reference method documents are provided in the References section of the Addendum.

Chlordane: The target compound Chlordane (CAS No. 57-74-9) is reported for GC ECD analyses. Per EPA,this compound "refers to a mixture of chlordane isomers, other chlorinated hydrocarbons and numerous other components." (Reference: USEPA Toxicological Review of Chlordane, In Support of Summary Information on the Integrated Risk Information System (IRIS), December 1997.)

Difference: With respect to Total Oxidizable Precursor (TOP) Assay analysis, the difference is defined as the Post-Treatment value minus the Pre-Treatment value.

Final pH: As it pertains to Sample Receipt & Container Information section of the report, Final pH reflects pH of container determined after adjustment at the laboratory, if applicable. If no adjustment required, value reflects Initial pH.

Frozen Date/Time: With respect to Volatile Organics in soil, Frozen Date/Time reflects the date/time at which associated Reagent Water-preserved vials were initially frozen. Note: If frozen date/time is beyond 48 hours from sample collection, value will be reflected in 'bold'.

Gasoline Range Organics (GRO): Gasoline Range Organics (GRO) results include all chromatographic peaks eluting from Methyl tert butyl ether through Naphthalene, with the exception of GRO analysis in support of State of Ohio programs, which includes all chromatographic peaks eluting from Hexane through Dodecane.

Initial pH: As it pertains to Sample Receipt & Container Information section of the report, Initial pH reflects pH of container determined upon receipt, if applicable.

PAH Total: With respect to Alkylated PAH analyses, the 'PAHs, Total' result is defined as the summation of results for all or a subset of the following compounds: Naphthalene, C1-C4 Naphthalenes, 2-Methylnaphthalene, 1-Methylnaphthalene, Biphenyl, Acenaphthylene, Acenaphthene, Fluorene, C1-C3 Fluorenes, Phenanthrene, C1-C4 Phenanthrenes/Anthracenes, Anthracene, Fluoranthene, Pyrene, C1-C4 Fluoranthenes/Pyrenes, Benza(a)anthracene, Chrysene, C1-C4 Chrysenes, Benzo(b)fluoranthene, Benzo(j)+(k)fluoranthene, Benzo(e)pyrene, Benzo(a)pyrene, Perylene, Indeno(1,2,3-cd)pyrene, Dibenz(ah)+(ac)anthracene, Benzo(g,h,i)perylene. If a 'Total' result is requested, the results of its individual components will also be reported.

PFAS Total: With respect to PFAS analyses, the 'PFAS, Total (5)' result is defined as the summation of results for: PFHpA, PFHxS, PFOA, PFNA and PFOS. In addition, the 'PFAS, Total (6)' result is defined as the summation of results for: PFHpA, PFHxS, PFOA, PFNA, PFDA and PFOS. For MassDEP DW compliance analysis only, the 'PFAS, Total (6)' result is defined as the summation of results at or above the RL. Note: If a 'Total' result is requested, the results of its individual components will also be reported.

Total: With respect to Organic analyses, a 'Total' result is defined as the summation of results for individual isomers or Aroclors. If a 'Total' result is requested, the results of its individual components will also be reported. This is applicable to 'Total' results for methods 8260, 8081 and 8082.

## Data Qualifiers

- A -Spectra identified as "Aldol Condensates" are byproducts of the extraction/concentration procedures when acetone is introduced in the process.
- The analyte was detected above the reporting limit in the associated method blank. Flag only applies to associated field samples that have detectable concentrations of the analyte at less than ten times (10x) the concentration found in the blank. For MCP-related projects, flag only applies to associated field samples that have detectable concentrations of the analyte at less than ten times (10x) the concentration found in the blank. For DOD-related projects, flag only applies to associated field samples that have detectable concentrations of the analyte at less than ten times (10x) the concentration found in the blank AND the analyte was detected above one-half the reporting limit (or above the reporting limit for common lab contaminants) in the associated method blank. For NJ-Air-related projects, flag only applies to associated field samples that have detectable concentrations of the analyte above the reporting limit. For NJ-related projects (excluding Air), flag only applies to associated field samples that have detectable concentrations of the analyte, which was detected above the reporting limit in the associated method blank or above five times the reporting limit for common lab contaminants (Phthalates, Acetone, Methylene Chloride, 2-Butanone).
- Co-elution: The target analyte co-elutes with a known lab standard (i.e. surrogate, internal standards, etc.) for co-extracted analyses.
- Concentration of analyte was quantified from diluted analysis. Flag only applies to field samples that have detectable concentrations of the analyte.
- E Concentration of analyte exceeds the range of the calibration curve and/or linear range of the instrument.
- F The ratio of quantifier ion response to qualifier ion response falls outside of the laboratory criteria. Results are considered to be an estimated maximum concentration.
- G The concentration may be biased high due to matrix interferences (i.e, co-elution) with non-target compound(s). The result should be considered estimated.
- H The analysis of pH was performed beyond the regulatory-required holding time of 15 minutes from the time of sample collection.
- I The lower value for the two columns has been reported due to obvious interference.
- Estimated value. The Target analyte concentration is below the quantitation limit (RL), but above the Method Detection Limit
   (MDL) or Estimated Detection Limit (EDL) for SPME-related analyses. This represents an estimated concentration for Tentatively

Report Format: DU Report with 'J' Qualifiers



#### Data Qualifiers

Identified Compounds (TICs).

- $\label{eq:main_equation} \textbf{M} \qquad \text{-Reporting Limit (RL) exceeds the MCP CAM Reporting Limit for this analyte.}$
- ND Not detected at the method detection limit (MDL) for the sample, or estimated detection limit (EDL) for SPME-related analyses.
- NJ Presumptive evidence of compound. This represents an estimated concentration for Tentatively Identified Compounds (TICs), where the identification is based on a mass spectral library search.
- ${f P}$  The RPD between the results for the two columns exceeds the method-specified criteria.
- Q The quality control sample exceeds the associated acceptance criteria. For DOD-related projects, LCS and/or Continuing Calibration Standard exceedences are also qualified on all associated sample results. Note: This flag is not applicable for matrix spike recoveries when the sample concentration is greater than 4x the spike added or for batch duplicate RPD when the sample concentrations are less than 5x the RL. (Metals only.)
- **R** Analytical results are from sample re-analysis.
- RE Analytical results are from sample re-extraction.
- S Analytical results are from modified screening analysis.
- The surrogate associated with this target analyte has a recovery outside the QC acceptance limits. (Applicable to MassDEP DW Compliance samples only.)
- The batch matrix spike and/or duplicate associated with this target analyte has a recovery/RPD outside the QC acceptance limits.
   (Applicable to MassDEP DW Compliance samples only.)

Report Format: DU Report with 'J' Qualifiers



### REFERENCES

Test Methods for Evaluating Solid Waste: Physical/Chemical Methods. EPA SW-846. Third Edition. Updates I - VI, 2018.

Method for the Determination of Volatile Petroleum Hydrocarbons (VPH), MassDEP, February 2018, Revision 2.1 with QC Requirements & Performance Standards for the Analysis of VPH under the Massachusetts Contingency Plan, WSC-CAM-IVA, June 1, 2018.

## **LIMITATION OF LIABILITIES**

Alpha Analytical performs services with reasonable care and diligence normal to the analytical testing laboratory industry. In the event of an error, the sole and exclusive responsibility of Alpha Analytical shall be to re-perform the work at it's own expense. In no event shall Alpha Analytical be held liable for any incidental, consequential or special damages, including but not limited to, damages in any way connected with the use of, interpretation of, information or analysis provided by Alpha Analytical.

We strongly urge our clients to comply with EPA protocol regarding sample volume, preservation, cooling, containers, sampling procedures, holding time and splitting of samples in the field.



Alpha Analytical, Inc. Facility: Company-wide

Department: Quality Assurance

Title: Certificate/Approval Program Summary

ID No.:17873

Revision 19

Page 1 of 1

Published Date: 4/2/2021 1:14:23 PM

Pre-Qualtrax Document ID: 08-113

## Certification Information

### The following analytes are not included in our Primary NELAP Scope of Accreditation:

### Westborough Facility

EPA 624/624.1: m/p-xylene, o-xylene, Naphthalene

EPA 625/625.1: alpha-Terpineol

EPA 8260C/8260D: NPW: 1,2,4,5-Tetramethylbenzene; 4-Ethyltoluene, Azobenzene; SCM: Iodomethane (methyl iodide), 1,2,4,5-Tetramethylbenzene;

EPA 8270D/8270E: NPW: Dimethylnaphthalene,1,4-Diphenylhydrazine, alpha-Terpineol; SCM: Dimethylnaphthalene,1,4-Diphenylhydrazine.

SM4500: NPW: Amenable Cyanide; SCM: Total Phosphorus, TKN, NO2, NO3.

## **Mansfield Facility**

**SM 2540D:** TSS

EPA 8082A: NPW: PCB: 1, 5, 31, 87,101, 110, 141, 151, 153, 180, 183, 187.

EPA TO-15: Halothane, 2,4,4-Trimethyl-2-pentene, 2,4,4-Trimethyl-1-pentene, Thiophene, 2-Methylthiophene,

3-Methylthiophene, 2-Ethylthiophene, 1,2,3-Trimethylbenzene, Indan, Indene, 1,2,4,5-Tetramethylbenzene, Benzothiophene, 1-Methylnaphthalene.

Biological Tissue Matrix: EPA 3050B

### The following analytes are included in our Massachusetts DEP Scope of Accreditation

### Westborough Facility:

#### **Drinking Water**

EPA 300.0: Chloride, Nitrate-N, Fluoride, Sulfate; EPA 353.2: Nitrate-N, Nitrite-N; SM4500NO3-F: Nitrate-N, Nitrite-N; SM4500F-C, SM4500CN-CE,

EPA 180.1, SM2130B, SM4500CI-D, SM2320B, SM2540C, SM4500H-B, SM4500NO2-B

EPA 332: Perchlorate; EPA 524.2: THMs and VOCs; EPA 504.1: EDB, DBCP.

Microbiology: SM9215B; SM9223-P/A, SM9223B-Colilert-QT,SM9222D.

#### Non-Potable Water

SM4500H,B, EPA 120.1, SM2510B, SM2540C, SM2320B, SM4500CL-E, SM4500F-BC, SM4500NH3-BH: Ammonia-N and Kjeldahl-N, EPA 350.1: Ammonia-N, LACHAT 10-107-06-1-B: Ammonia-N, EPA 351.1, SM4500NO3-F, EPA 353.2: Nitrate-N, SM4500P-E, SM4500P-B, E, SM4500SO4-E, SM5220D, EPA 410.4, SM5210B, SM5310C, SM4500CL-D, EPA 1664, EPA 420.1, SM4500-CN-CE, SM2540D, EPA 300: Chloride, Sulfate, Nitrate. EPA 624.1: Volatile Halocarbons & Aromatics,

EPA 608.3: Chlordane, Toxaphene, Aldrin, alpha-BHC, beta-BHC, gamma-BHC, delta-BHC, Dieldrin, DDD, DDE, DDT, Endosulfan II, Endosulfan II, Endosulfan sulfate, Endrin, Endrin Aldehyde, Heptachlor, Heptachlor Epoxide, PCBs

EPA 625.1: SVOC (Acid/Base/Neutral Extractables), EPA 600/4-81-045: PCB-Oil.

Microbiology: SM9223B-Colilert-QT; Enterolert-QT, SM9221E, EPA 1600, EPA 1603, SM9222D.

## Mansfield Facility:

## **Drinking Water**

EPA 200.7: Al, Ba, Cd, Cr, Cu, Fe, Mn, Ni, Na, Ag, Ca, Zn. EPA 200.8: Al, Sb, As, Ba, Be, Cd, Cr, Cu, Pb, Mn, Ni, Se, Ag, TL, Zn. EPA 245.1 Hg. EPA 522, EPA 537.1.

#### Non-Potable Water

EPA 200.7: Al, Sb, As, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Mo, Ni, K, Se, Ag, Na, Sr, TL, Ti, V, Zn.


EPA 200.8: Al, Sb, As, Be, Cd, Cr, Cu, Fe, Pb, Mn, Ni, K, Se, Ag, Na, TL, Zn.

EPA 245.1 Hg

SM2340B

For a complete listing of analytes and methods, please contact your Alpha Project Manager.

Document Type: Form



# Chain of Custody

# Environmental Forensics Practice LLC

L2240634

Proj. No	S: Signature	Proj. Name Hawaii DOl	H - Fingerprinting			Light Control								
oun case.	E	Enrc 4.4m	N.		ANALYSIS REQUESTED→ "NUMBER OF CONTANIERS"	UX Water)	-TPH	& F2 Fractions	MAVPH)	VOA				
DATE	TIME	LAB ID	CLIENT ID	SAN	IPLE DESCRIPTION	MATRIX (Oil/Soil/Water)	GC-FID-TPH (Cs+)	FI & F2 F	VPH-FID (MAVPH	PIANO - VOA				
7/26/2022		40634-01,62,03	Gasoline 87	L1801304.	- G P A	0	х	x	x		_		-	
/26/2022		04.05,06	Gasoline 91	L 1901304		0		- 27	-	X				_
//26/2022		07,08,09		41801304	2114	0	x	x	X	X			-	-
/26/2022		10,11,12		1011003	024	0	x	X	X	x	-	+	-	
/26/2022		13,14,15	Road Diesel	L1801304 ~	LIA	0	x	X	x	x			-	-
7/26/2022		16,17,13	JP-5	Accu stendard	- FU-011 - D-40K	0	x	x	x	x	-	++	-	
//26/2022	20 22	19,20,21	JP-8	Acuchadad	- FU -015 -D-404	0	x	X	x			+	-	+
/26/2022	-32,-33,	-34-22-23-24	Waste Oil (auto)	0509022- 0	- FU -015 -D-40X	0	x	X	X	x		+	-	-
/26/2022		25.26,27	Bunker C	L205243	A 50 - 5	0	x	-	x	x	-	++	+-	-
_	-								-	^				
-														
nquished	by:													
11 1	<b>A</b>			Date/Time	Received by:			-				D.	e/Time	
11/1	1/				201							Dat	c/ I ime	_
VL	V			7/29/12 9	A A						7/:	29/22	09	20
linquished	by:			DAME BUILD IN							5.40	2 6 22		
The state of the s	270			Date/Time	Received by:							Det	e/Time	
												Dat	i ime	
mments:	Samples to	be shipped to: Al	pha Laboratory											
	State Sand	32	20 Forbes Blvd. ansfield, MA 02048											
			el: (508) 822-9300											
			ttn: Sue Oneil											



818122

# Chain of Custody

# LZZ40634

## **Environmental Forensics Practice LLC**

Proj. No SAMPLERS	Signature	Proj. Name Hense	men NoH				ANA "NUME	LYSIS RE	QUESTED→ ONTAINERS"	UX slow)	-TPH	cyl PAH	markers	VOA	Lead	ST	m	des	WED	umber
DATE	TIME	LAB ID			IENT ID			AMPLE DES		MATRIX (* see below)	GC-FID-1 (C <sub>x</sub> +)	GCMS-Alkyl PAH	GCMS-Biomarkers	PIANO - VOA	Organic Lead	METALS	PCB	Pesticides	PRESERVED	Total Number of Containers
18/22		-28 -29	26-	8			he	o H		F	× ×			ž						
	0																			
Reinquished	by:				Dat	e/Time		Received by				3 0			-		E	ate/Ti	ime	
Relinquished	<- t				8 9 202	5952		Dog Received by	Welo	_	- 0	14	f L	- \		3/8	1/22	ate/Ti	3'40	_
Duri	Role	9 Ao	AL		3/3/22	e/Time	45			~(						81	8/20	-	164	5
Relinquished		Ja			8/8/2	190	$\infty$	Received by	Lis blex	_						81	du	ate/Ti	15v	7
* O=Oil SO=Soil SE=Sedir T=Tissue W=Wate			Samples to	be shippe	ed to: Alpha La 320 Forb Mansfiel Tel: (508 Attn: Suc	boratory es Blvd. d, MA 02 ) 844-41	2048	Comments												



# Chain of Custody

# Environmental Forensics Practice LLC

Proj. No		Proj. Name				1	_22	4 (	96.	34								
SAMPLERS	Signature	lu	4		A "NU	NALYSIS REQUESTE MBER OF CONTAIN	D <del>→</del> ERS"	RIX below)	GC-FID-TPH (Cs+)	GCMS-Alkyl PAH	GCMS-Biomarkers	PIANO - VOA	Organic Lead	METALS	PCB	Pesticides	PRESERVED	Total Number of Containers
DATE	TIME	LAB ID	80	CLIENT ID		SAMPLE DESCRIPTION		MAT (* see	GC-FII	GCMS-A	GCMS-B	PIANO	Organi	MET	)d	Pesti	PRESE	Total P
8/11/22	12:15	Acus	Acutos	Standard		Standard		Liqu	1									l
Relinquished	l by:	<u> </u>		De	te/Time	Received by:										Date/	Time	
Relinquished		1	-200	8/17/2	2 /2:1/3	Received by:	lle			A	AL	_		9/	וארי	2z Date/		:15
Relinquished	nide	o AAL		8/17/22	16:50	Received by:	Har	21	′					81	712	0	165	50
Reimquisned		ghan Muring	υ	817/02	1900	Acceived by:	11-	-						81	17/0	Date/		,W
* O=Oil SO=Soil SE=Sedi T=Tissue W=Wate	ment e		Samples to be ship	320 Fort Mansfie	aboratory bes Blvd. ld, MA 02048 8) 844-4117 e O'Neil	Comments:												

#### Quantitation Report (QT Reviewed)

Data Path : I:\VOLATILES\_GC\PVPH\2022\220902Aali\

Data File : P220902A33.D
Signal(s) : FID2B.ch

Acq On : 3 Sep 2022 1:23 am

Operator : PVPH:BAD

Sample : 12240634-25d,41,10,1.17,0.005,,w

Misc : WG1684889,ICAL19300,VPH-50 ALS Vial : 33 Sample Multiplier: 1

Integration File: autoint1.e
Quant Time: Sep 03 13:07:22 2022

Quant Method : I:\VOLATILES\_GC\PVPH\2022\220902Aali\vph-ali220830A.m

Quant Title : VPH ALIPHATIC


QLast Update : Wed Aug 31 12:33:08 2022

Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Sub List : Default - All compounds listed



vph-ali220830A.m Thu Sep 08 09:59:45 2022

#### Quantitation Report (QT Reviewed)

Data Path : I:\VOLATILES\_GC\PVPH\2022\220902Aaro\

Data File : P220902A33.D Signal(s) : CPDET1A.ch

Acq On : 3 Sep 2022 1:23 am

Operator : PVPH:BAD

Sample : 12240634-25d,41,10,1.17,0.005,,w

Misc : WG1684889,ICAL19301,VPH-50 ALS Vial : 33 Sample Multiplier: 1

Integration File: autoint1.e
Quant Time: Sep 03 13:53:04 2022

Quant Method: I:\VOLATILES\_GC\PVPH\2022\220902Aaro\vph-aro220830A.m

Quant Title : VPH AROMATIC


QLast Update : Wed Aug 31 12:38:17 2022

Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Sub List : Default - All compounds listed



vph-aro220830A.m Thu Sep 08 10:05:23 2022

#### Quantitation Report (QT Reviewed)

Data Path : I:\VOLATILES\_GC\PVPH\2022\220902Aali\

Data File : P220902A35.D
Signal(s) : FID2B.ch

Acq On : 3 Sep 2022 2:22 am

Operator : PVPH:BAD

Sample : 12240634-32d,41,10,1.01,0.02,,z

Misc : WG1684889, ICAL19300, VPH-50 ALS Vial : 35 Sample Multiplier: 1

Integration File: autoint1.e
Quant Time: Sep 03 13:08:26 2022

Quant Method : I:\VOLATILES\_GC\PVPH\2022\220902Aali\vph-ali220830A.m

Quant Title : VPH ALIPHATIC


QLast Update : Wed Aug 31 12:33:08 2022

Response via : Initial Calibration

Integrator: ChemStation

Volume Inj. : Signal Phase : Signal Info :

Sub List : Default - All compounds listed



vph-ali220830A.m Thu Sep 08 09:59:48 2022

## Chemistry and Toxicity of Petroleum Vapors (Brewer et al (2013) **Common TPH questions (HDOH 2012)**

Hawai'i DOH Appendix 6

OPEN ACCESS

International Journal of
Environmental Research and
Public Health
ISSN 1660-4601
www.mdpi.com/journal/ijerph

Article

# **Risk-Based Evaluation of Total Petroleum Hydrocarbons in Vapor Intrusion Studies**

Roger Brewer 1,\*, Josh Nagashima 1,†, Michael Kelley 2,†, Marvin Heskett 3,† and Mark Rigby 4,†

- Hawaii Department of Health, 919 Ala Moana Blvd Room 206, Honolulu, HI 96814, USA; E-Mail: josh.nagashima@doh.hawaii.gov
- <sup>2</sup> EA Engineering, Science and Technology, 615 Piikoi St #515, Honolulu, HI 96814, USA; E-Mail: mkelley@eaest.com
- <sup>3</sup> Geotek Hawaii, Inc., P.O. Box 1555, Pearl City, HI 96782, USA; E-Mail: mhesketts@mac.com
- <sup>4</sup> Parsons Corporation, 10235 South Jordan Gateway, Suite 300, South Jordan, UT 8409, USA; E-Mail: mark.rigby@parsons.com
- <sup>†</sup> These authors contributed equally to this work.
- \* Author to whom correspondence should be addressed; E-Mail: roger.brewer@doh.hawaii.gov; Tel.: +1-808-586-4249; Fax: +1-808-586-7537.

Received: 9 April 2013; in revised form: 8 May 2013 / Accepted: 24 May 2013 /

Published: 13 June 2013

Abstract: This paper presents a quantitative method for the risk-based evaluation of Total Petroleum Hydrocarbons (TPH) in vapor intrusion investigations. Vapors from petroleum fuels are characterized by a complex mixture of aliphatic and, to a lesser extent, aromatic compounds. These compounds can be measured and described in terms of TPH carbon ranges. Toxicity factors published by USEPA and other parties allow development of risk-based, air and soil vapor screening levels for each carbon range in the same manner as done for individual compounds such as benzene. The relative, carbon range makeup of petroleum vapors can be used to develop weighted, site-specific or generic screening levels for TPH. At some critical ratio of TPH to a targeted, individual compound, the overwhelming proportion of TPH will drive vapor intrusion risk over the individual compound. This is particularly true for vapors associated with diesel and other middle distillate fuels, but can also be the case for low-benzene gasolines or even for high-benzene gasolines if an adequately conservative, target risk is not applied to individually targeted

chemicals. This necessitates a re-evaluation of the reliance on benzene and other individual compounds as a stand-alone tool to evaluate vapor intrusion risk associated with petroleum.

**Keywords:** petroleum; TPH; carbon ranges; benzene; soil gas; soil vapor; vapor intrusion; risk assessment

#### 1. Introduction

Much emphasis has been placed in the past ten-plus years on the potential intrusion of chlorinated solvent vapors into buildings from underlying contaminated soil and groundwater. The study of vapor intrusion associated with subsurface releases of petroleum fuels is, in comparison, still in its infancy. The complex chemistry of petroleum fuels and the difficulty of predicting the fate and transport of vapors in the subsurface hamper the development of easy-to-use guidance that can be applied under multiple site scenarios. This paper addresses the first issue. Other efforts are currently underway to compile field data and address the second topic.

Petroleum-contaminated soil and groundwater are traditionally assessed in terms of Total Petroleum Hydrocarbons (TPH) and targeted, individual compounds such as benzene, toluene, ethylbenzene, xylenes and naphthalene (BTEXN). The buildup of methane vapors at petroleum-release sites can also pose potential fire and explosion hazards. This topic is beyond the scope of this paper, however. As noted in Table 1, non-specific, aliphatic and aromatic compounds collectively quantified as TPH make up the overwhelming mass of liquid fuels. Risk-based assessment of TPH in soil is well established and in use in numerous states [1–9]. While relatively straight forward, the quantitative inclusion of TPH in vapor intrusion investigations is less-well established and few papers and guidance documents have been published on this topic [10,11]. Some states require an assessment of potential vapor intrusion hazards associated with both TPH and individually targeted compounds at sites where long-term, *in situ* management of petroleum-contaminated soil or groundwater is proposed [12].

**Table 1.** Range of current and past BTEX and naphthalene (BTEXN) concentrations in petroleum fuels.

Chemical	Gasolines 1	Diesel <sup>2</sup>	Residuel Fuels <sup>3</sup>
Benzene	0.1-4.9%	0.003-0.1%	0.06-0.1%
Ethylbenzene	0.1-3%	0.007 – 0.2%	
Toluene	1–25%	0.007-0.7%	0.1-0.2%
Xylenes	1-15%	0.02-0.5%	0.2-0.3%
Naphthalene	<1%	0.01-0.8%	

<sup>&</sup>lt;sup>1</sup> Gasoline ranges after [1,13,14]; <sup>2</sup> Diesel #2 [1]; <sup>3</sup> Lubricating and motor oil [1].

This paper considers a series of key questions related to potential vapor intrusion concerns posed by TPH in contaminated soil and groundwater: (1) "How are the chemistry and toxicity of petroleum vapors characterized and evaluated?"; (2) "What is the composition of vapors emitted from fresh fuels and petroleum-contaminated soil and groundwater in terms of TPH and traditionally targeted,

individual compounds such as BTEXN?"; (3) "What is the chemical makeup of the TPH component of these vapors in terms of aliphatic and non-BTEXN aromatic carbon ranges?"; (4) "What is the toxicity of the TPH in terms of the weighted, carbon range composition?"; (5) At what critical ratio of TPH to an individual compound will the former begin to drive relative vapor intrusion risk over the latter, due to its overwhelming dominance of soil vapors?"; (6) "Under what site scenarios might vapor intrusion be driven by TPH rather than a individual compound such as benzene?"

The methodology described in this paper consists of six components: (1) Categorization of petroleum fuels into broad types based on the number of carbon atoms in compounds that typify the fuels, (2) Characterization of the non-BTEXN, TPH component of the fuels in terms of aliphatic and aromatic "carbon ranges", (3) Assignment of inhalation toxicity factors to volatile carbon ranges, (4) Calculation of risk-based, carbon range screening levels for indoor air and soil vapor, (5) Calculation of weighted screening levels for TPH based on the carbon range makeup of petroleum vapors, and (6) Calculation of the "critical ratio" of TPH in soil vapor to an individual chemical (e.g., benzene), at which point TPH will drive vapor intrusion risk over the individual compound even when a conservative, target risk is applied to the latter. These tools are then applied to two example sets of soil vapor data, the first associated with releases of gasolines and the second from sites associated with releases of middle distillates. The results are used to evaluate the relative role of TPH in vapor intrusion in comparison to traditionally targeted compounds such as benzene.

#### 2. Methods


#### 2.1. Categorization of Fuel Types

Petroleum fuels can be broadly categorized as "gasolines", "middle distillates" and "residual fuels", following the methodology used by the American Petroleum Institute [15]. The chemistry of these fuels has been extensively studied [1,16]. These categories in part reflect the number of carbon atoms in individual compounds that characterize the fuels (Figure 1). Compounds with less than approximately sixteen carbon atoms are considered to be "volatile" to "semi-volatile," with a propensity to partition into the vapor phase under ambient conditions. These compounds, which include a host of short-chain, aliphatic chemicals collectively measured as "TPH" as well as aromatic chemicals such as benzene, toluene, ethylbenzene, xylenes and naphthalene, are the primary target of vapor intrusion investigations. A summary of the BTEXN composition of petroleum fuels is provided in Table 1. Non-specific, TPH aliphatic and aromatic compounds comprise the remainder of the fuels.

Gasolines, including automotive gasoline and older jet fuels such as AVGAS, are dominated by "lighter" compounds with six to twelve carbon atoms. This causes gasolines to be highly volatile in comparison to other types of fuels. The amount of benzene, toluene, ethylbenzene and xylenes in gasolines can vary dramatically, from just a few percent to greater than 20%, depending on the refiner, the desired performance of the fuel and the historical time period that the fuel was produced (see Table 1). The benzene content of automotive gasolines can in particular vary significantly, from less than 0.1% to greater than 5% [14]. Recent regulations in the United States limit the average amount of benzene in gasolines to less than one-percent after the year 2011 in order to reduce health effects from exposure to

vapors and exhaust [17,18]. Older formulations of jet fuels and aviation gasoline likewise contained a relatively minor amount of benzene [13].

**Figure 1.** Composition of typical petroleum fuels with respect to the number of carbon molecules in individual compounds.



Middle distillate fuels (e.g., diesel, kerosene, JP-8 jet fuel, *etc.*) are dominated by hydrocarbon compounds with approximately nine to twenty-five carbon atoms and a relatively minor fraction of BTEX (see Table 1). Naphthalene, a suspected carcinogen, can comprise up to one-percent of these fuels. As a result, these fuels are less volatile than gasolines. Middle distillate fuels do, however, include a minor but important component of lighter and more volatile aliphatic compounds and, to a lesser extent, aromatic compounds. As discussed below, these aliphatic compounds not surprisingly dominate vapors emitted from these fuels under ambient conditions. Older jet fuels such as JP-4 are a mixture of gasoline and kerosene and again, while less volatile than gasolines, display a distinct vapor phase that is dominated by lighter-range aliphatic and aromatic compounds.

Residual fuels (e.g., Fuel Oil Nos. 4, 5, and 6, lubricating oils, "waste oils", asphalts, *etc.*) are characterized by complex, polar PAHs and other high molecular weight hydrocarbon compounds with carbon ranges that generally fall between C24 and C40. Residual fuels lack a significant amount of volatile compounds (e.g., see Table 1) and, aside from the potential generation of methane, are generally assumed to pose a minimal vapor intrusion risk. This subsequent focus of this paper will therefore be on vapors associated with gasolines and middle distillate fuels.

#### 2.2. Characterization Total Petroleum Hydrocarbons Using Carbon Ranges

Understanding the chemical makeup of the TPH component of petroleum fuels and more importantly the vapors emitted from these fuels is important, first step to evaluate the role of these compounds in vapor intrusion. Petroleum is a complex mixture of hundreds of different compounds composed of hydrogen and carbon or "hydrocarbons". These compounds can be collectively grouped into "aromatic" and "aliphatic" carbon ranges, based in part on the number of carbon atoms in each compound [1].

Compounds formed by single or multiple, six-carbon rings are referred to as "aromatic". Aromatic compounds include the familiar chemicals benzene, toluene, ethylbenzene and xylenes (BTEX) as well as naphthalene and other "polyaromatic" hydrocarbons. A small percentage of additional, aromatic compounds are included in the TPH component of fuels. These include alkylated compounds such as trimethylbenzene, which although sometimes reported by laboratories as part of an environmental investigation are not traditionally evaluated in human health and ecological risk assessments as individual chemicals.

Compounds formed by chains or non-aromatic rings of carbon and hydrogen are referred to as "aliphatic" and include such chemicals as pentane, hexane and octane. These compounds make up the bulk of petroleum fuels [1]. A host of additional terms are used to classify aliphatic compounds in more detail, depending for example on the presence or absence of ring structures, nature of carbon bonds, saturation with hydrogen and overall chemical structure (e.g., "alkanes", "alkenes", "olefins" and "cycloalkanes", etc.).

Evaluation of each individual, TPH-related aromatic and aliphatic compound as part of an environmental investigation is not feasible or practical due to the large number of compounds involved and the lack of physiochemical and toxicological information for these chemicals. The TPH component of petroleum is instead evaluated in terms of "carbon ranges" of aliphatic and aromatic compounds. Carbon ranges are defined by groups of aliphatic or aromatic compounds that exhibit similar physiochemical and, presumably, toxicological characteristics. Carbon range fractions designated by Massachusetts are the most commonly referenced in the United States (see Figure 1) [19]:

- C5-C8 aliphatics:
- C9-C12 aliphatics;
- C13-C18 aliphatics;
- C19-C36 aliphatics;
- C9-C10 aromatics:
- C11-C22 aromatics.

These carbon range groups represent a consolidation and simplification of a larger number of ranges originally published by the TPH Criteria Working Group, an environmental consortium of regulators, consultants and oil company experts convened to develop a more comprehensive, risk-based approach for the evaluation of petroleum-contaminated soil and groundwater [20]. This was done in part on available toxicity factors for individual ranges. Compounds that fall within the C5-C8 aliphatic carbon range are the most volatile, although C9-C12 aliphatics and C9-C10 aromatics also fall in this category. Compounds that fall within the C13-C18 aliphatic and C11-C22 aromatic carbon ranges are

considered to be "semi-volatile." Aliphatic compounds with greater than 18 carbon atoms and aromatic compounds with greater than ten carbon atoms are not considered to be volatile. Carbon ranges can also be defined in terms of "Equivalent Carbons," based on the boiling point of individual compounds [5,20].

As discussed below, assignment of physiochemical and toxicological parameter values to individual carbon ranges allows for quantitative inclusion of TPH in environmental risk assessments in the same manner as individual compounds. This includes the development of risk-based screening levels for water, soil, soil vapor and indoor air. This approach was first developed by the Total Petroleum Hydrocarbon Criteria Working Group [20]. Guidance on the use of carbon-range approaches to quantitatively evaluate the non-BTEX, TPH component of petroleum-contaminated media was subsequently developed by a number of state agencies (e.g., [2–6,8,9]).

The bulk chemistry of petroleum fuels in terms of TPH carbon ranges and commonly targeted, individual, aromatic compounds is summarized in Table 2 (after [2,21]). Aliphatic compounds dominate both the TPH and overall component of petroleum fuels. Gasolines are dominated by C5-C8 aliphatics and C9-C12 aromatics, although the proportion of the latter can vary widely depending on the fuel blend. Residual fuels are dominated by longer-chain aliphatics and a lesser amount of polyaromatic hydrocarbons.

**Table 2.** Example carbon range makeup of non-BTEXN, TPH component of petroleum fuels (exact carbon range makeup of individual fuels will vary).

Carbon Range	Gasolines 1	Diesel 1	Residual Fuels <sup>2</sup>
C5-C8 aliphatics	45%	<1%	<1%
C9-C18 aliphatics	12%	35%	<1%
C19+ aliphatics	<1%	43%	75%
C9-C12+ aromatics	43%	22%	25%

<sup>&</sup>lt;sup>1</sup> Indiana Department of Environmental Management [21]; <sup>2</sup> Massachusetts Department of Environmental Protection [2].

Physiochemical constant values published by Massachusetts [2], currently most in use in the US, are summarized in Table 3. Values for BTEX and naphthalene are included for comparison [22]. The chemical makeup of vapors emitted from petroleum fuels is predictable based on the composition of the fuels and the theoretical partitioning of chemicals into sorbed, dissolved and vapor phases upon release to the environment [23]. Vapors emitted from fresh gasolines can be predicted to be dominated by C5-C8 aliphatics (and C2-C4 aliphatics, if present) based both on the abundance and relative volatility of these compounds, with a variable but lesser amount of BTEX and other aromatic compounds depending on the specific fuel blend (see also [24] and [25]). While less volatile than gasolines, diesel and other middle distillate fuels contain variable amounts of C5-C8 aliphatics and a relatively large component of C9-C18 aliphatics (see Table 2). These compounds should again dominate vapors emitted from the fuels. The relative proportion of C5-C8 to C9-C12 aliphatics in vapors will depend in part on the original composition of the fuel (see also [26]). The fraction of BTEX in the vapors should be significantly smaller than for gasolines, given their lower relative abundance.

This general makeup of petroleum vapors is indeed observed in the case studies presented later in this paper. As discussed in the case studies, soil vapor samples from some of the middle distillate-release sites contain a significant proportion of C5-C8 "gasoline-range" compounds. Requesting a lab to test a sample for "diesel-range" hydrocarbons as the sum of C9 and higher compounds is reasonable for soil, since this fraction dominates the liquid fuel and should similarly dominate the TPH present in the soil. Requesting that TPH be quantified in terms of traditional, diesel-range compounds for soil vapor could result in a significant underreporting of the total TPH present, however. Laboratories should instead be requested to report TPH in soil vapors simply as the sum of C5 to C12 hydrocarbons for both gasoline- and middle distillate-contaminated sites. Testing for additional, heavier vapor-phase compounds (e.g., C13+ aliphatics) may also be necessary. This is discussed further in the following section, as well as in the example case studies.

Chemical/Carbon	Molecular	Vapor Pressure	Solubility in Water	Henry's Constant	Partition Coeff,		ffusion ient (cm²/s)
Range <sup>1</sup>	Weight	(atms)	(mg/L)	(unitless)	$k_{oc} (cm^3/g)$	air	water
Benzene	78	0.1	1,790	0.23	146	0.09	$1 \times 10^{-5}$
Ethylbenzene	106	0.01	169	0.32	446	0.068	$8.5 \times 10^{-6}$
Toluene	92	0.04	526	0.27	234	0.078	$9.2 \times 10^{-6}$
Xylenes	106	0.01	161	0.29	375	0.068	$8.4 \times 10^{-6}$
Naphthalene	128	$1.0 \times 10^{-4}$	30	0.018	1,540	0.06	$8.4 \times 10^{-6}$
C5-C8 Aliphatics	93	0.1	11	54	2,265	0.08	$1 \times 10^{-5}$
C9-C12 Aliphatics	149	$8.7 \times 10^{-4}$	0.07	65	150,000	0.07	$1 \times 10^{-5}$
C13-C18 Aliphatics	170	$1.4 \times 10^{-4}$	$3.5 \times 10^{-4}$	69	680,000	0.07	$5.0 \times 10^{-6}$
C19-C36 Aliphatics	280	$1.1 \times 10^{-6}$	$1.5 \times 10^{-6}$	110	$4.0 \times 10^{-8}$		
C9-C10 Aromatics	120	$2.9 \times 10^{-3}$	51	0.33	1,778	0.07	$1 \times 10^{-5}$
C11-C22 Aromatics	150	$3.2 \times 10^{-5}$	5.8	0.03	5,000	0.06	$1 \times 10^{-5}$

**Table 3.** Default physiochemical constants for BTEXN and TPH carbon ranges.

#### 2.3. Assignment of Inhalation Toxicity Factors to Carbon Ranges

Key to the risk-based assessment of TPH in vapor intrusion investigations is the assignment of inhalation toxicity factors or "Reference Concentrations (RfC)" to individual, volatile carbon ranges. A summary of published inhalation toxicity factors for carbon ranges is presented in Table 4. Lower RfCs reflect progressively increasing toxicity (*i.e.*, less of the chemical is required to result in a health effect).

The TPH Criteria Working Group published an extensive overview of the carbon range chemistry of petroleum fuels in the late 1990s and assigned preliminary toxicity factors to each fraction [28]. The US Department of Health and Human Services quickly published updated guidance in 1999 [29]. The Massachusetts Department of Environmental Protection published initial guidance during the same time period and last updated their factors for carbon range fractions in 2003 [19]. The Washington Department of Ecology published toxicity factors for TPH carbon ranges in 2005 and 2006 [5]. In 2009, the California EPA Department of Toxics Substances Control published guidance

<sup>&</sup>lt;sup>1</sup> Constants for BTEXN from USEPA RSL guidance [22]; vapor pressures from TOXNET [27]; Carbon range values from Massachusetts DEP [2] except C13-C18 Aliphatics (based on EC > 12–16) and C19-C36 Aliphatics (based on EC > 16–35 aliphatics) [20].

and proposed toxicity factors similar to those proposed by MADEP [30]. The USEPA National Center for Environmental Assessment published a detailed review of TPH carbon range toxicity and recommended Provisional Peer-Reviewed Toxicity Values (PPRTVs) in 2009 [16].

**Table 4.** Published inhalation toxicity factors for petroleum aliphatic and aromatic carbon ranges (listed in order of publication).

Reference	RfC (mg/m <sup>3</sup> )	RfC (μg/m <sup>3</sup> )
TPH Criteria Working Group [28]	. =	
(C5-C8) Aliphatics	18.4	18,400
(C9-C18) Aliphatics	1.0	1,000
(C9-C16) Aromatics	0.2	200
USDHHS <sup>1</sup> [29]		
(C5-C8) Aliphatics	2.2	2,200
(C9-C18) Aliphatics	0.3	300
(C9-C16) Aromatics	0.01	10
Massachusetts DEP [19]		
(C5-C8) Aliphatics	0.2	200
(C9-C18) Aliphatics	0.2	200
(C9-C18) Aromatics	0.05	50
Washington DOE <sup>2</sup> [5]		
(C5-C8) Aliphatics	6.0	5,950
(C9-C16) Aliphatics	0.3	298
(C9-C10) Aromatics	0.399	399
(C11-C12) Aromatics (naphthalene)	0.003	3.0
(C13-C16) Aromatics	0.2	175
CalEPA-DTSC <sup>3</sup> [30]		
(C5-C8) Aliphatics	0.7	700
(C9-C18) Aliphatics	0.3	300
(C9-16) Aromatics	0.05	50
USEPA <sup>4</sup> [16]		
(C5-C8) Aliphatics (noncancer)	0.6	600
(C9-C18) Aliphatics	0.1	100
(C9-C16) Aromatics	0.1	100

<sup>&</sup>lt;sup>1</sup> ATSDR C5-C8 aliphatics RfC converted to 2.2 mg/m<sup>3</sup> from 0.6 ppm based on hexane molecular weight of 86; C9-C16 aromatics RfC converted to 0.01 mg/m<sup>3</sup> from 0.002 ppm based on naphthalene molecular weight of 128; <sup>2</sup> Washington DOE Inhalation Reference Dose extrapolated to a Reference Concentration: using RfC (mg/m<sup>3</sup>) = RfD (mg/kg-day) × 70 kg × (1/20m<sup>3</sup>-day); <sup>3</sup> California EPA toxicity factors withdrawn in 2010 pending review of additional data; <sup>4</sup> USEPA toxicity factors selected for calculation of risk-based indoor air and soil vapor screening levels.

The variability of published toxicity factors for individual carbon ranges is important, since this directly affects the estimated risk (or more appropriately noncancer hazard) posed by TPH in a vapor intrusion study. Of particular interest is the RfC assigned to C5-C8 aliphatics, since as discussed above and noted in case studies below, these compounds tend to dominate the TPH component of petroleum vapors. For example, the inhalation RfC published by USEPA (600  $\mu$ g/m³) is less conservative (*i.e.*, higher) than the correlative toxicity factor published by Massachusetts (200  $\mu$ g/m³) but an order of magnitude or more lower than toxicity factors published by the State of Washington (equal to 5,950  $\mu$ g/m³) and the earlier toxicity factor the TPH Criteria Working Group (18,400  $\mu$ g/m³).

Based on a review of published guidance, the State of Hawaii [8] opted to incorporate PPRTVs for volatile carbon ranges published by the USEPA [16]. Conclusions drawn from the case studies

presented would necessarily differ based on the toxicity factors selected for the carbon ranges. Full consensus is rarely if ever reached on toxicity values for specific chemicals, however, including toxicity factors posted to USEPA's IRIS database—considered to be the most supportable and defensible database available. States as well as USEPA routinely draw on available information for assessment of the health risk posed by chemicals that are not currently listed in IRIS. Indeed, Regional Screening Levels published in USEPA's guidance document are based in part or entirely on PPRTV toxicity factors for over one-hundred of the chemicals listed [22].

A summary of the PPRTV inhalation toxicity factors [16] for carbon ranges and inhalation toxicity factors for BTEXN is provided in Table 5. The toxicity factors address systemic, noncancer health hazards. Cancer risk is assumed to be driven by well-studied, individual compounds such as benzene, ethylbenzene and naphthalene [8,22].

Chemical	IUR <sup>1</sup> (μg/m <sup>3</sup> ) <sup>-1</sup>	RfC $^2$ (µg/m $^3$ )
Benzene	7.8E-06	30
Ethylbenzene	2.5E-06	1,000
Toluene		5,000
Xylenes		100
Naphthalene	3.4E-05	3.0
C5-C8 aliphatics		600
C9-C18 aliphatics		100
C9+ aromatics		100

**Table 5.** Inhalation toxicity factors for targeted VOCs and carbon range fractions.

#### 2.4. Calculation of Risk-Based Air and Soil Vapor TPH Screening Levels

Calculation of risk-based screening levels for TPH in indoor air and soil vapor or direct inclusion in human-health risk assessments is relatively straight forward following assignment of inhalation toxicity factors to volatile carbon ranges. Accurate quantitative evaluation of vapor intrusion risks based on soil and groundwater data is much more difficult, as discussed earlier, due to the variability of biodegradation and attenuation processes on a site-by-site basis. This likewise impedes the development of meaningful TPH screening levels for other than subslab or very shallow soil vapors [8]. The collection of sub-slab soil vapor samples helps to minimize uncertainty regarding the fate and transport of petroleum vapors in the subsurface, since these vapors can be assumed to undergo minimal, additional attenuation prior to intruding into an overlying building.

For the purposes of this paper, the PPRTV toxicity factors published by the USEPA in 2009 [16] were selected for calculation of example, indoor air and subslab soil vapor screening levels for individual carbon ranges (see Table 4). The development of indoor air and subslab, soil vapor screening levels for vapor intrusion can be condensed into three relatively simple steps: (1) Calculation of a target indoor-air goal based on the assigned toxicity factor and default exposure assumptions (e.g., exposure frequency and duration); (2) Assignment of an indoor air: subslab soil vapor attenuation

<sup>&</sup>lt;sup>1</sup> Inhalation Unit Risk [22]; <sup>2</sup> Reference Concentration; BTEXN RfCs from USEPA [22]; Carbon Range RfCs from USEPA [16].

factor based on a comparison of vapor flow rates into a building and air flow rates through the building and (3) Calculation of a soil vapor screening level. A summary of these steps is provided below.

Indoor air screening levels can be calculated using the ambient air equations presented in the USEPA Regional Screening Level guidance [22]:

Carcinogens: Cia = 
$$\frac{TR \times ATc \times 365 \text{ days/year}}{IUR \times EF \times ED}$$
 (1)

Noncarcinogens): Cia = 
$$\frac{TR \times ATnc \times 365 \text{ days/year}}{\frac{1}{RfC} \times EF \times ED}$$
 (2)

where:

Cia = Indoor air concentration ( $\mu g/m^3$ );

 $TR = Cancer Target risk (10^{-6}, unitless);$ 

THQ = Noncancer Target Hazard Quotient (1.0, unitless);

ATc = Carcinogen Averaging Time (70 years);

ATnc = Noncancer Averaging time (30 years);

IUR = Cancer Inhalation Unit Risk (chemical-specific,  $(\mu g/m^3)^{-1}$ )

RfC = Noncancer Reference Concentration (chemical-specific,  $\mu g/m^3$ );

EF = Exposure frequency (350 days/year); and

ED = Exposure duration (30 years).

Default exposure and target risk parameter values used for calculation of the indoor air screening levels are noted above and based on residential exposure assumptions used for development of the USEPA RSLs [22].

Example indoor-air screening levels for BTEX, naphthalene and carbon ranges based on the above equations and exposure assumptions and toxicity factors noted in Table 4 are presented in Table 6. Noncancer screening levels for benzene, ethylbenzene and naphthalene are not shown, since they would be higher than and over ridden by cancer-based screening levels. A target excess cancer risk was of  $10^{-6}$  was used for carcinogenic VOCs. A target Hazard Quotient of 1.0 was used for noncancer-based screening levels. Note that these screening levels do not directly take into account cumulative risk posed by the potential presence of other chemicals with similar health effects. This is less of an issue for screening levels based on cancer risk, since they are set at the most conservative end of the target risk range of  $10^{-4}$  to  $10^{-6}$ . Consideration of potential cumulative risk is especially important for screening levels based on noncancer concerns, however, since no safety margin is included (*i.e.*, maximum target Hazard Index often set at 1.0) [22].

Calculation of a subslab soil vapor-to-indoor air attenuation factor (AF) essentially reduces to:

$$AF(unitless) = \frac{Vapor Flux Rate}{Vapor Flux Rate + Indoor Air Exchange Rate}$$
(3)

For the purposes of this paper, indoor air-soil vapor attenuation factors of 0.001 (residential scenario) and 0.0005 (commercial/industrial scenario) published by the state of Hawaii were referred to for calculation of soil vapor screening levels [8]. These attenuation factors are based on building

ventilation rates typical of tropical and Mediterranean climates and may not be appropriate for use in colder regions where buildings are heated for much of the year, but are adequate for demonstration purposes. The rapid breakdown of aliphatic compounds under aerobic conditions is anticipated to significantly lower the persistence of aliphatic compounds in indoor air in comparison to chlorinated solvents and play an important role in the reduction of long-term, vapor intrusion risk [31]. A detailed discussion of this issue is beyond the scope of this paper, however, and the noted attenuation factors are presented for use as examples only.

	]	Indoor Air <sup>1</sup>	Subslab Soil Vapor <sup>2</sup>				
Chemical	Residential (μg/m³)	Commercial/Industrial (µg/m³)	Residential (μg/m³)	Commercial/Industrial (µg/m³)			
Benzene	0.31	1.6	310	3,200			
Ethylbenzene	0.97	4.9	970	9,800			
Toluene	5,200	22,000	5,200,000	44,000,000			
Xylenes	100	440	100,000	880,000			
Naphthalene	0.072	0.36	72	720			
C5-C8 aliphatics	630	880	630,000	1,760,000			
C9-C18 aliphatics	100	150	100,000	300,000			
C9-C16 aromatics	100	150	100,000	300,000			

**Table 6.** Example indoor air and subslab, soil vapor screening levels for petroleum-related chemicals.

Soil-gas screening levels (C<sub>sg</sub>) are subsequently calculated as:

$$Csg = \frac{Indoor Air Goal}{AF}$$
 (4)

Example subslab soil-gas screening levels for BTEXN and volatile aliphatic and aromatic carbon ranges, and TPH using the above approach are included in Table 6.

Screening levels for C5-C8 aliphatics are the least stringent of the carbon range compounds (e.g., indoor air screening level 630  $\mu g/m^3$ ), reflecting the higher inhalation Reference Concentration assigned to this fraction of 600  $\mu g/m^3$ . Screening levels for C9-C18 aliphatics and C9-C16 aromatics are most stringent, reflecting the lower Reference Concentration of 100  $\mu g/m^3$  common to both fractions and generating an identical indoor air screening level of 100  $\mu g/m^3$ , after rounding. The screening levels are based on a target, noncancer hazard quotient of 1.0.

The example soil-gas screening levels do not take into account an expected decrease in vapor concentrations over time due to biodegradation and source area depletion and can be overly conservative for sites with limited contamination. Mass-balance approaches can be used to estimate maximum, average vapor concentrations over the assumed exposure duration based on an estimate of the mass of the chemical present in the source area.

As discussed later in this paper, a comparison of TPH carbon range screening levels to screening levels for individual compounds provides a useful tool to determine if the former might drive vapor

<sup>&</sup>lt;sup>1</sup> Based on target cancer risk of 10<sup>-6</sup> (benzene, ethylbenzene, naphthalene) or noncancer Hazard Quotient of 1.0 (toluene, xylenes and carbon range compounds); <sup>2</sup> Based on indoor air-soil vapor (subslab) attenuation factors of 0.001 for residential structures and 0.0005 for commercial/industrial structures (after [8]; for example only).

intrusion risk over the latter at a site. Calculation and use of a single, TPH screening level weighted with respect to the representative (or assumed), carbon range makeup of petroleum vapors at a site will significantly speed up this process, however, and avoid the need to collect expensive carbon range data for every sample. Variability in TPH composition within a site due to biodegradation and other factors that affect partitioning (e.g., soil moisture and organic carbon content) can complicate this assessment, however. In these cases use of the most conservative, weighted RfC calculated for the site may be warranted.

#### 2.5. Calculation of Weighted, TPH Screening Levels

The use of TPH soil vapor data is generally preferable for initial screening of petroleum-contaminated sites due to the added cost and the currently limited number of laboratories that can provide vapor-phase carbon range data. The following equation can be used to calculate weighted inhalation Reference Concentration (RfC) for TPH based on the site-specific carbon range makeup of TPH in soil vapor or indoor air [8,10]:

$$\begin{aligned} &\text{Weighted RfC } \left( \frac{\mu g}{m^3} \right) \\ &= \frac{1}{\left[ \left( \frac{\text{Fraction C5} - \text{C8 Aliphatics}}{\text{C5} - \text{C8 Aliphatics RfC}} \right) + \left( \frac{\text{Fraction C9} - \text{C18 Aliphatics}}{\text{C9} - \text{C18 Aliphatics RfC}} \right) + \left( \frac{\text{Fraction C9} - \text{C16 Aromatics}}{\text{C9} - \text{C16 Aromatics RfC}} \right) \right]} \end{aligned} \tag{5}$$

This approach can be used to calculate weighted TPH toxicity factors (RfCs) and associated indoor air and soil vapor screening levels based on either site-specific data or an assumed, carbon range makeup of TPH vapors for a specified fuel type.

Very few studies have been published regarding the detailed, carbon range makeup of vapors from common petroleum fuels. Carbon range data presented in the USEPA Petroleum Vapor Intrusion (PVI) database were used to approximate the chemistry and ultimately the weighted toxicity of TPH vapors associated with gasolines (see paper Supplementary Material) [32]. The database is intentionally biased toward gasoline-contaminated sites, although as noted later in this paper significantly high TPH:Benzene ratios for some samples suggest that data from diesel-contaminated sites may also be included.

For illustration purposes in this paper, the average carbon range makeup of the data presented in the USEPA database was used to approximate the carbon range makeup of gasoline vapors in general. The review was limited to samples from gasoline-only sites with paired TPH and benzene data and reported concentrations of TPH >1,000 μg/m³. The latter filter was included in order to limit potential biases due to laboratory detection limits or interference from background, petroleum vapors associated with unrelated, indoor or outdoor sources [2]. Apparent duplicate sample data for some sites was also ignored (*i.e.*, identical concentrations of TPH and benzene). A total of 364 samples from 48 sites met these criteria (see paper supplement). Carbon range data were included for 35 samples from ten of the original 48 sites. The average carbon range composition of TPH in the samples is 77.3% C5-C8 aliphatics, 15.4% C9-C12 aliphatics and 7.3% C9-C10 aromatics. The aliphatic and aromatic makeup of the samples spans a broad range, with the median composition more biased toward C5-C8 aliphatics than the mean composition. The proportion of C5-C8 aliphatics in the samples ranges from 12% to 100%,

with a median of 88%. The proportion of C9-C12 aliphatics ranges from 0% to 77%, with a median of 10%. The proportion of C9-10 aromatics ranges from 0% to 55%, with a median of median 2%.

For the purposes of this example, the average carbon range makeup of the samples in the USEPA PVI database report [32]was used to generate a weighted, TPH RfC for gasoline vapors of 279 µg/m<sup>3</sup> using Equation 5 above:

Weighted RfC = 
$$\frac{1}{\left[\left(\frac{0.773}{600}\right) + \left(\frac{0.154}{100}\right) + \left(\frac{0.073}{100}\right)\right]} = 279 \,\mu\text{g/m}^3$$
 (6)

Risk-based screening levels and associated "critical ratios" for TPH vapors associated with gasoline (TPHg) based on this example RfC are used later in this paper to evaluate a soil vapor database for gasoline-contaminated sites published by the USEPA.

Even less data are available for the carbon range makeup of vapors from diesel and other middle distillates. A limited, field study by the Hawaii Department of Health (HDOH) identified a highly variable composition of vapors for diesel fuels and jet fuels, with C5-C8 aliphatics dominating at some sites and C9-C12 aliphatics dominating at others [10]. Data from this study are discussed later in this paper. The study intentionally focused on diesel- and middle distillate-contaminated sites, as a compliment to the developing, USEPA database for gasoline-contaminated sites. Sorbent tube data suggested an insignificant amount of C13-C18 aliphatics and C11-C16 aromatics in the samples. For the purposes of this paper, the hypothetical TPH composition for diesel and other middle distillate vapors of 25% C5-C8 aliphatics, 75% C9-C12 aliphatics and 0% C9-C16 aromatics adopted by HDOH for use in their guidance was selected. This generates a carbon range-weighted, TPH RfC for middle distillate vapors (TPHd) of 130 μg/m³:

Weighted RfC = 
$$\frac{1}{\left[\left(\frac{0.25}{600}\right) + \left(\frac{0.75}{100}\right) + \left(\frac{0.00}{100}\right)\right]} = 130 \,\mu\text{g/m}^3$$
 (7)

Note that the HDOH study did not identify a significant proportion of aliphatic compounds greater than C12 and aromatic compounds greater than C10 at any of the sites investigated. Laboratory-based studies have suggested a dominance of heavier compounds in vapors from some middle distillate fuels, however [26]. This would not significantly alter the weighted RfC for middle distillate vapors, since the toxicity of these compounds is assumed to be identical to medium-weight aliphatics and aromatics (see Table 4).

**Table 7.** Example, indoor air and soil vapor screening levels for TPH based on default, carbon range compositions for gasolines and middle distillates noted in text.

		Indo	or Air <sup>1</sup>	Subslab S	oil Vapor <sup>2</sup>
Fuel Type	Weighted RfC (μg/m³)	Residential (μg/m³)	Commercial/ Industrial (µg/m³)	Residential (μg/m³)	Commercial/ Industrial (µg/m³)
Gasolines	279	290	410	290,000	810,000
Middle Distillates	130	140	190	140,000	380,000

<sup>&</sup>lt;sup>1</sup> Based on noncancer Hazard Quotient of 1.0; <sup>2</sup> Based on indoor air-soil vapor (subslab) attenuation factors of 0.001 for residential structures and 0.0005 for commercial/industrial structures (for example only) (after [8]).

The weighted, TPH toxicity factors for gasoline and diesel vapors can now be used to calculate TPHg and TPHd screening levels for indoor air and soil vapor in the same manner as done for individual compounds. Total Petroleum Hydrocarbon screening levels based on the equations and exposure assumptions discussed earlier are presented in Table 7. These screening levels can now be used to estimate "critical ratios" where the proportion of TPH in vapors in comparison to individual, targeted compounds such as benzene reaches a point that TPH will drive vapor intrusion risk.

#### 2.6. Calculation of TPH Critical Ratios

The relative risk posed by two (or more) different chemicals under a given exposure pathway (e.g., vapor intrusion) is in part a function of toxicity and concentration. Aliphatic compounds that dominate TPH are, for example, significantly less toxic than benzene at equivalent exposure concentrations. This can be seen by a simple comparison of indoor air and soil vapor screening levels for carbon ranges and benzene in Tables 6 and 7. At some "critical ratio", however, the overwhelming proportion of TPH in the vapors will override the risk posed by benzene and TPH will "drive" vapor intrusion risk. (Note that the term "risk" is used in a generic fashion to denote "noncancer hazard" and/or "excess cancer risk.")

This ratio represents the weighted, indoor air, TPH screening level calculated for the samples divided by the indoor air screening level for benzene. If the ratio of TPH to benzene in soil vapor measured in the field exceeds this value, then the concentration of TPH in indoor air (or soil vapor) would in theory still exceed its risk-based screening level even though the concentration of benzene was at or below its respective screening level. If the critical ratio is not exceeded, then the concentration of TPH in indoor air (or soil vapor) would be at or below its respective screening level when the screening level for benzene is met. In the first case, TPH can be said to "drive" vapor intrusion risk, since screening and/or remediation of a site to address TPH vapors would coincidentally address potential vapor intrusion risks posed by benzene. In the second case, benzene can be said to drive vapor intrusion risk (*i.e.*, potential vapor intrusion risks posed by TPH would be adequately addressed at the point that the risk posed by benzene is addressed. This assumes, among other factors, that the average ratio of TPH to benzene calculated for the samples reflects the ratio in subslab soil vapor at the point that vapors intrude an overlying building.

As noted in Table 6, screening levels for TPH in indoor air or soil vapor can be up to 2,032 times higher than screening levels for benzene (e.g., C5-C8 aliphatic indoor air screening level of 630  $\mu$ g/m³ divided by benzene indoor air screening level of 0.31  $\mu$ g/m³ = 2,032). In this case, TPH will always drive vapor intrusion risk when the TPH:Benzene ratio exceeds 2,032:1, even if a conservative, target risk of  $10^{-6}$  is applied to benzene. Similarly, screening levels for TPH can be almost 8,750 times higher than screening levels for naphthalene (*i.e.*, maximum TPH indoor air screening level of 630  $\mu$ g/m³ divided by minimum naphthalene indoor air screening level of 0.072  $\mu$ g/m³). This ratio will decrease as the proportion of longer-range aliphatics in petroleum vapors increases, along with the toxicity of the TPH vapors in general (*i.e.*, less TPH required to drive vapor intrusion risk over individual compounds).

Table 8 presents a summary of critical ratios for TPH and individual compounds based on the example, indoor air and soil vapor screening levels presented in Tables 6 and 7 and the assumed, carbon range makeup of TPH vapors for gasoline and middle distillate fuels presented in Table 2.

Table 8. Example critical ratios	over which	TPH in soil	vapor will	drive vapor	intrusion
risk over individual compound.					

Chamiaal	Critical Ratio 1,2						
Chemical	TPH Gasoline Vapors	TPH Middle Distillate Vapors					
Benzene	935	452					
Ethylbenzene	299	144					
Toluene	0.06	0.03					
Xylenes	2.9	1.4					
Naphthalene	4,028	1,944					

<sup>&</sup>lt;sup>1</sup> TPH vapor intrusion screening level (Table 7) divided by individual compound screening level (Table 6);

A critical ratio of 935:1 (290  $\mu g/m^3/0.31~\mu g/m^3$ ) is generated for TPH:Benzene, based on an assumed TPH vapor composition of 75% C5-C8 aliphatic compounds and 25% C9-C12 aliphatic plus aromatic compounds. The TPH critical ratios are reduced by a factor of two for vapors associated with diesel and other middle distillate fuels (*i.e.*, less TPH required to drive risk over individual compounds), based on an assumed TPH vapor composition of 25% C5-C8 aliphatic compounds and 75% C9-C12 aliphatic and C9-C10 aromatic compounds.

Default or site-specific critical ratios provide a very simple and quick tool to determine the potential significance of TPH as a vapor intrusion risk driver at a site where both TPH and benzene soil vapor data are available. For example, if the TPH:Benzene ratio exceeds 2,032:1 at a site then TPH will *always* drive vapor intrusion risk over benzene, regardless of the carbon range makeup of the TPH (*i.e.*, even if TPH is composed of 100% C5-C8 aliphatics) and even if a conservative, excess cancer risk of 10<sup>-6</sup> is applied to benzene. The same is true when the TPH:Naphthalene ratio exceeds 8,750:1. In such cases, TPH vapors could still pose a vapor intrusion risk even though screening levels for individually targeted compounds are met. The lowest possible TPH:Benzene critical ratio using a benzene target risk of 10<sup>-6</sup> is 323:1, based on a TPH vapor composition of 100% C9-C12+ aliphatics and/or C9-C10 aromatics (*i.e.*, 100 μg/m³ divided by benzene indoor air screening level of 0.31 μg/m³; see Table 6). In this example, TPH *could* drive vapor intrusion risk over benzene at a TPH:Benzene ratio as low as 323:1, depending on the actual carbon range makeup and weighted toxicity of the TPH.

Similar, example critical ratios were calculated for other targeted compounds (*i.e.*, TEXN). The ratio increases for compounds that are more toxic than benzene (e.g., naphthalene critical ratio 8,750:1) and decreases for compounds that are less toxic (e.g., toluene critical ratio 0.06:1). In other words, a higher proportion of TPH in soil vapor (or indoor air) is required to overwhelm the vapor intrusion risk posed by an individual compound as the toxicity of the targeted compound increases.

The relative role of TPH in vapor intrusion risk will ultimately depend on the actual carbon range chemistry of the TPH and the associated toxicity and the target risk used to screen for individual compounds. Less TPH is required to overwhelm the risk posed by an individual chemical as the

<sup>&</sup>lt;sup>2</sup> Ratio at which TPH will exceed vapor intrusion screening level when individual compound is at or below its respective screening level (based on a target cancer risk of  $10^{-6}$  or a noncancer Hazard Quotient of 1.0).

proportion of more toxic, C9-C18 aliphatics (or C9-C16 aromatics) increases. Critical ratios are also necessarily dependent on the toxicity factors applied to individual, TPH carbon ranges. Toxicity factors published by the State of Massachusetts [19], for example, are more conservative than USEPA toxicity factors by a factor of two to three [16]. Critical ratios based on Massachusetts toxicity factors would be lower (*i.e.*, more conservative) by a similar amount.

In the next section of this paper, these screening tools are applied to the soil vapor database compiled by the USEPA and to a separate petroleum vapor study carried out by the State of Hawaii in order to evaluate the relative role of TPH in vapor intrusion at petroleum-contaminated sites. The first database focuses on soil vapor sample data from purported gasoline releases. The Hawaii study focuses primarily on soil vapor data from middle distillate releases, and serves as a supplement to the USEPA database.

#### 3. Application of Method to Case Studies

#### 3.1. Selection of Representative Case Studies

In the previous sections we reviewed the basic chemistry and toxicity of petroleum vapors in terms of TPH carbon ranges and targeted, individual compounds such as benzene. We presented published toxicity factors for carbon ranges and summarized the approach for calculation of risk-based, indoor air and soil vapor screening levels, including screening levels for TPH in general. We then presented the concept of "critical ratios" of TPH to individual, targeted compounds that can be used to quickly assess the relative role of TPH in potential vapor intrusion threats on a site-by-site basis.

In the following discussions, we apply these tools to two sets of case studies for petroleum-contaminated sites in order to answer the ultimate question posed at the beginning of this paper: "Do field data support conditions where vapor intrusion concerns posed by petroleum could be driven by the TPH rather by individual compounds such as benzene?" Data are first screened in terms of TPH:Benzene ratios and the potential for TPH to play a significant role in vapor intrusion risk reviewed. The carbon range makeup of the TPH is then evaluated in more detail. Weighted, TPH reference doses are then used to calculate more site specific (or database-specific), TPH screening levels for indoor air and soil vapor and the data re-evaluated.

The first set of case studies reflect a soil vapor sample data set being compiled by the USEPA for primarily gasoline-contaminated sites. The second set of case studies and data are based on a study carried out by the State of Hawaii under a grant from the USEPA for sites contaminated with diesel and other middle distillate fuels. The sites included in the Hawaii study were targeted to fill in gaps in the USEPA database and more closely evaluate the potential for non gasoline-contaminated sites to pose potential vapor intrusion threats.

Both data sets focus primarily on the nature of petroleum vapors within the immediate vicinity of the source area (*i.e.*, within fifteen feet of contaminated soil or groundwater). The fate and transport of vapors at increasing distances from the source areas is not directly reviewed, although characteristics such as the ratio of TPH to key, indicator compounds such as benzene can shed light on this subject.

The reviews presented below are intended for illustration purposes only and are not intended to be a comprehensive evaluation of the sites involved. The USEPA data are, for example, summarized in

terms of individual sample points rather than the range and average for sites. This introduces a potential bias toward sites with a higher number of sample points in comparison to those with only a few sample points. For the purposes of this paper it is assumed that this bias is small and that the data in general are adequately representative.

#### 3.2. Vapors Associated with Gasolines

As introduced earlier, the USEPA Office of Underground Storage Tanks (UST) has compiled a "Petroleum Vapor Intrusion" database of soil vapor data for seventy sites in the US, Canada and Australia [32]. The database focuses on known or presumed, gasoline-contaminated sites associated with releases from USTs. Although limited in terms of the total number of petroleum release sites in these countries, in the hundreds of thousands in the US alone, the database provides a useful snapshot of the chemistry of vapors associated with gasoline-contaminated sites. A summary of data used in the following evaluation of the database is provided in the supplement to this paper.


Figure 2 presents a summary of TPH-to-Benzene ratios for soil vapor samples included in the USEPA PVI database. As discussed earlier, only samples with reported concentrations of TPH greater than 1,000 µgm³ were considered in order to limit potential biases due to laboratory detection limits or interference from outdoor air [2]. A total of 364 samples met these criteria and included data for both TPH and benzene (see paper supplement). The inclusion of benzene in reported TPH concentrations is not known. The consistently high ratio of TPH to benzene in the samples negates a significant bias with respect to double counting of benzene in the TPH data. Non-specific, TPH hydrocarbon compounds clearly dominate petroleum vapors in the samples included in the USEPA database. The ratio of TPH to benzene ratio is consistently greater than 4:1, however, with a median ratio of 301:1, an average of 5,566:1 and a high of 4,000,000:1. The TPH:Benzene ratio varies by an order of magnitude or more at most sites where multiple samples were collected and up to three orders of magnitude at some sites (see supplement). The potential causes of this variability are discussed below.

As depicted in Figure 2, the ratio of TPH to benzene exceeds the default, critical ratio of 900:1 (rounded from 935:1, see Table 8) developed earlier for gasoline vapors in 33% of the samples included the database. This implies that the overwhelming proportion of aliphatic compounds in these samples would cause TPH, and not benzene, to drive potential vapor intrusion risks. In other words, if vapor intrusion were indeed a concern at these sites (e.g., subslab soil vapor screening levels exceeded and intrusion pathways present), then remediation of the site to reduce benzene in soil vapor down to target screening levels may not adequately address the noncancer risk posed by the TPH component of the vapors. Screening and/or remediation of the site to address TPH concerns would, however, concurrently address vapor intrusion concerns associated with benzene (*i.e.*, benzene would be below respective screening level at the point that TPH screening level was met).

Recall that this ratio assumes a target risk for benzene of  $10^{-6}$  and a correlatively conservative indoor air and subsequent soil vapor screening level (e.g., target indoor air goal of  $0.31 \,\mu\text{g/m}^3$  for residential scenarios; see Table 6). If a less conservative, target risk were used to calculate screening levels then the risk of missing potential vapor intrusion problems posed by TPH would be much higher. For example, the critical TPH:Benzene ratio associated with a target risk of  $10^{-5}$  for the latter would be 90:1, adjusting the previous example downward by a factor of ten (*i.e.*, 290  $\mu\text{g/m}^3$  divided by

3.1 µg/m³). In the case of the samples referenced from the USEPA database, the TPH:Benzene ratio exceeds this critical ratio 78% of the time (see Figure 2). This highlights the importance of quantitatively including TPH in vapor intrusion studies when a less conservative, target risk and associated screening levels are applied for individual compounds such as benzene. Note that this is not affected by attenuation factors assumed in the screening levels, since they are presumably identical for both benzene and TPH.

**Figure 2.** Summary of TPH to benzene ratios for soil vapor samples included in the USEPA PVI database (n = 364). Reflects gasoline-only sites with  $>1,000 \mu g/m^3$  TPH.



The relatively high proportion of TPH to benzene for a significant number of vapor samples from gasoline-only sites included in the USEPA database was initially surprising, given the traditional focus on only the BTEX fraction of these fuels [33]. As discussed earlier, seemingly low levels of benzene in the samples could be due to a number of factors, including: (1) Inadvertent inclusion of vapor data associated with middle distillate fuels in the database, (2) An original, minimal concentration of benzene in the gasoline released, (3) Preferential removal of benzene from soil vapors due to partitioning into soil moisture, and/or preferential biodegradation. Given the relatively high concentration of TPH reported in the samples (up to 31,000,000 µg/m³), the dominance of C5-C8 aliphatics over C9-C12 aliphatics in seven of nine samples with carbon range data and a TPH:Benzene ratio >900:1 (see supplement), and laboratory studies that suggest a much lower biodegradation rate for aromatics than aliphatics [34], the most likely cause for at least some of the samples appears to be an initially low concentrations of benzene in the gasoline released at the site. Likely variation in the degradation and removal of aliphatic and aromatic compounds between and even within sites complicates interpretation of the data. A more detailed study of this issue is beyond the scope of this paper.

As discussed earlier, several oil companies have moved toward low-benzene gasolines in recent years in order to lower the toxicity of auto exhaust as well as soil and groundwater contaminated by inadvertent releases of the fuels. Releases associated with some of these fuels appear to have been

captured in the USEPA database. This is an important observation, given a common assumption that benzene can be used as a stand-alone tool to evaluate the risk posed by releases of gasoline to the environment, including vapor intrusion (e.g., see [32]). This evaluation appears to have focused on traditionally targeted, individual compounds and did not specifically consider the relative role of TPH in vapor intrusion. Indeed, the TPH:Benzene ratio exceeds the maximum critical ratio of 2,032:1 in 24% of the soil vapor samples from supposed gasoline-only sites (see supplement). This implies that TPH would drive vapor intrusion risk over benzene regardless of both the target risk applied to benzene (e.g.,  $10^{-6}$  excess cancer risk) *and* the carbon range composition of the TPH vapors (e.g., best case 100% C5-C8 aliphatics).

#### 3.3. Vapors Associated with Diesel and Other Middle Distillate Fuels

The PVI database being compiled by the USEPA focuses on vapors associated with gasoline-contaminated soil and groundwater. As presented earlier, the Hawaii Department of Health (HDOH), through a grant from the USEPA, carried out a field study of the chemistry and toxicity of vapors associated soil and groundwater contaminated with diesel and other middle distillate fuels in an effort to supplement the USEPA database [10]. Particular emphasis was placed on the aliphatic and aromatic makeup of the TPH component of petroleum vapors and the potential for TPH to drive potential vapor intrusion risk over individual compounds such as benzene, toluene, ethylbenzene, xylenes and naphthalene.

Soil vapor data for petroleum-contaminated sites across Hawaii were reviewed as part of the study. Five sites with known, heavy contamination were targeted for detailed sampling. A limited number of samples were also collected over fresh fuels, although these data are not reviewed as part of this paper. Fuels released at sites included gasolines, including AVGAS and JP-4, JP-8 and diesel. Pipeline releases with widespread contamination and existing soil vapor monitoring points were targeted in order to ensure that vapors would be encountered and to minimize field sample collection costs. Sites A, B, C and E are believed to reflect a progressive domination by diesel and/or other middle distillate fuels such as JP-8 (similar to diesel). Site D is associated with a forty year-old release of JP-4 (mix of gasoline and kerosene) from a large fuel pipeline.

TPH compounds dominated petroleum vapors at each of the five, primary sites investigated during the study as well as other sites reviewed during the study, with less than 1% of the total vapors generally attributable to BTEXN (Table 9). The average ratio of TPH to benzene in soil vapors ranged from 1,500:1 at a site contaminated with JP-4 and AVGAS to over 18,000:1 at a site contaminated primarily by diesel fuel. The average TPH:Benzene ratio exceeded 2,000:1 at the three sites where diesel and other middle distillate fuels were known to be present. As noted in Table 9, the maximum concentration of TPH in soil vapor samples collected at the sites were well above screening levels ultimately generated for potential vapor intrusion concerns.

The overwhelming proportion of TPH in the soil vapors at these sites ensure that TPH will dominate vapor intrusion risks over benzene and other individual VOCs regardless of the actual carbon range makeup and weighted toxicity of the TPH, even if a conservative, target risk were used for carcinogens. The average TPH:Benzene ratio at an aged, JP-4/AVGAS release site included in the study (>9,000:1; Site A) exceeded the default, critical ratio for gasoline vapors of 900:1 noted earlier. The TPH:Benzene

ratio for soil vapor samples collected at middle distillate sites was even higher. The near absence of benzene in soil vapors at the JP-4/AVGAS site could be associated with a preferential removal of vapor-phase, aromatic compounds over aliphatic compounds over time due, for example, to preferential diffusion into soil moisture. This could also be simply due to an absence of significant benzene in the original fuels released. Similar observations have been made at other gasoline-contaminated sites in Hawaii [10].

**Table 9.** Example TPH concentration in soil vapor, average TPH:Benzene ratio and TPH carbon range makeup of soil vapor samples collected in the Hawaii DOH petroleum vapor study (based on summa canister, TO-15 data).

Site/Fuel Type	Example TPH (μg/m³)	Average TPH:Benzene Ratio	Average Carbon Range Composition		
			Aliphatics		Aromatics
			C5-8	C9-10	C9-12
Site A (JP-4/AVGAS)	300,000,000 μg/m <sup>3</sup>	1,513:1	96%	0.2%	3.3%
Site B (mixed fuels)	220,000,000 μg/m <sup>3</sup>	4,174:1	93%	0.3%	6.8%
Site C (JP-8 +/- JP-4)	86,000,000 μg/m <sup>3</sup>	18,710:1	72%	0.6%	27%
Site D (JP-4/AVGAS)	$2,600,000  \mu \text{g/m}^3$	9,135:1	63%	4.1%	33%
Site E (diesel)	$13,000,000  \mu g/m^3$	54,236:1	25%	0.9%	74%

Aliphatic compounds dominate TPH vapors at all of the sites, although the relative proportion of C5-C8 *versus* C9-C12 compounds varied considerably (see Table 9). A comparison of co-located and concurrent Summa canister data to sorbent tube data identified only a minor contribution of C13+ aliphatic compounds for TPH vapors at the sites (<10%). The contribution of C9 and higher, aromatic TPH compounds in the samples was likewise negligible.

Weighted TPH Reference Concentrations and associated indoor air and soil as screening levels based on the carbon range makeup of the TPH follow a similar trend (Table 10). The weighted TPH RfC and associated action levels calculated for vapors associated with a relatively recent, gasoline-contaminated site (e.g., Site A and Site B) approach those for C5-C8 aliphatics (e.g., TPH RfC 400 to  $600 \, \mu g/m^3$ ). The weighted TPH RfC and associated action levels calculated for vapors collected from sites progressively dominated by diesel or other middle distillate fuels (Sites B, C and E) or associated with aged, JP-4 (Site D) approach those for the more toxic, C9-C12 aliphatic compounds (e.g., TPH RfC 100 to 200  $\mu g/m^3$ ) and are reflective of the higher proportion of these compounds in the vapors.

The lowest (*i.e.*, most "toxic"), weighted Reference Concentration calculated was calculated for samples collected from an aged, diesel-contaminated site where TPH vapors were composed of an average 75% C9-12 aliphatics (Site E in Table 10). Free product on groundwater at the site was relatively shallow (<10 ft). Concentrations of TPH in soil vapor were perhaps an order of magnitude lower than would be anticipated at a site contaminated to a similar amount of gasoline. Even so, TPH in some samples exceeded 100,000,000 µg/m³, and were well above screening levels for potential vapor intrusion concerns.

OPEN ACCESS

International Journal of
Environmental Research and
Public Health
ISSN 1660-4601
www.mdpi.com/journal/ijerph

Correction

# Correction: Brewer, R.; et al. Risk-Based Evaluation of Total Petroleum Hydrocarbons in Vapor Intrusion Studies. Int. J. Environ. Res. Public Health 2013, 10, 2441–2467

Roger Brewer 1,\*, Josh Nagashima 1, Michael Kelley 2, Marvin Heskett 3 and Mark Rigby 4

- Hawaii Department of Health, 919 Ala Moana Blvd Room 206, Honolulu, HI 96814, USA; E-Mail: josh.nagashima@doh.hawaii.gov
- <sup>2</sup> EA Engineering, Science and Technology, 615 Piikoi St #515, Honolulu, HI 96814, USA; E-Mail: mkelley@eaest.com
- Geotek Hawaii, Inc., P.O. Box 1555, Pearl City, HI 96782, USA; E-Mail: mhesketts@mac.com
- <sup>4</sup> Parsons Corporation, 10235 South Jordan Gateway, Suite 300, South Jordan, UT 8409, USA; E-Mail: mark.rigby@parsons.com
- \* Author to whom correspondence should be addressed; E-Mail: roger.brewer@doh.hawaii.gov; Tel.: +1-808-586-4249; Fax: +1-808-586-7537.

Received: 7 July 2014 / Accepted: 9 July 2014 / Published: 14 July 2014

The authors wish to add the following amendments and corrections to their paper published in *IJERPH* [1].

Page 2460, Table 9: The data in last two columns are reversed. The correct Table 9 should be:

**Table 9.** Example TPH concentration in soil vapor, average TPH:Benzene ratio and TPH carbon range makeup of soil vapor samples collected in the Hawaii DOH petroleum vapor study (based on summa canister, TO-15 data).

	Example	Average TPH:Benzene Ratio	<b>Average Carbon Range Composition</b>			
Site/Fuel Type	TPH (μg/m³)		Aliphatics		Aromatics	
			C5-8	C9-12	C9-10	
Site A (JP-4/AVGAS)	$300,000,000 \mu g/m^3$	1,513:1	96%	3.3%	0.2%	
Site B (mixed fuels)	$220,000,000 \mu g/m^3$	4,174:1	93%	6.8%	0.3%	
Site C (JP-8 +/- JP-4)	$86,000,000  \mu g/m^3$	18,710:1	72%	27%	0.6%	
Site D (JP-4/AVGAS)	$2,600,000 \mu g/m^3$	9,135:1	63%	33%	4.1%	
Site E (diesel)	$13,000,000 \mu g/m^3$	54,236:1	25%	<mark>74%</mark>	0.9%	

Site E

**TPH** 

Site/Fuel Type	Weighted RfC <sup>1</sup> (μg/m <sup>3</sup> )	Indoor Air Screening Level <sup>2</sup> (µg/m³)	Subslab Soil VaporScreening Level <sup>3</sup> (µg/m <sup>3</sup> )	TPH:Benzene Critical Ratio <sup>4</sup>	TPH:Benzene Measured Ratio	Vapor Intrusion Risk Driver <sup>5</sup>
Site A	510	530	530,000	1,710:1	1,513:1	Benzene
Site B	443	460	460,000	1,484:1	4,174:1	TPH
Site C	251	260	260,000	839:1	18,710:1	TPH
Site D	211	220	220,000	710:1	9,135:1	TPH

**Table 10.** Weighted TPH Reference Concentration and example TPH subslab soil vapor screening levels for soil vapor samples collected in the Hawaii DOH petroleum vapor study.

410

130,000

130

The TPH:Benzene critical ratio for each set of study site samples is noted in Table 10. A comparison of these ratios to the measured, TPH:Benzene ratio for samples collected at each site provides insight on the relative role of TPH in overall vapor intrusion risk. As indicated in Table 10, benzene drives potential vapor intrusion risk over TPH for soil vapor samples collected at Site A, a JP-4/AVGAS release (*i.e.*, measured TPH:Benzene ratio in soil vapor below critical ratio). Dividing the measured TPH:Benzene ratio by the risk-based, critical ratio for the same samples represents the theoretical, noncancer Hazard Quotient for TPH with respect to vapor intrusion at the point that the concentration of benzene in soil vapor equals the target, benzene screening level. In the case of Site A, a Hazard Quotient of 0.9 is calculated, suggesting that TPH will not pose a significant vapor intrusion risk if a target,  $10^{-6}$  risk is met for benzene. Note that use of a target risk of  $10^{-5}$  to screen for benzene would be associated with a theoretical, noncancer Hazard Quotient of approximately nine for TPH. This highlights the need to use a conservative, target cancer risk for benzene at sites with the measured, TPH:Benzene ratio of more than approximately 100:1, as a rough guide.

It is interesting to note that screening and/or remediation of Site A with respect to TPH only and without consideration of benzene would at worst leave benzene in soil vapors only marginally above the target,  $10^{-6}$  risk goal. Reducing TPH in soil vapor to 530,000  $\mu g/m^3$  would in theory result in a concentration of benzene in soil vapor of approximately 350  $\mu g/m^3$ , only marginally above the screening level of 310  $\mu g/m^3$  and equating to a cancer risk of only  $1.1 \times 10^{-6}$ . Ignoring benzene and focusing only on TPH would be unlikely to leave potentially significant, vapor intrusion risks posed by the former unaddressed.

A comparison of the TPH to benzene field ratio to the calculated, risk-based, critical ratio at the remaining four sites included in the Hawaii study clearly identifies TPH as the vapor intrusion risk driver. For samples collected from Site B, the measured TPH:Benzene ratio exceeds the risk-based, critical ratio for the same sample set by a factor of almost three (see Tables 9 and 10). In theory, this suggests that the noncancer, Hazard Quotient posed by TPH in soil vapor for vapor intrusion would

<sup>&</sup>lt;sup>1</sup> Based on average carbon range composition (see Table 9); <sup>2</sup> Residential exposure scenario; see equation and assumptions in text; <sup>3</sup> Assuming an indoor air:subslab soil vapor attenuation factor of 0.001; <sup>4</sup> TPH indoor air screening level divided by benzene screening level (based on target cancer risk of 10<sup>-6</sup>); Above this ratio, TPH in soil vapor could still pose a vapor intrusion risk even if benzene is at or below target screening levels.

<sup>&</sup>lt;sup>5</sup> Based on comparison to average TPH: Benzene ratio for samples noted in previous table.

still approach three at the point that the concentration of benzene was reduced to a target,  $10^{-6}$  risk (*i.e.*, TPH in soil vapor would equal approximately 1,300,000  $\mu$ g/m³ at the point that benzene equals 310  $\mu$ g/m³). The TPH:Benzene critical ratio is exceeded by an even larger degree for samples collected at the remaining three sites (*i.e.*, twenty-two, thirteen and one-hundred thirty two for Sites C, D and E, respectively). This suggests that TPH could still pose a significant vapor intrusion hazard at the sites well beyond the point that a target risk of  $10^{-6}$  for benzene was met. This is not surprising, given the relatively minor contribution of benzene to overall petroleum vapors at the sites. It is also worthwhile to note that naphthalene and methylnaphthalenes played a limited role in potential vapor intrusion risk at the middle distillate sites reviewed in the study, in spite of the assumed higher concentration of these chemicals in the original fuel released. The lack of significant naphthalenes in soil vapor samples is most likely due to the propensity of these chemicals to sorb to soil particles rather than partition into the vapor phase.

The Hawaii study highlights the potential for significant, vapor intrusion concerns posed by subsurface releases of middle distillate fuels, including diesel, as well as low-benzene gasolines. Reported concentrations of TPH in shallow soil vapor samples collected within or near source areas were well above risk-based screening levels for vapor intrusion concerns. The study also highlights the need to quantitatively consider TPH in vapor intrusion risk assessments at these sites when the ratio of TPH to benzene in soil vapor exceeds a value of approximately 450:1 if a target risk of  $10^{-6}$  is applied to benzene or a value of approximately 45:1 if a target risk of  $10^{-5}$  is applied (e.g., TPH indoor air screening level of 140  $\mu$ g/m³ divided by benzene screening level of 0.31  $\mu$ g/m³ or 3.1  $\mu$ g/m³; see Tables 6 and 7).

#### 4. Summary and Conclusions

Vapors emitted from petroleum fuels are dominated by aliphatic and to a lesser degree aromatic compounds collectively measured as Total Petroleum Hydrocarbons or "TPH". Published physiochemical constants and toxicity factors for volatile, TPH aliphatic and aromatic carbon ranges allows for quantitative, risk-based evaluation of TPH in vapor intrusion investigations in the same manner as carried out for traditionally targeted chemicals such as benzene, toluene, ethylbenzene, xylenes and naphthalene. Generic and/or site-specific TPH screening levels can be generated based on the assumed or known aliphatic and aromatic makeup of the petroleum vapors.

The relative role of TPH in vapor intrusion in comparison to individually targeted compounds such as benzene can be quickly determined by comparison of the ratio of TPH to the compound measured in the field to the ratio of risk-based screening levels for these chemicals. If, for example, the ratio of TPH to benzene in soil vapor measured in the field exceeds this "critical ratio" based on a comparison of screening levels then the concentration of TPH in indoor air (or soil vapor) would still exceed its risk-based screening level even though the concentration of benzene was at or below its respective screening level. If the critical ratio is not exceeded, then the concentration of TPH in indoor air (or soil vapor) would be at or below its respective screening level when the screening level for benzene is met. In the first case, reliance on benzene data alone to assess potential vapor intrusion risks would be inappropriate. In the latter case, a focus on benzene for final decision making purposes should ensure that potential vapor intrusion risks posed by TPH will also be addressed.

Critical ratios are necessarily dependent on the toxicity factors applied to individual, TPH carbon ranges. Based on TPH toxicity factors published by the USEPA [16] and a  $10^{-6}$  excess cancer risk for benzene, a TPH:Benzene critical ratio of approximately 900:1 serves as a conservative tool for initial screening of gasoline-contaminated sites (*i.e.*, TPH could drive vapor intrusion risk when the concentration of TPH is more than 900 times that of benzene). This ratio is not exceeded for the majority (67%) of samples from gasoline-contaminated sites included a soil vapor database compiled by the USEPA [32]. This suggests that consideration of benzene in the absence of TPH data will be adequate to screen most gasoline-contaminated sites for potential vapor intrusion concerns if a conservative target cancer risk is applied to benzene.

Benzene clearly drives vapor intrusion risk for only 22% of the samples in the USEPA database, however, if a less conservative target risk of  $10^{-5}$  is applied (*i.e.*, order-of-magnitude higher concentration of benzene considered acceptable). Furthermore, the measured ratio of TPH to benzene exceeded the screening value of 900:1 for 33% of the samples in the database, implying that TPH could drive vapor intrusion risk over benzene with respect to these samples depending on the target risk applied to the latter and the actual carbon range makeup of TPH. At least some of these sites appear to be associated with releases of gasoline that was originally low in benzene. In addition, the TPH:Benzene ratio exceeds a hypothetical, toxicity-based, maximum critical ratio of 2,032:1 in 24% of the soil vapor samples in the USEPA database. This implies that TPH would drive vapor intrusion risk over benzene regardless of both the target risk applied to benzene *and* the carbon range composition of the TPH vapors.

Initial screening of gasoline-contaminated sites with respect to relative proportions of TPH and benzene present in soil vapors therefore appears to be prudent. Note that this may appear to conflict with the statement in the USEPA PVI database report that "available data indicate benzene is the risk driver for the (gasoline-release) sites evaluated" [32]. This conclusion however, was based on a comparison of the relative vapor intrusion risk posed by benzene to other, traditionally targeted, individual compounds such as toluene, ethylbenzene, xylenes and naphthalene. A detailed evaluation of the TPH component of the PVI database had not been carried out at the time that the USEPA report was published. This paper expands the database evaluation to include this comparison.

Vapors associated with subsurface releases of diesel and other middle distillate fuels can exhibit a higher proportion of more toxic, C9-C12 and higher aliphatic compounds, although the magnitude of vapors released from contaminated soil and groundwater will be lower than for an equivalent amount of gasoline. In this case a lesser amount of TPH in soil vapor (or indoor air) is required before the TPH fraction of the vapors begins to drive vapor intrusion risk over benzene or other individual compounds. Based on a limited study carried out by the State of Hawaii, a critical TPH to benzene ratio of approximately 450:1 served as a useful tool for initial screening of vapor data at sites contaminated with diesel or other middle distillate fuels. The measured ratio of TPH to benzene at all of the middle distillate sites reviewed in the Hawaii study reviewed in this paper exceeded this ratio by a wide margin, suggesting that TPH will play a dominant role in vapor intrusion at sites contaminated by these types of fuels. Significant levels of both C5-C8 aliphatics and C9-C12 aliphatics at the sites investigated highlight the need to report TPH as the sum of C5-C12 compounds for soil vapor samples collected at middle distillate-release sites, even though this is traditionally referred to as "gasoline range" hydrocarbons by commercial laboratories.

Carbon range data for TPH in soil vapor can be used to develop site-specific vapor intrusion screening levels for TPH or for direct calculation of potential vapor intrusion risk. A review of case studies highlights the importance of including a review of TPH in vapor intrusion investigations. This can be done at an initial screening level by simple comparison of the measured ratio of TPH to benzene and other targeted compounds to the ratio of generic or site-specific, risk-based screening levels for these compounds. The gradual reduction of benzene in gasolines over time and high concentrations of aliphatic compounds in vapors associated with diesel releases highlights the need to consider TPH in vapor intrusion studies.

Identification of TPH or individual compounds in soil vapor above target screening levels and/or critical ratios does not necessarily imply that a vapor intrusion problem indeed exists. It is worthwhile to note that odor thresholds for petroleum fuels are within an order of magnitude of the risk-based screening levels for TPH presented in this paper. Given the hundreds of thousands of petroleum releases identified in the US over the past twenty years, the fact that few instances of petroleum-related vapor intrusion have been reported suggests in itself that significant risks are most likely limited to the presence of heavy contamination in soil or groundwater within close proximity to a building floor.

As discussed in numerous studies, this suggests that significant attenuation forces beyond those typically assumed for chlorinated solvents are in play both beneath and most likely within the subject buildings. Natural biodegradation of vapor-phase, petroleum compounds in contaminated soil and groundwater will significantly reduce the long-term vapor-intrusion risk of subsurface contamination in comparison to soil contaminated with an equal amount of chlorinated solvents. Regional climate, geology and associated building ventilation designs strongly influence local indoor air: subslab attenuation factors. The relative persistence of petroleum compounds in indoor air with respect to vapor flux rates should also be considered.

#### Acknowledgements

The soil vapor study carried out by the Hawaii Department of Health was carried out under a grant from the United States Environmental Protection Agency.

#### Disclaimer

This document has been funded partly or wholly through the use of U.S. EPA State Response Program Grant funds. Its contents do not necessarily reflect the policies, actions or positions of the U.S. Environmental Protection Agency. The Hawai'i Department of Health does not speak for nor represent the U.S. Environmental Protection Agency.

#### **Conflict of Interest**

The authors declare no conflict of interest.

#### References

- 1. Potter, T.L.; Simmons, K.E. Total Petroleum Hydrocarbon Working Group Series. In *Composition of Petroleum Mixtures*; Association for Environmental Health and Sciences: Amherst, MA, USA, 1998; Volume 2.
- 2. Characterizing Risks Posed by Petroleum Contaminated Sites (Policy No. WSC-02-41-1); Massachusetts Department of Environmental Protection: Boston, MA, USA, 2002.
- 3. Risk-Based Decision Making for the Remediation of Petroleum-Contaminated Sites; Oregon Department of Environmental Quality, Environmental Cleanup and Tanks Program: Portland, OR, USA, 2003.
- 4. Screening for Environmental Concerns at Sites with Contaminated Soil and Groundwater; California Environmental Protection Agency, Regional Water Quality Control Board, San Francisco Bay Area Region: Oakland, CA, USA, 2005.
- 5. Cleanup Levels and Risk Calculations Focus Sheets: Reference Doses for Petroleum Mixtures; Washington Department of Ecology: Lacey, WA, USA, 2006.
- 6. *Cleanup Levels Guidance*; Alaska Department of Environmental Conservation, Division of Spill Prevention and Response: Juneau, AK, USA, 2008.
- 7. Guidelines for Utah's Corrective Action Process for Leaking Underground Storage Tank Sites; Utah Department of Environmental Quality, Division of Environmental Response and Remediation: Salt Lake City, UT, USA, 2010.
- 8. Evaluation of Environmental Hazards at Sites with Contaminated Soil and Groundwater; Hawaii Department of Health, Office of Hazard Evaluation and Emergency Response: Honolulu, HI, USA, 2011.
- 9. Guidelines for TPH Fractionation at Leaking Underground Storage Tank Sites; Utah Department of Environmental Quality, Division of Environmental Response and Remediation: Salt Lake City, UT, USA, 2012.
- 10. Field Investigation of the Chemistry and Toxicity of TPH in Petroleum Vapors: Implications for Potential Vapor Intrusion Hazards; Hawaii Department of Health, Office of Hazard Evaluation and Emergency Response: Honolulu, HI, USA, 2012.
- 11. Kelly, M.J.; Brewer, R.; Rigby, M. Use of TPH Carbon Range Data to Guide Remediation of Petroleum Contamination for Vapor Intrusion. Remediation of Chlorinated and Recalcitrant Compounds. In Proceedings of the Eighth International Battelle Conference, Monterey, CA, USA, 21–24 May 2012.
- 12. Long-Term Management of Petroleum-Contaminated Soil and Groundwater; Hawaii Department of Health, Office of Hazard Evaluation and Emergency Response: Honolulu, HI, USA, 2007.
- 13. Kaplan, I.R.; Galperin, Y.; Lu, S.T.; Lee, R.U. Forensic environmental geochemistry: Differentiation of fuel types, their sources and release times. *Org. Geochem.* **2007**, *27*, 289–317.
- 14. Chevron and Texaco Premium Unleaded Gasolines; Chevron: San Ramon, CA, USA, 2011; MSDS No. 2653.
- 15. Transport and Fate of Non-BTEX Petroleum Chemicals in Soils and Groundwater; American Petroleum Institute, Health and Environmental Sciences Department: Washington, DC, USA, 1994; Publication No. 4593.

- 16. Provisional Peer-Reviewed Toxicity Values for Complex Mixtures of Aliphatic and Aromatic Hydrocarbons; U.S. Environmental Protection Agency, Superfund Health Risk Technical Support Center, National Center for Environmental Assessment, Office of Research and Development: Washington, DC, USA, 2009.
- 17. U.S. Environmental Protection Agency. Control of hazardous air pollutants from mobile sources. *Fed. Regist.* **2007**, *72*, 8428–8570.
- 18. *Gasoline Composition Regulations Affecting LUST Sites*; U.S. Environmental Protection Agency, Office of Research and Development: Washington, DC, USA, 2010.
- 19. Updated Petroleum Hydrocarbon Fraction Toxicity Values for the VPH/EPH Methodology; Massachusetts Department of Environmental Protection, Bureau of Waste Site Cleanup: Boston, MA, USA, 2003.
- 20. Gustafson, J.; Tell, J.G.; Orem, D. Selection of Representative TPH Fractions Based on Fate and Transport Considerations. In *Total Petroleum Hydrocarbon Working Group Series*; Association for Environmental Health and Sciences: Amherst, MA, USA, 1997; Volume 3.
- 21. Risk Integrated System of Closure, Technical Resource Guidance Document; Indiana Department of Environmental Management: Indianapolis, IN, USA, 2010.
- 22. Screening Levels for Chemical Contaminants at Superfund Sites (Soil, Air, Tapwater.); U.S. Environmental Protection Agency: Washington, DC, USA, 2012.
- 23. Supplemental Guidance for Developing Soil Screening Levels for Superfund Sites; U.S. Environmental Protection Agency, Solid Waste and Emergency Response: Washington, DC, USA, 2002; OSWER 9355.4–24.
- 24. Hartman, B. The great escape—From the UST. LUSTLine 1998, 30, 18–20.
- 25. BIOVAPOR—A 1-D Vapor Intrusion Model with Oxygen-Limited Biodegradation (Version 2.0); American Petroleum Institute: Washington, DC, USA, 2010.
- 26. Hayes, H.C.; Benton, D.J.; Grewal, S.; Khan, N. Evaluation of Sorbent Methodology for Petroleum-Impacted Site Investigation. In Proceedings of the Air and Waste Management Association, Providence, RI, USA, 26–27 September, 2007.
- 27. *Hazardous Substances Database*; U.S. National Library of Medicine (Toxnet): Bethesda, MD, USA, 2012.
- 28. Tveit, A.; Hayes, L.A.; Youngren, S.H.; Nakles, D.V. Development of Fraction Specific Reference Doses (RfDs) and Reference Concentrations (RfCs) for Total Petroleum Hydrocarbons. In *Total Petroleum Hydrocarbon Working Group Series*; Association for Environmental Health and Sciences: Amherst, MA, USA, 1997; Volume 4.
- 29. *Toxicological Profile for Total Petroleum Hydrocarbons*; U.S. Department of Health and Human Services, Agency for Toxic Substances and Disease Registry: Atlanta, GA, USA, 1999.
- 30. Evaluating Human Health Risks from Total Petroleum Hydrocarbons; California Department of Toxic Substances Control, Human and Ecological Risk Division: Sacramento, CA, USA, 2009.
- 31. DeVaull, G.E. Indoor vapor intrusion with oxygen-limited biodegradation for a subsurface gasoline source. *Environ. Sci. Tech.* **2007**, *41*, 3241–3248.
- 32. Evaluation of Empirical Data to Support. Soil Vapor Intrusion Screening Criteria for Petroleum Hydrocarbon Compounds (EPA 510-R-13-001); U.S. Environmental Protection Agency, Office of Underground Storage Tanks: Washington, DC, USA, 2013.

- 33. Standard Guide for Risk-Based Corrective Action Applied at Petroleum Release Sites; American Society for Testing and Materials: West Conshohocken, PA, USA, 2010.
- 34. Petroleum Hydrocarbons and Chlorinated Hydrocarbons Differ in their Potential for Vapor Intrusion; U.S. Environmental Protection Agency, Office of Underground Storage Tanks: Washington, DC, USA, 2012.
- © 2013 by the authors; licensee MDPI, Basel, Switzerland. This article is an open access article distributed under the terms and conditions of the Creative Commons Attribution license (http://creativecommons.org/licenses/by/3.0/).

### 2002 Massachusetts VPH-EPH Guidance

Hawai'i DOH Appendix 6



Governor

# COMMONWEALTH OF MASSACHUSETTS EXECUTIVE OFFICE OF ENVIRONMENTAL AFFAIRS

# **DEPARTMENT OF ENVIRONMENTAL PROTECTION**

ONE WINTER STREET, BOSTON, MA 02108 617-292-5500

**BOB DURAND** Secretary LAUREN A. LISS

Commissioner

# **Characterizing Risks Posed by Petroleum Contaminated Sites:** Implementation of the MADEP VPH/EPH Approach

FINAL POLICY

October 31, 2002

Policy #WSC-02-411

This Policy provides guidance for parties conducting response actions under the Massachusetts Contingency Plan (MCP) on the use and application of the Volatile Petroleum Hydrocarbons (VPH) and Extractable Petroleum Hydrocarbons (EPH) methods to characterize risks posed by releases of petroleum products to the environment. This Policy updates and replaces draft documents that were issued on October 31, 1997 and June 2001. Parties who are currently using criteria and guidance contained in the June 2001 draft document may do so until May 1, 2003. A summary of significant changes between these earlier drafts and this Final Policy is provided in Appendix 6.

The information contained in this document is intended solely as guidance. This Policy does not create any substantive or procedural rights, and is not enforceable by any party in any administrative proceeding with the Commonwealth. This Policy provides recommendations and guidance on approaches the Department considers acceptable for meeting the performance standards set forth in the MCP and discussed in this document. These performance standards include, but are not limited to, the Response Action Performance Standards of section 310 CMR 40.0191 of the MCP. Parties using this guidance should be aware that there may be other acceptable alternatives for achieving and documenting compliance with the general regulatory requirements and performance standards of the MCP, including those of 310 CMR 40.0191. The regulatory citations in this document should not be relied upon as a complete list of the applicable regulatory requirements.

This Policy and further information on the development and application of the aliphatic/aromatic hydrocarbon evaluative technique employed by the Department, referred to as the "VPH/EPH" approach, may be obtained at http://www.state.ma.us/dep/bwsc/vph\_eph.htm

10/31/02	Signature on Original		
Date	Deirdre C. Menoyo Assistant Commissioner		
	Bureau of Waste Site Cleanup		

# **Table of Contents**

1.0	INTR	ODUCTION	••••				
	1.1	Background					
	1.2	Purpose and Scope					
	1.3	Applicability					
	1.5	1.3.1 Site Closure on or after October 31, 1997					
		1.3.2 Site Closure Prior to October 31, 1997					
2.0	SUM	MARY OF THE VPH/EPH APPROACH					
	2.1	The Concept					
	2.1	Hydrocarbon Fractions of Interest					
	2.2						
	2.3	Relationship of VPH/EPH to TPH and Gasoline Range Organics (GRO)					
3.0	ANAl	LYTICAL METHODS					
	3.1	Gas Chromatography					
	3.2	MADEP Analytical Methodologies	•••				
		3.2.1 Volatile Petroleum Hydrocarbons (VPH)					
		3.2.2 Extractable Petroleum Hydrocarbons (EPH)					
		3.2.3 Air-Phase Petroleum Hydrocarbons (APH)					
	3.3	VPH/EPH Target Analytes					
	3.4	Sampling Procedures and Requirements for the VPH/EPH Methods					
	3.5	Modifications of the VPH/EPH Methods					
	3.6	Data Quality and Report Content					
	3.7	Other Hydrocarbon Testing Methods					
		3.7.1 Total Petroleum Hydrocarbons					
		3.7.2 Environmental Forensic Techniques					
	3.8	Analytical Screening Techniques					
		3.8.1 Principles of Operation, Biases, and Calibration					
		3.8.2 Recommended Approach					
	3.9	Drinking Water Testing Methods					
4.0	CLEA	ANUP STANDARDS					
	4.1	Exposure Point Concentrations					
		4.1.1 Groundwater EPCs					
		4.1.2 Soil EPCs					
		4.1.3 Indoor Air EPCs					
	4.2	Method 1 Cleanup Standards					
	7.2	4.2.1 Using Method 1 VPH/EPH Fractional Standards					
		4.2.2 Target Analytes					
		4.2.2.1 Petroleum Product Additives.					
		4.2.2.2 Petroleum Product Additives as Target Analytes					
		4.2.2.3 Ethanol					
		4.2.2.4 Additional Petroleum Additives					
		4.2.3 Hydrocarbon Fractions of Interest					
		r					
		4.2.4.1 Hydrocarbons					
		4.2.4.2 Additives					
		4.2.4.3 Air-Phase Contamination					
		4.2.5 Odors					
	4.3	Method 2 Risk Characterization					
		4.3.1 Using a Method 2 Approach to Demonstrate "No Impact" to Indoor Air					
		4.3.1.1 Level 1 - Soil Gas Screening					
		4.3.1.2 Level 2 - Soil Gas Analysis	••••				

# **Table of Contents (continued)**

		4.3.1.3 Level 3 - Indoor Air Analysis	
		4.3.1.4 Use of Vapor Transport Models	33
		4.3.1.5 Vertical Profiling of Groundwater Contaminants to Evaluate Vapor Transport	34
			34
		4.3.3 Using a Method 2 Approach to Evaluate Leaching	37
	4.4	Method 3 Risk Characterization	38
		4.4.1 Requirements and Limitations of a Method 3 Characterization	38
		4.4.2 Impacts to Indoor Air	39
			39
		4.4.4 MADEP Petroleum Contaminated Site Risk Assessment Short Forms	40
	4.5		40
	4.6	1	40
	4.7	1 ' '	41
		11	41
		rr	41
		4.7.3 NAPL and Vapor/Indoor Air Impacts	
	4.8	Elimination of Continuing Sources	
	4.9	Feasibility of Achieving Background Concentrations	43
5.0	IMPL	EMENTATION ISSUES	44
	5.1	Site Characterization	44
		5.1.1 Analytical Parameters	44
			44
			45
	5.2	Use of Old and New TPH Data	46
			46
		e e	47
	5.3	1 11	48
	5.4	E .	48
			48
			49
		5.4.3 Characterization of Remedial Air Emissions	
		5.4.4 Characterization of Coal Tar Contaminated Sites	49
		T	
		List of Tables	
		2-2: Hydrocarbon Fractions of Interest	4
		3-1: Sample Collection, Preservation, and Holding Times	10
		<b>→</b> 11	13
		3-3: Common/Available TPH Testing Methods	14
			16
		3-5: Recommended Minimum VPH/EPH Laboratory Confirmation Data Needed	10
			18
			19
		4-2: Minimum Recommended Quarterly Rounds of Groundwater Monitoring at sites	20
			20
		•	22
			23
		• •	24
		·	25
		· · · · · · · · · · · · · · · · · · ·	27
			27
		4-9: Soil Gas PID/FID Screening Levels for Evaluating Indoor Air Impacts	29

# **List of Tables (continued)**

4-10	: Soil Gas GC Screening Levels for Evaluating Indoor Air Impacts	32
	: Estimated Background Indoor Air Concentrations (Residential)	
4-12	: Surface Water Quality Guidelines	35
4-13	: Recommended VPH/EPH Toxicological & Risk Assessment Parameters	40
4-14	: Recommended VPH/EPH Fractional Properties for Modeling Purposes	41
5-1:	Recommended TPH Compositional Assumptions in Soil	47
5-2	Mobility and Persistence Scoring Criteria for VPH/EPH Fractions	48
	List of Figures	
2-1:	Relationship of VPH/EPH to TPH and Gasoline Range Organics (GRO)	
2-2:	Overlap of VPH and EPH Test Methods	
3-1:	Sample Chromatogram - #2 Fuel Oil	
4-1:	Evaluating Indoor Air Pathway via Method 2	
4-2:	GC/FID Soil Gas Chromatogram	
4-3	Recommended Hierarchy of Vapor Mitigation Efforts	35
4-4:	Groundwater Dilution Factors for Dissolved Hydrocarbons	
4-5:	Leaching Scenario Used to Develop Leaching-Based Method 1 Soil Standards	37
	List of Appendices	
	endix 1: Collecting and Preserving VPH Samples	
	endix 2: Shipping Methanol Preserved Samples	
	endix 3: Recommended Data Reporting Formats	
	endix 4: VPH/EPH Cleanup Standards and Reportable Concentrations	
	endix 5: Additional Reference/Support Materials	
Anne	endix 6: Summary of Significant Changes to Final Implementation Policy	62

# LIST OF ACRONYMS

APH Air-Phase Petroleum Hydrocarbons AQWC Ambient Water Quality Criteria BTEX Benzene, Toluene, Ethylbenzene, and Xylenes CEP Critical Exposure Pathway EDB Ethylene Dibromide EPA Environmental Protection Agency EPC Exposure Point Concentration EPH Extractable Petroleum Hydrocarbons e V Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatography/Hame Ionization Detector GC/MS Gas Chromatography/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Dose	AAS	Atomic Absorption Spectroscopy
AQWC Ambient Water Quality Criteria BTEX Benzene, Toluene, Ethylbenzene, and Xylenes CEP Critical Exposure Pathway EDB Ethylene Dibromide EPA Environmental Protection Agency EPC Exposure Point Concentration EPH Extractable Petroleum Hydrocarbons eV Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Hame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-billion by volume PMAP Relative Absorption Factor RAO Response Action Outcome RiC Reference Dose		
BTEX Benzene, Toluene, Ethylbenzene, and Xylenes CEP Critical Exposure Pathway EDB Ethylene Dibromide EPA Environmental Protection Agency EPC Exposure Point Concentration EPH Extractable Petroleum Hydrocarbons eV Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC RfC Reference Dose		·
CEP Critical Exposure Pathway  EDB Ethylene Dibromide  EPA Environmental Protection Agency  EPC Exposure Point Concentration  EPH Extractable Petroleum Hydrocarbons  e V Electron Volt  FID Flame Ionization Detector  GC Gas Chromatography or Gas Chromatograph  GC/FID Gas Chromatograph/Flame Ionization Detector  GC/MS Gas Chromatograph/Plame Ionization Detector  GC/MS Gasoline Range Organics  GW Groundwater  HVAC Heating, Ventilation, Air-conditioning  ICP-AES Inductively coupled plasma atomic emissions spectroscopy  IR Infra-red  LNAPL Light Non-Aqueous Phase Liquids  LSP Licensed Site Professional  MADEP Massachusetts Department of Environmental Protection  MCP Massachusetts Contingency Plan  MtBE Methyl tertiary butylether  NAPL Non-Aqueous Phase Liquids  NRS Numerical Ranking System  OTP Ortho-terphenyl  PAH Polycyclic Aromatic Hydrocarbon  PCB Polychlorinated Biphenyl  PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-billion by volume  ppmV Parts-per-million by volume  RAF Relative Absorption Factor  RAO Response Action Outcome  RTC Reference Concentration  RfD Reference Dose		
EDB Ethylene Dibromide EPA Environmental Protection Agency EPC Exposure Point Concentration EPH Extractable Petroleum Hydrocarbons e V Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
EPA Environmental Protection Agency EPC Exposure Point Concentration EPH Extractable Petroleum Hydrocarbons e V Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		•
EPC Exposure Point Concentration EPH Extractable Petroleum Hydrocarbons e V Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-million by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration Refp Reference Dose		•
EPH Extractable Petroleum Hydrocarbons e V Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Plame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration Reference Concentration		
eV Electron Volt FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume PPDPV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration Reference Dose		*
FID Flame Ionization Detector GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Dose		·
GC Gas Chromatography or Gas Chromatograph GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration		
GC/FID Gas Chromatograph/Flame Ionization Detector GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
GC/MS Gas Chromatograph/Mass Spectrometer GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration Reference Dose		
GRO Gasoline Range Organics GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration Reference Dose		
GW Groundwater HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration Reference Dose		• • •
HVAC Heating, Ventilation, Air-conditioning ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
ICP-AES Inductively coupled plasma atomic emissions spectroscopy IR Infra-red LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
IR Infra-red  LNAPL Light Non-Aqueous Phase Liquids  LSP Licensed Site Professional  MADEP Massachusetts Department of Environmental Protection  MCP Massachusetts Contingency Plan  MtBE Methyl tertiary butylether  NAPL Non-Aqueous Phase Liquids  NRS Numerical Ranking System  OTP Ortho-terphenyl  PAH Polycyclic Aromatic Hydrocarbon  PCB Polychlorinated Biphenyl  PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-million by volume  QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		
LNAPL Light Non-Aqueous Phase Liquids LSP Licensed Site Professional MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		<u> </u>
Licensed Site Professional  MADEP  Massachusetts Department of Environmental Protection  MCP  Massachusetts Contingency Plan  MtBE  Methyl tertiary butylether  NAPL  Non-Aqueous Phase Liquids  NRS  Numerical Ranking System  OTP  Ortho-terphenyl  PAH  Polycyclic Aromatic Hydrocarbon  PCB  Polychlorinated Biphenyl  PID  Photoionization Detector  ppbV  Parts-per-billion by volume  ppmV  Parts-per-million by volume  QA/QC  Quality Assurance/Quality Control  RAF  Relative Absorption Factor  RAO  Response Action Outcome  RfC  Reference Concentration  RfD  Reference Dose		
MADEP Massachusetts Department of Environmental Protection MCP Massachusetts Contingency Plan MtBE Methyl tertiary butylether NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
MCP Massachusetts Contingency Plan  MtBE Methyl tertiary butylether  NAPL Non-Aqueous Phase Liquids  NRS Numerical Ranking System  OTP Ortho-terphenyl  PAH Polycyclic Aromatic Hydrocarbon  PCB Polychlorinated Biphenyl  PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-million by volume  QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		
MtBE Methyl tertiary butylether  NAPL Non-Aqueous Phase Liquids  NRS Numerical Ranking System  OTP Ortho-terphenyl  PAH Polycyclic Aromatic Hydrocarbon  PCB Polychlorinated Biphenyl  PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-million by volume  QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		*
NAPL Non-Aqueous Phase Liquids NRS Numerical Ranking System OTP Ortho-terphenyl PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		· ·
NRS Numerical Ranking System  OTP Ortho-terphenyl  PAH Polycyclic Aromatic Hydrocarbon  PCB Polychlorinated Biphenyl  PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-million by volume  QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		• • •
OTP Ortho-terphenyl  PAH Polycyclic Aromatic Hydrocarbon  PCB Polychlorinated Biphenyl  PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-million by volume  QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		
PAH Polycyclic Aromatic Hydrocarbon PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		•
PCB Polychlorinated Biphenyl PID Photoionization Detector ppbV Parts-per-billion by volume ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
PID Photoionization Detector  ppbV Parts-per-billion by volume  ppmV Parts-per-million by volume  QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		
ppbVParts-per-billion by volumeppmVParts-per-million by volumeQA/QCQuality Assurance/Quality ControlRAFRelative Absorption FactorRAOResponse Action OutcomeRfCReference ConcentrationRfDReference Dose		
ppmV Parts-per-million by volume QA/QC Quality Assurance/Quality Control RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose		
QA/QC Quality Assurance/Quality Control  RAF Relative Absorption Factor  RAO Response Action Outcome  RfC Reference Concentration  RfD Reference Dose		•
RAF Relative Absorption Factor RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose	ppmV	Parts-per-million by volume
RAO Response Action Outcome RfC Reference Concentration RfD Reference Dose	QA/QC	Quality Assurance/Quality Control
RfC Reference Concentration RfD Reference Dose	RAF	Relative Absorption Factor
RfD Reference Dose		Response Action Outcome
	RfC	Reference Concentration
PI Paparting Limit	RfD	Reference Dose
KL Kepotting Limit	RL	Reporting Limit
SIM Selective Ion Monitoring	SIM	Selective Ion Monitoring
SW Surface Water		Surface Water
TIC Tentatively Identified Compound	TIC	
TOV Total Organic Vapor	TOV	Total Organic Vapor
TPH Total Petroleum Hydrocarbons	TPH	
TPHCWG Total Petroleum Hydrocarbon Criteria Working Group	TPHCWG	Total Petroleum Hydrocarbon Criteria Working Group
UCL Upper Concentration Limit	UCL	
UCM Unresolved Complex Mixture	UCM	Unresolved Complex Mixture
UST Underground Storage Tank		
UV Ultra-violet		
VOC Volatile Organic Compound		
VPH Volatile Petroleum Hydrocarbons		
WSC Waste Site Cleanup		

# 1.0 INTRODUCTION

### 1.1 Background

Spills and releases of petroleum fuels are the leading source of environmental contamination in Massachusetts. Because petroleum products are a complex and highly variable mixture of hundreds of individual hydrocarbon compounds, however, characterizing the risks posed by petroleum-contaminated soil and water has proven to be difficult and inexact.

Traditional approaches have focused on the identification and evaluation of specific indicator compounds, like benzene, and/or the quantitation of a "Total Petroleum Hydrocarbon" (TPH) value. The limitations of an "indicator only" approach have long been recognized, especially at gasoline-contaminated sites, and it is clear that focusing on a select few compounds cannot adequately characterize the risks posed by all hydrocarbons present. While the quantitation of a TPH value is a step in the right direction, in that an attempt is being made to account for all compounds present, traditional TPH methods and approaches provide little or no information on the composition or toxicity of generated data.

In response to these shortcomings, the Massachusetts Department of Environmental Protection (MADEP) published a document in August 1994 entitled *Interim Final Petroleum Report: Development of Health-Based Alternative to the Total Petroleum Hydrocarbon (TPH) Parameter*. This document presented a new toxicological approach to characterize and evaluate risks posed by petroleum-contaminated sites, by breaking down TPH into collective aliphatic and aromatic fractions.

To support and implement this new toxicological approach, MADEP developed two analytical methods that differentiate and quantitate collective concentrations of aliphatic and aromatic hydrocarbons in soil and water. These methods, for *Volatile Petroleum Hydrocarbons* (VPH) and *Extractable Petroleum Hydrocarbons* (EPH), were issued in draft form in August 1995, and as final procedures in January 1998. At present, MADEP is in the process of finalizing a method for *Air-Phase Petroleum Hydrocarbons* (APH), which will allow for the collective quantitation of aliphatic and aromatic hydrocarbons in air. A draft APH method was issued by the agency in February 2000.

MADEP has integrated this new approach into the Massachusetts Contingency Plan (MCP), by developing and promulgating soil and groundwater cleanup standards for the aliphatic and aromatic ranges of interest. These standards became effective on October 31, 1997. Parties undertaking cleanup actions at petroleum-contaminated sites in Massachusetts now have the means to quickly and easily address risks posed by these complex mixtures, by the optional use of the generic *Method 1* cleanup standards. Conversely, such parties may elect to develop site-specific cleanup standards via use of a *Method 2* or *Method 3* risk assessment process.

# 1.2 Purpose and Scope

The purpose of this document is to (1) provide a succinct summary of key provisions of the "VPH/EPH" approach, (2) provide greater detail and specificity on important elements of this new approach, and (3) provide technical and regulatory insight, guidance, and *Rules of Thumb* to assist Licensed Site Professionals and others in understanding and applying this approach in a practical and cost-effective manner.



**Rules of Thumb** are suggestions and recommendations on how to approach, evaluate, and resolve investigatory, assessment, and remedial issues. In most cases, they are based upon reasonably conservative or "worst case" assumptions and considerations, and are intended to assist competent professionals in "ruling out" items of concern, or affirming a need to proceed to a more comprehensive level of evaluation. These rules are based upon current information, and are designed to be protective at most, but not all sites.

Derivation details are provided in "Background/Support Documentation for the Development of Publication Guidelines and Rules of Thumb", available at: <a href="http://www.state.ma.us/dep/bwsc/vph\_eph.htm">http://www.state.ma.us/dep/bwsc/vph\_eph.htm</a>

Rules of Thumb may only be applied to the specific situations described in this document, as such guidelines are predicated upon a designated scenario and are reflective of the totality of conservative assumptions incorporated into that scenario. Changing any developmental element of these guidelines and/or applying them to situations not detailed in this document may not be sufficiently protective. Moreover, the use of these rules may not be appropriate at sites with complex or highly heterogeneous contaminant conditions or migration pathways, or at sites or portions of sites with highly sensitive receptors (e.g., drinking water wells).

While striving to be as useful and complete as possible, nothing in this document should be viewed as limiting or obviating the need for the exercise of good professional judgment.

# 1.3 Applicability

The provisions of this document are applicable at sites contaminated by releases of one or more petroleum fuels and/or lubricating oils. The guidance contained in this policy is designed to help Licensed Site Professionals (LSPs) and others comply with the risk-based/performance-based requirements of the MCP to adequately investigate and assess releases of oil and waste oil to the environment.

The MCP – since 1988 – has required that parties conducting response actions at disposal sites document or achieve a level of no significant risk of harm to human health, safety, public welfare, and the environment. Because the MCP is performance-based, it does not dictate the specific means by which one demonstrates compliance with these standards. From a practical point of view, however, most parties did not have ready access to the tools and procedures needed to adequately characterize the total risks posed by petroleum contamination – until promulgation of the VPH/EPH approach, analytical methodologies, and Method 1 cleanup standards in 1997. For this reason, MADEP has adopted a prospective and retrospective position on the application of the VPH/EPH approach:

### 1.3.1 Site Closure on or after October 31, 1997

Since October 31, 1997, MADEP has provided parties conducting response actions a means to easily and adequately assess risks posed by petroleum contaminants. Therefore, all sites closed on or after this date (e.g., by filing of a Response Action Outcome Statement) must demonstrate compliance with this standard, by use of the VPH/EPH approach, or by use of another scientifically valid and health-protective approach. In these cases, the use of an "indicator only" approach is NOT acceptable.

There are no "grand fathering" provisions for sites that were not closed out prior to October 31, 1997. However, this document provides guidance on how one might utilize and/or "convert" old data obtained prior to this date, to more fully assess risks pursuant to the VPH/EPH approach, and support a post-1997 closure submittal.

Notwithstanding the implementation of this new approach, it should be noted that the MCP retains a cleanup standard for Total Petroleum Hydrocarbons (TPH), which is set conservatively at the lowest EPH fractional cleanup standard (typically  $G_1$ - $G_2$  Aromatic Hydrocarbons). Parties may continue to use a TPH approach to characterize heavier petroleum products (i.e.,  $>G_9$ ), using the EPH method (in the TPH screening mode) or other scientifically valid and defensible method (See Section 3.7.1).

### 1.3.2 Site Closure Prior to October 31, 1997

In general, MADEP will not require reevaluation of petroleum-contaminated sites properly closed prior to October 31, 1997. Nonetheless, the agency reserves the right to do so, in cases where direct and compelling exposure concerns are believed to be present, and where human health is being directly threatened. Such concerns may exist at sites where (1) a release of gasoline has impacted a drinking water well, or (2) a release of gasoline has resulted in persistent, long-term odors or vapors within an occupied structure.

In cases where parties voluntarily conduct VPH/EPH testing at sites closed prior to October 31, 1997 (e.g., pursuant to a property transfer evaluation), the applicable "re-opener" language is contained at 310 CMR 40.0317(17). Under the provisions of this section of the MCP, a notification obligation would exist for this newly obtained VPH/EPH data if such information would change or negate the findings of the closure document (e.g., RAO, LSP Evaluation Opinion).

### 2.0 SUMMARY OF VPH/EPH APPROACH

### 2.1 The Concept

Petroleum is a mixture of hundreds of hydrocarbon compounds. Industry specifications for refined products, such as gasoline and diesel fuel, are based upon physical and performance-based criteria, not upon a specific chemical formulation. As such, the composition of petroleum products released to the environment are complex and variable, and are a function of (1) the origin and chemistry of the parent crude oil, (2) refining and blending processes, and (3) the use of performance-enhancing additives. Once released to the environment, the chemistry of a petroleum product is further altered by contaminant fate and transport processes, such as leaching, volatilization, and biodegradation.

It would be extremely difficult and expensive to identify and quantitate every single hydrocarbon compound present in petroleum-contaminated media. Even if this activity was accomplished, there is little toxicological data available for the vast majority of petroleum constituents. While there are limited data available on the toxicity of some petroleum fuels, the chemistry of weathered products typically encountered at contaminated sites may be quite different from the chemistry of the fresh product that was the subject of toxicological evaluation.

Based upon an evaluation of information and data available on the chemistry and toxicity of petroleum products, however, it is possible to make some broad observations and conclusions:

- petroleum products are comprised mainly of aliphatic/alicyclic and aromatic hydrocarbon compounds;
- ♦ aromatic hydrocarbons appear to be more toxic than aliphatic compounds; and
- \$\delta\$ the toxicity of aliphatic compounds appears to be related to their carbon number/molecular weights.

These three precepts are the foundation of the VPH/EPH approach. Specifically, under this approach, the **non-cancer** toxicity of petroleum-contaminated media is established by (1) determining the collective concentrations of specified ranges of aliphatic and aromatic hydrocarbons, and (2) assigning a toxicity value (e.g., Reference Dose) to each range. Toxicity values are determined on the basis of a review and/or extrapolation of available toxicological data on hydrocarbon mixtures and specific hydrocarbon compounds. The complete breakdown for all ranges of interest is summarized in Table 2-1.

Table 2-1: Toxicological Approach for Non-Cancer Health Effects

Hydrocarbon Fraction	Reference Dose (mg/kg/day)
C5-C8 Aliphatic Hydrocarbons	0.04 <sup>a</sup>
C9-C18 Aliphatic Hydrocarbons	0.1 <sup>a</sup>
C19-C36 Aliphatic Hydrocarbons	2.0 <sup>a</sup>
C9-C22 Aromatic Hydrocarbons	0.03

<sup>&</sup>lt;sup>a</sup> updated values (2002)

**Cancer effects** are evaluated separately, by the identification and quantitation of those specific hydrocarbon compounds, like benzene and certain polycyclic aromatic hydrocarbons (PAHs), which are designated carcinogens. Additional information and details on this approach are provided in the MADEP publication *Interim Final Petroleum Report: Development of Health-Based Alternative to the Total Petroleum Hydrocarbon (TPH) Parameter*, August, 1994, and as amended, available at <a href="http://www.state.ma.us/dep/bwsc/vph\_eph.htm">http://www.state.ma.us/dep/bwsc/vph\_eph.htm</a>

# 2.2 Hydrocarbon Fractions of Interest

Although the non-cancer toxicity of petroleum-contaminated media can be adequately described by division into the four hydrocarbon fractions listed above, MADEP has chosen to designate six hydrocarbon fractions of interest, because of the following analytical and program considerations:

- ♦ EPA analytical methods have traditionally used one approach for the analysis of volatile organics (i.e., purge and trap), and another for the analysis of semi-volatile/extractable organics (i.e., solvent extraction). To facilitate use by commercial laboratories accustomed to such division, the VPH and EPH methods developed by MADEP maintain this distinction. Moreover, because of the large carbon range covered by the new approach (i.e., C5 to C36), it would be difficult to detect all fractions using just one method: the volatile/purgeable methods can adequately cover the lighter hydrocarbons, but not the heavier fractions (>C12), while, due to losses of low molecular weight hydrocarbons that occur during the sample preparation process, extractable methods are generally unable to reliably detect lighter fractions (<C9).
- Given the need for two analytical methods, and a desire to minimize use of both methods on all samples, a decision was made to break up the C9-C18 Aliphatic range, to enable detection of all gasoline-range hydrocarbons in the VPH method. In this manner, it would only be necessary to use the VPH procedure to characterize gasoline releases.

For these reasons, it was necessary and desirable to divide the aliphatic and aromatic hydrocarbon ranges of interest into six separate entities; three detected by the VPH method, and three detected by the EPH Method, as listed in Table 2-2.

**Table 2-2: Hydrocarbon Fractions of Interest** 

Toxicologically Defined Hydrocarbon Fraction	Analytical/Program Defined Hydrocarbon Fraction	Analytical Method	Reference Dose (mg/kg/day)
C5-C8 Aliphatics	C5-C8 Aliphatics	VPH	0.04 <sup>a</sup>
C9-C18 Aliphatics	C9-C12 Aliphatics	VPH	0.1 <sup>a</sup>
	C9-C18 Aliphatics	ЕРН	0.1 <sup>a</sup>
C19-C36 Aliphatics	C19-C36 Aliphatics	ЕРН	2.0 <sup>a</sup>
C9-C22 Aromatics	C9-C10 Aromatics	VPH	0.03
	C11-C22 Aromatics	ЕРН	0.03

<sup>&</sup>lt;sup>a</sup> updated value (2002)

# 2.3 Relationship of VPH/EPH to TPH and Gasoline Range Organics (GRO)

The relationship between TPH, GRO, VPH and EPH is graphically displayed in Figure 2-1.

Universe of Petroleum Hydrocarbons (C5-C36+)**C5 C9** C36 C12 **GRO TPH C5** C12 **C9** C36 C5-C8 C9-C12 C9-C18 C19-C36 ALIPHATICS **ALIPHATICS ALIPHATICS ALIPHATICS VPH EPH** BTEX C9-C10 17 C11-C22 AROMATICS **PAHs** MtBE/NAPH AROMATICS

Figure 2-1: Relationship of GRO, TPH, VPH, and EPH

As can be seen in Figure 2-1, if the concentrations of the three EPH fractions and target PAH analytes were added together, it would be equal to a traditional "TPH" value. Similarly, if the three VPH fractions and BTEX/MtBE/naphthalene concentrations were added together, it would equal a GRO value.

It may also be noted that an overlap exists between the VPH and EPH methods, in that C9-C12 aliphatic hydrocarbons are quantitated by both methods. This overlap, further discussed in Section 4.2.3, is graphically illustrated in Figure 2-2.

C36 VPH ALIPHATICS EPH ALIPHATICS C9-C10 17 AROMATICS BTEX/MtBE C11-C22 AROMATICS **PAHs** C22 **C9** C10 **VPH EPH** AROMATICS **AROMATICS** 

Figure 2-2: Overlap of VPH and EPH Test Methods

Note that there is no overlap in the aromatic fractions: the C9-C10 Aromatic fraction from the VPH method ends just before naphthalene, and the C11-C22 Aromatic fraction from the EPH method starts just after naphthalene.

### 2.4 Additional Research and Data Needs

MADEP continues to gather and review information and data on petroleum hydrocarbon chemistry and toxicity. Recent efforts have focused on the review and evaluation of previously unavailable oral and inhalation toxicological data, which has lead to some revisions to the recommended RfD and RfC values for hydrocarbon fractions of interest (see Table 413). Additional study is also needed to better evaluate ecological risks posed by aliphatic and aromatic hydrocarbons.

On a national level, the Total Petroleum Hydrocarbon Criteria Working Group (TPHCWG) has published a number of documents relating to this subject. TPHCWG is comprised of representatives from the oil industry, Department of Defense, EPA, state agencies, environmental consulting firms, and academia. This group has recommended an aliphatic/aromatic fractional approach similar to the MADEP approach. Additional information and recommendations have also been provided on petroleum chemistry, hydrocarbon fate and transport, and analytical methodologies.

A number of TPHCWG publications are available on the World Wide Web at http://www.aehs.com/

### 3.0 ANALYTICAL METHODS

In order to use the VPH/EPH toxicological approach, it is necessary to be able to measure the collective concentrations of aliphatic and aromatic hydrocarbons in impacted media. Because conventional TPH and EPA test methods cannot produce this type of data, MADEP has developed and published two detailed analytical methods for Volatile Petroleum Hydrocarbons (VPH) and Extractable Petroleum Hydrocarbons (EPH). Both methods are gas chromatography (GC) techniques, and are modifications of traditional EPA procedures contained in SW-846. As such, most laboratories that have conducted volatile and extractable organic analyses in the past should be able to perform these techniques.

### 3.1 Gas Chromatography

Chromatography is the separation of compounds or groups of compounds in a complex mixture. In gas chromatography, hydrocarbons in a sample are transferred to the vapor phase by purging (VPH) or heating (EPH). The gaseous sample then flows through a (100 meter long +/-) *capillary column* to a detector. A chemical coating on the walls of the column first sorbs, and then desorbs each compound in the sample, with the heavier molecular weight compounds being "detained" longer than the lighter compounds. In this manner, analytes exit or *elute* from the column in a predictable and reproducible manner, based upon the structure, molecular weight, and boiling point of the compound.

Once they elute from the column, analytes pass through a detector, where the presence of each compound produces a small electrical current, proportional to its mass. This current is then amplified and used to produce a chromatogram, which is simply a plot of electrical (detector) response over time. Each peak on a chromatogram represents one or more individual compounds. Compounds are identified based upon their *retention times*, which is the time (in minutes) it takes the compound to travel through the column. Compounds or ranges of interest are quantitated by an *integration* process that calculates the area beneath the chromatographic peak(s), for comparison to mass/area ratios derived from the injection of *calibration standards* of known mass or concentration.

To transfer the hydrocarbons within a sample medium into a gas chromatograph, and into a gaseous phase, various sample preparation techniques may be used. Volatiles within water samples are generally *purged* with an inert gas, which strips the dissolved volatile compounds from the aqueous phase into the gaseous phase, where they are initially retained on a *trap* containing an appropriate sorbent. This trap is then rapidly heated to desorb the analytes, and load them onto a chromatographic column. Volatiles within soils are first extracted with a solvent (e.g., methanol), then mixed with water and purged. Heavier non-volatile hydrocarbons in both water and soil samples are generally extracted with a solvent (e.g., methylene chloride); the extract is then injected into a gas chromatograph, where it is heated and vaporized into a gaseous state

A key and novel requirement of the VPH/EPH approach is the need to separate or *fractionate* hydrocarbon mixtures into collective groupings of aliphatic and aromatic hydrocarbons. This fractionation is something that is not done in conventional TPH or Gasoline Range Organic analyses, or the EPA volatile/extractable methodologies detailed in SW-846. There are several different ways to accomplish this task, each with advantages and disadvantages. The recommended MADEP analytical methods use detector selectivity and a chemical exchange process to fractionate samples, but other techniques may also be acceptable and cost-effective.

An example of an EPH (GC/FID) chromatogram of the aliphatic portion of a weathered #2 Fuel Oil soil sample is provided in Figure 3-1.




Figure 3-1: Sample Chromatogram - #2 Fuel Oil

Note that the "x" axis is the retention time, in minutes, and the "y" axis is the detector signal strength. The retention time of some of the individual peaks are printed above those peaks. Note also the presence of a large chromatographic "hump" between 10 and 26 minutes, indicating the presence of an *Unresolved Complex Mixture (UCM)*; this feature is an important issue discussed in more detail below.

# 3.2 MADEP Analytical Methodologies

MADEP has developed and published two analytical methodologies for the detection of Volatile Petroleum Hydrocarbons (VPH) and Extractable Petroleum Hydrocarbons (EPH) in soil and water. Both methods separate complex hydrocarbon

mixtures into collective fractions of aliphatic and aromatic hydrocarbons, and produce data that can be directly compared to MCP *Method 1* cleanup standards. MADEP has also issued a draft methodology for the detection of Air-Phase Petroleum Hydrocarbons (APH), to identify and quantitate collective ranges of aliphatic and aromatic hydrocarbons in air and soil gas.

The VPH, EPH, and APH methods were developed to allow a meaningful evaluation of the risks posed by hydrocarbon mixtures. Other procedures may also be available to fulfill this objective, or, perhaps more importantly, other data quality objectives. For example, it may be more cost-effective to use (or initially use) EPA Method TO-14 to evaluate indoor air quality, and establish whether a subsurface hydrocarbon transport pathway is present at a disposal site; if there is no pathway, there is no need to evaluate risks via the APH procedure.

### 3.2.1 Volatile Petroleum Hydrocarbons (VPH)

The MADEP VPH Method (1998) is a *Purge and Trap, GC/PID/FID* procedure. Using this method, the collective concentrations of C5-C8 Aliphatic, C9-C12 Aliphatic, and C9-C10 Aromatic Hydrocarbons can be quantitated in soil or water matrices. In addition to these fractional ranges, the VPH method may also be used to concurrently identify and quantitate individual concentrations of the *Target VPH Analytes* benzene, toluene, ethylbenzene, and xylenes (BTEX); Methyl-tertiary-butylether (MtBE); and naphthalene.

Samples are analyzed using a *purge-and-trap* sample preparation/concentration procedure. The gas chromatograph is temperature-programmed to facilitate separation of hydrocarbon compounds. Detection is achieved by a photoionization detector (PID) and flame ionization detector (FID) in series. The PID chromatogram is used to determine the individual concentrations of Target Analytes and the collective fractional concentration of aromatic hydrocarbons in the C9 through C10 range. The FID chromatogram is used to determine the collective fractional concentrations of aliphatic hydrocarbons within the C5 through C8 and C9 through C12 ranges. Individual "marker" compounds are used to establish the beginning and end of the hydrocarbon ranges of interest.

The MADEP VPH method relies upon the selectivity of the PID detector to differentiate aromatic hydrocarbons from aliphatic hydrocarbons. Specifically, the PID will preferentially respond to hydrocarbon compounds with pi or double carbon (C=C) bonds, but will not respond well to hydrocarbon compounds with single carbon (C-C) sigma bonds. Because aromatic compounds have at least one benzene ring with three double bonds, they respond well to a PID; straight, branched, and cyclic aliphatic compounds with single carbon bonds respond poorly. Conversely, the FID is more of a universal detector, and will respond equally well to both aliphatic and aromatic hydrocarbons.

Because the PID can detect sample analytes without destroying them, compounds eluting from the chromatographic column are first passed through the PID, and then through the FID, where they are combusted in a hydrogen flame. In theory, the FID will detect the total concentrations of all petroleum hydrocarbons in the sample, and the PID will detect only (or mostly) aromatic compounds. By subtracting the PID from the FID response, it would be possible to quantitate just the aliphatic compounds. However, reality deviates from this theoretical ideal in the following ways:

- ♦ *Pi* bonds are present in hydrocarbon compounds other than aromatics most notably alkenes, which are present in gasoline. Therefore, alkenes will be quantitated as aromatics. However, this bias is not deemed to be a major methodological limitation, due to the fact that (a) alkenes are typically not found in high concentrations in most petroleum products, and (b) alkenes may be more toxicologically similar to aromatics than to aliphatics.
- ♦ A more problematic issue is the fact that aliphatic compounds will produce some measurable response on a PID, especially heavier-molecular-weight branched and cyclic alkanes. Collectively, this response can become significant if there are a lot of these types of aliphatic compounds present, and will result in a falsely inflated quantitation of aromatics. Since a good portion of the hydrocarbons in the C9-C12 range of gasoline are in fact substituted aromatic compounds, this analytical overquantitation is not a major problem. However, other products, like kerosene and Jet A fuel, contain predominately aliphatic compounds within this range, and therefore use of the PID/FID approach can lead to significant overquantitation of the aromatic fraction.

Steps can be taken to minimize overquantitation of the aromatic fraction. Using a low energy PID lamp (e.g., 9.5 eV) will further diminish aliphatic response. Where essential, other techniques, such as chemical fractionation and/or use of a GC/MS approach, may be used to ensure more accurate data in this regard.

### 3.2.2 Extractable Petroleum Hydrocarbons (EPH)

The MADEP EPH Method (1998) is a *solvent extraction/fractionation GC/FID* procedure. Using this method, the collective concentrations of C9-C18 Aliphatic, C19-C36 Aliphatic, and C11-C22 Aromatic Hydrocarbons can be quantitated in soil or water matrices. In addition to these fractional ranges, the EPH method may also be used to concurrently identify and quantitate individual concentrations of the 17 Polycyclic Aromatic Hydrocarbon (PAH) *Target EPH Analytes*.

Soil and water samples are extracted with methylene chloride, solvent exchanged into hexane, and loaded onto a silica gel cartridge or column. The silica gel cartridge/column is rinsed with hexane to strip aliphatic compounds, and the resultant extract is collected and labeled. The silica gel cartridge/column is then rinsed with methylene chloride, to strip aromatic compounds, and the resultant extract is collected and labeled. The two extracts are then analyzed separately by direct injection into a temperature-programmed GC/FID. Individual target PAH compounds are identified by GC/FID analysis of the aromatic extract.

There are two important methodological elements that should be considered when reviewing EPH data:

- ◆ The MADEP EPH method relies upon a solvent-exchange/silica-gel-fractionation process to differentiate aromatic hydrocarbons from aliphatic hydrocarbons. This fractionation process is a sensitive yet critical element of the analytical approach; small errors at this stage can result in significant over or underquantitation of aromatic and aliphatic ranges. For this reason, the method specifies use of *Fractionation Surrogates* to verify proper separation of the aliphatic and aromatic fractions.
- ◆ Like any GC/FID procedure, an *unresolved complex mixture (UCM) or "hump"* will typically be observed on the chromatogram of a heavier molecular weight petroleum product, particularly weathered products. (See Figure 3-1). A UCM is produced when many individual hydrocarbon compounds are eluting from the capillary column at the same time, overwhelming and preventing the detector signal from returning to baseline. Nevertheless, it is important that these compounds are included in the sample quantitation calculation, and for that reason the EPH method specifies the use of a *forced or projected baseline* when integrating chromatographic areas of fractional ranges. If a laboratory does not takes steps to ensure this integration technique, resultant fractional range data may significantly under-report true hydrocarbon concentrations.

The EPH method also contains an option to forego the solvent-exchange/silica-gel-fractionation process, to obtain a Total Petroleum Hydrocarbon (TPH) concentration. While this data will provide little information on the chemistry or toxicity of the petroleum mixture, it can provide a cost-effective analytical screening value, for comparison with TPH reporting and cleanup standards.

### 3.2.3 Air-Phase Petroleum Hydrocarbons (APH)

The draft MADEP APH method (2000) is a GC/MS procedure. Using this method, the collective concentrations of C5-C8 Aliphatic, C9-C12 Aliphatic, and C9-C10 Aromatic Hydrocarbons can be quantitated in air or soil gas matrices. In addition to these fractional ranges, the APH method may also be used to concurrently identify and quantitate individual vapor-phase concentrations of the *Target APH Analytes* 1,3-butadiene, benzene, ethylbenzene, and xylenes (BTEX); Methyl-tertiary-butylether (MtBE), naphthalene, and 2-methylnaphthalene.

Samples are collected in SUMMA ® passivated stainless steel canisters (other collection techniques are permissible and may be more appropriate for certain data quality objectives). A specified volume of sample is withdrawn from the canister through a mass flow controller using a vacuum pump. The sample is cryogenically concentrated to a volume of less than one mL in a nickel trap filled with nonsilanized glass beads. Following preconcentration, the sample is refocused at the head of a capillary column on a gas chromatograph using a cryofocusing accessory. This step further reduces the sample volume to less than one microliter for injection.

The sample is then injected into a gas chromatograph, which is used to separate the compounds and hydrocarbon fractions of interest. All compounds are detected using a mass spectrometer. Target APH Analytes are identified and quantitated using characteristic ions. Collective concentrations of  $C_9$ - $C_{10}$  Aromatic Hydrocarbons are quantitated using extracted ions. Collective concentrations of aliphatic hydrocarbon fractions are quantitated using a total ion chromatogram, subtracting out Target APH Analytes and  $C_9$ - $C_{10}$  Aromatic Hydrocarbons. It is important to note that the final APH method may contain modifications of the above procedures.

Air testing, whether by the APH procedure or other methodologies, is a specialty service that is not as widely available as soil and water analytical services. However, unlike the VPH and EPH methods, MADEP does not expect use of the APH method will be required at most petroleum contaminated sites, for the reasons listed below:

- Most releases of petroleum products do not result in an indoor air impact;
- For those sites where an indoor air impact is a potential concern, it is usually possible to evaluate and/or ruleout indoor air contamination problems using low-cost soil gas analytical screening techniques, as further detailed in Section 4.3.1; and
- ♦ Where indoor air sampling is required to evaluate a potential subsurface vapor transport pathway, traditional EPA procedures (e.g., EPA Method TO-14) may be used to determine if an impact is likely (based upon concentration of target analytes and qualitative presence of hydrocarbon peaks). The use of the APH (or similar) procedure would only be necessary if contamination is confirmed, and a quantitative risk assessment is required.

# 3.3 VPH/EPH Target Analytes

Although both the VPH and the EPH methods are capable of providing quantitation of Target Analytes (concurrent with the quantitation of aliphatic and aromatic ranges), because they are GC methods which identify analytes solely on the basis of retention times, they can produce "false positive" or over-inflated concentration data for these individual compounds. For example, the large peak eluting at 14.740 minutes in Figure 3.1 may be identified by the EPH method as hexadecane, because a hexadecane standard run as part of the calibration procedures eluted at this retention time. However, it is possible that hexadecane is not present in this sample at all, and some other (unknown) hydrocarbon compound is present which elutes at precisely this same time; or it is possible that hexadecane is indeed present, but that 2 or 3 other hydrocarbon compounds are *co-eluting* with hexadecane at precisely this time, which will lead to an overquantitation of the hexadecane concentration.

Although the sample-extract cleanup and fractionation procedures specified in the EPH method will tend to minimize interferences of this nature (by removing aliphatic compounds that may co-elute with the PAH Target Analytes), the only way to get positive identification and quantitation of these Target Analytes is to use a GC/MS analytical technique, like EPA Method 8270 for the PAHs, and EPA Method 8260 for BTEX/MtBE. For this reason, a laboratory may advise a client to use the VPH and EPH methods to quantitate the aliphatic/aromatic fractional ranges, but a GC/MS method to quantitate individual (Target) analytes. This approach is acceptable, although it may increase analytical costs.



To save money, it may be a worthwhile gamble to quantitate Target Analytes using the VPH/EPH Methods for samples that are believed to be relatively free from contamination - for example, when trying to confirm a "clean closure" at a tank removal site. If significant concentrations of Target Analytes are in fact found to be present, a re-analysis can be done using GC/MS, to provide a definitive determination in this regard (if the laboratory was instructed to retain the sample extract from the VPH/EPH samples, the cost for this re-analysis would be reduced).

### 3.4 Sampling Procedures and Requirements for the VPH/EPH Methods

Sample collection and preservation are critical elements in the VPH and EPH methodologies. A summary of requirements in this regard is provided in Table 3-1; detailed step-by-step sampling recommendations are provided in Appendix 1.

Sample preservation is essential. VPH and EPH aqueous samples must be preserved in a manner that prevents biodegradation of hydrocarbons. Simply cooling these samples is not sufficient. Biodegradation can be prevented by addition of acids (e.g., HCl to pH <2) or by the addition of bases (e.g., Trisodium Phosphate Dodecahydrate to pH > 11). Note that acid preservation can significantly degrade levels of MtBE in aqueous samples (see Appendix 1).

**VPH** soil samples must be preserved in a manner that (1) prevents sample losses due to volatilization, and (2) prevents sample losses due to biodegradation. There is now considerable evidence and data demonstrating substantial losses of volatile petroleum hydrocarbons from unpreserved sampling containers. The recommended preservation technique is to immerse VPH soil samples in methanol *at the time of collection*. Alternative techniques will be considered only if sufficient data are available to demonstrate the efficacy of sample preservation. Currently, only one alternative has been shown to provide acceptable preservation: the use of specially designed sealed-tube devices that obtain an air-tight soil sample.

**Table 3-1: Sample Collection, Preservation, and Holding Times** 

Method	Matrix	Container	Preservation	<b>Holding Time</b>
VPH	Aqueous	40 mL VOC vial w/Teflon- lined septa screw caps; fill completely to zero headspace	pH <2 (add 3-4 drops of 1:1 HCl); cool to &C. Where MtBE is of concern, use 0.40– 0.44 grams TSP to raise pH > 11 (see Appendix 1)	14 days
	Soil	VOC vial or container; add 15g to 40mL vial; 25g to 60 mL vial	1 mL methanol per 1g soil (+/-25%); cool to 4°C	28 days
ЕРН	Aqueous	1-Liter amber glass bottle with Teflon-lined screw cap	pH<2 (add 5 mL of 1:1 HCl); cool to 4°C	Extract within 14 days; analyze extract within 40 days
	Soil	4-oz (120 mL) +/- widemouth amber glass jar with Teflon-lined screw cap	cool to 4°C	Extract within 7 days; analyze extract within 40 days

Such devices have been shown to maintain sample integrity for 48 hours, by which time the sample must be extruded and preserved in methanol. Additional detail on the preservation of VPH aqueous and soil samples is provided in Appendix 1. Information and guidance on shipping methanol-preserved samples is contained in Appendix 2.

### 3.5 Modifications of the VPH/EPH/APH Methods

The MADEP VPH, EPH, and APH analytical techniques are "performance-based" methods, which means that modifications to specified procedures are allowable, as long as acceptable performance is demonstrated and documented.

The most common modification of the VPH and EPH methods involves the use of a GC/MS technique to identify and quantitate collective ranges of aliphatic and/or aromatic hydrocarbons. Under this approach, a mass spectrometer is used to break up the hydrocarbon molecules in a sample into fragments with certain masses and charges. A computer program is then used to search for specified fragments that are indicative of an aliphatic and/or aromatic hydrocarbon structure. Quantitation of a collective hydrocarbon range is accomplished by comparing the total mass of these selected fragments with the mass of fragments produced by calibration standards.

While MADEP believes that a GC/MS approach has promise, it has not yet issued guidelines or recommendations in this regard. Until such time as this occurs, all laboratories conducting such modifications must be able to provide complete documentation on their procedures, and must be able to demonstrate that their methodology is capable of generating data of a known level of accuracy and precision. Specific questions that a data user might want to address to laboratories include:

- What "ions" (fragments) were used to quantitate specific aliphatic and/or aromatic hydrocarbon ranges? How were these ions chosen? Because hydrocarbon molecules fragment in different manners and proportions, how do the fragmentation patterns of the calibration standards correlate to the fragmentation patterns of the hydrocarbons likely contained in the sample?
- ♦ What studies did the laboratory do to validate the method? Were "neat" petroleum products analyzed? Fresh and/or "weathered"?
- Based upon the choice of quantitating ions and the results of the validation studies, under what (sample chemistry) conditions would a positive or negative identification and/or quantitating bias be expected?

While MADEP encourages laboratories to develop "better mouse traps", ultimately, it is the responsibility of the data user to determine the validity and application of data obtained from modified methods. Parties unfamiliar with analytical chemistry and/or laboratory operations are advised to seek expert advice in such matters, and understand the nature, extent, and implication of all method modifications.

# 3.6 Data Quality and Report Content

Because the VPH and EPH methods are performance-based, and because MADEP does not (at this time) have a laboratory certification program for non-drinking/non-wastewater matrices, it is incumbent upon the laboratory and data users to take steps to ensure and document the quality of analytical data, consistent with the provisions and requirements of 310 CMR 40.0017.

The VPH and EPH methods have detailed and specific Quality Assurance and Quality Control (QA/QC) requirements, and a required data reporting content, which is provided in Appendix 3. The reporting content is designed to ensure that data users can easily ascertain (1) what is being reported, (2) basic sample and QA/QC information, (3) whether significant modifications were made to the recommended methods, (4) whether all recommended QA/QC steps were taken, and (5) whether all specified QA/QC and performance standards were met. While it is not necessary to obtain and provide data in exactly the same form and order detailed on the reporting sheets provided in Appendix 3, data users should insist that all indicated information and statements be provided.

Although a comprehensive review of all QA/QC information and data is beyond the ability and/or resources of most data users, there are several quick and easy steps that can and should be taken to help ensure the accuracy and reliability of VPH/EPH/APH data, by simply reviewing the information and data required in the data report:

- All sample information specified in Appendix 3 should be provided, describing the sample matrix, condition of containers, and sample preservation. VPH samples that were not preserved in the field with methanol (or sampled/preserved in an acceptable alternative manner) are highly suspect.
- ♦ The dates of sample collection, receipt by laboratory, extraction (EPH) and analyses should be provided. Samples held beyond the recommended holding times are suspect, especially EPH soil samples that are preserved only by refrigeration.
- A percent moisture value should be reported for all soil samples, to ensure that such data have been adjusted to a "dry weight" reporting basis.
- $\Diamond$  The analytical units must be clearly indicated, and should be appropriate for the matrix under evaluation (i.e.,  $\mu g/g$ , mg/kg, or  $\mu g/kg$  for soil;  $\mu g/L$  or mg/L for water;  $\mu g/m^3$  or ppbv for air).
- Reporting Limits (RLs) should be specified for each aliphatic and aromatic range and each Target Analyte. The VPH, EPH, and APH methods contain specific procedures and requirements on how to establish Reporting Limits, which are the minimum concentration values that a laboratory can discern and report with sufficient confidence. These values must be experimentally determined by each laboratory. Note that expected RLs for the aliphatic and aromatic ranges in water are between 50 and 100 μg/L; expected RLs for the aliphatic and aromatic ranges in soil are between 2 and 10 mg/kg; expected RLs for the aliphatic and aromatic fractions in air are between 25 and 100 μg/m<sup>3</sup>.
- ♦ The percent recovery of sample surrogates should be provided, along with the acceptable range. A surrogate is a (non-petroleum) chemical compound added ("spiked") into each VPH and EPH water and soil sample prior to extraction and analyses. The purpose of surrogate spiking is to determine the efficiency and accuracy of sample extraction (EPH), sample purging (VPH), and instrument analyses. Surrogate recovery is expressed in terms of percent recovery; for example, if 1000 μg of the surrogate compound ortho-terphenyl (OTP) is spiked onto a 10 gram soil sample that is to be analyzed by the EPH method (yielding a theoretical concentration of 100 μg/g), and the resultant analysis quantified OTP at 70 μg/g, the percent recovery would be 70%. Although sample data with surrogate recoveries outside of the stated acceptance range should be carefully evaluated, they need not be summarily dismissed or considered categorically unusable. For example, data associated with a surrogate recovery greater than specified limits may be appropriate to use as an "upper limit" value; data associated with a surrogate recovery lower than specified limits may be appropriate to use as a "lower limit", and would constitute knowledge of a release if exceeding Reportable Concentrations. Note that low recoveries are not uncommon (or unexpected) in clay/organic soil matrices. Also, low recoveries of sample surrogates may be observed in VPH soil samples with high moisture content.
- For the EPH Method, the percent recovery of Fractionation Surrogates should be provided, along with the acceptable range. In the EPH method, a sample extract is baded onto silica gel, followed by a hexane rinse, to

remove and collect aliphatics, and a methylene chloride rinse, to remove and collect aromatics. However, because of the weakly polar nature of naphthalene and substituted naphthalenes, they are easily "stripped" into the aliphatic fraction - an especially problematic occurrence in water samples, as the naphthalenes constitute a large percentage of the water-soluble fraction of fuel oils. To monitor whether this action is occurring, Fractionation Surrogates are added directly to the sample extract just prior to the silica gel fractionation step (as opposed to the sample surrogates, which are added to the soil and water samples prior to extraction, to evaluate extraction efficiency). The currently recommended Fractionation

Surrogates are 2-Fluorobiphenyl and 2-Bromonaphthalene - two compounds that are not normally present in petroleum, and that have polarities similar to naphthalene. Both compounds should be detected in the aromatic fraction within the specified acceptable percent recovery ranges.

- The laboratory should clearly indicate whether the reported VPH/EPH/APH fractional range concentrations include or do not include the concentration of Target Analytes, and the range(s) in which the Target Analytes elute. By definition, these ranges exclude Target Analytes, which are evaluated separately. (Absent this exclusion, Target Analytes like BTEX and PAHs would be "double counted" once in the collective range concentrations, and once in a separate Target Analyte evaluation). If the laboratory did not subtract out the concentrations of these Target Analytes (perhaps they only provided range data), the data user may make this adjustment. It is also permissible for a data user to adjust a range concentration value by excluding the concentration(s) of non-petroleum analytes eluting within that hydrocarbon range (e.g., TCE eluting within a C5-C8 Aliphatic Hydrocarbon range). Note that unadjusted data are also acceptable to MADEP they are just overly conservative.
- The laboratory must clearly indicate whether significant modifications were made to MADEP VPH/EPH/APH methods, and if so, should detail the nature and extent of these modifications. Examples of "significant modifications" are specifically listed in Section 11 of each method. Note that MADEP encourages innovation, where appropriate.
- The laboratory should clearly indicate whether it has followed and met the QA/QC program and performance standards specified by the MADEP VPH/EPH/APH Methods. Such an affirmation is contained in the required laboratory report content. Note that on some samples, it will not be possible to meet all QA/QC specifications, and that such data need not be summarily dismissed as unacceptable, as long as an appropriate explanation is provided, and as long as limitations inherent in the data are acceptable for the given application and use of the data.
- ♦ A report narrative should be provided, if necessary, to document and explain any deviations from the method, analytical problems, and/or QA/QC issues. Laboratories using modifications of the method should have on file a written Standard Operating Procedure, which should be referenced or provided as appropriate. While a failure to perform or meet the data reporting and performance standards specified above does not necessarily mean that the provided data are not of sufficient quality, it does place the burden on the data user to make this determination.
- ♦ The laboratory should certify under the pains and penalties of perjury that the information contained in the data report form is accurate and complete. This attestation should be done via the signature of a responsible laboratory representative.

While minimum standards are specified in the methods, to ensure a minimum level of quality for all data, there is an expectation that laboratories should be able to achieve better results on most samples. In selecting a laboratory, a data user should make sufficient inquiry into the experience of the laboratory performing these (and any other) analytical methods, and on the QA/QC program in operation to monitor, document, and improve analytical quality. In addition, the scope of laboratory services should be negotiated and clearly articulated "up front", to ensure that the data user is procuring (and the laboratory is receiving compensation for) all desired information and data (e.g., QA/QC data, narrative reports, data usability discussions, etc.).

Additional guidance and recommendations on data quality issues for the VPH/EPH methods (as wells as most other common EPA methods) can be downloaded from MADEP at: <a href="http://www.state.ma.us/dep/bwsc/files/data/QAQCDocs.htm">http://www.state.ma.us/dep/bwsc/files/data/QAQCDocs.htm</a>

Analytical data and testing should not be viewed as a commodity, but as a highly technical and sophisticated professional service, requiring the same level of scrutiny and oversight as any other professional service that will be relied upon by a Licensed Site Professional in rendering a waste site cleanup opinion.

# 3.7 Other Hydrocarbon Testing Methods

The VPH and EPH methods were developed to provide data on the chemistry and toxicity of complex hydrocarbon mixtures, to facilitate risk evaluations and to complement MADEP Method 1 cleanup standards. However, in cases where the total concentrations of hydrocarbons are relatively low, use of these fractionation procedures may be "overkill", and a "total petroleum hydrocarbon" (and Target Analyte) evaluation may suffice. Moreover, risk characterization is not the only site assessment objective or concern at disposal sites; other characterization needs may include: petroleum product identification, petroleum source identification, and/or Remediation Waste characterization. In these cases, other analytical procedures may be more appropriate and cost-effective.

A summary of other possible analytical approaches and methodologies in this regard is provided in Table 3-2.

**Table 3-2: Other Analytical Approaches** 



Objective	Analytical Approach	Conditions/Caveats/Comments
Characterization of Remediation Wastes	TPH, VOCs, and/or jar headspace screening. Metals, PCBs and/or TCLP often required	Need to check with disposal or recycling facility for requirements
Risk Assessment & Compliance with Cleanup Standards	TPH via an appropriate methodology. Characterize Target Analytes as needed with EPA SW-846 methodologies	Applicable for low levels of C9 and heavier hydrocarbons (i.e., when TPH concentrations will likely < TPH cleanup standards)
Determining Type of Petroleum Product	High resolution GC/FID; advanced GC/MS chemical fingerprinting	Also recommended to differentiate petrogenic vs. pryrogenic PAHs
Determining Source of Petroleum Product	High resolution GC/FID; advanced GC/MS chemical fingerprinting; quantitation of biomarkers	Not always definitive; requires interpretative expertise

# 3.7.1 Total Petroleum Hydrocarbons (TPH)

Though a widely used and conceptually-simple testing parameter, there is no universal definition of TPH, and the term is essentially defined by the analytical method chosen by the laboratory. To further complicate this matter, many laboratories use undefined and inconsistent "modifications" of published methodologies to detect and quantitate TPH concentration values (e.g., Modified EPA Method 8100). This situation has lead to a significant degree of confusion over the application, comparability, and quality of TPH data.

The MCP provides a definition of TPH at 310 CMR 40.0006:

<u>Total Petroleum Hydrocarbons</u> and <u>TPH</u> each mean the total or cumulative concentration of hydrocarbons with boiling points equal to or greater than 150°C [C<sub>9</sub>] and associated with a petroleum product, as measured by standard analytical techniques and/or by procedures approved by the Department, excluding the individual compounds listed at 310 CMR 40.0974(2).

This definition reflects the fact that the vast majority of "TPH" analyses traditionally conducted in Massachusetts involved the use of an extraction solvent (e.g., Method 418.1), which leads to the loss of lighter hydrocarbons (<C9) present in the sample. Based upon this definition, the following rules and recommendations would apply to parties electing to use a TPH analytical method to support a risk assessment or document compliance with an MCP Method 1 TPH cleanup standard:

- The TPH method and resultant data may only be used to characterize releases of petroleum products that consist of hydrocarbons primarily in the C9 to C36 range. In other words, it may only be used in lieu of an EPH procedure, not a VPH procedure. Guidance on when an EPH procedure is appropriate is contained in Table 4-6.
- In addition to the TPH analysis, all appropriate Target Analytes must also be addressed. Guidance in this regard is contained in Tables 4-3 and 4-5.

- For analytical procedures that utilize a GC/FID technique, the TPH quantitation value must be based upon the integration to baseline of all peak areas from n-Nonane (C9) to n-Hexatriacontane (C36).
- As the MCP specifically excludes "individual compounds listed at 310 CMR 40.0974(2)" from its definition of TPH, it is acceptable to adjust gross TPH values by subtracting out the collective concentrations of these individual compounds. Note that, for all intents and purposes, the "individual compounds listed at 310 CMR 40.0974(2)" are synonymous with the EPH Target Analytes listed in Tables 4-3 and 4-5.

While the MCP defines TPH to be C9 and heavier hydrocarbons, there are some TPH and/or "Gasoline Range Organics" methodologies that may collectively quantitate lighter hydrocarbons in the range of C5-C12. Typically, these methods involve the use of a purge-and-trap or headspace development technique, followed by a GC/FID analytical procedure. While these procedures may NOT be used to obtain TPH data for comparison to the MCP Method 1 cleanup standards (because of the definition of TPH at 40.0006), they can be used as a screening tool for VPH range contaminants. Specifically, if the TOTAL concentration of hydrocarbons within the C5-C12 range (excluding VPH Target Analytes) is less than the lowest VPH Method 1 standard (usually C9-C10 Aromatic Hydrocarbons), it would be safe to assume that hydrocarbon levels are within all fractional standards.

While use of TPH methods may offer certain advantages, it is the responsibility of the party using and submitting such data to ensure that the specific technique and procedure(s) used is appropriate for the disposal site in question, and that appropriate Quality Assurance and Quality Control (QA/QC) measures are taken to monitor and document the quality and usability of the generated data. In general, MADEP expects all such methods to achieve a level of QA/QC consistent with the VPH and EPH methods.

A tabulation of commonly and/or historically available TPH analytical techniques is provided in Table 3-3.

Method **Technique Comments** MADEP EPH Extraction with methylene Use in the "TPH" screening mode by eliminating the chloride & GC/FID analysis fractionation step per Section 1.5 of EPH Method EPA Method 1664 New method (1999) to replace Method 418.1 (Freon Extraction with n-hexane & gravimetric analyses extraction with IR analyses) Modified EPA Extraction with appropriate Must ensure quantitation in C9-C36 range with forced Method 8100 solvent & GC/FID analysis baseline integration if data is used to support MCP TPH cleanup standard Modified EPA Purge-and-trap or headspace Must ensure quantitation in the C5-C12 range with forced Method 8015 sample preparation & baseline integration if data is to be used to screen samples GC/FID analysis for compliance with MCP VPH cleanup standards

**Table 3-3: Common/Available TPH Testing Methods** 

### 3.7.2 Environmental Forensic Techniques

In conducting a characterization of a petroleum-contaminated site, it may be necessary and/or desirable to identify the types of petroleum product present and/or the source of their release to the environment. In recent years, new analytical testing techniques have evolved to facilitate evaluations of this nature, and support an evolving specialization known as "environmental forensics".

In order to identify the types and/or source of petroleum products that were detected at a site, (up to) a three-step analytical regiment is recommended:

• Initially, samples should be analyzed by a high-resolution gas chromatography/flame ionization detection (GC/FID) methodology. Such techniques have been utilized for many years, and are a useful "first cut" to help identify the boiling-point range of the hydrocarbon mixtures present in the sample, which can then be used to make judgments on the type(s) of petroleum product(s) released at the site (e.g., #2 fuel oil vs. #6 fuel oil). In some cases, the data obtained in this manner is sufficiently conclusive to satisfy site characterization objectives.

In other cases, however, the contamination is highly weathered, and/or intermingled with hydrocarbons of pyrogenic origin (e.g., coal ash, soot, engine emissions).

- In situations where a GC/FID evaluation is inconclusive, additional analytical characterization by a gas chromatography/mass spectrometry (GC/MS) "advanced chemical fingerprinting" technique may be advisable. These methodologies focus on the identification and quantitation of polycyclic aromatic hydrocarbons (PAHs). Although most people are familiar with the 17 priority pollutant PAH compounds quantitated by the MADEP EPH method and EPA Method 8270, there are in fact many more PAH compounds present in petroleum products. Using a GC/MS technique and sophisticated quantitation algorithm, it is possible to identify and quantitate collective groupings of these PAH compounds based upon their structure, e.g., naphthalene with a side chain containing 1 carbon atom; naphthalene with a side chain containing 2 carbon atoms, etc. The presence and distribution of these side chains can then be used to help establish the type of petroleum product(s) present at the site. Moreover, this same information often plotted as histograms may also be used to differentiate petroleum-derived (petrogenic) hydrocarbons from combustion-derived (pyrogenic) hydrocarbons (given that the latter are predominated by the parent PAH compound, while the former are predominated by the alkylated side chain PAH compounds).
- Data on the distribution of alkylated PAHs can often provide definitive information on the type(s) of petroleum products present at a site, and even some evidence on the specific source(s) of release. However, in order to obtain more definitive proof of the source of a petroleum release, one additional analytical tool should be considered: the identification and quantitation of biomarkers. Biomarkers are chemical compounds present in petroleum products that are the remnants of the biological life (e.g., algae, plants, bacteria) that help create the parent crude oil. While certain biomarkers are identifiable using a GC/FID methodology (e.g., pristane and phytane), the most useful compounds in this regard (e.g., terpanes and steranes) are identified using a GC/MS technique in a selected ion monitoring (SIM) mode. Because each crude oil source has a distinct "fingerprint" of biomarkers, it is often possible to identify the specific source of a release of petroleum at a site using this approach (e.g., using a statistical/multivariate component analyses), though weathering processes may sometimes decrease confidence in such conclusions.

At the present time, advanced chemical fingerprinting is an innovative technology used by only a small number of laboratories. Given this status, and given the sophistication, complexity, and professional judgment inherent in these approaches, it is essential that data users seek out facilities and personnel with the appropriate expertise and experience.

# 3.8 Analytical Screening Techniques

The use of analytical screening techniques is encouraged, to provide timely and cost-effective data. As the sophistication and reliability of so-called "field" methods continue to increase, the distinction between conventional laboratory and analytical screening techniques becomes less defined, and less important. However, with this increased capability and performance comes an increased need to demonstrate and document a commensurate level of quality assurance/quality control (QA/QC), consistent with the provisions and requirements of 310 CMR 40.0017.

Various levels/approaches are possible:

- Screening techniques may be used solely to direct remedial actions and/or sampling programs for conventional VPH/EPH testing. Because such screening data will not be used in a "stand alone" capacity, QA/QC requirements are not as critical.
- Screening techniques may also be employed to obtain data that will be used, in whole or in part, to assess risks and/or determine compliance with cleanup standards, and/or to support the representativeness of ("lab") data used in the risk assessment process. While it is understood that such screening methodologies may lack the qualitative or quantitative accuracy of conventional VPH/EPH testing, the same level of QA/QC will be expected, within the limits and bounds of the stated application of the data.

The use of screening techniques depends upon, or may be enhanced by, the use of assumptions and conditions. This approach is acceptable, as long as conservative assumptions are made, and the use of such methods and assumptions are appropriate, given contaminant chemistry, site conditions, and area receptors. A tabulation of commonly used screening techniques, and recommended applications and *Rules of Thumb*, are provided in Table 3-4.



# Table 3-4 VPH/EPH Analytical Screening Techniques

Technique	Description	Range	Applications	Limitations	Recommendations
PID/FID Headspace	Soil or water sample is placed in sealed container & headspace is allowed to develop. PID and/or FID meter is then used to test the headspace for total volatile organic compounds (VOCs). Reference: Recommended DEP jar headspace procedure	VPH	Excellent screening tool for gasoline; good tool for kerosene, jet fuel and fresh fuel oil. Best used to direct remedial operations, and provide first-cut site characterization data. PID preferentially responds to the more toxic aromatic compounds.	Not appropriate for heavy mineral/lube/fuel oils or weathered diesel/#2 fuel oil. PID can be non-linear and/or erratic for gasoline headspace vapors > 150 ppmv. PID response lessened by high humidity/ moisture (instrument dependent). Additional confirmatory analyses usually required.	For gasoline, excluding clays & organic soils, headspace readings less than 100 ppmv usually means that all VPH fractions are below 100 µg/g. Confirmatory analyses needed.
PID/FID Soil Gas	Soil gas is extracted from a probe and analyzed with a PID and/or FID meter. Reference: see Section 4.3.1.1	VPH & EPH	Use to investigate soil gas/indoor air pathways, and evaluate sites with g.w. concentrations > GW-2 Method 1 standards. PID preferentially responds to the more toxic aromatic compounds.	Instrument response is flow-dependent; must ensure adequate flow rates. PID response affected by high moisture & high petroleum vapor concentrations (>150 ppmv). FID will respond to pipeline/naturally-occurring methane.	See recommendations in Section 4.3.1.1 and Table 4-9.
UV Fluorescence & Absorbance	The absorbance or fluorescence of a UV light source is used to directly quantitate the aromatic content of soil sample.  Extraction solvent, such as methanol or Isopropyl alcohol, must be used. Reference:  ASTM 5831-95	VPH & EPH	Good screening tool for petroleum products with significant aromatic content (e.g., diesel/#2 fuel oil and gasoline). UV Fluorescence has lower detection limits than absorbance, but is not as linear. UV methods target the more toxic aromatic fractions.	Does not respond to aliphatics; not appropriate for petroleum products that are primarily aliphatics (mineral oils or dielectric fluids). May pick up naturally occurring humic acids - calcium oxide can be used to decrease interference.	Calibrate with aromatic standard, like C11-C22 EPH standard, for direct measurement of aromatic hydrocarbons. For diesel/#2 fuel oil, assume aliphatic content is twice aromatic. This approach may significantly over-predict aliphatic content of highly weathered diesel/#2 fuel oil. Confirmatory analysis recommended for representative/worst-case samples.
Emulsion- Based TPH Methods	Hydrocarbons are extracted from a soil sample with a solvent (e.g. methanol), and a surfactant is added to create an emulsion. Optical sensor is used to measure extract turbidity	ЕРН	Gives "TPH" screening values, quantitating both aromatic and aliphatic hydrocarbons. Best correlation shown with diesel/#2 fuel oil.	Does not discriminate between aliphatics and aromatics. Interference possible in organic-rich and clay soils. Not recommend for gasoline.	For diesel/#2 fuel oil, assume 60% C11-C22 Aromatics and 40% C9-C18 Aliphatics.
Immunoassay Test Kits	Soil or water samples analyzed by antibody-antigen reaction. Enzyme conjugates used to allow colorimetric analysis of antigen (contaminant) conc. Soil extraction with methanol. Reference: EPA 4030/4035	VPH & EPH	Can be used to detect specific compounds or groups of compounds (e.g., BTEX and PAHs). "TPH" methods usually target naphthalene, and assume correlation to TPH.	Because antibodies bind with specific antigens (contaminants), cannot directly quantitate collective aliphatic/aromatic fractions or total hydrocarbons. Not effective for lube/hydraulic oils.	No general assumptions can be made. Each kit and application has to be individually evaluated.
Fiber-Optic Chemical Sensors	Probe with hydrophobic/organo- phyllic optical fiber is lowered into a well. Change in refraction index used to est. hydrocarbon conc. in groundwater	VPH & EPH	Allows in-situ measurements of volatile and semi-volatile dissolved hydrocarbons. Results calibrated to a p-xylene response. In-situ vapor measurement also possible.	Response decreases with increasing solubility; response to benzene 10 times less than p-xylene. Significant calibration/cleaning requirements between uses.	Insufficient information available to offer general recommendations.

### 3.8.1 Principles of Operation, Biases, and Calibration

All screening techniques and instruments are predicated upon certain principles of operation, detection, and calibration. Many have limitations and biases that need to be understood and accommodated. For example, an immunoassay "TPH" test method may be designed to detect the presence of naphthalene, and then extrapolate a TPH concentration based upon an assumption on the percentage of naphthalene in fresh fuel oil. Thus, two important assumptions and biases are present: (a) the concentration of a single compound (naphthalene) can be used to determine the concentration of a product which is made up of numerous (perhaps hundreds of) hydrocarbon compounds, and (b) the chemistry of a fresh fuel oil standard can be used to estimate the chemistry of a field sample. As such, a highly weathered fuel oil sample, or a fuel product low in naphthalene (e.g., mineral oils) may not yield reliable results.

To effectively use analytical/screening techniques, especially for risk and cleanup decisions, it is incumbent upon the data user to:

- 1. understand the application and limitations of the screening method(s) of interest;
- 2. consider site-specific contaminant/mixture chemistry and fate/transport processes; and
- 3. determine the precision and accuracy boundaries of the generated data, to see if they meet the desired data quality objectives and site characterization needs (e.g., if data can be considered accurate at 100 μg/g +/- 300%, and the cleanup standard is 500 μg/g, it may be acceptable).


In general, the following recommendations are offered:

- Techniques that detect a structural class and/or range of compounds are preferred, as opposed to methods that rely upon one specific indicator compound. Techniques that detect a range of compounds include PID/FID headspace techniques, UV absorbance/fluorescence, and emulsion-based TPH techniques. Procedures that target a single indicator compound require sufficient site-specific correlative and confirmatory data.
- ♦ Techniques that target aromatic hydrocarbons are preferred, as opposed to methods that target aliphatic compounds, due to the fact that aromatic hydrocarbons are, as a class, more toxic and mobile than aliphatic hydrocarbons. On the whole, it is better to be able to accurately quantitate collective aromatic hydrocarbons, and estimate aliphatics, than to accurately quantitate collective aliphatic hydrocarbons, and estimate aromatics. Techniques that target aromatics include PID headspace and UV absorbance/fluorescence.
- ♦ Techniques that involve a quick "shake out" extraction technique for soil analyses may not be sufficient for clay or organic-rich soils, due to partitioning efficiencies.

### 3.8.2 Recommended Approach

For small sites, such as residential underground storage tank (UST) excavations, screening techniques are perhaps best used to direct soil removal operations, identify areas for assessment and/or confirmatory VPH/EPH laboratory analysis, and/or provide a database to support the representativeness of decision-quality data. For larger sites, the use of screening data as a substitute and complement for VPH/EPH laboratory data may provide a better and less expensive approach to site characterization. For example, for the price of a single EPH test (approximately \$200), it may be possible to perform 4 to 10 field screening analyses. So, for a sampling and analytical budget of \$2000, it may make sense to take 8 EPH samples, and 8 to 20 field-screening samples, rather than (just) 10 EPH samples. The minimum number of VPH/EPH laboratory samples needed to understand contaminant chemistry, and provide confidence in screening data, is necessarily site-specific. The key variables are the heterogeneity of site conditions (stratigraphic/microbiological), source vs. migration areas, and the degradability of the petroleum product(s). Generalized *Rules of Thumb* in this regard are provided in Table 3-5. Note that additional confirmatory sampling would be indicated if sufficient correlation could not be established between the VPH/EPH values and screening/TPH values.

Table 3-5: Recommended Minimum VPH/EPH Laboratory Confirmation Data Needed to Support Analytical Screening



### 3.9 Drinking Water Testing Methods

When testing a potable drinking water supply, the use of the VPH/EPH analytical methods should be limited to quantitation of hydrocarbon ranges of interest; specific analytes of interest should be quantitated using the appropriate EPA "500" series drinking water methods.

# 4.0 CLEANUP STANDARDS

The Massachusetts Contingency Plan (MCP) provides three methods to assess risks and determine how clean is clean enough:

- ♦ Method 1 generic cleanup standards in soil and groundwater
- ♦ Method 2 site-specific modification of generic cleanup standards
- ♦ Method 3 completely site-specific risk assessment

The easiest approach is Method 1, in that cleanup standards have already been established by MADEP. In support of the VPH/EPH approach, 6 generic standards have been developed and promulgated for the aliphatic and aromatic fractions of interest. A conservative TPH standard has also been retained, to allow continued use of such methods. *Note that it is not necessary to meet a TPH cleanup standard (or Reportable Concentration) if all 3 EPH fractional standards are achieved [see 310 CMR 40.0973(7) and 40.0360(2)].* 

Because the Method 1 standards are generic, and were calculated assuming conservative site conditions, they can overestimate risk at some sites. In such cases, use of a Method 2 or 3 alternative approach may be advisable and cost effective. Guidance and recommendations in this regard are provided in Table 4-1.

For complete information and guidance on the use of the MCP risk assessment methods, consult the Massachusetts Contingency Plan at 310 CMR 40.0900, and MADEP's *Guidance for Disposal Site Risk Characterization in Support of the Massachusetts Contingency Plan*, available at <a href="http://www.state.ma.us/dep/ors/orspubs.htm">http://www.state.ma.us/dep/ors/orspubs.htm</a>.

Table 4-1: Choosing an MCP Risk Assessment/Cleanup Method

Method	Consider Using If	Significant Limitations
	• simple/small site	♦ cannot be (solely) used if sign. sediment contam
1	• contamination in soil and gw only	♦ cannot be (solely) used if sign. indoor air impacts
	• cleanup to Method 1 standards is feasible	[see 40.0942]
	• groundwater concentrations > GW-2 standards	♦ can't use if sign. sediment contamination
2	• groundwater concentrations > GW -3 standards	♦ can't use if sign. indoor air impacts
	◆ sites in GW-1 areas and C9-C10 or C11-C22 Aromatic fraction(s) in soil > Method 1 stds	[see 40.0942]
	• complex/large sites	♦ can't achieve permanent solution if: (1) more than
3	• sites with indoor air impacts	0.5 inches NAPL, or (2) above drinking water std in GW-1 area; or (3) soil conc above Upper Conc
	• sites with sediment contamination	Limits (UCLs) unless deeper than 15' or below
	• sites with soil/gw > Method 1 standards	engineered barrier; or (4) gw conc > UCL

# **4.1 Exposure Point Concentrations**

Regardless of the risk assessment method selected, it is necessary to calculate Exposure Point Concentrations in media and pathways of interest.

#### 4.1.1 Groundwater EPCs

In accordance with the provisions of 310 CMR 40.0924(2)(a)(1.), when using a Method 1 or 2 Risk Characterization approach, EACH well and/or groundwater monitoring point is a separate Exposure Point, and data from each well is considered a separate Exposure Point Concentration. Accordingly, the (temporal) average concentration of dissolved analytes in EACH monitoring well cannot exceed appropriate GW-1, GW-2, and/or GW-3 standards (i.e., spatial averaging of data among wells is not permitted). More flexibility is allowed in a Method 3 risk assessment, with the exception of GW-1 areas [40.0924(2)(b)(2.)].

Because groundwater is a dynamic medium, a single "snapshot in time" is generally not sufficient to characterize contaminant levels, and calculate Exposure Point Calculations. *Except for petroleum products with a low water soluble fraction, it is generally not possible to adequately characterize groundwater quality on the basis of a single round of sampling*. Seasonal and antecedent precipitation events can significantly influence groundwater quality in any given well on any given day. Over the course of a year, temporal fluctuations in the concentration of dissolved analytes in monitoring wells can be substantial; variation by factors of 2-3 are common at most sites, and factors of up to 5-10 are possible, especially for water table wells, and when monitoring low levels of analytes (i.e.,  $< 50 \,\mu g/L$ ).

The amount of spatial and temporal monitoring data needed to make reasonable and meaningful conclusions on groundwater quality is necessarily a site-specific decision, based upon (1) the type/water-solubility of the petroleum product(s) released, (2) the homogeneity of the formation, (3) the sensitivity of potential pollutant receptors, (4) the magnitude of contaminant concentrations (with respect to the standard(s) of interest), and (5) the degree of confidence and understanding of the Conceptual Site Model.

Table 4-2 provides the <u>minimum</u> recommended number of rounds of groundwater sampling at petroleum-contaminated sites where NAPL is not present. A <u>preferred</u> approach is to obtain at least 4 measurements over a 1-year period, coinciding with seasonal variations. In cases where less than 1 year of quarterly monitoring has been performed, it is necessary to consider and address expected variations in analyte concentrations over time (especially in cases where limited sample data is *just below* the applicable standard).

Table 4-2 Minimum Recommended Quarterly Rounds of Groundwater

Monitoring at Sites Where NAPL is Not Present

Location/GW Category	Gasoline/ JP-4	Diesel/#2-4 Fuel/Kerosene	Mineral/Lube/#6 Fuel Oil
< 800 feet from water supply	4+	3-4	2-3
GW-2	2-3	2	1
GW-3	1-2	1-2	1

It is important to stress that the recommendations provided above are for *quarterly* sampling efforts, with each quarter comprising a 3-month time period coinciding with spring, summer, fall, and/or winter conditions. Multiple sampling rounds in any given season, while providing potentially useful site data, cannot be considered equivalent to multiple samples over multiple seasonal conditions.

Beyond the general concerns and recommendations provided above for all sites, additional monitoring efforts are necessary at sites where groundwater remediation has been undertaken, to determine if contaminant "rebound" has occurred (i.e., a significant increase in dissolved groundwater contaminant concentrations that occurs as contaminants partition and diffuse from and near soil solids). In such cases, groundwater monitoring should be systematically conducted for at least 6 - 9 months after the termination of all remedial activities.

#### 4.1.2 Soil EPCs

A general discussion of issues and recommendations for the development and calculation of soil Exposure Point Concentrations (EPCs) is contained in *Guidance for Disposal Site Risk Characterization in Support of the Massachusetts Contingency Plan*. Of particular interest at petroleum-contaminated sites is the evaluation of subsurface soil contamination associated with releases from Underground Storage Tanks (USTs). In this regard, when obtaining soil samples at an UST grave for the purposes of determining an EPC, it is necessary to specifically investigate whether a "hot spot" exists within the groundwater table fluctuation zone (i.e., the "smear zone"). For gasoline and fresh diesel/fuel oil releases, this action may be easily accomplished by headspace analysis of samples from sidewall excavations using a PID meter. In cases where headspace concentrations within this smear zone are equal to or greater than 10 times other locations on the sidewall, soil samples from this zone should be discretely collected/composited (either as the sidewall sample or with other sidewall samples) for appropriate analyses.

#### 4.1.3 Indoor Air EPCs

Extensive guidance on this subject is provided in the *MADEP Indoor Air Sampling and Evaluation Guide*, available at <a href="http://www.state.ma.us/dep/ors/files/indair.pdf">http://www.state.ma.us/dep/ors/files/indair.pdf</a>. When evaluating indoor air impacts at disposal sites, however, it is important to understand and differentiate sampling and evaluation objectives and requirements.

Specifically, when the objective is to calculate indoor air EPCs for the purpose of conducting a quantitative risk assessment, temporal and/or spatial averaging of data may be appropriate. Conversely, when the objective is to determine whether a Critical Exposure Pathway (CEP) is present at a home or school, averaging of this nature is NOT appropriate; rather, data from "worse case" site conditions are of interest. Additional discussions in this regard are provided in Section 4.3.

### 4.2 Method 1 Cleanup Standards

Generic soil and groundwater cleanup standards have been developed by MADEP for the 3 hydrocarbon fractions detected using the VPH analytical procedure (i.e., C5-C8 Aliphatics, C9-C12 Aliphatics, and C9-C10 Aromatics) and the 3 hydrocarbon fractions detected using the EPH analytical procedure (i.e., C9-C18 Aliphatics, C19-C36 Aliphatics, and C11-C22 Aromatics). These standards are designed to be protective at most sites, and were developed using a series of conservative site scenarios to evaluate risks to human health, public welfare, and the environment via a number of exposure pathways and concerns, including direct contact, ingestion, leaching (soil), and volatilization (groundwater).

Method 1 cleanup standards have been developed for 3 categories of groundwater (see 310 CMR 40.0932):

- ♦ **GW-1 Standards** applicable in (GW -1) areas where groundwater is or may be used for drinking water purposes. The GW -1 standards are based upon ingestion/use of groundwater as a potable water supply.
- ♦ **GW-2 Standards** applicable in areas within 30 feet of an occupied structure if the depth to groundwater is less than 15 feet from the ground surface. GW-2 standards are based upon inhalation exposures that could occur to occupants of a building impacted by volatile compounds which partition from shallow groundwater.
- ♦ **GW-3 Standards** applicable at all sites. **GW** -3 standards consider impacts to aquatic receptors in surface water bodies that receive recharge from a contaminated groundwater plume.

Based upon the above, it can be seen that any given disposal site may fall in one, two, or all three categories. At sites where more than one category applies, groundwater contaminants must be at or below all applicable GW standards in all applicable categories in order to demonstrate a condition of "No Significant Risk" per Method 1.

Method 1 cleanup standards have also been developed for 3 categories of soil (see 310 CMR 40.0933):

- ♦ S-1 Standards applicable to soils that are accessible or potentially accessible, and where the frequency and/or intensity of exposure is high.
- ♦ **S-2 Standards** applicable to less accessible soils, with lower exposure potential.
- ♦ S-3 Standards applicable to isolated soils, and/or soils where the frequency and/or intensity of exposure is low.

Because all soil standards consider leaching impacts to underlying groundwater, and because there are 3 groundwater categories, there is a matrix of nine possible Method 1 soil standards for each contaminant (e.g., S-1/GW-1, S-1/GW-2, etc.). As with the GW standards, any given disposal site may fall in one or more of these nine soil standards. At sites where more than one category applies, soil contaminants must be at or below all applicable "S-x/GW-y" standards in all applicable categories in order to demonstrate a condition of "No Significant Risk" per Method 1.

In addition to the human health and environmental exposures described above, all Method 1 standards are bounded by certain *basement* and *ceiling* conditions established by MADEP. As a lower limit, no Method 1 standard is set below a background or analytical reporting limit, even if the risked-based concentration was less than this value. On the other extreme, no Method 1 standard is set above a series of "ceiling" concentrations established for classes of soil and groundwater contaminants. Ceiling levels were established to account for exposure pathways and factors that were not considered in developing these generic standards, including "public welfare" concerns related to odors. The ceiling level in groundwater is set at 50,000 μg/L; the ceiling levels in soil are 100, 500, 1000, 2500, and 5000 μg/g, depending upon the soil category (i.e., S-1, S-2, or S-3) and the vapor pressure and/or Odor Index of the compound or hydrocarbon range of interest. Additional information on ceiling levels and Method 1 standards are provided in the MADEP publication *Background Documentation for the Development of the MCP Numerical Standards*, April 1994, and as amended, which is available and may be downloaded from <a href="http://www.state.ma.us/dep/ors/orspubs.htm">http://www.state.ma.us/dep/ors/orspubs.htm</a>.

### 4.2.1 Using Method 1 VPH/EPH Fractional Standards

Using Method 1 to characterize a petroleum release is a two step process:

- Step 1 identify and evaluate individual Target Analytes of interest, to address specific hydrocarbon constituents of concern, including carcinogenic compounds; and
- Step 2 identify and evaluate aliphatic/aromatic fractions of interest, to address the rest of the hydrocarbon mixture.

Note: When using Method 1 fractional standards, it is necessary to have some actual (VPH/EPH) fractional range data. Although it is possible to make assumptions on the aliphatic/aromatic breakdown of TPH and GRO data, and demonstrate compliance with cleanup standards without any VPH/EPH data, such actions must be undertaken as part of a Method 3 Risk Characterization process. Alternatively, TPH data may continue to be compared directly to Method 1 TPH standards, at sites contaminated by heavier petroleum products.

### 4.2.2 Target Analytes

Target Analytes are those constituents of petroleum which have traditionally been used to characterize environmental pollution, and for which MADEP has specific Method 1 cleanup standards: benzene, toluene, ethylbenzene, xylenes, MtBE, lead, Ethylene Dibromide, and the 17 "priority pollutant" PAHs. *By definition, Target Analytes are not counted within the VPH and EPH Aliphatic and Aromatic hydrocarbon fractions.* 

It is not necessary to test all media and all petroleum releases for all Target Analytes; this decision is site-specific, based upon (1) the type (chemistry) of the petroleum product(s) released, (2) fate and transport considerations, and (3) the sensitivity of area receptors. Guidance and *Rules of Thumb* on the most commonly released petroleum products, based upon Total Organic Vapor (TOV) headspace screening and/or TPH data, are provided in Table 4-3.

**Table 4-3: Recommended Target Analyte List for Petroleum Products** 



Petroleum Product	Media	Headspace TOV	ТРН	Recommended Target Analytes
Gasoline	soil			benzene, toluene, ethylbenzene, xylenes (BTEX), naphthalene, and appropriate additives (e.g., MtBE, lead, and/or EDB).
	gw			benzene, toluene, ethylbenzene, xylenes (BTEX), naphthalene, and appropriate additives (e.g., MtBE, lead, and/or EDB).
	soil	≥100 ppmv		benzene, toluene, ethylbenzene, xylenes, naphthalene
#2 Fuel/Diesel			>500 µg/g	acenaphthene, naphthalene, 2-methylnaphthalene, phenanthrene
	gw			acenaphthene, naphthalene, 2-methylnaphthalene, phenanthrene; in GW-1, test also for BTEX, MtBE <sup>1</sup>
#3-#6 Fuel	soil	≥100 ppmv		benzene, toluene, ethylbenzene, xylenes, naphthalene
Jet Fuels				
Kerosene				17 priority pollutant PAHs, unless justification not to
Lube Oils	gw			If in GW-1 area, test for BTEX and 17 priority pollutant
Hydraulic Oils				PAHs
	soil	≥ 10 ppmv		BTEX/VOCs, PAHs, PCBs, heavy metals
Waste Oils				PAHs, PCBs, heavy metals
	gw			BTEX/VOCs, PAHs, PCBs, heavy metals

<sup>1</sup>While MtBE is not an additive in fuel oils, it may become present during the transport and distribution process due to mixing of residue product

### 4.2.2.1 Petroleum Product Additives

The topic of petroleum product additives warrants special consideration with respect to the selection of Target Analytes.

Since 1923, organic, inorganic, and/or organo-metallic compounds have been added to petroleum products to enhance performance characteristics or address operational or air pollution concerns. While additives of this nature have been numerous — and often proprietary — the list of common additives with significant environmental concerns is relatively small. Details in this regard are presented in Table 4-4.

**Table 4-4: Common Gasoline Additives (Massachusetts)** 

Additive	Purpose	Amount Added	Peak Years	Analytical Methods (soil/groundwater)	
alkyl leads (tetraethyl lead;	anti- knock/octane	1-2.5 grams/gal	1923-1981 (automotive gasoline)	Total Pb via ICP-AES (EPA 6010B) or AAS (EPA 7000); alkyl Pb by California LUFT/DHS or other proced.	
tetramethyl lead)	enhancer	2-4 grams/gal	1920s-present (aviation gasoline)		
Ethylene Dibromide (EDB)	"scavenger" in leaded gasoline	variable	1923-1981 (cont use in aviation gasoline	EPA Method 8260B or EPA Method 8021B	
MtBE	octane enhancer	1-8% by volume	1979-1991	MADEP VPH; EPA Method 8260B <sup>a</sup>	
	oxygenate	10-15 % by volume	1991-present	MADEP VPH; EPA Method 826OB <sup>a</sup>	

<sup>&</sup>lt;sup>a</sup> acidification of aqueous samples can lead to significant breakdown of MtBE

### 4.2.2.2 Petroleum Product Additives as Target Analytes

Rules of Thumb on the selection and analysis of specific petroleum product additives as Target Analytes are provided below:

- Given its history of use as an octane enhancer and oxygenate in New England, *MtBE* should always be considered a <u>soil</u> and <u>groundwater</u> Target Analyte of concern (all soil and groundwater categories) at disposal sites where a release of unleaded gasoline occurred or likely occurred after 1979.
- In addition to unleaded gasoline, *MtBE* should also be considered a groundwater Target Analyte of concern within the GW-1 areas of disposal sites where a release of #2 fuel/diesel oil occurred or likely occurred after 1979. Although not (purposely) added to these products, it is believed that trace levels of MtBE are introduced into stocks of #2 fuel/diesel oil during the storage and transportation process. Recent studies have identified the presence of low to moderate concentrations of MtBE within the groundwater at sites contaminated (solely) by a release of #2 fuel/diesel oil.



- Lead and Ethylene Dibromide should be considered groundwater Target Analytes of concern within
  the GW-1 areas of disposal sites where a release of gasoline occurred or likely occurred prior to 1988.
  In addition, Lead should be considered a soil Target Analyte of concern within the S1 areas of
  disposal sites where a release of leaded gasoline occurred or likely occurred prior to 1988. Because
  alkyl lead complexes are expected to break down into inorganic salts within a 15-year timeframe, use
  of a "total lead" methodology (e.g., AA/ICP) is generally appropriate and sufficient in such cases.
- Lead and Ethylene Dibromide should be considered soil and groundwater Target Analytes of concern (all soil/groundwater categories) at disposal sites where a release of leaded gasoline occurred or likely occurred after 1987. Due to their toxicities, it may be necessary to use analytical methods capable of detecting and quantitating the specific alkyl lead compounds of concern (e.g., tetraethyl lead). Although there are few published methods for alkyl lead analysis, one procedure is provided in the California LUFT Manual (http://www.swrcb.ca.gov/general/publications/docs/luft-manual-1989.pdf)

A summary of the above recommendations is provided in Table 4-5.

#### **4.2.2.3** Ethanol

Because of its persistence and mobility in the environment, which has lead to wide-scale groundwater contamination, the use of MtBE as a gasoline additive will likely be reduced or eliminated in the coming years. The most likely replacement for MtBE is ethanol, which is already a widely used oxygenate in

 Table 4-5: Recommended Target Analyte List for Petroleum Additives



Petroleum	Date of Release	Recommended	Soil Category			Groundwater Category		
Product Released at Site		Target Analyte(s)	S-1	S-2	S-3	GW-1	GW-2	GW-3
Unleaded Gasoline	≥1979	MtBE	✓	✓	✓	✓	✓	✓
#2 Fuel/Diesel Oil	≥1979	MtBE <sup>1</sup>				✓		
		Total Lead	✓			✓		
Leaded Gasoline	≤1987	EDB				✓		
		Lead/alkyl leads	✓	✓	✓	✓		✓
Leaded Gasoline	>1987	EDB	✓	✓	✓	✓	✓	✓

While MtBE is not an additive in fuel oils, it may become present during the transport and distribution process due to mixing of residue product

certain parts of the United States, and, in fact, has already been identified at some gasoline release sites in Massachusetts. To date, MADEP has not established a Method 1 standard for ethanol, though it is considered a "hazardous material" under the MCP (see 310 CMR 40.1600). Until such time as the use of ethanol becomes more widespread in Massachusetts, it is not necessary to routinely test for this additive at disposal sites, except as noted below:



- In cases where ethanol is *known* to have been present in gasoline released at a disposal site (e.g., based upon information provided by a service station owner), sampling and analysis for ethanol should be *considered*, based upon the nature of site conditions and sensitivity of surrounding receptors;
- In cases where a release of gasoline has contaminated a drinking water supply, and where ethanol is *known* or *suspected* to be present in the gasoline released at the site (e.g., lack of MtBE contamination), a sample of the drinking water should be analyzed for ethanol.

Note that while ethanol is believed to be less toxic than MtBE, and, unlike MtBE, readily biodegradable under both aerobic and anaerobic conditions, elevated concentrations in the environment may result in certain adverse impacts:

- ➤ Due to cosolvency effects, the presence of high concentrations of ethanol may lead to increased levels of gasoline constituents in groundwater, including the Target Analytes benzene, toluene, ethylbenzene, and xylenes (BTEX).
- ➤ Because of its highly biodegradable nature, ethanol exerts a high biochemical oxygen demand that can quickly deplete oxygen (and nutrient) levels in the area of contamination, which may lead to longer plumes of BTEX and other dissolved gasoline hydrocarbons. This phenomenon has implications to natural attenuation considerations, and bearing on the design of enhanced and engineered bioremediation systems at such sites.

### 4.2.2.4 Additional Petroleum Additives

In general, beyond the recommendations contained above, it is not necessary to routinely test for additional petroleum product additives at disposal sites. At disposal sites where releases of gasoline or diesel fuel have impacted drinking water supplies, however, samples of the impacted drinking water should be analyzed (a) by EPA Method 8260B for all method analytes and for Tentatively Identified Compounds (TICs), and (b) for the metals listed in Method EPA 6010B, excluding the common "background" elements calcium, iron, manganese, and sodium. Such an action is appropriate given (i) the wide variety of chemical additives in


petroleum products, (ii) the relative mobility of volatile organic compounds and certain metal salts and complexes, and (iii) the sensitivity of the exposure pathway.

### 4.2.3 Hydrocarbon Fractions of Interest

It is not necessary to test all media and all petroleum releases for all 6 VPH/EPH hydrocarbon fractions; this decision is also site-specific, based upon (1) the type (chemistry) of the petroleum product(s) released, (2) fate and transport considerations, and (3) the sensitivity of area receptors. Guidance and *Rules of Thumb* on ranges of interest, as determined by either the VPH or EPH test method, are provided in Table 4-6 for the most commonly released petroleum products.

When using a Method 1 approach, each VPH/EPH fraction is treated as if it were a single entity or unique chemical. The general rules that apply to Method 1 Risk Characterization, such as averaging data and hot spot determinations, also apply to these aliphatic and aromatic fractions.

Table 4-6: Hydrocarbon Fractions of Interest



For samples analyzed by both the VPH and EPH test procedure, there are two methodological issues that warrant discussion and clarification:

When a (split) sample is analyzed by both the VPH and EPH methods, it is not necessary to quantitate or address a (VPH) value for C9-C12 Aliphatic Hydrocarbons, as these hydrocarbons are included within the C9-C18 Aliphatic Hydrocarbon range detected by the EPH test method. Note that there may be cases where the C9-C12 Aliphatic concentration via the VPH test method exceeds the C9-C18 Aliphatic concentration quantitated by the EPH method – this dichotomy occurs because the VPH method tends to over-quantitate aliphatics in this range (because the FID is also quantitating aromatic compounds). In general, the EPH method should provide more accurate data for this range.

♦ In cases where Target Analytes are quantitated by both the VPH and EPH methods, naphthalene will be reported by both procedures. Because it is within the dividing region between purgeable and extractable organics, naphthalene is a problem analyte in both methods: it's the heaviest VPH compound, and difficult to purge, while at the same time being the lightest EPH compound, and therefore subject to volatilization losses during the EPH extraction process. *Accordingly, in such cases, the highest reported value should be used.* 

### 4.2.4 Limitations on the Use of Method 1 Cleanup Standards

Because of the generic assumptions used in the development of the Method 1 standards, they are not appropriate, and cannot be (solely) used at all sites. The most significant limitations in this regard for VPH/EPH standards are:

- there must be a Method 1 standard for all Contaminants of Concern (including any non-petroleum contaminants); and
- the contamination must be limited to just soil and groundwater, and cannot be present in sediments, air, or surface water.

### 4.2.4.1 Hydrocarbons

With respect to Contaminants of Concern, if only petroleum products are present at a site, there should be no limitations on the use of the Method 1 standards, as the collective VPH and EPH fractional ranges should address all detected constituents. Note that these collective range standards eliminate problems that arose in the past when laboratories using a GC/MS technique would report petroleum constituents, such as trimethylbenzenes, which did not have a Method 1 Standard - and which therefore called into question the applicability of Method 1. It also follows that this practice of identifying additional petroleum (non-target) analytes is no longer necessary, as long as the compound in question is a petroleum constituent that is collectively quantitated in a hydrocarbon range of interest (e.g., the trimethylbenzenes are picked up in the C9-C10 Aromatic Hydrocarbon range detected by the VPH test method).

#### 4.2.4.2 Additives

At present, Method 1 standards exist only for lead and MtBE. If other additives are identified at a disposal site, it will be necessary to evaluate risks using a Method 2 or Method 3 risk assessment process.

#### 4.2.4.3 Air-Phase Contamination

With respect to contamination present in a medium other than soil or groundwater, the most common and problematic limitation occurs when hydrocarbon contaminants are present in the ambient or indoor air at a site. Since this exposure was NOT considered in the development of the Method 1 cleanup standards, a Method 3 assessment must be conducted in such cases.

Volatile non-aqueous phase liquids (NAPL), including separate-phase gasoline, kerosene, jet fuels, and fresh diesel/#2 fuel oils, can result in the generation of significant concentrations of volatile petroleum hydrocarbon vapors in the vadose zone, which can potentially impact the indoor air of nearby structures. Purging a monitoring well containing such NAPL prior to obtaining a groundwater sample may underestimate risks of this nature, as the groundwater sample may contain relatively low concentrations of dissolved hydrocarbons. For this reason, soil gas investigations should be considered at any site at which volatile NAPL has been identified in monitoring wells or test pits, to characterize the risks posed to indoor air quality, and determine whether use of a Method 1 approach is appropriate.

### **4.2.5** *Odors*

Odors are an indication that hydrocarbon compounds are present in another medium (air) beyond soil or groundwater (although a lack of odors does not mean that hydrocarbon compounds are <u>not</u> present). Such odors could constitute a significant risk to human health, and/or a nuisance condition that may be considered a significant risk to public welfare.

For this reason, Method 1 cleanup standards should not be used at sites with the following odor conditions:

- persistent, long term (>3 months) odors in the ambient air at a disposal site; or
- \$\phi\$ persistent, long term (>3 months) odors in the indoor air of a building impacted by a disposal site.

Short term, ephemeral odors, and/or odors noted at depth during subsurface excavation or exploration, would not, by themselves, invalidate the use of a Method 1 approach.

A tabulation of Method 1 Cleanup Standards for the VPH/EPH hydrocarbon fractions, and TPH, is provided in Appendix 4. Note that these values are current as of the date of this publication, but are subject to change. For a current list of cleanup standards (and Reportable Concentrations), consult the most current version of the Massachusetts Contingency Plan.

### 4.3 Method 2 Risk Characterization

Using Method 2, site-specific fate and transport factors and considerations may be used to modify certain Method 1 standards. The Method 1 standards that are most likely to be exceeded at petroleum contaminated sites, and for which a Method 2 approach may be advisable, are listed in Table 4-7.

Table 4-7: Method 1 Standards Most Likely to be Exceeded

	Ground	dwater	Soil (standards based upon leaching)			
Contaminant	GW-2 (μg/L)	GW-3 (μg/L)	S-1/GW-1 (μg/g)	S-2/GW-1 (μg/g)	S-3/GW-1 (μg/g)	
C5-C8 Aliphatics (VPH)	✓	✓				
C9-C12 Aliphatics (VPH)	✓					
C9-C10 Aromatics (VPH)	✓	✓	✓	✓	✓	
C9-C18 Aliphatics (EPH)	✓					
C11-C22 Aromatics (EPH)		✓	✓	✓	<b>✓</b>	
benzene			✓	✓	✓	
2-Methylnaphthalene			<b>√</b>	<b>√</b>	<b>✓</b>	
naphthalene			<b>√</b>	✓	✓	

A summary of recommended Method 2 assessment approaches and limitations is provided in Table 4-8.

Table 4-8: Use of Method 2 at Petroleum-Contaminated Sites

<b>Site Condition</b>	Method 2 Assessment Actions	Limitations	
groundwater concentration > GW -2 Std	Evaluate potential for dissolved hydrocarbons in groundwater to impact indoor air of adjacent structures	Assessment limited to demonstration of "no impacts" to structure, based upon actual field data	
groundwater concentration > GW -3 Std	Evaluate potential for dissolved hydrocarbons in groundwater to impact receiving surface water body	Cannot modify to exceed an Upper Concentration Limit or have $\geq 0.5$ inches NAPL	
soil concentration > Soil Standard	Evaluate potential for hydrocarbons to leach from soil and impact underlying groundwater	Cannot modify to exceed an appropriate "direct contact" soil-exposure concentration [40.0985(6)]	

Two important limitations to a Method 2 approach at petroleum-contaminated sites warrant additional emphasis:

\* Method 2 may **NOT** be used to modify an applicable Method 1 GW-1 standard, including the VPH/EPH fractional standards; and

\* Fate and transport models may **NOT** be (solely) used to evaluate or "rule out" an impact to indoor air from dissolved concentrations of the VPH/EPH fractions in groundwater. This prohibition is due to the fact that the GW-2 standards for the VPH/EPH fractions were not directly calculated from a modeling exercise, because of a lack of relevant fate/transport and toxicological information. Thus, because there are no generic modeling assumptions for these fractions, there are no direct site-specific modeling modifications possible via a Method 2 approach.

### 4.3.1 Using a Method 2 Approach to Demonstrate "No Impact" to Indoor Air

At sites where a Method 1 GW -2 standard is exceeded for a VPH/EPH fraction and/or Target Analyte, a multi-level, progressively structured investigatory program is recommended, to obtain sufficient information and data to determine whether an impact to indoor air has occurred or is likely to occur. This same approach may be used to investigate concerns over the presence of contaminated soils in close proximity to a building. At some sites, conclusions in this regard are relatively clear; at others, a "tool-box" approach may be needed to establish lines of evidence to make such a determination. In most cases, an optimal and cost-effective tool-box approach is to proceed along a continuum of low-cost/conservative-efforts toward higher-cost/more-accurate-techniques, using the cumulative totality of information to rule out impacts as "unlikely", or, when such a decision cannot be supported, arrive at a conclusion that such impacts are in fact likely. This process is illustrated in Figure 4-1.

Contaminants > GW-2 standard, contaminated soils near building. and/or other evidence of potential indoor air impacts Optional pathway/secondary iterations Recommended first iteration Install soil gas Collect site-specific Sample indoor air via probes beneath TO-14 or APH method information on during "worst case" potentially impacted soil/building structure(s) seasonal conditions PID/FID conc of Indoor air levels < Conduct site-specific YES total organic vapors published background model of indoor air < action levels in concentrations in pathway (e.g., Johnson Table 4-11? and Ettinger) Table 4-9? YES No No Evaluate all lines of GC screening conc Evaluate evidence to decide if YES of soil-gas < action chemistry of indoor air impact is levels listed in indoor air data more likely than not No Table 4-10? Indoor air impacts confirmed, likely, or Indoor air impacts are not likely cannot be ruled out – proceed with (absent any other information or data to notification/IRA/risk assessment/CEP the contrary) mitigation as needed

Figure 4-1: Evaluating Indoor Air Pathway via Method 2

Initially, a relatively inexpensive soil gas screening effort is recommended, utilizing a series of conservative assumptions, in an attempt to rule out exposure/pathway concerns. Stes not screened out at this stage should consider increasingly more sophisticated and invasive actions, up to and including sampling and analysis of indoor air. Step-by-step recommendations are provided below. Additional guidance may be obtained from the MADEP Indoor Air Sampling and Evaluation Guide.

#### 4.3.1.1 Level 1 - Soil Gas Screening

a) Install at least one or two soil gas sampling probes beneath the structure of concern (e.g., through the concrete slab of a basement floor). For larger structures, additional probes may be needed. If probes cannot be installed within the footprint of the structure, install soil gas sampling probes along the perimeter of the building, as close as possible to the structure. Locations beneath pavement or other impervious surfaces are preferred to obtain representative conditions.

Soil gas probes located in unpaved areas and/or other areas where rain/snowmelt/surface water infiltration is occurring may not yield representative data. Data from such locations may be biased low, due to displacement and/or solubilization of soil gas vapors during an infiltrative event.

- b) Install and sample probes placed within the footprint of the structure in a manner that enables the collection of a soil gas sample from just beneath the lowest (floor/slab) elevation. Probes outside of the footprint of the building should be installed and sampled in a manner that enables the collection of a soil gas sample from a point just below the lowest (floor/slab) elevation.
- c) Withdraw a sample of soil gas from each probe, for analysis by a Photoionization Detector (PID) and/or Flame Ionization Detector (FID) meter. The PID should be calibrated to an isobutylene response, the FID to a methane response. Continuous, real-time measurements may be made, or a sample can be pumped to a Tedlar (or equivalent) bag for subsequent PID/FID analyses. Unless a demonstration is made that the sampling technique and equipment is capable of delivering a soil gas sample to the PID/FID meter at an adequate pressure and flow rate, use of the bag technique is recommended. Additional guidance is provided in MADEP's *Policy for the Investigation, Assessment, and Remediation of Petroleum Releases*, April, 1991 (DEP Publication #WSC-401-91), available at <a href="http://www.state.ma.us/dep/bwsc/finalpol.htm">http://www.state.ma.us/dep/bwsc/finalpol.htm</a>
- D) Compare the readings obtained on the PID and/or FID meters with the screening values in Table 4-9.

Table 4-9: Soil Gas PID/FID Screening Levels for Evaluating Indoor Air Impacts



Hydrocarbon Fraction(s) and Target Analytes which	Indoor air impacts unlikely if below listed value for <u>each</u> hydrocarbon fraction & Target Analyte of interest					
exceed applicable Method 1 GW-2 Standards and/or are	PID ppm	FID ppmV				
present in proximate soils	< 10.1 eV	10.1 – 11.4 eV	>11.4 eV	(methane response)		
C5-C8 Aliphatic Hydrocarbons	N/A	7	29	25		
C9-C12 Aliphatic Hydrocarbons	3	7	33	19		
C9-C10 Aromatic Hydrocarbons	28	29	37	21		
C9-C18 Aliphatic Hydrocarbons	3	7	33	19		
Toluene	11	12	12	10		
Ethylbenzene	4	4	4	3		
Total Xylenes	25	26	24	22		

- > On the left side of the table, identify EACH hydrocarbon fraction(s) and/or Target Analyte(s) which exceed an applicable GW-2 groundwater standard and/or are otherwise of concern.
- Fig. 1. If a Photoionization Detector (PID) unit was used to analyze the soil gas, identify the energy level of the (UV) lamp in electron-volts (eV). Identify the ppmV reading listed in the appropriate column, and compare this value to the site value for EACH hydrocarbon range and/or analyte of interest. If EACH site value is less than the listed value for the hydrocarbon range(s) and Target Analyte(s) of interest, impacts to indoor air are not likely.

  Example: BTEX and aliphatic/aromatic fractions present at site, but GW-2 standards exceeded for only Toluene and C9-C10 Aromatic Hydrocarbons. Soil gas below structure is found to have 25 ppmV (isobutylene calibration) total
- ➤ If a Flame Ionization Detector (FID) unit was used to sample the soil gas, compare the site value to the value listed in the table. If the site value is less than the listed value for each hydrocarbon range and/or Target Analyte of interest, impacts to indoor air are not likely.

Example: BTEX and aliphatic/aromatic fractions present at site, but GW-2 standards exceeded for only Toluene and C9-C10 Aromatic Hydrocarbons. Soil gas below structure is found to have 25 ppmV (isobutylene calibration) total VOCs via a 10.6 eV PID unit. While this PID reading indicates impacts from C9-C10 Aromatic Hydrocarbons are unlikely (since < 29 ppmV), this data cannot rule out impacts by Toluene (since 25 ppmV > 12 ppmV).

- > In situations where soil gas data are available from both a PID and FID, the FID data should be the basis of this evaluation.
- In situations where soil gas data are available from PID units with different lamp (eV) intensities, the data from the highest intensity lamp should be the basis of this evaluation.

The values provided in Table 49 are based upon conservative assumptions on (a) likely partitioning and dilution and attenuation factors for the identified hydrocarbon compounds and ranges, (b) response characteristics of commonly available PID and FID units; and (c) empirical observations, experience, and professional judgment. Because of its toxicity and low rate of anaerobic biodegradation, screening values have not been provided for benzene. This table should not be used to rule out impacts for non-listed contaminants, or to rule out impacts at structures with earthen floors, standing water, or open floor sumps.

#### 4.3.1.2 Level 2 - Soil Gas Analysis

If indoor air impacts cannot be ruled out by PID/FID screening, more sophisticated testing is recommended for a soil gas sample obtained in accordance with the recommendations provided in Section 4.3.1.1. Recommendations in this regard follow:

### GC SCREENING

Soil gas samples obtained in a bag, canister, or directly into a gas-tight syringe are analyzed using a GC equipped with a flame ionization detector (FID). In cases where only aromatic contaminants are of interest (i.e., G- $C_{10}$  Aromatic Hydrocarbons, toluene, ethylbenzene, and/or xylenes), a GC/PID may be used in lieu of a GC/FID. Even where only aliphatic hydrocarbons are of interest, the use of a PID in series with an FID will lead to more accurate and less conservative data.

A GC/FID sample chromatogram of a fresh gasoline sample is presented in Figure 4-2.

Under this approach, a series of assumptions are used to estimate the concentration of the hydrocarbon range(s) of interest; the more sophistication employed in this effort (i.e., use of GC/PID/FID), the less conservative the assumptions:

<u>C5-C8 Aliphatic Hydrocarbons</u>: On a GC/FID, quantitate all peak elutions between n-pentane and just before n-nonane using a response factor from one or several of the normal alkanes which elute in this range (e.g., n-heptane, n-octane).




Figure 4-2: GC/FID Soil Gas Chromatogram

Conservatively assume that this entire concentration value is C5-C8 Aliphatic Hydrocarbons (even though MtBE and some or all of the BTEX compounds also elute in this range). Compare this value (in  $\mu g/m^3$ ) with the value listed in Table 410. If less than the listed value, measurable indoor air impacts are not likely. If more than this value, consider use of a GC/PID to quantitate MtBE, benzene, toluene, ethylbenzene, xylenes (BTEX), and naphthalene, and "adjust" the C5-C8 Aliphatic Hydrocarbon value previously obtained by subtracting out the GC/PID  $\mu g/m^3$  concentrations of compounds eluting within this range. If this adjusted C5-C8 Aliphatic Hydrocarbon value is less than the value listed in Table 4-10, measurable indoor air impacts are not likely. If more than this value, a Level 3 evaluation may be necessary.



<u>C9-C12 Aliphatic Hydrocarbons</u>: On a GC/FID, quantitate all peak elutions between n-nonane and just before naphthalene using response factors from one or several of the normal alkanes which elute in this range (e.g., n-nonane, n-decane). Conservatively assume that this entire concentration value is C9-C12 Aliphatic Hydrocarbons (even though some aromatic compounds are also likely eluting in this range). Compare this value (in  $\mu g/m^3$ ) with the value listed in Table 410. If less than the listed value, measurable indoor air impacts are not likely. If more than this value, consider use of a GC/PID to quantitate BTEX, naphthalene, and C9-C10 Aromatic Hydrocarbon, and "adjust" the C9-C12 Aliphatic Hydrocarbon value previously obtained by appropriate subtraction from the Aliphatic range. If this adjusted C9-C12 Aliphatic Hydrocarbon value is less than the value listed in Table 4-10, measurable indoor air impacts are not likely. If more than this value, a Level 3 evaluation may be necessary.

<u>C9-C10 Aromatic Hydrocarbons</u>: On a GC/FID, quantitate all peak elutions just after the last xylene peak and just before naphthalene using the response factor for 1,2,4-Trimethylbenzene. Conservatively assume that this entire concentration value is C9-C10 Aromatic Hydrocarbons (even though some aliphatic compounds are also likely eluting in this range). Compare this value (in  $\mu$ g/m³) with the value listed in Table 4-10. If less than the listed value, measurable indoor air impacts are not likely. If more than this value, consider use of a GC/PID to quantitate this range in the same manner. If this GC/PID range concentration is less than the value listed in Table 4-10, measurable indoor air impacts are not likely. If more than this value, a Level 3 evaluation may be necessary.

<u>Toluene, Ethylbenzene, Total Xylenes</u>: On a GC/PID or GC/FID, identify and quantitate Target Analyte peak via retention times and response factors/curves established for each analyte. Compare these values ( $\mu g/m^3$ ) with the values listed in Table 4-10. If all data are less than the listed values, measurable indoor air impacts are not likely. If one or more of the analytes are above their respective values, a Level 3 evaluation may be necessary.

NOTE: When using a "field" GC screening technique, all appropriate and necessary quality assurance/quality control procedures must be employed. At a minimum, the following steps would generally be expected:


- ➤ Calibration of the GC system at a minimum of 3 concentration levels, using gaseous-phase calibration standards; and
- ➤ Daily analysis of a blank sample and mid-range calibration or QC check standard, to ensure and document system performance.

#### LABORATORY PROCEDURES

Soil gas samples obtained in a bag, canister, or directly into a gas-tight syringe are analyzed using a VPH procedure (modified by changing sample introduction from purge and trap to direct injection/desorption) or by the APH methodology.

Using either the "screening" or laboratory procedure, the concentration of each fraction (in  $\mu g/m^3$ ) should be compared to the soil gas action level indicated in Table 4-10. NOTE: THESE VALUES MAY NOT BE PROTECTIVE AT BUILDINGS WITH EARTHEN FLOORS OR STANDING GROUNDWATER WITHIN A BASEMENT OR CRAWL SPACE AREA.

Table 4-10: Soil Gas GC Screening Levels for Evaluating Indoor Air Impacts





As an alternative to the active soil-gas sampling procedures detailed above, the use of passive/diffusion samplers may also be an appropriate technique to characterize and quantitate hydrocarbon vapors beneath and proximate to structures of concern.


#### 4.3.1.3 Level 3 - Indoor Air Analysis

If soil gas analysis cannot rule out an indoor air impact, direct measurement of indoor air is usually necessary. At least one (2-4 hour) time-weighted sample should be obtained from the lowest occupied level of the structure and analyzed using EPA Method TO-14A/15 or the MADEP Air-Phase Petroleum Hydrocarbon (APH) methodology. (While TO-14A/15 may be used to determine if a pathway is present, the APH method is recommended to evaluate risks from such a pathway). Additional (2-4 hour) time-weighted samples on other levels of the structure could be helpful in evaluating the lkelihood of a subsurface vapor infiltration pathway in the event that elevated concentrations of contaminants are identified in the lowest level (e.g., higher concentrations in upper levels could be a potential line of evidence contrary to a subsurface infiltration pathway).

Sampling during Winter or early Spring is usually considered a "worst case" evaluation, due to (a) depressurization of the structure that occurs due to the operation of combustion furnaces and chimney stack effects, (b) lack of building ventilation, (c) presence of frost layer impeding diffusion to the atmosphere, and/or (d) presence of a high groundwater table (Spring). At structures with a central air-conditioning system that obtains make-up air from a basement, worst-case conditions may be during summer months. Sampling during times of the year that are not considered worst case may not conclusively rule out indoor air impacts.

Concentrations of hydrocarbon fractions and Target Analytes obtained by this analysis should be evaluated to determine if they are in excess of a "background" condition for that structure. In lieu of determining a site-specific background concentration, the generic values presented in Table 4-11 may be used.

**Table 4-11: Estimated Background Indoor Air Concentrations** 





#### 4.3.1.4 Use of Vapor Transport Models

On occasion, it may be necessary or desirable to use predictive/computer models to help evaluate vapor transport issues at disposal sites. This option is most necessary when it is not possible or feasible to obtain soil gas and/or indoor air measurements, or when such data are ambiguous. While use of these techniques can aid in the understanding of the Conceptual Site Model, and facilitate characterization of current and future exposure pathways, it is MADEP's longstanding position that current exposure pathways should be evaluated/validated with actual site data, to the extent feasible.

Accordingly, unless precluded by unavoidable logistical constraints and/or "background" interference (e.g., toluene migration into a commercial/industrial site where toluene is used as a raw product), there is an expectation that (some) actual soil gas and/or indoor air data will be generated during the evaluation of sites with an exceedance of GW-2 standards. Sufficient explanation and justification must be provided in the appropriate report submittals for sites where such data are not obtained.

Most mathematical evaluations of this vapor transport pathway involve use of the Johnson & Ettinger model. Spreadsheet applications of the model are available for downloading free of charge from MADEP at <a href="http://www.state.ma.us/dep/bwsc/files/standard/GW2/GW2.htm">http://www.state.ma.us/dep/bwsc/files/standard/GW2/GW2.htm</a> and from the US Environmental Protection Agency at <a href="http://www.epa.gov/superfund/programs/risk/airmodel/johnson">http://www.epa.gov/superfund/programs/risk/airmodel/johnson</a> ettinger.htm.

<sup>\*</sup> concentration of MtBE in ambient air; may be higher in immediate vicinity of gasoline filling stations or if gasoline storage in building (e.g., lawnmower)

When using models of this nature, <u>all</u> input parameters and values have to be individually justified as appropriate and/or conservative for the specific site in question; it is not permissible to "pick and chose" generic modeling default values absent such justification. A particularly sensitive modeling parameter in this regard is the vadose zone moisture content **below the structure of concern**, which should be empirically determined on a site-specific basis.

#### 4.3.1.5 Vertical Profiling of Groundwater Contaminants to Evaluate Vapor Transport

In cases where soil gas and/or indoor air data are ambiguous, vertical profiling of groundwater contaminants may provide useful lines of evidence in the evaluation of vapor transport pathways.

Typically, groundwater plumes "dip" as they flow from a source area, due to the infiltration of rainfall and snowmelt. This recharge can result in the formation of a "fresh water lens" above a plume of dissolved contaminants. In such situations, contaminants must diffuse through the (uncontaminated) lens in order to reach the groundwater table/capillary fringe, and partition from the aqueous phase into the gaseous phase. Because of the slow rate of liquid-phase diffusion, the formation of such a fresh water lens can effectively eliminate the vapor transport pathway, by preventing dissolved contaminants from partitioning into the overlying vadose zone.

Predicting the exact point in the path of a plume where vapor generation is "cut off" in this manner is difficult, if not impossible, due to the transient and dynamic nature of the governing parameters. Moreover, plumes that dip will eventually reverse direction and rise toward a groundwater discharge point, where contaminants may again be flowing in close proximity to the groundwater table and aqueous/vapor interface.

Despite these difficulties and unknowns, it may be useful at some sites to profile groundwater contaminant concentrations in the first 5-10 foot interval of the saturated zone, to determine whether a freshwater lens is present at the site in question. Typically, this action is accomplished by advancement of small diameter driven well points, obtaining groundwater samples at 1 to 2 foot depth intervals, for analysis by GC screening or laboratory techniques. Such data, in conjunction with soil gas data and/or other site factors, may provide the necessary weight of evidence to adequately evaluate and/or eliminate this pathway.

#### **4.3.1.6** Response Actions at Sites with Indoor Air Impacts

Evidence of the migration of petroleum vapors from the subsurface into a school building or occupied residential dwelling (above a background condition) represents a Critical Exposure Pathway and Condition of Substantial Release Migration under the Massachusetts Contingency Plan. In such cases, pursuant to the provisions of 310 CMR 40.0414, an Immediate Response Action must be undertaken to evaluate the risks associated with this infiltration, and determine if there is a feasible remedial measure to prevent or mitigate this continued infiltration. *If feasible mitigative options exist, remedial actions must be taken*.

When considering and implementing mitigative options, a hierarchy of remedial efforts is recommended, from least-invasive/least-costly to most-invasive/most-costly. Details are provided in Figure 4.3.

#### 4.3.2 Using a Method 2 Approach to Evaluate Exceedances of Method 1 GW-3 Standards

The Method 1 GW -3 standard most likely to be exceeded at a petroleum-contaminated site is for C9-C10 Aromatic Hydrocarbons. This standard and all Method 1 GW -3 standards were derived based upon an assumption that (a) impacts may occur to ecological receptors in a surface water body at concentrations equal to or greater than the ambient water quality guideline, (b) groundwater from the site is discharging to such a surface water body, and (c) dilution between the groundwater and surface water body is minimal. A summary and description of currently recommended fractional ambient water quality guidelines is provided in Table 4-12.

Using a Method 2 approach, site-specific data, fate and transport factors, and/or predictive models may be used to modify Method 1 GW-3 standards. Recommended fractional fate and transport parameters are provided in Section 4.6. Note that per 310 CMR 40.0982(4), a Method 1 GW-3 standard cannot be modified to a concentration in excess of the Upper Concentration Limit for the fraction of interest.

**Evidence of Vapor Intrusion** Screen utility annulus spaces, floor/wall interfaces, cracks in basement floor/walls with PID or FID meter to identify specific vapor entry points. Take all necessary efforts to seal discrete vapor entry points. Consider sealing other cracks with grout Do not use sealants formulated and/or latex caulking. If soil floor, consider with significant concentrations of installation of polyethylene/concrete barrier Volatile Organic Compounds and/or other toxic materials (e.g., many specialty concrete epoxies). Cover, seal and (externally) vent drainage sumps, if present. (Homeowner) access hatch must be provided for sump pumps. Eliminate basement air intake vents in HVAC Consult with local code inspectors systems. Consider ducting in outside air for for assistance/approvals combustion/drafting/fresh air intake, to minimize negative pressure in basement. See Guidelines for the Design, Install sub-slab depressurization system, if less Construction, and Operation of invasive measures are not sufficiently effective or if Sub-Slab Depressurization Systems imminent hazard conditions are present. http://www.state.ma.us/dep/nero/bw sc/files/ssd1e.pdf

Figure 4-3: Recommended Hierarchy of Vapor Mitigation Efforts

**Table 4-12: Recommended Surface Water Quality Guidelines** 

Install air/air heat exchanger to over-pressurize basement, when less invasive measures are not sufficiently effective, and sub-slab depressurization is

not feasible (e.g., high groundwater; fieldstone

foundation).

Fraction	Surface Water Guideline (ng/L)	Basis of Guideline
C5-C8 Aliphatics	250 <sup>a</sup>	Acute LC50/10 for Hexane (as surrogate for this range)
C9-C12 Aliphatics	1800	Acute LC50/10 for Decane (as surrogate for this range)
C9-C10 Aromatics	540 <sup>a</sup>	Acute LC50/10 for Trimethyllbenzene (as surrogate for this range)
C9-C18 Aliphatics	1800	Acute LC50/10 for Decane (as surrogate for this range)
C19-C36 Aliphatics	2100	Acute EC50/10 for Cyclododecane (as surrogate for this range)
C11-C22 Aromatics	N.A.ª	Effects may be seen at less than the EPH Reporting Limit; other testing methods (e.g., GC/MS) may be needed on site-specific basis

<sup>a</sup>updated value (2002)

Consult with local code inspectors

for assistance/approvals

In lieu of site-specific modeling, the conservative dilution factors graphically illustrated in Figure 44 may be used as part of a Method 2 evaluation of groundwater-to-surface-water impacts dissolved hydrocarbon contaminants.




Figure 4-4: Groundwater Dilution Factors for Dissolved Hydrocarbons

```
Equations: 

10ft x 10ft source area, DF = 177 (distance in feet)^{-1.455}, r^2 = 0.99

30ft x 30ft source area, DF = 303 (distance in feet)^{-1.365}, r^2 = 0.99

60ft x 60ft source area: DF = 237 (distance in feet)^{-1.214}, r^2 = 0.99
```

The graphs presented in Figure 44 are generalized, source-area dependent conservative dilution and dispersion curves for any dissolved groundwater contaminant, including hydrocarbon range fractions and Target Analytes. They were developed using the Domenico and Robbins analytical transport model (1985) assuming an infinite source condition. The only attenuation mechanism considered is hydrodynamic dispersion, and as such may be used for any dissolved organic compound.

The use of these graphs, however, is limited to sites where **ALL** of the following conditions are met:

- ♦ groundwater/contaminant flow is occurring only in an overburden aquifer;
- ♦ there is no "short circuiting" of groundwater/contaminants along preferred flow paths;
- δ no fractional range is present at a concentration greater than 100,000 μg/L (i.e., exceeding UCLs); and
- \$\delta\$ the nearest downgradient surface water body is at least 100 feet from the impacted well/groundwater area on the site.

Because of modeling uncertainties, and limitations that typically exist on the availability of temporal and spatial groundwater monitoring data, the graphs and equations contained in Figure 4-4 may not be used at sites where the distance to surface water is less than 100 feet.

Using Figure 44, it is possible to conservatively calculate the concentration of a hydrocarbon range or Target Analyte of interest at some distance from a site (typically, a monitoring well located at a site). For example, at a site in which the source area of contamination is approximately 30ft x 30ft, if the concentration of  $C_9$ - $C_{10}$  Aromatic Hydrocarbons in a well located 400 feet from a receiving water is 600  $\mu$ g/L, a (dimensionless) Dilution Factor of 0.09 is obtained from Figure 44. Multiplying this Dilution Factor by 600  $\mu$ g/L yields 54  $\mu$ g/L, which would be a conservative estimate of the maximum concentration of  $C_9$ - $C_{10}$  Aromatic Hydrocarbons in groundwater that would migrate to this point. An additional dilution factor may then be applied to account for the mixing of groundwater with the surface water, based upon site-specific information and data.

Parties wishing to provide alternative ambient water quality guidelines for the VPH/EPH fractions, and/or provide a site-specific evaluation of environmental impacts, must do so via a MCP Method 3 approach.

#### 4.3.3 Using a Method 2 Approach to Evaluate Leaching

All Method 1 soil standards consider leaching impacts to underlying groundwater. The leaching-based component of the Method 1 standards were derived using the SESOIL and AT123D computer models to evaluate unsaturated and saturated zone transport, as depicted in Figure 4-5.

Figure 4-5: Leaching Scenario Used to Develop Leaching-Based Method 1 Soil Standards

The standards developed by MADEP in 1993 were based upon a deterministic modeling effort, using "point" value input parameters (i.e., in Figure 45 a, b, and c = 1 meter, x and y = 10 meters). More recent efforts by MADEP have involved use of a probabilistic modeling approach, using ranges or distributions for input parameters. In all cases, "Dilution and Attenuation Factors" were developed to relate concentrations of soil contaminants in the source area to concentrations of those contaminants in a hypothetical "point of compliance" downgradient monitoring well.

Based upon the assumptions and models used by MADEP, the only VPH/EPH Method 1 soil standard controlled by leaching concerns is C11-C22 Aromatics in GW-1 (drinking water) areas. However, the Method 1 soil cleanup standards for two important Target Analytes - naphthalene and 2methylnaphthalene - are also controlled by leaching considerations.

Using a Method 2 approach, site-specific data, fate and transport factors, and/or predictive models may be used to modify a Method 1 soil standard that is based upon leaching concerns. In such an exercise, the site-specific soil concentration(s) of a hydrocarbon fraction or Target Analyte of interest is used to predict maximum groundwater concentrations that may be expected in areas beneath and downgradient of the contaminated soil. These

groundwater concentrations are then compared to the appropriate Method 1 or 2 groundwater standards. A modified soil standard derived in this manner is acceptable if:

- the maximum predicted groundwater concentration of the contaminant of interest downgradient of the zone of soil contamination is at or below the appropriate Method 1 or 2 GW standard; and
- the modified soil standard does not exceed the appropriate S-1, S-2, or S-3 levels which are protective of direct-contact exposure concerns [as listed at 310 CMR 40.0985(6)].


Example: under a Method 2 approach, the S 1/GW-1 Method 1 standard for C11-C22 Aromatic Hydrocarbons can be modified, based upon site-specific leaching considerations, to a maximum concentration of  $800~\mu g/g$ , which is the level at which the human health risks associated with direct contact controls the setting of this standard.

Note that while the generic Method 1 standards were predicated on a specified or probabilistic downgradient receptor of concern, (e.g., 10 meters downgradient of the source area), actual site-specific conditions and receptors should be used when undertaking a Method 2 evaluation effort (e.g., buildings, surface water bodies, GW-1 areas).

Recommended fractional fate and transport parameters are provided in Section 4.6. For additional information on the calculation of leaching-based Method 1 soil standards, consult *Background Documentation for the Development of the MCP Numerical Standards* (MADEP, 1994 and as amended).

In lieu of or in conjunction with predictive models, the use of groundwater monitoring data is often an acceptable and cost-effective means to evaluate site-specific leaching concerns. In order to have sufficient confidence in such an approach, however, the following site conditions are desirable:

- the release occurred at least 24 months ago;
- \$\displaystyle \text{ the depth between the zone of soil contamination and groundwater table is less than 6 feet;}
- ♦ the surface(s) overlying the contaminated soil is pervious (i.e., no pavement or buildings);



♦ sufficient temporal monitoring data exist to evaluate seasonal trends.

#### 4.4 Method 3 Risk Characterization

Under Method 3, a completely site-specific evaluation is conducted to determine risks to human health, safety, public welfare, and the environment. Recommended toxicological and fate and transport values for the VPH/EPH fractions in this regard are provided in Tables 4-13 and 4-14, respectively. Although it is not necessary to use any of these values in a Method 3 risk characterization effort, the burden is on the party conducting the assessment to document and defend the selection of alternative assumptions, parameters, and values. Complete details on the Method 3 risk assessment process are provided in *Guidance for Disposal Site Risk Characterization* (MADEP, 1995 and as amended).

#### 4.4.1 Requirements and Limitations of a Method 3 Characterization

While a Method 3 characterization allows a significant degree of flexibility, there are important obligations and limitations:

- Site-specific risks to public welfare must be evaluated. Under the Massachusetts "superfund" legislation (MGL c. 21E), risks to public welfare are given the same weight as risks to human health, safety, and the environment. In deriving the Method 1 standards, MADEP imposed ceiling levels on acceptable concentrations of contaminants, in an attempt to ensure that each standard would be set at a low enough level to rule out significant impacts to public welfare. "Public welfare" is a difficult standard to articulate, and it is much easier to define a de minimis condition, than to define a precise point where a risk to public welfare becomes significant. Nevertheless, parties conducting a Method 3 assessment must make an independent evaluation of all relevant public welfare concerns, and conclude that all such concerns are below a level of No Significant Risk.
- Site-specific risks to ecological receptors must be evaluated. Under the MCP, environmental risk assessment is done via a two-stage process. Stage I is a screening process used to (1) eliminate from further consideration those sites where exposures are clearly unlikely to result in environmental harm, or, on the other extreme, (2)

eliminate from further consideration those sites where harm is readily apparent (i.e., it is clear that remediation is needed, and additional study is not necessary). Those sites that are not eliminated must proceed to a Stage II evaluation, which involves a quantitative, site-specific characterization of the risk to ecological receptors.

- A Method 3 approach cannot be used to modify or eliminate Upper Concentration Limits. Upper Concentration Limits (UCLs) are "gross" levels of contamination in soil and groundwater that, by their very presence in the environment, constitute a significant risk to public welfare and the environment. Under the provisions of 40.0996(2), the UCL standards are to be applied to the arithmetic average of the concentration of oil or hazardous materials at a site or within a "hot spot". If the average concentrations of site contaminants exceed an applicable UCL value, remediation must be undertaken to treat or encapsulate areas of concern, if feasible. In cases were it is not feasible to remediate such conditions, it may be still possible to obtain an interim site closure by filing a Class C Response Action Outcome, representing a Temporary Solution.
- A Permanent Solution cannot be achieved if drinking water standards are exceeded in a GW-1 area. In conducting a Method 3 assessment, all applicable or suitably analogous health standards must be identified and achieved. Under the provisions of 310 CMR 40.0993(3)(a), the Massachusetts Drinking Water Quality Standards promulgated in 310 CMR 22.00 are considered applicable in all GW-1 areas. While drinking water standards have been promulgated for a number of Target Analytes (e.g., benzene at 5 μg/L), at the present time, the VPH/EPH fractional ranges are not included on this list. While it is necessary to characterize the risk these factional ranges pose to the water supply of concern, it is not necessary to consider these values "analogous health standards".

#### 4.4.2 Impacts to Indoor Air

Relevant guidance contained in Section 4.3.1 should be considered by parties undertaking an evaluation of impacts to indoor air as part of a Method 3 risk assessment process. The use of the inhalation RfC values provided in Table 4-13 would be a conservative means to quantitate risks via the inhalation pathway, and use of the estimated background concentration values listed in this table would be a conservative means to evaluate Critical Exposure Pathways.

#### 4.4.3 Odors as a Significant Risk to Public Welfare

Under the provisions of 310 CMR 40.0994, the existence of a nuisance condition shall be considered in a characterization of risks to public welfare. Given the low odor recognition thresholds of many petroleum constituents (and breakdown products), the presence of odors at petroleum-contaminated sites can constitute a nuisance condition, and preclude achievement of a condition of No Significant Risk to Public Welfare, even if a condition of No Significant Risk to Human Health has been achieved.

Definitive and quantitative guidelines and standards on when a petroleum odor constitutes a nuisance condition and significant risk to public welfare are difficult to articulate. In the context of petroleum-contaminated sites, however, the following *Rules of Thumb* are suggested for when an odor condition would generally NOT be considered a nuisance condition:

Odors observed in the subsurface during excavation or boring advancement would generally not be considered a nuisance condition, as long as such odors are not detectable in ambient or indoor air, and as long as there are no plans to excavate or disturb such areas.



- Odors observed in the breathing zone of the ambient air, or indoor air of an impacted structure, would generally not be considered a nuisance condition, if such odors do not persist for more than 3 months.
- Odors observed in the breathing zone of the ambient air would generally not be considered a nuisance condition if they are discernable less than 10 days a year.
- Odors observed in the ambient air or indoor air of an impacted structure would generally not be considered a nuisance condition if the occupants of such a structure do not believe such odors significantly affect or degrade their quality of life.

#### 4.4.4 MADEP Petroleum-Contaminated Site Risk Assessment Short Forms

To streamline the Method 3 risk assessment process, MADEP has developed a series of Risk Assessment "Short Forms" which incorporate the aliphatic and aromatic fractional ranges, for optional use at sites contaminated by various petroleum products. Like other MADEP Short Forms, these spreadsheet-based tools incorporate standardized exposure assumptions and toxicological profiles, and allow the user to input site-specific concentration data. The output is a series of summary tables that describe chemical-specific, medium-specific, and cumulative (total site) risks, which may be used and/or applied as part of a Method 3 risk assessment at petroleum-contaminated sites.

The Short Forms, and supporting documentation, are available for downloading from the MADEP Web site, at <a href="http://www.state.ma.us/dep/ors/orspubs.htm">http://www.state.ma.us/dep/ors/orspubs.htm</a>

#### **4.5** Recommended Toxicological Parameters

The currently recommended toxicological values for assessing risks associated with the VPH/EPH aliphatic and aromatic hydrocarbon fractions are listed in Table 4-13. Note that these values are subject to change as additional information and data become available to MADEP.

Table 4-13: Recommended VPH/EPH Toxicological & Risk Assessment Parameters

	C5-C8 Aliphatics	C9-C12 Aliphatics	C9-C10 Aromatics	C9-C18 Aliphatics	C19-C36 Aliphatics	C11-C22 Aromatics
Chronic Oral RfD (mg/kg/day)	0.04 <sup>a</sup>	0.1 <sup>a</sup>	0.03	0.1 <sup>a</sup>	2.0 <sup>a</sup>	0.03
Subchronic Oral RfD (mg/kg/day)	0.4 <sup>a</sup>	1.0 <sup>a</sup>	0.3	1.0 <sup>a</sup>	6 <sup>a</sup>	0.3
Chronic Inhalation RfC (mg/m3)	200	200	50 <sup>a</sup>	200	N/A	50 <sup>a</sup>
Est. Background Indoor Air (mg/m3)	<u>&lt;</u> 85	<u>&lt;</u> 90	<u>&lt;</u> 80	<u>≤</u> 100	N/A	<u>&lt;</u> 50
Chronic RAF - Soil Ingestion	1 <sup>a</sup>	1 <sup>a</sup>	1 <sup>a</sup>	1 <sup>a</sup>	1 <sup>a</sup>	0.36 <sup>a</sup>
Chronic RAF - Soil Dermal	1 <sup>a</sup>	0.5 <sup>a</sup>	0.5 <sup>a</sup>	0.5 <sup>a</sup>	0.1	0.1 <sup>a</sup>
Chronic RAF – Water Ingestion	1	1	0.91	1	1	0.91
Subchronic RAF - Soil Ingestion	1 <sup>a</sup>	1 <sup>a</sup>	1 <sup>a</sup>	1 <sup>a</sup>	1 <sup>a</sup>	$0.36^{a}$
Subchronic RAF - Soil Dermal	1 <sup>a</sup>	0.5 <sup>a</sup>	0.5 <sup>a</sup>	0.5 <sup>a</sup>	0.1	0.18
Subchronic RAF - Water Ingestion	1	1	0.91	1	1	0.91
Ambient Water Quality Guide (ng/L)	250 <sup>a</sup>	1800	540 <sup>a</sup>	1800	2100	N.A <sup>a,b</sup>

<sup>&</sup>lt;sup>a</sup> updated value (2002)

#### 4.6 Recommended Fate and Transport Parameters

For recommended approaches, procedures, and values to conduct fate and transport evaluation/modeling of Target Analytes and hydrocarbon ranges, consult *Volume 3: Selection of Representative TPH Fractions Based on Fate and Transport Considerations*, a (1997) publication prepared by the Total Petroleum Hydrocarbon Criteria Working Group (TPHCWG), available at <a href="http://www.aehs.com/whatsnew.htm">http://www.aehs.com/whatsnew.htm</a>.

Relative to the VPH and EPH hydrocarbon ranges – FOR MODELING PURPOSES ONLY - recommended fractional properties are provided in Table 4-14.

<sup>&</sup>lt;sup>b</sup>see table 4-12

Table 4-14: Recommended VPH/EPH Fractional Properties for Modeling Purposes

	Equivalent Carbon Number	Molecular Weight	Weight Pressure in Water Constant, H Ko					ion Coeff m <sup>2</sup> /s)			
	(EC)	C	(atms)	( <b>ng</b> /L)	(dimensionless)	(mL/g)	air	water			
C5-C8 Aliphatics	6.5	93	0.10	11,000	54	2265	0.08	1 x 10 <sup>-5</sup>			
C9-C12 Aliphatics	10.5	149	8.7 x 10 <sup>-4</sup>	70	65	1.5 x 10 <sup>5</sup>	0.07	1 x 10 <sup>-5</sup>			
C9-C10 Aromatics	9.5	120	2.9 x 10 <sup>-3</sup>	51,000	0.33	1778	0.07	1 x 10 <sup>-5</sup>			
C9-C18 Aliphatics	12	170	1.4 x 10 <sup>-4</sup>	10	69	6.8 x 10 <sup>5</sup>	0.07	5 x 10 <sup>-6</sup>			
C19-C36 Aliphatics	considered immobile										
C11-C22 Aromatics	14	150	3.2 x 10- <sup>5</sup>	5800	0.03	5000	0.06	1 x 10 <sup>-5</sup>			

#### 4.7 Non-Aqueous Phase Liquids (NAPL)

The presence of non-aqueous phase liquids (NAPL) adds significant complexity to the assessment and remediation of petroleum-contaminated sites. Of primary concern are (1) the bulk fluid migration of petroleum NAPL, and potential discharge into underground structures, utilities, and/or surface water bodies, and (2) NAPL acting as a continuing source of soil, groundwater, and/or soil gas contamination. Due to these concerns, under the provisions of 310 CMR 40.0996(4), the presence of a non-aqueous phase liquid having a thickness equal to or greater than 0.5 inches in *any environmental medium* is considered an exceedence of an Upper Concentration Limit (UCL).

#### 4.7.1 Upper Concentration Limits

A *single* measurement of  $\geq 0.5$  inches NAPL in a *single* groundwater monitoring well does not necessarily constitute exceedence of a UCL standard:

The standard applies to the formation, not a groundwater monitoring well. Typically, the thickness of NAPL measured in a monitoring well does not correspond to the thickness of NAPL in the surrounding formation. Moreover, seasonal and short-term water table fluctuations and tidal influences will affect apparent levels of petroleum product thickness in monitoring wells, with thickness levels often increasing with a declining water table, and decreasing or "disappearing" with a rising water table. Although the relationship between the thickness of NAPL in a monitoring well and the surrounding formation is not easily established, there may be methods and sites for which reasonable assumptions and conclusions can be reached, based upon:



- \* an evaluation of formation properties, especially the thickness of the capillary fringe;
- \* an evaluation of test pit, split-spoon, and/or analytical screening observations within the presumed NAPL "smear zone"; and
- \* an evaluation of sufficient spatial and temporal monitoring well data, relative to the observed thickness of the NAPL and the elevation of the potentiometric surface.
- As with all UCL standards, averaging of data is permissible. In the case of NAPL, however, temporal averaging of data from monitoring wells is generally not appropriate, due to distortions introduced by a falling and rising water table.
- ♦ It is permissible to spatially average wells within the contiguous area of the NAPL plume, excluding "hot spots", which are defined by the MCP to be discrete areas where the thickness of NAPL is more than 10 times the thickness of surrounding areas.

#### 4.7.2 Apparent NAPL Thickness vs. Actual NAPL Thickness

The occurrence, detection and migration of non-aqueous phase liquids in the subsurface are a complex phenomenon. Many investigators have attempted to develop theoretical and/or empirical methods to correlate the apparent

thickness of NAPL, as measured in a monitoring well, to the actual thickness of that NAPL in the surrounding formation. Most of these methods involve relationships based upon the density of the liquid hydrocarbon (de Pastrovich *et al.*, 1979), properties of the geologic medium (Hall *et al.*, 1984), height of the capillary fringe (Blake and Hall, 1984; Ballestero *et al.*, 1994; and Schiegg, 1985), and/or idealized capillary pressures in homogeneous porous media (Farr *et al.*, 1990; and Lenhard and Parker, 1990). Unfortunately, none of the methods or approaches presented to date appears to be sufficiently reliable or reproducible at field sites, especially when significant fluctuations occur in the elevation of the groundwater table.

Despite these limitations, at most sites, it is likely that the *maximum* apparent (measured) thickness of light non-aqueous phase liquid (LNAPL) in a monitoring well is significantly greater than the actual thickness of that LNAPL in the surrounding formation. This phenomenon occurs when a monitoring well is installed into a formation in which mobile LNAPL is pooled on top of the capillary fringe above the water table. In such cases, LNAPL will flow into the monitoring well, depressing the true elevation of the potentiometric surface, until such time as equilibrium is achieved with the level of the LNAPL above the capillary fringe, and the weight/density of the hydrocarbon liquid in the well.

While LNAPL occurrence and measurement is a complicated matter, it is possible to make one simple conclusion: it is usually not possible to adequately characterize this concern without sufficient temporal gauging data. At a minimum, monitoring activities should include at least 4 rounds of gauging during the 4 seasons of the year.

Until such time as additional guidance is available on this topic, site investigators must undertake a "weight of evidence" approach to determine compliance with the 0.5 inch NAPL standard. A conservative approach would be to assume that the maximum (temporal) LNAPL thickness *observed* in a monitoring well is equivalent to the *actual* thickness of LNAPL in the formation. If the spatial average of these values within an area of concern (excluding hot spots) is less than 0.5 inches, compliance has been achieved. If the average of these values – or of a hot spot area – is greater than 0.5 inches, additional evaluations/calculations are needed to relate the observed/apparent thickness to actual formation thickness.

#### 4.7.3 NAPL and Vapor/Indoor Air Impacts

Volatile non-aqueous phase liquids (NAPL), including separate-phase gasoline, kerosene, jet fuels, and fresh diesel/#2 fuel oils, can result in the generation of significant concentrations of volatile petroleum hydrocarbon vapors in the vadose zone, which can potentially impact the indoor air of nearby structures. Purging a monitoring well containing such NAPL prior to obtaining a groundwater sample may underestimate risks of this nature, as the groundwater sample may contain relatively low concentrations of dissolved hydrocarbons. For this reason, soil gas investigations should be considered at any site at which volatile NAPL has been identified in monitoring wells or test pits, to characterize the risks posed to indoor air quality, and determine whether use of a Method 1 approach is appropriate

#### 4.8 Elimination of Continuing Sources

Under the provisions of 310 CMR 40.1003(5), a permanent solution cannot be achieved at a site if a continuing source(s) of environmental contamination is present. At petroleum-contaminated sites, the following conditions could constitute a continuing source:

- Abandoned Storage Tanks any abandoned storage tank containing any amount of mobile and/or soluble petroleum product would be considered a continuing source of environmental contamination, regardless of its current condition, unless such a tank has been closed pursuant to all applicable federal, state, and local regulations.
- Pt

♦ Septic Tanks/Dry Wells - any wastewater storage, conveyance, or disposal system containing significant quantities of Non-Aqueous Phase Liquids (NAPL) would be considered a continuing source of environmental contamination, unless such systems are operating in compliance with all applicable federal, state, and local regulations.

- ♦ Gasoline NAPL measurable amounts of gasoline NAPL could constitute a ontinuing source of environmental contamination, unless modeling, groundwater and/or soil gas monitoring data can demonstrate decreasing concentrations of dissolved and/or vapor-phase contaminants over time.
- ♦ Gasoline/VPH-contaminated soils concentrations of VPH fractions in soil above applicable Method 1 standards could constitute a continuing source of environmental contamination, unless modeling, groundwater and/or soil gas monitoring data can demonstrate decreasing concentrations of dissolved and/or vapor-phase contaminants over time.

#### 4.9 Feasibility of Achieving Background Concentrations

Under the provisions of MGL c. 21E and the MCP, a permanent solution shall, at a minimum, achieve a condition of No Significant Risk. However, the statute and regulations go one step further: a permanent solution shall also include measures to reduce contaminant levels in the environment to concentrations that achieve or approach a "background" condition, to the extent such measures are feasible. Thus, remedial decisions under the MCP are predicated on two distinct evaluation processes: risk and feasibility. Generic and site-specific procedures and criteria to evaluate and eliminate significant risk are extensively detailed in the MCP and associated guidance documents. Procedures and criteria to evaluate the feasibility of achieving or approaching background are less defined, and are typically considered on a site-by-site basis.

A feasibility evaluation of this nature identifies and weighs the benefits and costs of eliminating or minimizing the mass or volume of contaminants in the environment, beyond a "risk-based" endpoint. The costs of such actions can be generally calculated. The benefits are less quantifiable, but include property-value/economic and non-pecuniary benefits, as well as potential health benefits. With respect to the latter, it is important to understand that all risk-based standards have inherent uncertainties, due to limitations in our understanding of how toxins affect human and ecological receptors; these limitations are especially true and problematic when considering potential synergistic effects of multiple contaminants, and exposures to sensitive populations (e.g., children). While most standards are thought to be conservative, better studies and future data may lead to a different conclusion. A good example in this regard is the risk-based GW-1 standard for MtBE, which in recent years has been lowered by MADEP from  $700 \,\mu\text{g/L}$  to  $70 \,\mu\text{g/L}$  (and which may be lowered even further in the future).

While it is necessary to consider the feasibility of achieving or approaching background at petroleum-contaminated sites, certain attributes of petroleum hydrocarbons are germane to the benefit/cost evaluation, and allow for generalized conclusions and recommendations on feasibility issues. Specifically, most of the petroleum hydrocarbons contained in gasoline and lighter fuel oils are biodegradable, under both aerobic and anaerobic conditions. At most sites, residual levels of such contaminants will naturally degrade to levels that achieve or approach a background condition, in a foreseeable time period. In such cases, the "benefit" side of the feasibility equation becomes more an issue of timing than of concentration endpoints: is the benefit of *accelerating* this mass reduction worth the cost?

Based upon the above, certain generic guidelines are offered to streamline background restoration considerations at sites contaminated ONLY with petroleum hydrocarbons:

♦ Given the typical "asymptotic" response for contaminant reduction in aquifer systems, at sites contaminated solely by releases of gasoline of diesel?#2 fuel oil, achieving or approaching background concentrations of petroleum hydrocarbons in *groundwater* may generally be considered infeasible, provided that indigenous or enhanced microbial populations present at the site of concern would be expected to naturally degrade petroleum hydrocarbon concentrations.



- Achieving or approaching background concentrations of petroleum hydrocarbons may generally be considered infeasible in soils that are located beneath a permanent structure.
- Achieving or approaching background concentrations of petroleum hydrocarbons may generally be considered infeasible at sites where such remedial activities would interrupt vital public services and/or threaten public safety (e.g., energy interruption; traffic disruption).

It is important to stress that the above guidelines pertain <u>only</u> to the feasibility of remediation <u>beyond</u> a risk-based **endpoint.** Under the MCP, all sites must achieve a condition of No Significant Risk.

Additional policy documents on this subject are currently under development by MADEP; refer to the BWSC publication page at http://www.state.ma.us/dep/bwsc/pubs.htmto track progress/provide input in this regard.

#### 5.0 IMPLEMENTATION ISSUES

#### 5.1 Site Characterization

#### 5.1.1 Analytical Parameters

Recommended Target Analytes and VPH/EPH hydrocarbon ranges of interest for the most commonly released petroleum products are detailed in Tables 4-3, 4-5, and 4-6.

#### 5.1.2 Site and Media Characterization

Site characterization may involve evaluation and/or testing of NAPL, soil, groundwater, surface water, soil gas, ambient air, indoor air, or freshwater or marine sediments. Decisions of this nature are necessarily site-specific, based upon the type and quantity of petroleum product(s) released, depth to groundwater, and sensitivity of potential pollutant receptors.

**Rules of Thumb** for the most commonly released petroleum products and problematic situations are provided below:

#### **NAPL**

- When gauging a well for the purpose of monitoring the presence and thickness of NAPL, it is essential that all free-phase petroleum product be evacuated from the well after each gauging round, to help ensure that the well remains in good hydraulic communication with the surrounding formation, and accurately reflects dynamic aquifer conditions.
- ♦ Generally, it is not possible (or meaningful) to attempt to measure the concentration of dissolved petroleum product in a monitoring well which contains a measurable thickness of NAPL.

#### Soil



When obtaining samples at an UST grave for the purposes of determining an Exposure Point Concentration (EPC), it is necessary to specifically investigate whether a "hot spot" exists within the groundwater table fluctuation zone (i.e., the "smear zone"). For gasoline and fresh diesel/fuel oil releases, this action may be easily accomplished by headspace analysis of samples from sidewall excavations using a PID meter. In cases where headspace concentrations within this smear zone are equal to or greater than 10 times other locations on the sidewall, soil samples from this zone should be discretely collected/composited (either as the sidewall sample or with other sidewall samples) for appropriate analysis.

#### Groundwater

- A Regardless of the type of petroleum product released, groundwater characterization should be undertaken at any site where the distance to a groundwater withdrawal well is less than 500 feet.
- ♦ In most cases, it is necessary to obtain groundwater samples to adequately characterize releases of gasoline, aviation gasoline, and military jet fuels. Exceptions may include: very small releases of product (less than a few gallons), or sites with a deep vadose zone (>30 feet to the groundwater table), **IF** there are no sensitive receptors (e.g., no groundwater withdrawal wells or potentially impacted structures). At sites where the groundwater table is located in bedrock, the use of passive and/or active soil gas sampling is recommended to help determine if NAPL or significant concentrations of dissolved constituents are present in the groundwater.
- At sites where there has been a release of diesel/#2 fuel oil, and where excavation is being accomplished to remove a tank or contaminated soil, an attempt should be made to reach the groundwater table using on-site equipment. If reached, visible observations of the presence or absence of NAPL should be documented, and a groundwater and/or soil sample (from within the groundwater fluctuation zone) should be obtained

for analysis by a TPH or EPH methodology. If not reached, the installation of a groundwater monitoring well would generally not be necessary if (a) site data, before or after remediation, document concentrations of EPH fractional ranges below appropriate Method 1 standards, and (b) there are no groundwater withdrawal wells within 500 feet. Further guidance on tank removal is available in *Commonwealth of Massachusetts Underground Storage Tank Closure Assessment Manual*, DEP Policy # WSC-402-96, April, 1996.

- At gasoline-contaminated sites, particular attention and emphasis should be placed on the characterization of MtBE in groundwater. This compound, an additive in unleaded gasoline, is extremely soluble and mobile, and can migrate significant distances in groundwater. While most petroleum hydrocarbon plumes tend to biodegrade before significantly "dipping" below the groundwater table, MtBE plumes can "sink" below the typical 10-foot water table well screens in monitoring wells with increasing distance from a source area, necessitating consideration of deeper wells in downgradient plume areas (i.e., beyond about 100 meters from the source area). Moreover, unlike BTEX and other petroleum hydrocarbons, MtBE may not be a good candidate for natural attenuation, as it does not tend to volatilize, sorb to soils, or readily biodegrade. Recent information and data developed by the USEPA (2002) have disclosed that conventional sampling and analysis techniques can significantly underestimate MtBE concentration in groundwater; additional details and recommendations are provided in Appendix 1.
- When investigating vapor partitioning/transport concerns due to the presence of an open groundwater collection sump in a basement structure, it is recommended that 3-5 sump volumes of water be evacuated (as permitted by site/recharge conditions) immediately prior to sampling, to ensure collection of a representative sub-slab groundwater sample.



- Testing of soil gas and/or indoor air should be considered at any site where (a) a groundwater sump is present within a potentially impacted structure, (b) an earthen floor is present within a potentially impacted structure, (c) volatile LNAPL is present beneath or near a potentially impacted structure, or (d) contaminated soils are located within 5 feet of a potentially impacted structure (including beneath a basement slab). Note that the current MCP Method 1 soil standards do NOT consider the direct partitioning of volatile contaminants from impacted soils to an overlying or nearby structure, or impacts from groundwater that infiltrates a structure.
- When the objective for indoor air sampling is to determine whether a Critical Exposure Pathway (CEP) is present at a home or school, testing must be conducted under "worst case" site conditions; spatial and temporal averaging of indoor air data, while potentially appropriate for determining Exposure Point Concentrations for risk assessment purposes, is NOT appropriate when evaluating CEP conditions. Additional discussions in this regard are provided in Section 4.3.

#### 5.1.3 Filtering of Groundwater Samples

The objective of a groundwater characterization program is to determine the concentrations of contaminants within, and moving through, an aquifer or formation. Groundwater monitoring wells are installed to help meet this objective. However, monitoring wells are not perfect instruments for this purpose, as they can introduce a (false-positive) bias in the form of (a) suspended sediments containing significant concentrations of sorbed (non-dissolved) hydrocarbons, and/or (b) colloidal suspensions of non-aqueous phase liquids (NAPL). In either case, the analyses of water samples from such wells can provide an overquantitation of contaminant levels of concern. For this reason, groundwater samples are sometimes filtered prior to analyses, generally through a 0.45 micron filter. However, filtering in such a manner can produce a (false-negative) bias, by (1) removing particles smaller than 0.45 microns, and/or (2) removing colloids that are in fact contaminants that are moving through a formation.

Recommendations on this issue are outlined below:

The use and sampling of properly installed, constructed, and developed groundwater monitoring wells, using low-flow sampling techniques, is a preferred alternative to filtering. Recommended guidance and a standard operating procedure for low-flow/low-stress groundwater sampling is available from the EPA Region I website at: <a href="http://www.epa.gov/region01/measure/well/wellmon.html">http://www.epa.gov/region01/measure/well/wellmon.html</a>

- ♦ Samples obtained from potable water supply wells should NOT be filtered prior to analysis.
- ♦ Filtering should generally NOT be conducted in monitoring wells outside the "source area" of a petroleum release. Such wells are designed to determine the dissolved plume migration of petroleum contaminants, and should not contain suspended sediments with significant concentrations of sorbed hydrocarbons, or any NAPL.
- When filtering samples, the use of an "in line" device is recommended, to minimize handling and disturbance of the sample.
- ♦ When filtering samples, the collection and analysis of a separate (split) non-filtered sample may be appropriate, to help discern biases present in the characterization process, and determine compliance with characterization objectives.

Because of the potential to produce a false-negative/bias, all site investigations that rely upon data obtained from filtered groundwater samples must include an adequate discussion and justification for using such techniques.

#### 5.2 Use of Old and New TPH Data

While the use of the VPH/EPH approach is a preferred means to characterize risks from petroleum products released to the environment, there are significant amounts of historical Total Petroleum Hydrocarbon (TPH) data that have been obtained in the past for contaminated sites. Moreover, the future use of new TPH data may also be appropriate, to screen out problems in a cost-effective manner. For this reason, in addition to the VPH/EPH aliphatic and aromatic range standards, TPH reporting and cleanup standards have been retained in the Massachusetts Contingency Plan. Note, however, that many of the (post 1997 MCP) standards have been changed, in that the TPH standards are now set at the lowest EPH fractional standard (usually C11-C22 Aromatics), as a "worst case" assumption on hydrocarbon chemistry.

There are two ways to use TPH data:

- ♦ TPH data may be used *directly*, by comparison to TPH Reportable Concentrations and Cleanup Standards; or
- TPH data may be used *indirectly*, by using (conservative) assumptions on hydrocarbon chemistry to break down and "convert" the TPH data into aliphatic and aromatic ranges.

#### 5.2.1 Comparing TPH Data to Reportable Concentrations, Method 1 Cleanup Standards, and UCLs

Soil and groundwater data obtained from a TPH test method may be directly used to ascertain reporting obligations, compliance with MCP Method 1 cleanup standards, and compliance with Upper Concentration Limits (UCLs). Because the TPH standards assume that the entire hydrocarbon mixture is comprised of the most toxic/problematic hydrocarbon fraction, in theory, use of TPH data would be viewed as a conservative screening effort. However, parties electing to proceed in such a fashion should be aware of the following practical conditions and concerns:

- ♦ Effective October 31, 1997, the MCP defines TPH as "the total or cumulative concentration of hydrocarbons with boiling points equal to or greater than 150°C (C9) and associated with a petroleum product...." All data termed TPH must meet this performance standard. Given the lack of standardized testing, calibration, and reporting techniques for TPH test methods, and methodological biases for techniques such as EPA Method 418.1 (Infra-red detection), demonstrating compliance with this definition is a burden that must be met by data users.
- ♦ In lieu of using an ill-defined TPH methodology, parties seeking to use this screening tool should consider using the EPH test method in the "TPH mode". Specifically, the EPH method provides an option to forego the aliphatic/aromatic fractionation step, and generate a GC/FID TPH quantitation value. If this value is low, and below the TPH cleanup standard, compliance has been achieved. If this value is above the TPH cleanup standard, the laboratory can be instructed to then

proceed to the fractionation step, to produce more toxicologically relevant and less conservative fractional data.

- Decause common TPH test techniques employ a solvent extraction and concentration step, which can lead to significant losses of hydrocarbons lighter than C9, the use of such methods are not appropriate in the characterization of light petroleum products, such as gasoline, aviation gasoline, and certain military jet fuels.
- Because the EPH fractional ranges provide a better characterization of hydrocarbon chemistry and risks, such data will take precedence over TPH data. For example, parties that exceed a TPH Method 1 cleanup standard have the option of obtaining EPH fractional range data, to see if the individual fractions comprising the TPH value are within listed standards. Similarly, under the provisions of 310 CMR 40.0360(2), parties that exceed a TPH Reportable Concentration have 120 days to obtain EPH fractional data, and demonstrate that NONE of the fractions exceeds an applicable Reportable Concentration, to avoid reporting.

#### 5.2.2 Converting TPH Data into EPH Fractional Ranges

Since TPH is essentially a summation of the 3 EPH fractions (i.e., C9-C18 Aliphatics, C19-C36 Aliphatics, and C11-C22 Aromatics), it is possible to "convert" TPH data into the EPH fractional ranges, by making informed and reasonably conservative judgments on the chemistry of the TPH data. Compositional assumptions for soil data that are believed to be protective at most sites are provided in Table 5-1.

Table 5-1: Recommended TPH Compositional Assumptions in Soil



Petroleum Product	C11-C22 Aromatics	C9-C18 Aliphatics	C19-C36 Aliphatics
Diesel/#2/Crankcase Oil	60%	40%	0%
#3-#6 Fuel Oil	70%	30%	0%
Kerosene and Jet Fuel	30%	70%	0%
Mineral Oil Dielectric Fluid	20%	40%	40%
Unknown Oil	100%	0%	0%

For water data, only conservative assumptions can be made:



- ♦ For TPH water data, all of the TPH should be assumed to be the most conservative EPH fractional standard for the groundwater category(ies) of interest, although it is permissible to subtract out the concentrations of Target PAH analytes (e.g., naphthalene), if known;
- ♦ For Gasoline Range Organic (GRO) water data, the entire GRO concentration should be assumed to be the most conservative VPH fractional standard for the groundwater category(ies) of interest, although it is permissible to subtract out the concentration of Target BTEX/MtBE analytes, if known.

For old GRO soil data, a conservative assumption would be to consider all of the non-BTEX/MtBE hydrocarbons greater than C8 to be C9-C10 Aromatics. (All non-BTEX/MtBE compounds lighter than C9 are aliphatic hydrocarbons). Note, however, that if the GRO soil sample was not preserved in methanol, the integrity and validity of this data would be suspect.

In using and applying assumptions on the composition of petroleum hydrocarbons, it is essential that all relevant factors be carefully considered, including (1) level of certainty of identification of petroleum product(s) released at the site, (2) reliability, validity, and bias of TPH/screening techniques, and (3) sensitivity of pollutant receptors. Given the wide variability in "TPH" analytical methods, and inherent biases of these methods, the determination of a true TPH concentration is not a trivial exercise.

When evaluating risks for Critical Exposure Pathways, such as drinking water wells, the use of assumptions is generally not appropriate, unless it can be demonstrated that such assumptions represent "worst case" conditions.

#### 5.3 VPH/EPH Compositional Variability/Recommended Approach

Because of fate and transport processes that act upon hydrocarbon compounds and mixtures when they are released to the environment, the chemical composition of petroleum contamination will vary across a site of concern. Accordingly, it is not possible to analyze one soil or groundwater sample by the VPH or EPH methods to establish a compositional template, and apply that template to break down TPH data from other parts of the site into aliphatic/aromatic fractional ranges. For example, soil in the saturated zone in the plume migration area will be contaminated with higher concentrations/proportions of more soluble compounds (e.g., aromatics); soils in older spill sites will have higher concentrations/proportions of less soluble/degradable compounds, such as heavy aliphatics and 3-5 ring PAH hydrocarbons.

For small sites, it may be more cost-effective to simply analyze all impacted media samples by VPH and/or EPH test methods, though use of field screening techniques would be desirable to optimize the selection and support the representativeness of such samples. For larger sites, however, cost savings may be realized by using a combination of VPH/EPH test methods and screening techniques to determine the nature and extent of contamination, and calculate Exposure Point Concentrations (EPCs). In such cases, the following would be recommended:

1. obtain VPH/EPH data fromkey areas and exposure pathways;



- 2. supplement VPH/EPH data with screening/TPH data;
- 3. consider the chemistry of the petroleum products released to the environment, fate and transport factors, the VPH/EPH data, and the conservative compositional parameters recommended in Table 5-1; and
- determine conservative fractional composition/EPCs for risk assessment purposes and/or comparison with Method 1 standards.

#### 5.4 Other Program Issues

#### 5.4.1 Numerical Ranking System (NRS)

Under the provisions of 310 CMR 40.1500, sites are classified as either Tier I or Tier II on the basis of a numerical score, and scoring criteria are contained within a number of tables throughout this section. Recent additions to the MCP (1999) have provided (human) toxicity scoring criteria for the VPH/EPH fractions at 310 CMR 40.1511. Future revisions to the MCP will include additional VPH/EPH scoring criteria for mobility and persistence; until that occurs, scoring may be accomplished using the values listed in Table 5-2.

Table 5-2: Mobility and Persistence Scoring Criteria for VPH/EPH Fractions



		Mobility and Persistence Values and Scores											
Fraction		bility g/L)	Vapor (mm		K o	w	Deg Poter		Spec Gra		Total		
	Value	Score	Value	Score	Value	Score	Value	Score	Value	Score	Score		
C5-C8 Aliphatics	11	5	80	10	< E+04	5	NP	0	<1	0	20		
C9-C12 Aliphatics	0.07	0	0.7	5	>E+04	0	NP	0	<1	0	5		
C9-C10 Aromatics	51	5	2	10	<e+04< td=""><td>5</td><td>NP</td><td>0</td><td>&lt;1</td><td>0</td><td>20</td></e+04<>	5	NP	0	<1	0	20		
C9-C18 Aliphatics	0.01	0	0.2	5	>E+04	0	NP	0	<1	0	5		
C19-C36 Aliphatics	N/A	0	N/A	0	N/A	0	P	10	<1	0	10		
C11-C22 Aromatics	5.8	5	0.02	5	>E+04	0	NP	0	<1	0	10		

#### 5.4.2 Characterization of Remediation Wastes

For the purpose of characterizing Remediation Wastes, & well as other purposes, the sum of the 3 EPH fractions (i.e., C9-C18 Aliphatics, C19-C36 Aliphatics, and C11-C22 Aromatics) is equivalent to a TPH concentration, as defined by the MCP.

#### 5.4.3 Characterization of Remedial Air Emissions

Requirements for the evaluation and/or treatment of remedial air emissions are specified in the MCP at 310 CMR 40.0049. Further guidance in this regard is provided in *Off-Gas Treatment of Point-Source Remedial Air Emissions*, Policy #WSC-94-150, available at <a href="http://www.state.ma.us/dep/bwsc/finalpol.htm">http://www.state.ma.us/dep/bwsc/finalpol.htm</a>

For the purposes of characterizing remedial air emissions at petroleum-contaminated sites, the following guidelines may be applied:

- The specification in 310 CMR 40.0049(5) to achieve 95% removal of emitted oil and hazardous materials applies to the <u>collective</u> concentrations of all influent/effluent hydrocarbons, not to individual target analytes and/or hydrocarbon ranges. Therefore, if monitored by the APH method, the collective concentration of all influent Target Analytes and hydrocarbon ranges is compared to the collective concentration of all effluent Target Analytes and hydrocarbon ranges.
- Consistent with the recommendations contained in Section 5.0 of *Off-Gas Treatment of Point-Source Remedial Air Emissions*, it is permissible to monitor influent and effluent vapor concentrations using a portable PID or FID unit. In such cases, the PID unit should be calibrated to an isobutylene response standard, and the FID unit should be calibrated to a methane response standard. At sites where gasoline vapors are being emitted, the PID must be equipped with a minimum 10.0 eV lamp. When using a PID or FID unit to monitor vapor emissions, a reading of 1 ppmV or less can generally be considered a "background" concentration.
- It is permissible to evaluate off-gas remedial emissions using the Emission-Distance Graphs contained in Section 7.3 of *Off-Gas Treatment of Point-Source Remedial Air Emissions*. When using these graphs, the C5-C8 Aliphatic, C9-C12 Aliphatic, and C9-C18 Aliphatic Hydrocarbon ranges are considered "Group 4" contaminants, and the C9-C10 Aromatic and C11-C22 Aromatic Hydrocarbon Fractions are considered "Group 3" contaminants.

#### 5.4.4 Characterization of Coal Tar Contaminated Sites

MADEP is evaluating the applicability of the VPH/EPH approach in the characterization of sites contaminated by coal tars. As an interim recommendation, the use of VPH and EPH would appear to be an appropriate approach to characterize the risks posed by the aliphatic and aromatic hydrocarbons that comprise coal tars; because of the chemistry of this material, aliphatic and aromatic ranges quantitated by both the VPH and EPH methods would appear to be necessary, along with all method Target Analytes except MtBE (i.e., BTEX and the 17 Target PAHs). In addition to the aliphatic and aromatic ranges and Target Analytes, additional contaminants of concern for coal tars would include phenolics, cyanide, and trace metals.

#### APPENDIX 1 Collecting and Preserving VPH Samples Page 1 of 3

#### SOIL SAMPLES

#### **OPTION 1: In-Field Methanol Preservation Technique**

PERFORMANCE STANDARD: Obtain undisturbed soil sample and immediately preserve with methanol at a ratio of 1 mL methanol per 1 gram soil (+/- 25%).

Step 1: Choose appropriate sampling container:

60 mL wide mouth packer bottle; or

60 mL straight sided wide mouth bottle; or

60 mL VOA vial; or 40 mL VOA vial

All sampling containers should have an open-top screw cap with Teflon-coated silicone rubber septa or equivalent.

Step 2: Pre-label each container with a unique alpha/numerical designation. Obtain and record tare (empty) weight of each container to nearest 0.1 gram *This information must be available to the laboratory performing the analyses*.

Add 25 mLs of purge and trap grade methanol to 60 mL containers, or 15 mL to 40 mL containers. *It is essential that the methanol be purge and trap grade or equivalent quality*. Immediately cap the container. Make a mark on the 60 mL containers approximately 15 mL above the level of methanol, or a mark on the 40 mL container approximately 10 mL above the level of methanol. The objective is to obtain 25 grams of soil in the 60 mL container, or 15 grams of soil in the 40 mL container, which is approximately 15 and 10 mL of soil volume, respectively, depending upon soil type and moisture content. Other masses of soil are permissible, as long as the ratio of [grams soil]/[mL methanol] is 1:1, +/- 25%. Store at 4°C. *The use of a methanol trip blank prepared in this manner is recommended*.

In the field, carefully add soil to the sample container, until the level of methanol in the vial reaches the designated volumetric mark. For wet soil, add slightly beyond the mark. IN NO CASE, HOWEVER, MAY THE LEVEL OF SOIL IN THE CONTAINER RISE ABOVE THE LEVEL OF METHANOL. The use of a 10-30 mL disposable syringe with the end cut off is recommended to obtain an undisturbed soil sample from freshly exposed soils. In such cases, obtain and extrude the soil into sample container, avoiding splashing methanol out of the container.

Optional: use a field electronic balance to ensure addition of desired mass of soil (25 grams to 60 mL containers, 15 grams to 40 mL containers).

Use a clean brush or paper towel to remove soil particles from the threads of the sample container and screw cap. Tightly apply and secure screw cap. Gently swirl sample to break up soil aggregate, if necessary, until soil is covered with methanol. DO NOT SHAKE. Duplicate samples obtained in this manner are recommended. A split-sample must also be obtained for a determination of soil moisture content. This sample must NOT be preserved in methanol. HINT: fill this container 1/2 full, to allow screening of the sample headspace by the field investigator or the laboratory.

Immediately place containers in cooler for storage in an upright position. Sample vials may be placed in separate sealable bags to protect containers in case of leakage during transport. Transport to analytical laboratory using appropriate chain-of-custody procedures and forms.

Step 6:

Step 5:

Step 3:

Step 4:

# APPENDIX 1 Collecting and Preserving VPH Samples

Page 2 of 3

#### **SOIL SAMPLES (Continued)**

**OPTION 2:** Use of a Sealed-Tube Sampling/Storage Device

PERFORMANCE STANDARD: Obtain undisturbed soil sample and immediately seal in air-

tight container, for shipment to laboratory and immersion in

methanol within 48 hours.

Step 1: Obtain pre-cleaned and/or disposable samplers/containers that allow the collection and air-tight

storage of 5-25 grams of soil.

Step 2: In the field, obtain an undisturbed sample from freshly exposed soil. Immediately seal container, and

place in a cooler. Obtain a duplicate sample to enable the determination of soil moisture content (this may be stored/sealed in a conventional container). Transport to analytical laboratory using appropriate

chain-of-custody procedures and forms.

Step 3: Samples must be extruded and immersed in purge and trap (or equivalent) grade methanol at the

laboratory within 48 hours of sampling, at a ratio of 1 mL methanol to 1 gram soil. In no case, however, shall the level of soil in the laboratory container exceed the level of methanol (i.e., the

soil must be completely immersed in methanol).

NOTE: Documentation MUST be provided/available on the ability of the sampler/container to provide an air-tight seal in a manner that results in no statistically significant loss of volatile hydrocarbons for at

least 48 hours.

#### **OPTION 3:** Use of Alternative Collection/Storage/Preservation Techniques

PERFORMANCE STANDARD: Obtain and store an undisturbed soil sample in a manner

that ensures the chemical integrity of the sample by (1) preventing the volatilization of petroleum hydrocarbons

heavier than C5, and (2) preventing the biological

degradation of petroleum hydrocarbons.

NOTE: The onus is on the user of such techniques to demonstrate the validity of the procedures used, via reference to published literature and/or other pertinent data.

#### **SAFETY**

Methanol is a toxic and flammable liquid, and must be handled with appropriate care. Use in a well-vented area, and avoid inhaling methanol vapors. The use of protective gloves is recommended when handling or transferring methanol. Vials of methanol should always be stored in a cooler with ice at all times, away from sources of ignition such as extreme heat or open flames.

# APPENDIX 1 Collecting and Preserving VPH Samples Page 3 of 3

#### **AQUEOUS SAMPLES**

#### MOST VPH/VOC AQUEOUS SAMPLES

All aqueous samples that will not be analyzed within 4 hours of collection must be preserved by pH adjustment, in order to minimize analyte losses due to biodegradation. For most samples, this can be accomplished by acidification of the sample to pH <2, by adding 3-4 drops of 1:1 HCl to a 40 mL vial. The sample should then be stored at 4°C until it is analyzed. In lieu of acidification, samples may also be preserved with an appropriate base to pH > 11.0 (see below).

#### SAMPLES TO BE ANALYZED FOR MTBE

ISSUE

Traditionally, VPH and VOC aqueous samples have been preserved by addition of an acid (e.g., HCl) to lower the pH of the sample to less than 2.0. While this is still an acceptable approach for petroleum\hydrocarbons and most VOC analytes, recent information and data have indicated that such a technique can lead to significant losses (up to 89%) of MtBE and other ethers (White, H., Lesnik, B., Wilson, J., Analytical Methods for Fuel Oxygenates, LUSTLINE Bulletin #42, New England Interstate Water Pollution Control Commission, 2002 (http://www.epa.gov/swerust1/mtbe/LL42Analytical.pdf) Specifically, the combination of a low pH and high temperature sample preparation technique (e.g., heated purge and trap) hydrolyze the ether bonds present in the sample, converting the ethers into alcohols (e.g., TBA).

PRESERVING MTBE SAMPLES To prevent ether hydrolysis, samples should either (a) not be acidified or (b) not be heated. Because heating the sample may be necessary to achieve proper analyte purging/partitioning, an alternative to acidification is likely to be the most efficient means to prevent hydrolysis. Because ethers are not subject to base-catalyzed hydrolysis, raising the pH of the sample is an acceptable alternative to acidification. Studies by the USEPA have shown that preservation of aqueous samples to a pH greater than 11.0 using trisodium phosphate dodecahydrate will effectively prevent biological degradation of dissolved analytes, and will not result in deleterious effects on other dissolved oxygenates or on BTEX analytes.

PROTOCOL

A recommended protocol to achieve a pH level > 11.0 is to add between 0.40 and 0.44 grams of trisodium phosphate dodecahydrate to a 40 mL vial. For convenience, this can be done in the laboratory prior to sample collection in the field. Because it is more convenient to measure the required amount of trisodium phosphate dodecahydrate on a volume basis rather than by weight, the use of a precalibrated spoon is recommended. In the field, each vial is filled with the aqueous sample and sealed without headspace - as is traditionally done for acidified samples. The sample is then stored at  $4^{\circ}$ C until it is analyzed.

WHEN IS THIS NEEDED? Given the Method 1 standard for MtBE in GW-2 and GW-3 areas (i.e.,  $50,000~\mu g/L$ ), MADEP will generally not expect or require the use of alternative preservation or analytical protocols for disposal sites located ONLY in such areas, with respect to demonstrating attainment of a condition of No Significant Risk. Nevertheless, such efforts should be considered, and may be necessary, on a case-specific basis, to investigate other site assessment objectives, such as extent of contamination, source identification, etc.



For gasoline releases in GW-1 areas, it is generally expected that some level of assessment will be conducted to confirm the concentration of MtBE using alternative preservation and/or analytical procedures to prevent hydrolysis of ethers. In particular, confirmatory samples would be recommended in the "source area" and in the outer plume (or N.D.) monitoring wells. When sampling a private or public drinking water supply well that is proximate to a release of gasoline and/or #2 fuel oil, it is generally expected that all such samples will be evaluated for the presence of MtBE by use of an alternative preservation and/or analytical procedure.

#### APPENDIX 2 SHIPPING METHANOL PRESERVED SAMPLES

#### **Shipping of Hazardous Materials**

Methanol is considered a hazardous material by the US Department of Transportation (DOT) and the International Air Transport Association (IATA). Shipments of methanol between the field and the laboratory must conform to the rules established in Title 49 of the Code of Federal Regulations (49 CFR parts 171 to 179), and the most current edition of the IATA Dangerous Goods Regulations. Consult these documents or your shipping company for complete details, as these regulations may change without notice.

#### **Small Quantity Exemption**

The volumes of methanol recommended in the VPH method fall under the small quantity exemption of 49 CFR section 173.4. To qualify for this exemption, all of the following must be met:

- ♦ the maximum volume of methanol in each sample container must not exceed 30 mL
- ♦ the sample container must not be full of methanol
- the sample container must be securely packed and cushioned in an upright position, and be surrounded by a sorbent material capable of absorbing spills from leaks or breakage of sample containers
- ♦ the package weight must not exceed 64 pounds
- ♦ the volume of methanol per shipping container must not exceed 500 mL
- \$\dightarrow\$ the packaging and shipping container must be strong enough to hold up to the intended use
- ♦ the package must not be opened or altered while in transit
- the shipper must mark the shipping container in accordance with shipping dangerous goods in acceptable quantities, and provide the statement:

"This package conforms to conditions and limitations specified in 49 CFR 173.4"

#### **Shipping Papers**

All shipments must be accompanied by shipping papers that include the following:

Proper Shipping Name: Methyl Alcohol Hazardous Class: Flammable Liquid

Identification Number: UN1230

Total Quantity: (mL methanol/container x the number of containers)

Emergency Response Info: Methanol MSDS attached
Emergency Response Phone: provide appropriate number
Shipping Exemption: DOT-E 173.118, Limited Quantity

#### **Labeling & Placarding**

Labeling and placarding are not required for valid small quantity exemptions (per 173.118)

#### **APPENDIX 3 - Required VPH Data Report Content**

SAMPLE INF	ORMATIC	ON									
Matrix	☐ Aqueous	s 🗆 S	Soil	ent 🗆 (	Other:						
Containers	☐ Satisfact	tory	□ Broken	□ Leakiı	ng:						
	Aqueous		/A □ pH <u>&lt;</u> 2 □								
Sample	Soil or	□ N.	/A 🗆 Samples N	NOT pres	erved in M	ethanol or	air-tight co	ntainer	mL Metha	nol/g soil	
Preservatives	Sediment		amples rec'd in	Methanol	: 🗆 cover	ing soil 🛛	not cover	ing soil	□ 1:1 +/ <b>-</b>	25%	
		□ Sa	mples received	in air-tigh	t containe	r:			☐ Other:		
Temperature	□ Received	d on Ic	ee 🗆 Received	d at 4 ° C	□ Othe	r:					
VPH ANALY											
Method for Ran		P VPH	98-1		Client ID						
Method for Targ				_	Lab ID						
VPH Surrogate	Standards				Collected						
PID:					Received						
FID:					Analyzed						
Dilution Factor  % Moisture (soil)											
Range/Target A	nalvto		Elution	RL	Units						
Range Target II	naryte		Range	I KL	Cilits						
Unadjusted C5-	C8 Aliphatics <sup>1</sup>	1	N/A								
Unadjusted C9-	C12 Aliphatic	$s^1$	N/A								
Benzene	· · · · ·										
Ethylbenzene											
Methyl-tert-buty	vlether										
Naphthalene	,		N/A								
Toluene											
m- & p- Xylenes	3										
o-Xylene											
C5-C8 Aliphatic	Hydrocarbor	ns 1,2	N/A								
C9-C12 Aliphat			N/A								
C9-C10 Aromat			N/A								
PID Surrogate	% Recovery										
FID Surrogate	% Recovery										
Surrogate Accep	ptance Range					70-130%	70-130%	70-130%	70-130%	70-130%	
			centrations of any					that range			
			the concentration e conc of Target A					of C C Am	omotio Uvdu	noorhone	
C <sub>9</sub> C <sub>12</sub> Aliphauc	nyurocarbons	e xciude	e conc of Target Ai	iarytes eiut	mg m mat ra	ange AND co	ncentration	01 C <sub>9</sub> -C <sub>10</sub> Ar	omauc nyuro	carbons	
CERTIFICAT	TION										
		REOU	UIRED by the V	PH Meth	od followe	d?		Yes □ N	o - Details	Attached	
	-	_	standards for re						lo - Details		
_	_		made to the VP	_					es - Details		
I attest under th	e pains and pe	enaltie.	s of perjury that,	based up	on my inqu	iry of those	individuals	s immediate	ely responsit	ble for	
obtaining the in	formation, the	e matei	rial contained in	this repo	rt is, to the	best of my h	knowledge a	ınd belief, d	accurate and	d	
complete.	~~					200	·mv 0.3.1				
SI	GNATURE:					POSI	TION:				
PRIN	TED NAME:						DATE:				
						•					

#### APPENDIX 3 - Supplemental VPH QA/QC data (Optional)

#### QA/QC DATA

Range/Target Analyte	Range of	Reporting	Lab		<b>Duplicate Sam</b>	ple	Lab Fort	ified Blank
	Elution	Limit	Method Blank	Sample	Duplicate	%RPD	Spiking Conc	% Recov
Unadjusted C5-C8 Aliphatics	N/A						N/A	N/A
Unadjusted C9-C12 Aliphatics	N/A						N/A	N/A
Pentane								
2-Methylpentane								
Methyl-t-butylether								
2,2,4 - Trimethylpentane								
Benzene								
Toluene								
n-Nonane								
Ethylbenzene								
m- & p- Xylenes								
Naphthalene								
C5-C8 Aliphatics Hydrocarbons	N/A						N/A	N/A
C9-C12 Aliphatics Hydrocarbons	N/A						N/A	N/A
C9-C10 Aromatics Hydrocarbons	N/A						N/A	N/A
S	Sample Matrix							
	Units							
Sam	ple ID number	N/A						
	Date Analyzed	N/A						

#### VPH SOIL PRESERVATION DATA

	Client ID					
	Lab ID					
A	Tare Wt. Jar (g)					
В	Vol Methanol Initially Added (mL)					
C	Wt. Jar & Methanol (g)					
D	Wt Jar, Methanol & Soil (g)					
D-C	Wt. Soil (g)					
E	Est Vol loss Methanol after sampling (mL)					
F	Vol Methanol added after sampling (mL)					
B-E+F	Final Vol Methanol Preservative (mL)					
G	Vol Surrogates/Internal Stds Added (mL)					
H	Volume of Matrix Spikes Added (mL)					

#### **APPENDIX 3 – Required EPH Data Report Content**

SAMPLE I	NFORMA	TION								
Matrix		☐ Aqueous ☐ S	oil 🗆	Sediment	□ Other:	•				
Containers		-	Broken	□ Leakir	ıg:					
Aqueous Pres	ervatives	□ N/A □ pH≤2	□ рН	l>2 Comn	nent:					
Temperature		☐ Received on Ice	□ Rece	ived at 4 ° C	□ Othe	er:				
Extraction M	ethod	Water:			Soil:					
EPH ANA	LYTICAI	L RESULTS								
Method for R	anges: MA	DEP EPH 98-1		Client ID						
Method for T				Lab ID						
EPH Surroga			Date	Collected						
Aliphatic:			Date	e Received						
Aromatic:			Date	Extracted						
EPH Fraction	ation Surro	gates	Date	Analyzed						
			Diluti	ion Factor						
			% Mois	sture (soil)						
RANGE/TAR	GET ANA	LYTE	RL	Units						
Unadjusted C	11-C22 Aro	omatics <sup>1</sup>								
	Naphthale	ene								
Diesel PAH	2-Methyln	aphthalene								
Analytes	Phenanthi	ene								
	Acenaphtl	nene								
Other										
Target PAH										
Analytes										
C9-C18 Aliph	atic Hydro	carbons 1								
C19-C36 Alip										
C11-C22 Aron	•									
Aliphatic Sur										
Aromatic Sur		· · · · · · · · · · · · · · · · · · ·								
Sample Surro					40-140%	40-140%	40-140%	40-140%	40-140%	
Fractionation										
Fractionation		•								
		Acceptance Range		-4-(-) 1/	40-140%	40-140%	40-140%	40-140%	40-140%	
_	_	xclude concentrations of				aaras eluung 1	n tnat range			
		carbons exclude the conc	entration o	1 Target PAF	Analytes					
CERTIFIC										
_		ires REQUIRED by						No-Details		
_		ceptance standards fo	_		_					
		difications made to the		· -					s Attached	
	_	nd penalties of perjury								
_	information	, the material contain	ed in this i	report is, to	the best of n	ny knowledg	e and belief	, accurate a	nd	
complete.										
SIG	NATURE:				_ POSITI	ON:				
PRINT	ED NAME:	<b>!</b>			_ DA	TE:				

#### **APPENDIX 3 - Recommended TPH Data Report Content**

Matrix	
Aqueous Preservatives	
Received on Ke   Received at 4 ° C   Other:	
Extraction Method   Water:   Soil:	
TPH ANALYTICAL RESULTS     Client ID	
Method: MADEP EPH 98-1         Client ID         Image: Collected of the part of the	
Method for Target Analytes:	
TPH Surrogate Standards	
Date   Extracted	
Date   Extracted	
Date   Analyzed   Dilution   Factor   Dilution   Factor   Section   Dilution   Factor   Section   Dilution   Factor   Section   Dilution   Section	
Dilution Factor	
Range/Target Analyte Range/Target Analyte Range/Target Analyte RL Units Unadjusted Total Petroleum Hydrocarbons¹ Naphthalene Diesel PAH Analytes Phenanthrene Acenaphthene Acenaphthene Other PAH Target    Woman Moisture (soil)   Woman Moisture (soil)	
Range/Target Analyte Unadjusted Total Petroleum Hydrocarbons  Naphthalene Diesel PAH Analytes Phenanthrene Acenaphthene  Other PAH Target  RL Units  RL Units	
Unadjusted Total Petroleum Hydrocarbons¹  Naphthalene Diesel PAH Analytes Phenanthrene Acenaphthene  Other PAH Target  Naphthalene  Naphthalene  Analytes Naphthalene  Acenaphthalene  Other PAH Target  Naphthalene  Naphthalene  Acenaphthalene  Other PAH Target  Naphthalene  Other PAH Target	
Naphthalene Diesel PAH Analytes Phenanthrene Acenaphthene  Other PAH Target	
Diesel PAH Analytes Phenanthrene	
Analytes Phenanthrene Acenaphthene  Other PAH Target	
Acenaphthene  Other PAH Target	
Other PAH Target	
Target	
Target	
Target	
Target	
Analytes	
Total Petroleum Hydrocarbons <sup>2</sup>	
Sample Surrogate % Recovery	
	140%
<sup>1</sup> Hydrocarbon Range data exclude concentrations of any surrogate(s) and/or internal standards eluting in that range <sup>2</sup> Total Petroleum Hydrocarbons exclude the concentration of PAH Target Analytes	
Total Petroleum Hydrocarbons exclude the concentration of PAH Target Analytes	
CERTIFICATION	
Were all QA/QC procedures REQUIRED by the EPH Method (for TPH) followed?	
Were all performance/acceptance standards for the required QA/QC procedures achieved? ☐ Yes ☐ No-Details At Were any significant modifications made to the EPH method, as specified in Section 11.3? ☐ No ☐ Yes-Details At	
I attest under the pains and penalties of perjury that, based upon my inquiry of those individuals immediately responsible obtaining the information, the material contained in this report is, to the best of my knowledge and belief, accurate and	for
complete.	
SIGNATURE: POSITION:	
PRINTED NAME: DATE:	

### APPENDIX 3 - Supplemental EPH/TPH QA/QC data (Optional)

Range/Target Analyte	Range of	Reporting	Lab		Duplicate Sam	ple	Lab Forti	fied Blank
	Elution	Limit	Method Blank	Sample	Duplicate	%RPD	Spiking Conc	% Recov
Unadjusted C11-C22	N/A						N/A	N/A
Aromatics								
Unadjusted TPH	N/A							
C9-C18 Aliphatics	N/A						N/A	N/A
C19-C36 Aliphatics	N/A						N/A	N/A
TPH	N/A						N/A	N/A
	Sample Matrix						11///	11/74
	Units							
C		N/A						
Sam	ple ID number							
	Date Analyzed	N/A						

#### APPENDIX 4 - VPH/EPH Cleanup Standards and Reportable Concentrations October 31, 1997

#### Reportable Concentrations

Fraction/Parameter	RCS-1	RCS-2	RCGW-1	RCGW-2
	( <b>mg</b> /g)	( <b>ng</b> /g)	( <b>ng/L</b> )	( <b>ng</b> /L)
C5-C8 Aliphatic Hydrocarbons	100	500	400	1000
C9-C12 Aliphatic Hydrocarbons	1000	2500	1000	1000
C9-C10 Aromatic Hydrocarbons	100	500	200	4000
C9-C18 Aliphatic Hydrocarbons	1000	2500	1000	1000
C19-C36 Aliphatic Hydrocarbons	2500	5000	5000	20,000
C11-C22 Aromatic Hydrocarbons	200	2000	2000	30,000
Total Petroleum Hydrocarbons (TPH)	200	2000	2000	1000

#### Method 1 Cleanup Standards for Groundwater

Fraction/Parameter	GW-1	GW-2	GW-3	
	( <b>ng</b> /L)	( <b>ng</b> /L)	( <b>ng</b> /L)	
C5-C8 Aliphatic Hydrocarbons	400	1000	4000	
C9-C12 Aliphatic Hydrocarbons	4000	1000	20,000	
C9-C10 Aromatic Hydrocarbons	200	5000	4000	
C9-C18 Aliphatic Hydrocarbons	4000	1000	20,000	
C19-C36 Aliphatic Hydrocarbons	5000	N/A	20,000	
C11-C22 Aromatic Hydrocarbons	200	50,000	30,000	
Total Petroleum Hydrocarbons (TPH)	200	1000	20,000	

#### Method 1 Cleanup Standards for Soil

Fraction/Parameter	GW-1 Areas		GW-2 Areas		GW-3 Areas				
	S-1	S-2	S-3	S-1	S-2	S-3	S-1	S-2	S-3
	( <b>mg</b> /g)	( <b>ng</b> /g)	( <b>ng</b> /g)	( <b>ng</b> /g)	( <b>ng</b> /g)	( <b>mg</b> /g)	( <b>ng</b> /g)	( <b>ng</b> /g)	( <b>ng</b> /g)
C5-C8 Aliphatic Hydrocarbons	100	500	500	100	500	500	100	500	500
C9-C12 Aliphatic Hydrocarbons	1000	2500	5000	1000	2500	5000	1000	2500	5000
C9-C10 Aromatic Hydrocarbons	100	100	100	100	500	500	100	500	500
C9-C18 Aliphatic Hydrocarbons	1000	2500	5000	1000	2500	5000	1000	2500	5000
C19-C36 Aliphatic Hydrocarbons	2500	5000	5000	2500	5000	5000	2500	5000	5000
C11-C22 Aromatic Hydrocarbons	200	200	200	800	2000	5000	800	2000	5000
Total Petroleum Hydrocarbons (TPH)	200	200	200	800	2000	5000	800	2000	5000

#### **Upper Concentration Limits (UCLs)**

Fraction/Parameter	Groundwater (mg/L)	Soil ( <b>ng</b> /g)
C5-C8 Aliphatic Hydrocarbons	100,000	5000
C9-C12 Aliphatic Hydrocarbons	100,000	20,000
C9-C10 Aromatic Hydrocarbons	100,000	5000
C9-C18 Aliphatic Hydrocarbons	100,000	20,000
C19-C36 Aliphatic Hydrocarbons	100,000	20,000
C11-C22 Aromatic Hydrocarbons	100,000	10,000
Total Petroleum Hydrocarbons (TPH)	100,000	10,000

Cleanup Standards are subject to change; consult latest version of the MCP for most up to date values!

#### APPENDIX 5 - ADDITIONAL REFERENCE/SUPPORT MATERIALS



#### For a Closer Look......

The following documents and publications provided additional background, information, and insight into the VPH/EPH approach, guidance, and standards

#### **MADEP Publications**

#### **VPH/EPH Approach**

- ♦ Interim Final Petroleum Report: Development of Health-Based Alternative to the Total Petroleum Hydrocarbon (TPH) Parameter, August, 1994 Original report presenting the toxicological basis of the proposed new VPH/EPH approach.
- ♦ Issues Paper: Implementation of VPH/EPH Approach, Public Comment Draft, May, 1996 Detailed discussion and recommendations on how to develop MCP Method 1 cleanup standards, and otherwise incorporate new VPH/EPH approach into the MCP regulatory process.
- ♦ Beyond TPH: Understanding and Using the New VPH/EPH Approach, June, 1997 Slides and handouts from a day-long training session presented by MADEP in the Spring of 1997.
- ♦ #2 Fuel/Diesel Short Form, July, 2002 An Excel spreadsheet that allows for the site-specific characterization of human health risks for Target Analytes and appropriate aliphatic/aromatic hydrocarbon fractions.
- ♦ Reports on the Results of the VPH/EPH Round Robin Testing Programs, June 1997 and January 1998 Detailed reports outlining the methods and results of two interlaboratory "Round Robin" testing programs undertaken by MADEP to help refine and validate the VPH and EPH analytical test methods.
- ♦ *Method for the Determination of Volatile Petroleum Hydrocarbons (VPH), January, 1998* Detailed analytical procedure for this GC/PID/FID methodology developed by MADEP.
- ♦ *Method for the Determination of Extractable Petroleum Hydrocarbons (EPH), January, 1998* Detailed analytical procedure for this silica-gel/fractionation GC/FID method developed by MADEP.
- ♦ Draft Method for the Determination of Air-Phase Petroleum Hydrocarbons (APH), February, 2000 Proposed analytical procedure for this GC/MS methodology developed by MADEP.
- Background Documentation for the Development of VPH/EPH Cleanup Standards and Guidance, October, 2002, available at <a href="http://www.state.ma.us/dep/bwsc/vph\_eph.htm">http://www.state.ma.us/dep/bwsc/vph\_eph.htm</a>

#### **Related MADEP Regulations and Guidance Documents**

- ♦ Massachusetts Contingency Plan (MCP), 310 CMR 40.0000 State regulations that govern the cleanup of sites contaminated by oil or hazardous materials; now includes provisions for VPH/EPH approach and standards.
- ♦ Background Documentation for the Development of the MCP Numerical Standards, April, 1994 Contains information, data, assumptions, approaches, and spreadsheets for development of the MCP Method 1 cleanup standards, excluding VPH/EPH fractional range standards.
- Guidance for Disposal Site Risk Characterization in Support of the Massachusetts Contingency Plan, July, 1995 Comprehensive guidance on how to characterize risks to human and ecological receptors.

#### **APPENDIX 5 - ADDITIONAL REFERENCE/SUPPORT MATERIALS (continued)**

#### **Related MADEP Regulations and Guidance Documents (continued)**

- ♦ Commonwealth of Massachusetts Underground Storage Tank Closure Assessment Manual, April, 1996 Outlines requirements and procedures for conducting a closure assessment of underground storage tanks.
- ♦ Interim Remediation Waste Management Policy for Petroleum Contaminated Soils, April, 1994 Procedures, requirements, and recommendations for characterizing, classifying, managing, and recycling/disposing of petroleum contaminated soils.

All MADEP publications available on the World Wide Web at http://www.state.ma.us/dep/bwsc/pubs.htm

#### **Total Petroleum Hydrocarbon Criteria Working Group (TPHCWG) Publications**

TPHCWG is a national consortium of state regulatory agencies, academia, DOD, DOE, USEPA, ASTDR, petroleum, power and transportation industries, and consulting firms. The goal of this group is to evaluate and propose methods to



characterize risks posed by petroleum-contaminated media. TPHCWG has endorsed a toxicological approach similar to the MADEP VPH/EPH approach. Recommendations by this group on evaluating the fate and transport of aliphatic and aromatic hydrocarbon fractions were used by MADEP in developing the cleanup standards and the guidelines and recommendations contained in this policy. TPHCWG plans on publishing a six-volume series of reports on issues of interest; volumes of interest to parties using the VPH/EPH approach are listed below:

- ♦ Volume I Analysis of Petroleum Hydrocarbons in Environmental Media (1998) Contains an overview of petroleum hydrocarbon characterization and risk assessment, a discussion of available analytical methods, and a proposed GC-Based analytical method, developed by the Working group, that reports hydrocarbon results in equivalent carbon number groups or fractions.
- ♦ Volume II Composition of Petroleum Mixtures Contains a description of the chemical characteristics and composition of petroleum fuels, with a comprehensive series of tables and references.
- ♦ Volume III Selection of TPH Fractions Based upon Fate and Transport Consideration (1997)- Contains information and data on the physical and chemical properties of hydrocarbons and hydrocarbon mixtures, and recommended algorithms for determining the properties of aliphatic and aromatic fractions.
- ♦ Volume IV Development of Fraction-Specific Reference Doses (RfDs) and Reference Concentrations (RfCs) for Total Petroleum Hydrocarbons (TPH (1997) Contains extensive information and data on the toxicological properties of petroleum products and hydrocarbon mixtures, and a proposed approach to characterize risks based upon the collective fractions of aliphatic and aromatic fractions. NOTE: Certain provisions of these recommendations are in conflict with current MADEP positions and requirement, although the agency is currently evaluating recent data presented in this volume.

TPHCWG Publications are being cited as potentially relevant background/reference materials. MADEP is not necessarily endorsing the conclusions and/or recommendations provided in these various documents.

TPHCWG Publications available on the World Wide Web at

http://www.aehs.com/publications/catalog/contents/tph.htm

# APPENDIX 6 SUMMARY OF SIGNIFICANT CHANGES MADE TO FINAL IMPLEMENTATION POLICY

	BY SECTION				
Section	Subject	Change/Addition			
1.3	Applicability	New explanation of VPH/EPH reporting obligations at closed sites			
3.2.3	АРН	New explanation of Air-Phase Petroleum Hydrocarbon (APH) method			
3.5	Method Modification	New guidance on evaluating modifications to VPH/EPH/APH procedures			
3.7	Other Testing Methods	New guidance on use of TPH and other hydrocarbon testing procedures			
4.1	Exposure Point Conc.	New Section 4.1 added with additional guidance on determining EPCs			
4.2.2	Target Analytes	Modifications of Table 43, additional information and guidance on lead, EDB, MtBE, and other petroleum additives			
4.3	Vapor Pathway	Expanded "tool box" approach to investigate (Figure 4-1) and mitigate (Figure 4-3) subsurface vapor infiltration pathways			
4.3.1	Soil Gas Screening	Additional guidance on location of soil gas probes; new criteria for PID/FID Level 1 Screening (Table 4-9); additional guidance on Level 2 Screening			
4.3.1.1	Soil Gas Guidelines	Certain Target Analytes added to Tables 4-9, 4-10, and 4-11; criteria now relevant to soil contamination, as well as GW -2 exceedances			
4.3.1.4	Vapor Transport Models	New reference to DEP policy on use/utility of transport models			
4.3.1.5	Groundwater Profiling	New guidance on evaluating indoor air pathways by profiling contaminant concentrations at and below the groundwater table			
4.3.2	GW-3 Evaluation	New Dilution Graphs (Figure4-4) and guidance to evaluate plume dispersion			
4.5	Toxicological parameters	New RfD and RfC values for certain fractions			
4.6	Fate/Transport Parameters	New aqueous diffusivity coefficients for hydrocarbon fractions			
4.7	NAPL	Additional guidance on NAPL monitoring and evaluation			
5.4.1	NRS	New recommended mobility and persistence scoring criteria (Table 5-2) for hydrocarbon fractions when using Numerical Ranking System			
5.4.3	Remedial Air Emissions	New recommendations on monitoring and evaluating off-gas treatment for remedial air emissions			
App 1	MtBE analysis	New information/guidelines on preservation of aqueous samples for MtBE analysis (Due to degradation caused by acidification)			
App 3	VPH/EPH Report Format	Required Reporting Format for VPH/EPH methods			
App 5	References	Additional references/support materials for VPH/EPH approach			

Shading indicates changes that were made AFTER issuance of FINAL DRAFT document (June 2001)

# APPENDIX 6 SUMMARY OF SIGNIFICANT CHANGES MADE TO FINAL IMPLEMENTATION POLICY (Continued)

BY SUBJECT				
Subject	Section	Change/Addition		
АРН	3.2.3	New explanation of Air-Phase Petroleum Hydrocarbon (APH) method		
Applicability	1.3	New explanation of VPH/EPH reporting obligations at closed sites		
Exposure Point Conc.	4.1	New Section 4.1 added with additional guidance on determining EPCs		
Fate/Transport Parameters	4.6	New aqueous diffusivity coefficients for hydrocarbon fractions		
Groundwater Profiling	4.3.1.5	New guidance on evaluating indoor air pathways by profiling contamin concentrations at and below the groundwater table		
GW-3 Evaluations	4.3.2	New Dilution Graphs (Figure4-4) and guidance to evaluate plume dispersion		
Method Modifications	3.5	New guidance on evaluating modifications to VPH/EPH/APH procedures		
MtBE analysis	App 1	New information/guidelines on preservation of aqueous samples for MtBE analysis (Due to degradation caused by acidification)		
NAPL	4.7	Additional guidance on NAPL monitoring and evaluation		
NRS	5.4.1	New recommended mobility and persistence scoring criteria (Table 5-2) for hydrocarbon fractions when using Numerical Ranking System		
Other Testing Methods	3.7	New guidance on use of TPH and other hydrocarbon testing procedures		
References	App5	Additional references/support materials for VPH/EPH approach		
Remedial Air Emissions	5.4.3	New recommendations on monitoring and evaluating off-gas treatment for remedial air emissions		
Soil Gas Screening	4.3.1	Additional guidance on location of soil gas probes; <b>new criteria for PID/FID Level 1 Screening (Table 4-9);</b> additional guidance on Level 2 Screening		
Soil Gas Guidelines	4.3.1.1	Certain Target Analytes added to Table 4-9, 4-10, and 4-11; criteria now relevant to soil contamination, as well as GW-2 exceedances		
Target Analytes	4.2.2	Modifications of Table 43, additional information and guidance on lead, EDB, MtBE, and other petroleum additives		
Toxicological Parameters	4.5	New RfD and RfC values for certain fractions		
Vapor Pathway	4.3	Expanded "tool box" approach to investigate (Figure 4-1) and mitigate (Figure 4-3) subsurface vapor infiltration pathways		
Vapor Transport Models	4.3.1.4	New reference to DEP policy on use/utility of transport models		
VPH/EPH Report Format	App3	Required Reporting Format for VPH/EPH methods		

Shading indicates changes that were made AFTER issuance of FINAL DRAFT document (June 2001)

## **Overview of Gasoline Composition (NEIWPCC, 2003)**


Hawai'i DOH Spring 2024 Appendix 6





A Report On Federal & State Programs To Control Leaking Underground Storage Tanks

# A Hot Dog by Any Other Name Could Be Your Drinking Water



by Patricia Ellis

#### "Hot dogs, getcher hot dogs!"

The cry of the hot dog vendor at the ballpark. The steaming hot frank with your choice of mustard, ketchup, relish...the captivating aroma and the even more satisfying taste! But let's not stop to think about what's actually in a hot dog. Sure, some of us take comfort in consuming only hot dogs that are "all beef" or "chicken" or Kosher. But what's really in a hot dog? Do we really want to know? And just what has the composition of hot dogs got to do with an article that is ostensibly about leaking underground storage tanks, anyway? Well, it has to do with this propensity to not want to know about those ingredients...even the ingredients in our own drinking water.

■ continued on page 2

#### Inside

7 NEIWPCC Survey on Oxygenates at LUST Sites: Part 1
10 An Overview of Treatment Technologies for MTBE
14 Part 2: Surface Flux-Chamber Method
19 Taking On Today's Challenges
20 DE's Systemwide Approach to Preventing Releases
25 Baffled by a Leak? Check the Inventory Records
29 Thoughts on the Tortoise and the Hare Revisited
30 ME's Dispenser and Submersible-Pump Sump Study
33 PEI's 2003 Edition of RP200
34 CA Water District Sues Oil Companies
34 CA Updates Guidance on ELD and SIR
36 EPA HQ Update

#### ■ **Hot Dogs** *from page 1*

#### Is Ignorance Bliss?

The drinking water supply systems in the United States are unquestionably the best in the world. Most people can simply turn on the faucet and draw a glass of fresh, clear water that they can put unflinchingly to their lips and drink. Yet, a growing segment of the population uses a filter of some sort, and increasing numbers of people buy bottled water. In fact, in the last 40 years, it is estimated that the U.S. drinking water industry has lost nearly 60 percent of its customers to competitors (currently unregulated) who are "bottled water and point-of-use/point-of-entry providers." (Means et al., 2002) Why?

The reasons are many—taste, odor, color, fad/style, fear (justified or imagined). For those of us on public water supplies, our water suppliers provide us with annual Consumer Confidence Reports (CCRs) that show us that our water has been tested for



#### **LUSTLine**

Ellen Frye, Editor
Ricki Pappo, Layout
Marcel Moreau, Technical Advisor
Patricia Ellis, Ph.D., Technical Advisor
Ronald Poltak, NEIWPCC Executive Director
Lynn DePont, EPA Project Officer

LUSTLine is a product of the New England Interstate Water Pollution Control Commission (NEIWPCC). It is produced through a cooperative agreement (#CT825782-01-0) between NEIWPCC and the U.S. Environmental Protection Agency.

LUSTLine is issued as a communication service for the Subtitle I RCRA Hazardous & Solid Waste Amendments rule promulgation process.

LUSTLine is produced to promote information exchange on UST/LUST issues. The opinions and information stated herein are those of the authors and do not necessarily reflect the opinions of NEIWPCC.

This publication may be copied. Please give credit to NEIWPCC.

NEIWPCC was established by an Act of Congress in 1947 and remains the oldest agency in the Northeast United States concerned with coordination of the multimedia environmental activities of the states of Connecticut, Maine, Massachusetts, New Hampshire, New York, Rhode Island, and Vermont.

NEIWPCC Boott Mills South, 100 Foot of John Street Lowell, MA 01852-1124 Telephone: (978) 323-7929 Fax: (978) 323-7919 lustline@neiwpcc.org

LUSTLine is printed on Recycled Paper

a variety of contaminants and is safe to drink. But most water suppliers analyze for a couple dozen contaminants at most. The CCRs tell us whether or not these contaminants were detected and at what concentrations.

When these contaminants are detected, even when their concentration may from time to time exhibit a spike above a regulatory threshold, this water is still distributed to us. Generally an accounting gimmick, such as 30-day average concentration, is employed so that it can be claimed that although detected above the limit, the concentration did not exceed "permissible" levels and the water is safe to drink.

For example, if the analytical report for a sample indicates that each of the BTEX compounds is present but at concentrations below their MCLs (5 ppb, 1,000 ppb, 700 ppb, and 10,000 ppb, respectively), is water with up to 11,705 ppb of BTEX really safe to drink? Do we want to drink it knowing that although the levels are reportedly safe, these contaminants are present at all? Do we want our children drinking it? And, health concerns aside, how does it taste? What about other contaminants that are not on this list of only a couple dozen? Are some of them present and, if so, what do we know about them?

#### **Petroleum Cocktail Hour**

Petroleum (and the various fuels distilled from petroleum) is composed of hundreds to thousands of individual organic compounds. (Although this article focuses on gasoline, much of the discussion is applicable to other fuels as well.) "Gasoline" is a complex blend of several hundred hydrocarbons (i.e., compounds that contain only hydrogen and carbon atoms) and other organic compounds that typically contain nitrogen, oxygen, or sulfur. The specific composition of any particular blend of gasoline is a function of the petroleum source, refining and blending processes, and additives (Kreamer and Stetzenbach, 1990). The composition also varies with geographic location and from season to season to maintain performance specifications and comply with regulatory require-

The primary groups of hydrocarbons in gasoline are the paraffins, olefins, naphthenes, and aromatics (Youngless et al., 1985). Table 1 lists some representative examples for each of the various classes of these organic compounds. Additive packages (which are generally proprivary considerably etary) typically include compounds that function as antioxidants, antiicers, metal deactivators, detergents, and corrosion inhibitors, among others (Youngless et al., 1985). Some of these compounds are extremely large, complex molecules.

Some components of gasoline may also contain metal species. The most familiar of these, but not the only ones, are the organic lead compounds, which are no longer used in modern unleaded gasolines. In the past, especially with leaded fuels, a wide variety of dyes were incorporated into gasoline blends as well. Table 2 lists a few of the many gasoline additives.

In addition, a significant number of the compounds in gasoline are *unknown* (or unidentified), except for the number of carbon atoms they contain (Kreamer and Stetzenbach, 1990). What do we know about the toxicity of each of the compounds in gasoline? How do they behave in the environment? Which ones are in our drinking water and at what levels?

For an organic contaminant to show up in a water sample, it must be water soluble. It is well known that aromatic hydrocarbons (of which BTEX is probably the best recognized) are the most soluble constituents of gasoline. Table 3 lists 43 common gasoline constituents with solubility greater than 1 mg/L. Two of the nonaromatic compounds in this table have a higher solubility than ethylbenzene (the "E" in BTEX). This list isn't comprehensive, and there are undoubtedly other compounds with similar properties and, hence, significant water solubility.

While these constituents represent pure compound solubility, and individual solubilities from a mixture would be somewhat lower, the point is that there are lots of soluble constituents in gasoline that can appear in groundwater. If a sample is only analyzed for the aromatic fraction, how do we know that some of these other constituents are not also present?

## **Toxicity of Petroleum Constituents**

It should come as no surprise to anyone that exposure (e.g., through inhalation, ingestion, or dermal contact) to any of the constituents of gasoline (or any other fuel) at any concentration should be avoided. Exposure to the vapors from most gasoline constituents can cause dizziness, drowsiness, unconsciousness, and other adverse effects on the central nervous system. Prolonged exposure to low concentrations, or brief exposure to higher concentrations, may damage internal organs, cause cancer or birth defects, or may even be fatal. Ingestion of the liquid phase of neat gasoline (and most, if not all, of its individual constituents) is acutely toxic.

So where do we find information on the toxicity of specific constituents? We would expect that one of the best sources is a material safety data sheet (MSDS), and there are many places to find them on the Internet. But they are readily available only for a small percentage of the constituents of gasoline, and, as they only pertain to exposure to a single compound, the effects of exposure to dilute aqueous mixtures are entirely unknown. (This issue is likely to be one of the important public health challenges of this century, and further discussion is way beyond the scope of this article.)

One of the current ways to deal with a large number of organic compounds is to distribute them into smaller groups, each of which has a designated "surrogate." This is the approach adopted by the Total Petroleum Hydrocarbon Criteria Working Group (TPHCWG). In this method, it is presumed that all members of the group have properties that are similar to the surrogate.

But the approach has several drawbacks. First, compound toxicity isn't necessarily the same for each of the group members, and often the toxic characteristics of a significant proportion of the group are unknown. Second, the presence of the surrogate in a sample may not necessarily mean that there are any other compounds in the sample; if they are, they are probably not at the same concentration. Third, the absence of the surrogate in a sample may not

necessarily mean that all of the other compounds in the class are also absent from the sample. Fourth, many states are statutorily authorized to regulate only those contaminants that appear on EPA's list (i.e., 40 CFR 302.4, discussed in the "Regulation..." section below).

Sadly, the focus on compound toxicity has been so narrowly concentrated on human carcinogenicity that adverse effects other than cancer are usually conveniently ignored. In almost any discussion of risk management, there is no consideration of the teratogenic (birth defect) or mutagenic (mutation) effects of these toxic compounds—not to mention taste or odor!

We have no idea what contaminants are really in the water we drink (or the hot dogs we eat). Simply because a contaminant isn't listed on an analytical report does not mean that the contaminant is not present in the sample. The truth is that we just don't know, but what we don't know can potentially hurt us.

The issue of exposure to multiple toxicants is likewise given short shrift—exposure to multiple toxic compounds is limited to presumed simple additive effects, if it's considered at all. Yet, it is well recognized that the toxicity of a chemical may be increased (or in some cases even decreased) by simultaneous or consecutive exposure to another chemical (Lu, 1991). There is no consideration of synergistic (multiplicative) effects, or whether mixtures may contain procarcinogens, cocarcinogens, or cancer promoters.

And then there's the issue of whether or not a specific compound is a human carcinogen or just an animal carcinogen. Too often an animal carcinogen is touted as being a human noncarcinogen simply because there isn't any confirmation that the compound causes cancer in humans. However, saying that a compound is a noncarcinogen, when the truth is that there isn't enough

information about it to determine whether or not it is a human carcinogen (although the compound is a known animal carcinogen), is being less than honest.

Admittedly, it is difficult (maybe even impossible) to demonstrate with 100 percent certainty that any chemical is a noncarcinogen. But for compounds that are known animal (especially mammalian) carcinogens, ordinary common sense would tell a reasonable person that these are substances with which unnecessary contact should be avoided, even at low concentrations and especially in mixtures that contain substances that may promote cancer.

In theory, a single molecule of a carcinogen can induce cancer. This means that there is no threshold dose and therefore no safe level of exposure to carcinogens. While not all cancer researchers hold this view, the opposing view (i.e., that threshold doses for carcinogens do exist) has yet to be demonstrated, even though large-scale experiments have been conducted for this purpose (Lu, 1991). Further complicating the issue is that unless a fatal quantity of pure product is ingested, most of the toxic effects are slow to develop (10 to 20) years or more in humans) and may be masked by other ailments as we

# Regulation of Hazardous Substances

Underground storage tanks containing hazardous substances are regulated by the UST program under 40 CFR 280. Additional regulations regarding hazardous substances are found in 40 CFR 302.4 and 40 CFR 261.24. The first of these, CFR 302.4 (U.S. EPA, 2001a), is U.S. EPA's list of approximately 800 Hazardous Substances. Of these substances, only a handful are petroleum hydrocarbons found in fuels, and even fewer are fuel additives. (See Table 4.)

The second regulation, 40 CFR 261.24, is the Toxicity Characteristics (TC) rule for identifying RCRA hazardous wastes. The TC rule specifically exempts "petroleum contaminated" media and debris that fail the test for the toxicity characteristic of 40 CFR 261.24 (U.S. EPA, 2001b). Section 261.24(b) refers to 25 contami-

■ continued on page 4

#### ■ **Hot Dogs** *from page 3*

nants (but actually lists 26) that are specifically exempt from consideration as "hazardous wastes," provided they are subject to the corrective action regulations under 40 CFR 280 (the UST regulations). This list of 26 contaminants includes benzene and only two additional chemicals (cresol and pyridine) that *may* be present in gasoline or other petroleum fuels.

We all know that none of the components of gasoline (or other petroleum fuels) are healthy for us, so why is it that so few fuel constituents are officially designated as "toxic" or "hazardous"? Part of the answer is that there are simply too many potentially toxic substances to list; some are unidentified, and adequate toxicity testing hasn't been conducted on others. Although not limited to organic compounds, the Chemical Abstract Service (CAS) assigns unique registration numbers (known as CAS or CASRN) to new chemicals at a rate of about 4,000 per day!!! (See http://www.cas.org/EO/ regsys.html.)

Another part of the answer is that petroleum fuels as a whole are a critical part of the world economy. They've been used for close to 100 years, so we're familiar with them, we need them, and we consider them to be relatively "safe." Perhaps the primary reason why gasoline is considered "safe" is because UST regulations are relatively effective—at least to the extent that there aren't daily media reports of explosions, fires, and underground rivers of gasoline flowing beneath our feet.

However, as we all know, releases from UST systems do happen, sometimes with immediate and catastrophic effect. Every day there are releases of gasoline (and other fuels) into the environment, and a significant amount of the released fuel eventually winds up in groundwater or surface water or both, some of which is used for drinking water. So how do we know what toxic compounds (if any) are actually in our drinking water?

## Identification of Toxic Compounds

Let's assume that we have a water sample that may or may not be contaminated with one or more of the hundreds of petroleum constituents in gasoline. What tests can we conduct to determine what contaminants are in the sample? Several analytical methods are potentially available to us to determine if any contaminants are present in the sample and at what concentrations. Though not the sole source for analytical methods, EPA's compendium of analytical methods, SW-846, (U.S. EPA, 1997) offers us several choices of determinative analytical methods for organic compounds, including: Methods 8015, 8021, 8260, and 8270. Let's look into each of these in ascending numerical order. (See Table 5.)

- **Method 8015** (Nonhalogenated Organics Using GC/FID) explicitly lists 30 compounds, of which only four may be present in gasoline. Only one—methanol—is on the list of hazardous substances. This method may also be used for Gasoline Range Organics (GRO) and Diesel Range Organics (DRO), but other methods (which aren't specified in the scope) may be more applicable. No additional guidance is provided regarding GRO or DRO.
- **Method 8021** (Aromatic and Halogenated Volatiles by Gas Chromatography Using Photoionization and/or Electrolytic Conductivity Detectors) explicitly lists 57 compounds, of which 10 may be present in gasoline and are also on the list of hazardous substances.
- **Method 8260** (Volatile Organic Compounds by Gas Chromatography/Mass Spectrometry) explicitly lists 107 compounds, of which about a dozen may be found in gasoline and are also on the list of hazardous substances.
- Method 8270 (Semivolatile Organic Compounds by Gas Chromatography/Mass Spectrometry) explicitly lists about 250 compounds, of which only a couple are likely to be found in gasoline (although many more could be present in diesel fuel and heavier fuel oils) and are on the list of hazardous substances.

U.S. EPA drinking water methods 502 and 524.2 contain a slightly different list of chemicals.

Of the more than 400 target compounds identified by the four 8000-series methods, approximately 5 percent may be present at any given petroleum release site. "Well and good," you're thinking, "but what's the point of this?"

## Absence of Proof Is Not Proof of Absence

Well, the first point of this is that we have no idea what contaminants are really in the water we drink (or the hot dogs we eat). Simply because a contaminant isn't listed on an analytical report does not mean that the contaminant is not present in the sample. (Note that the converse is also true—that is, there is no proof that the contaminant is present.) The truth is that we just don't know, but what we don't know *can* potentially hurt us.

There are a lot of reasons why the presence of a contaminant in a sample might go unrecognized:

- There was no analysis for the contaminant.
- There was an analysis for the contaminant, but an inappropriate method was used.
- The analytical method was applied incorrectly.
- The detection limit is very high.
- Matrix interferences.

In each of these cases, a contaminant could be in a sample, but its presence (and concentration) is undetected (and undetermined). We have to do a better job than we currently do to both anticipate which potential contaminants may be present at a given site and analyze for all of them to determine whether they are in fact present or absent.

In addition to the desirability of knowing all chemicals present for the purpose of conducting a risk assessment, it is important to know all the contaminants present when developing a remediation plan.

In one of my recent projects, carbon filters used as point-of-entry treatment for domestic wells were breaking through in far shorter times than what was expected. After running Method 8260 plus requesting that all "tics" be identified by a library search, we identified a total of 45 additional chemicals, all potentially having a gasoline source, as being present in the water samples. These additional chemicals all contributed to the loading on the carbon filters and contributed to the early breakthrough. The library search gave estimated concentrations, but none of these compounds had been calibrated against a standard.

I might also have been happier if I hadn't added dissolved lead to the list of analytes because of earlier detections of EDC. Dissolved lead exceeded recommended levels in every sample (pre- and post-carbon filters), and in every well, even where gasoline components were detected. Further analysis, this time for tetraethyl and tetramethyl lead, the organic lead that would come from leaded gasoline, was negative. Elevated lead levels appeared to be present throughout the aquifer, which would also have to be factored into a risk assessment. While the carbon filters were dealing with the gasoline contamination in the wells, albeit in an expensive manner, the filters had no effect on the dissolved lead.

Further, it isn't enough to have samples analyzed even for all potential contaminants if the samples aren't representative. Samples must be collected from locations where contaminants are most likely to be present, and they must be correctly handled during collection, transport, preparation, and analysis.

# Fuel-Specific Analytical Methods

My second point is that the current analytical practices we rely on to determine whether gasoline compounds are present or absent in water (and soil) samples are incomplete and therefore inadequate. Standard operating procedures for Methods 8015, 8021, 8260, and 8270 require calibration for only a few of the many compounds that are present in gasoline, but many compounds are either not present or are unknown.

Target analyte lists must be refined so that they are more representative of the contaminants that are

#### Table 1 Representative Organic Compounds Found in "Gasoline"

#### **Straight Chain Alkanes**

propane n-hexane n-dodecane

#### **Branched Alkanes**

isobutane 2,2-dimethylbutane neopentane 3-ethylhexane

#### Cycloalkanes

cyclohexane n-propylcyclopentane ethylcyclohexane

#### **Straight Chain Alkenes**

cis-2-butene 1-pentene trans-2-heptane

#### **Branched Alkenes**

2-methyl-1-butene 4,4-dimethyl-cis-2-pentene

#### Cycloalkenes

cyclopentene 3-methylcyclopentene

#### **Alkyl Benzenes**

benzene toluene ethylbenzene o-xylene m-xylene p-xylene 1,2-dimethyl-3-e

1,2-dimethyl-3-ethylbenzene 1,2,3-trimethylbenzene 1,2,4,5-tetramethylbenzene n-propylbenzene

#### **Other Aromatics**

indan 1-methylindan phenol

#### Polycyclic Aromatic Hydrocarbons (PAHs)

naphthalene

Source: Adapted from Cole (1994).

#### Table 2 Representative Organic Compounds Used as Additives in "Gasoline"

#### **Oxygenates**

methyl tertiary-butyl ether (MTBE) ethanol ethyl tertiary-butyl ether (ETBE) tertiary-butyl alcohol (TBA) tertiary-amyl ethyl ether (TAEE) diisopropyl ether (DIPE) tertiary-amyl methyl ether (TAME) tertiary-amyl alcohol (TAA) methanol

#### Anti-knock compounds

tetra-ethyl lead (TEL) tetra-methyl lead (TML) methylcyclopentadienyl manganese tricarbonyl (MMT)

#### Anti-oxidant compounds

hindered phenols phenylene diamines aminophenols

#### **Anti-icing compounds**

isopropyl alcohol amides/amines glycols organophosphate ammonimum salts

#### **Corrosion inhibitors**

carboxylic acids sulfonates amine/alkyl phosphates

#### **Metal deactivators**

disalicylidene amines phenolic amines thiourea

#### Ignition controller additives

tri-o-cresol phosphates

#### **Detergents**

aminohydroxyamide alkylphenols imidazolines

#### Lead scavengers

1,2-dichloroethane (EDC) 1,2-dibromoethane (EDB)

#### Dyes

azobenzene-4-azo-2-napthol benzene-azo-2-napthol para-diethyl aminoazobenzene 1,4-diisopropylaminoanthraquinone

Source: Adapted from Cummings (1977) and Irwin, et. al. (1997).

likely to be encountered at fuel-release sites. For example, nearly 90 percent of the analytes listed for Method 8021 are halogenated compounds that would *not* be present at fuel-release sites—why should a sample be analyzed for them and *not* for some of the few hundred other

contaminants that may actually be present? If we're going to pay for an analysis for, say, 100 compounds, wouldn't it be more cost-effective if those 100 could be reasonably anticipated to be in the sample?

■ continued on page 6

#### ■ **Hot Dogs** *from page 5*

And, in order to credibly evaluate the actual risk posed by contaminants in our water, we absolutely must know which contaminants are in the water. In a recent series of articles by Uhler and others (2002, 2003), similar suggestions were made. They suggest a suite of 109 target analytes for the analysis of automotive gasoline using a Modified 8260 method. The list contains the PIANO compounds (Paraffins, <u>I</u>soparaffins, <u>A</u>romatics, <u>N</u>aphthenes, and Olefins), useful for recognizing peculiarities that might be inherited from refinery processes (including

# Table 3 Common Gasoline Constituents Ranked by Solubility (mg/L)

Benzene	1,780
Toluene	515
o-Xylene	220
cis-2-Pentene	203
Cyclopentane	156
Ethylbenzene	152
1-Pentene	148
3-Methyl-1-butene	130
Indan	100
1-Methyl-4-ethylbenzene	95
1,2,3-Trimethylbenzene	77
1-Methyl-2-ethylbenzene	75
Propane	62
1,2,4-Trimethylbenzene	57
Cyclohexane	55
n-Propylbenzene	52
Isopropylbenzene	50
1,3,5-Trimethylbenzene	50
Isobutane	48.9
Methylcyclopentane	42
Pentane	38.5
Naphthalene	31
1-Methyl-naphthalene	28
2-Methyl-naphthalene	25
2,2-Dimethylbutane	18.4
sec-Butylbenzene	17
Methylcyclohexane	14
Isopentane	13.8
2-Methylpentane	13.8
n-Butylbenzene	13.8
3-Methylpentane	12.8
Isobutylbenzene	10.1
Hexane	9.5
2,3-Dimethylpentane	5.25
1,2,4,5-Tetramethylbenzene	3.48
3-Methylhexane	3.3
n-Heptane	2.93
2-Methylhexane	2.54
2,2,4-Trimethylpentane	2.44
2,3,4-Trimethylpentane	2
1-Nonene	1.12
Source: Adapted from Gustafson et al	. (1997).
<u> </u>	

various major and minor iso-alkanes), and gasoline additives, including the oxygenate additives (alcohols and ethers), lead scavengers (EDC and EDB), and methylcyclopentadienyl manganese tricarbonyl (MMT). Some of this list of compounds can be useful in fingerprinting gasoline for environmental forensic investigations, as well as a basis for conducting a risk assessment.

Just how credible, how "scientifically defensible" is a risk assessment based on omission, neglect, or wishful thinking? To only evaluate the risk posed by some, but not all, contaminants present at a site is like crossing a busy highway but only looking

# Table 4 Hazardous Substances Listed in 40 CFR 302.4 That May be Present in "Gasoline"

oozii inatimaj so				
SUBSTANCE	CASRN			
1,2-dibromoethane	106934			
1,2-dichloroethane	107062			
1,3-pentadiene	504609			
benzene	71432			
cresols	1319773			
<i>ortho</i> -cresol	95487			
<i>meta-</i> cresol	108394			
<i>para</i> -cresol	106445			
cyclohexane	110827			
ethylbenzene	100414			
methanol	67561			
naphthalene	91203			
phenol	108952			
toluene	108883			
xylenes	1330207			
<i>ortho</i> -xylene	95476			
<i>meta</i> -xylene	108383			
<i>para</i> -xylene	106423			
Source: Adapted from Gustafson et al. (1997).				

in one direction as you make the attempt. Sure, you may not get hit by a car coming from the direction in which you're looking, but one from the blind side is likely to spoil your day.

Appropriate analytical method(s) already exist in today's marketplace. All that is lacking are appropriate calibration standards and standard operating procedures that have been optimized for analysis of these target analytes. Once it becomes routine to use these standards, risk assessments could be conducted for the contaminants to which receptors are actually exposed, rather than presumed surrogates. This will go a long way toward bolstering the credibility of risk assessment and restoring confidence in the safety of our drinking water.

#### Take Me Out to the Ballgame

Alternatively, we could opt to accept the status quo...we can slump down in our bleachers, hot dog in one hand, and glass of water (OK, beer) in the other, and blissfully pass away the time.

Pat Ellis is a hydrologist with the Delaware Department of Natural Resources and Environmental Control, Tank Management Branch and served as a member of EPA's Blue Ribbon Panel on MTBE. She is a technical advisor and regular contributor to LUSTLine and can be reached at Patricia. Ellis@state.de.us.

Table 5 Compounds Present in "Gasoline" That Appear on Target Analyte Lists for Methods in SW-846				
COMPOUND	8015*	8021	8260	8270
diethyl ether	Χ		Χ	
ethanol	Χ		Χ	
methanol	Χ		Χ	
pyridine	X		Χ	
benzene		Χ	Χ	
ethylbenzene		Χ	Χ	
naphthalene		X	Χ	Χ
toluene		Χ	Χ	
xylenes		Χ		
o-xylene		X	Χ	
m-xylene		Χ	Χ	
p-xylene		X	Χ	
1,2-dibromoethane		X	Χ	
1,2-dichloroethane		Χ	Χ	
tertiary-butyl alcohol			Χ	
phenol				Χ
*Method 8015 is also indicated to be applicable for GRO and DRO.				

#### **EPA HQ UPDATE**

## Analytical Methods Fact Sheet Available

Analytical methods for petroleum hydrocarbons are well established; however, methods that were developed for analysis of petroleum hydrocarbons in water samples may or may not be appropriate for fuel oxygenates. A fact sheet, titled *Analytical* Methodologies for Fuel Oxygenates (EPA 510-F-03-001), outlines the potential problems of analytical methods for common fuel oxygenates and ways to address these problems. It has been distributed to states and regions and is available on the OUST Web site at www.epa.gov/oust/mtbe/ omethods.pdf.

For more information, contact Hal White at (703) 603-7177.

# Senate Passes UST Legislation

On Thursday, May 1, the U.S. Senate passed the Underground Storage Tank Compliance Act (S. 195) by unanimous vote. The legislation provides additional flexibility and authorization of appropriations for preventing and cleaning up releases from USTs. It also includes a dedicated authorization of appropriation for the cleanup of MTBE, mandatory inspection frequencies, additional enforcement tools, and operator training guidelines. Although the House has been working on its version of UST legislation, companion legislation has not been introduced. EPA OUST has been providing technical comments on the proposed legislation.



API to Present Two Free-Product Cleanup Workshops at 20th Annual API/ NGWA Groundwater Conference

For more information, go to API Conferences and Workshops link at www.api.org/groundwater

### L.U.S.T.LINE

New England Interstate Water Pollution Control Commission Boott Mills South 100 Foot of John Street Lowell, MA 01852-1124 Non-Profit Org. U.S. Postage PAID Wilmington, MA Permit No. 200

# Use of TPH Action Levels (HDOH 2024) (includes Forensic Drinking Water Characterization; Newfields 2024)

Hawai'i DOH Appendix 6

JOSH GREEN, M.D. GOVERNOR OF HAWA!'I KE KIA'ĀINA O KA MOKU'ĀINA 'O HAWA!'I



KENNETH S. FINK, MD, MGA, MPH
DIRECTOR OF HEALTH

In reply, please refer to: File: RB-21-24

#### STATE OF HAWAI'I DEPARTMENT OF HEALTH KA 'OIHANA OLAKINO P. O. BOX 3378

HONOLULU, HI 96801-3378

Date: June 12, 2024

To: Interested Parties

Through: Grace Simmons, Program Manager gracelda Simmons

Hazard Evaluation and Emergency Response Office

From: Roger Brewer, PhD

Hazard Evaluation and Emergency Response Office

Subject: Comparison of HIDOH Total Petroleum Hydrocarbon (TPH) Action Levels to Data

for Water Samples

This memorandum provides additional information regarding use of Hawai'i Department of Health (HIDOH) Environmental Action Levels (EALs) for Total Petroleum Hydrocarbon (TPH) for screening of water data, including groundwater, tapwater and surface water. The basis for this described approach is provided in the attachment to the memorandum.

Three categories of petroleum fuel and associated TPH EALs are presented in the EAL lookup tables: 1) Gasolines (TPH<sub>gasolines</sub>), 2) Middle Distillates (TPH<sub>middle distillates</sub>) and 3) Residual Fuels (TPH<sub>residual fuels</sub>). "Middle Distillate" fuels include diesel, kerosene and jet fuel. "Residual Fuels" include motor oil and other heavy fuels and petroleum products. The action levels apply to the single, total concentration of non-specific (e.g., non BTEXMN) hydrocarbon and hydrocarbon-delated degradation compounds (aka "Hydrocarbon Oxidation Products" or "HOPs") present in a water sample and known or assumed to be associated with one of the three-noted categories of fuel (HIDOH 2018). The most conservative action levels should be used for comparison to sample data if the specific type of fuel released cannot be determined or contamination is associated with a mixture of fuel two or more of the noted fuel categories.

Scrutiny of groundwater sample data following the 2021 jet fuel release at the Navy's Red Hill facility in Honolulu identified concerns that the total concentration of TPH-related compounds in a sample was not being adequately quantified. This led to confusion regarding comparison of fuel-specific, TPH EALs to sample data for individual ranges of organic compounds in a sample often reported separately by laboratories.

In short, there is only one concentration of TPH-related contaminants in a sample. The concentration of "TPH" in a water sample derived for comparison to a corresponding TPH action level should be calculated as the sum of the concentration of Total Purgeable Organics (TPO) for volatile compounds plus the concentration of Total Extractable Organics (TEO) for semi-volatile

and non-volatile compounds. Volatile compounds are commonly reported as "Gasoline Range Organics (GRO)." Semi-volatile and non-volatile compounds are commonly and reported as "Diesel Range Organics (DRO)" and "Residual Range Organics (RRO)." The concentration of TPH in a sample is therefore calculated as:

TPH = Total Purgeable Organics + Total Extractable Organics;

or in terms of the volatility of the compounds present:

$$TPH = GRO + DRO + RRO.$$

The identification of middle distillate-related, organic compounds in a water sample and quantification of TPH based only gas chromatography becomes unreliable below a laboratory Method Reporting Limit ("MRL", aka "Laboratory Quantification Limit") of approximately 200 µg/L. This is because the pattern expressed on the chromatogram becomes lost in background "noise" and is no longer reliably discernable as being related to petroleum. As described in the Forensics Fact Sheet attached to this memorandum, samples of drinking water and groundwater with reported concentrations of Total Extractable Organics below this concentration should be retested for individual compounds using a combined gas chromatograph-mass spectrometry (GC-MS) method such as Method 8270. The resulting data should be reviewed by a chemist experienced in petroleum forensics to determine if the compounds are indeed associated with petroleum-related contamination or if they are more likely related to other, nonpetroleum-related organic matter such as algae. Concentrations of organic matter below the MRL should not be reported as "TPH" until such verification has been made.

Questions and comments regarding this Technical Memorandum should be directed to Roger Brewer with HIDOH (roger.brewer@doh.hawaii.gov). Refer also to examples in the use of TPH action levels to assess the risk posed by petroleum-contaminated soil, sediment, water and air are included in a series of petroleum-release case studies published by HIDOH in coordination with experienced consultants (HIDOH 2018).

#### References

HIDOH, 2018, Collection and Use of Total Petroleum Hydrocarbon Data for the Risk-Based Evaluation of Petroleum Releases - Example Case Studies: Hawaii Department of Health, Hazard Evaluation and Emergency Response Office. October 2018.

HIDOH, 2024, Evaluation of Environmental Hazards at Sites with Contaminated Soil and Groundwater – Hawaii Edition (Spring 2024): Hawai'i Department of Health, Office of Hazard Evaluation and Emergency Response.

HIDOH, 2023, *Technical Guidance Manual* (and updates): Hawai'i Department of Health, Office of Hazard Evaluation and Emergency Response, https://health.hawaii.gov/heer/tgm/

HIDOH 2 June 2024

#### Laboratory Analysis of Petroleum-Related Compounds

Petroleum fuels are made of hundreds of individual compounds of differing volatility and sorptive capacity (Figure 1). Gas chromatography and Method 8015 is most commonly used to estimate the total sum of petroleum-related compounds in in soil, water or air. Purge-and-trap techniques are used to sum volatile, C5 to C12 compounds present in a sample, referred to as "Total Purgeable Organics (TPO)." Extraction techniques are used to sum semi-volatile, C8 to C36 or higher compounds present in a sample, referred to as "Total Extractable Organics (TEO)." "TPH" is calculated as the sum of TPO and TEO data. Note that overlap of the two methods between C8 and C12 in does not result in significant double counting, since volatile compounds are largely lost in TEO test extraction methods.

Areas under TPO and TEO "humps" on a gas chromatograph (GC) are compared laboratory standards for fuels that primarily fall within these boiling point ranges (Figure 2). For example, the total concentration of volatile, TPO-related compounds present in a sample is estimated based on comparison to a laboratory standard for gasolines. Data for this range are thus often reported by the laboratory as "Gasoline Range Organics (GRO)." The total concentration of semi-volatile, TEO-related compounds is normally estimated by comparison of the mid-boiling point range of the chromatogram (e.g., C8 to C24) to a diesel or other middle distillate fuel standard and the higher boiling point range (e.g., C24-C36+) to a standard for motor oil. The former is often reported by the laboratory as "Diesel Range Organics (DRO)" while the latter is often reported as "Residual Range Organics (RRO)."

Note that the presence of "GRO" range compounds in a sample does not necessarily mean that gasoline is present, only that some compounds within the fuel itself fell within this range. Jet fuels, for example, can consist of hydrocarbon compounds that span both GRO and DRO boiling point ranges (e.g., refer to HIDOH 2022). This is considered in development of carbon range-weighted, TPH toxicity for neat fuels as well as TPH toxicity factors for vapors from fuels and fuel-specific mixtures of dissolved-phase hydrocarbons in water.

Partially oxidized, polar, hydrocarbon-related degradation products will be captured and included in TPO and TEO analysis of a sample. These compounds are also referred to as "Hydrocarbon Oxidation Products" or "HOPs." The toxicity of the mixture of HOPs compounds is assumed to be identical to that of the original mixture of parent hydrocarbon compounds (HIDOH 2024). Polar compounds should in particular not be removed from water samples using silica gel cleanup (SGC) or related methods prior to comparison to TPH action levels. Comparison of SGC to non-SGC data can, however, assist in determining the overall state of degradation of the petroleum.

#### **Laboratory Reporting Ranges vs TPH Action Levels**

The concentration of TPH in a sample is calculated as the sum of all volatile and semi-volatile, hydrocarbon-related compounds minus the concentration of compounds targeted for individual assessment (e.g., BTEX and PAHs):

TPH = Total Purgeable Organics + Total Extractable Organics;

or in terms of boiling point ranges referenced by the laboratory:

TPH = GRO + DRO + RRO.

HIDOH 3 June 2024

Sample data should not be reported as "TPH" by the laboratory unless the data represent the sum of TPO and TEO as noted above. It is otherwise preferable that the laboratory report data in terms of TPO and TEO with the corresponding carbon ranges noted, for example  $TPO_{C5-C12}$ ,  $TEO^{C8-C24}$  and  $TEO_{C24-C36}$ . Reference to the sum of the data as "TPH" is an interpretation and second step of the process, assuming that reviews of chromatograms and, as needed, forensic analyses described below, confirm that the main mass of the TPO and TEO is indeed related to petroleum.

Sample data for individual boiling point ranges should not be reported as "TPH" by the laboratory, since the data might not represent to total sum of petroleum-related compounds in the sample. For example, sample data for "GRO" range compounds should not be reported as "TPHg." Sample data for "DRO" and "RRO" range compounds should not be reported as "TPHd" or "TPHo."

The resulting summation of TPO and TEO data is compared to the TPH action level applicable to the primary category of fuel released. For example, where there has been a gasoline release, the total concentration of TPO and TEO compounds in a sample (minus BTEX) should be compared to action levels for TPH<sub>gasolines</sub>. In the case of suspected contamination by diesel or another middle distillate fuel, the sum of TPO plus TEO data is compared to action levels for TPH<sub>middle distillates</sub>. A similar approach is applied for comparison of laboratory data to action levels for TPH<sub>residual fuels</sub>. If the nature of the fuel release is uncertain or in cases of releases of multiple fuel types, then the sum of TPO and TEO should be compared to the fuel category with the most conservative action levels unless other supporting information is provided.

Determination of the primary type of fuel released in water based on a review of chromatograms is more complicated for water than for soil or air. Dissolution of hydrocarbons into water will be biased toward more soluble, aromatic compounds. The resulting mix of dissolved-phase compounds in water as reflected in the chromatogram will therefore be different from a chromatogram of the neat fuel itself. In the case of water contaminated by gasolines, dissolved-phase compounds such as benzene, toluene, ethylbenzene and xylenes (BTEX) will be reported as part of the GRO range compounds, as expected. Compounds of >C8 aromatics that might elute in the DRO range are likely to be minimal.

As the compounds degrade and become less volatile, however, original GRO-range compounds will begin to elute at a higher boiling point, with some compounds beginning to appear on the chromatogram in the DRO range (Figure 3). The sum of the GRO-range and DRO-range compounds represents the total concentration of TPH for the sample and would be compared to action levels for TPH<sub>gasolines</sub>. Compounds associated with degraded middle distillate fuels such as diesel or jet fuel could similarly elute in the RRO range of the chromatogram. The estimated concentration of these compounds is added to the estimate concentration of DRO-range compounds to generate a sum TPH concentration for the sample as a whole. This is then compared to action levels for TPH<sub>middle distillates</sub>.

Dissolved-phase middle distillate fuel, such as JP-5 jet fuel, can include BTEX as well as a significant amount of additional, heavier and less volatile aromatics (e.g., >C8 aromatics). This can lead to compounds falling within both the GRO and DRO ranges of a chromatogram even in the absence of degradation (see Figure 2). As the GRO-range compounds degrade, they will again begin to be reported as "DRO." As the DRO-range parent compounds degrade, they will elute on the chromatogram at a higher boiling point and in some case could reported as "RRO."

HIDOH 4 June 2024

The range of dissolved "TPH" in a sample could therefore span all three ranges on a chromatogram.

#### **Consideration of Individually Targeted Compounds**

The concentration of individually targeted compounds such as BTEX and PAHs should be subtracted from the TPH data to avoid double counting (refer to TGM Section 9.3.1.2). This can be done by the laboratory on request or by the project consultant. In practice, this will make minimal difference in the concentration of TPH used for comparison to EALs, since the proportion of BTEX, PAHs and other individually targeted compounds is normally minimal in comparison to non-specific compounds collectively assessed as "TPH."

#### **Case-Specific TPH Action Levels**

Toxicity, along with physiochemical and other factors considered in the development of TPH action levels for specific fuel types are discussed in Volume 2, Appendix 1, Section 6 of the HIDOH Environmental Action Level guidance (HIDOH 2024). The assumptions used are intended to address the majority of petroleum-impacted sites in Hawai'i without the need for a site-specific risk assessment.

Development of "case-specific," TPH action levels will, however, be required in a small number of cases when assumptions incorporated into the default TPH action levels do not apply to conditions in the field. For example, the TPH action level for middle distillate fuels are based on the assumed, combined toxicity of GRO and DRO components of typical middle distillate fuels. (RRO components are negligible). The action level for drinking water ("tapwater") also assumes that the fuel is partially oxidized and no longer significantly volatile. This decreases the overall exposure risk and results in a slight increase in action levels over fresh fuel that is still volatile.

If these conditions are not met in the field for a specific case, then a case-specific TPH action level(s) must be generated. For example, if fresh fuel is released and threatens a drinking water supply, then alternative action levels would need to be developed that take into consideration volatilization of compounds from water and exposure via inhalation (e.g., HIDOH 2022).

Preparation of case-specific TPH action levels will normally be undertaken by the responsible party but might need to be generated by HIDOH in some instances. In either situation, the case-specific EAL and the rationale for its calculation must be reviewed and approve by HIDOH. The responsible party will also have the option to prepare alternative action levels at a later time in the response action, based on changes in site conditions, and provide this to HIDOH for review and approval (e.g., degradation and reduced volatility and toxicity of fuel-contaminated groundwater over time). Supporting field data must be provided to support changes to the initial action level.

#### **Data Below the Method Reporting Limit**

The Method 8015 Method Detection Level should be no greater than the TPH action level for the subject fuel category (e.g., 91  $\mu$ g/L for TPH(middle distillates). Sample data for Total Purgeable Organics (e.g., GRO) or Total Extractable Organics (e.g., DRO or RRO) below the laboratory Method Reporting Limit for the test method ("MRL"; aka "Limit of Quantification") cannot directly be assumed to be associated with petroleum-related compounds. This is because the concentration of organic compounds in the sample is too low to generate a recognizable, fuel-related pattern.

An MRL of  $50~\mu g/L$  is typical for reporting of TPO range compounds in water. An MRL of  $200~\mu g/L$  or higher is common for reporting of TEO range compounds, including both "DRO" and "RRO." Sample data below the MRL are normally qualified with "J" flag in the laboratory report. This indicates that the specific nature of the organic compounds identified is certain. "J-flagged" data should be reported as "TPO" and "TEO" by the laboratory, rather than "TPH." The organic compounds identified might or might not be related to petroleum. Algae and other organic matter are also common in water at these concentrations.

This will primarily be an issue for TEO-related organic matter detected below the typical MRL of 200  $\mu$ g/L. In cases where J-flagged data could reflect hydrocarbon-related contamination and the sum concentration of TPO and TOE data exceeds the TPH action level, the sample should be immediately retested using Mass Spectrometry (MS) methods (e.g., Method 8260 for volatiles and Method 8270 for semi-volatiles). This allows individual compounds to be identified. An experienced chemist can then determine if the compounds are more likely to be associated with dissolved hydrocarbons or hydrocarbon-related degradation products or more likely related to other organic material in the sample, such as algae. A Fact Sheet on the use of mass spectrometry methods as a forensics tool to determine the likely origin of J-flagged compounds is included as an attachment to the memorandum.

If a conclusion is made that the compounds are likely related to hydrocarbons, then the data should be considered for calculation of a final TPH concentration for the sample (refer to attached Forensics Fact Sheet; Newfields 2024). This initially includes direct comparison of Method 8015 TPH data to applicable risk-based action levels. Additional consideration of data based on Non-Volatile Dissolved Organic Carbon (NVDOC) analysis or similar test methods might be required for heavily degraded plumes if Method 8015 data are suspected to underestimate the total concentration of polar, hydrocarbon-related metabolites present (USGS 2024).

If the GC-MS review suggests that the compounds are unlikely to be related to hydrocarbons, then the data do not need to be incorporated into calculation of TPH. Consult with HIDOH to determine if identification of nonpetroleum-related compounds requires additional action, including other identified contaminants and/or naturally occurring biogenic matter that could indicate elevated levels of bacteria in the water.

As a default, J-flagged data should be assumed to reflect hydrocarbon-related compounds in cases where petroleum contamination has otherwise been confirmed unless disproven by more MS or other detailed analysis. Note that this approach differs from the recommended use of the MRL as an action level for other type of contaminants when it exceeds the corresponding action level (refer to Volume 1, Section 2.3 of the EAL guidance). The MRL is not used as an action level in the case of TPH.

An elevated MRL for a range typically reflects a high concentration of contaminants in one of the other ranges or otherwise in the sample. Discussions regarding next steps can proceed if the sum TPH concentration exceeds the action level for the fuel-type involved. If not, discuss the reasons for the elevated MRL and need for retesting of the sample with the laboratory and the overseeing project manager at HIDOH.

"Non-detects" at the laboratory Method Detection Level (MDL) do not need to be considered in calculation of a final TPH concentration for a sample unless otherwise required by HIDOH.

#### Quantification of TPH in Other Media

HIDOH 6 June 2024

Summation of Total Purgeable Organics (e.g., GRO) data and Total Extractable Organics data (e.g., DRO and RRO) for calculation of TPH is generally not necessary for soil samples. Environmental Action Levels for different categories of TPH in soil reflect concentrations that necessitate the presence of free product in the soil. The predominant makeup of "TPH" in the soil sample should more closely match the makeup of the original fuel, even if partially weathered, should in turn be captured by a single reporting range test (see Figure 1).

For example, the concentration of gasoline product in soil should be adequately captured by a purgeable organic compound test method and associated GRO data. The concentration of diesel and other middle distillate fuels in soil should be adequately captured by extractable organic compound test methods and associated DRO data, etc. Reported concentrations of GRO, DRO and RRO in soil can therefore be individually compared to soil action levels for TPH<sub>gasolines</sub>, TPH<sub>middle distillates</sub> and TPH<sub>residual fuels</sub>.

The concentration of TPH in air and soil vapor samples should be reported as the sum of C5 to C12 compounds and the data similarly compared to the indoor air and subslab soil vapor action level appropriate for the fuel in question (Section 7.13.1 of the HIDOH *Technical Guidance Manual*, HIDOH 2023). Summa canister methods are normally used for reporting of up to C12 hydrocarbons in air and vapor samples. The use of sorbent tube methods is necessary for reporting of >C12 hydrocarbons in air or soil vapor. The *Technical Guidance Manual* currently recommends the use of both Summa and sorbent sampling methods for air and vapor samples associated with middle distillate fuels. Testing of vapors from such fuels has consitently identified insignificant amounts of >C12 compounds, however. This negates the need for sorbent tube vapor sample data at petroleum release sites unless otherwise requested by HIDOH or desired by the project consultant. Updates to the TGM to reflect this change are pending.

#### References

HIDOH, 2024, Evaluation of Environmental Hazards at Sites with Contaminated Soil and Groundwater – Hawaii Edition (Draft Spring 2024): Hawai'i Department of Health, Office of Hazard Evaluation and Emergency Response.

HIDOH, 2022, Recommended Risk-Based Drinking Water Action Levels for Total Petroleum Hydrocarbons (TPH) Associated with Releases of JP-5 Jet Fuel: Hawai'i Department of Health, Hazard Evaluation and Emergency Response, Technical Memorandum from Roger Brewer to Kathleen Ho, April 20, 2022.

ITRC, 2018, TPH Risk Evaluation at Petroleum Contaminated Sites: Interstate Technology & Regulatory Council. Washington D.C.

USGS, 2024, Distribution of Ancient Carbon in Groundwater and Soil Gas from Degradation of Petroleum near the Red Hill Bulk Fuel Storage Facility, Oʻahu, Hawaiʻi: U.S. Geological Survey, Scientific Investigations Report 2024–5034.

HIDOH 7 June 2024




Figure 1. Comparison of fuel categories to laboratory analytical methods and reporting ranges; a) Total Purgeable Organics (TPO) methods are used to quantify volatile compounds (e.g., Method 8260 for "GRO"), b) Total Extractable Organics (TEO) methods are used to quantify semi-volatile compounds (e.g., Method 8015M for "DRO" and "RRO").




Figure 2. Chromatogram depicting TPO and TEO analytical method ranges and associated "GRO," "DRO" and "RRO" reporting ranges sometimes used by laboratories. "TPH" is qual to the sum of the full range of petroleum-related compounds in the sample (TPH = TPO+TEO or GOR+DRO+RRO).




Figure 3. Comparison of partially degraded, dissolved-phased petroleum in water to laboratory analytical methods and reporting ranges. Note potential spread of fuel-related degradation compounds into higher boiling point ranges in comparison to Figure 1.

HIDOH 9 June 2024

Forensic Drinking Water Characterization (Newfields, June 2024)

HIDOH 10 June 2024



### **Forensic Water Characterization**

Identifying Purgeable and Extractable Chemicals Included in Total Petroleum Hydrocarbon Measurements
Prepared for the Hawaii Department of Health (HIDOH)

#### Introduction

Total Petroleum Hydrocarbon (TPH) analysis is a conventional laboratory technique used for monitoring water samples for petroleum hydrocarbons. TPH analyses conducted using methods like USEPA Method 8015D by Gas Chromatography with a Flame Ionization Detector (GC/FID) provides a bulk measurement of semi-volatile extractable organic compounds (EOC) in the  $C_8$  to  $C_{44+}$  carbon range. Total  $C_8$  to  $C_{44+}$  EOC is commonly measured in two carbon ranges reported as "Diesel Range Organics (DRO)" and "Residual Range Organics (RRO)." Volatile TPH analysis conducted using methods like USEPA Method 8260D by GC Mass Spectrometry (GC/MS) provide a bulk measurement of the purgeable organic compounds (POC) in the  $C_5$  to  $C_{12}$  carbon range and is commonly reported as "Gasoline Range Organics (GRO)." The HIDOH calculates the total concentration of volatile and semi-volatile TPH as the sum of POC + EOC (Figure 1). The HIDOH prefers the terms POC and EOC to indicate that these bulk measurements can include both petroleum and non-petroleum constituents.

GC/FID analysis cannot identify the specific chemicals reported within a bulk measurement. At higher relative concentrations it may be clear that a water sample contains petroleum hydrocarbons, but at low levels confirmation analysis is needed to identify the chemical constituents. When analyzing samples with low levels of organic matter, it is important to identify the specific chemicals present using a method like GC Mass Spectrometry (GC/MS). GC/MS analysis can be used to determine if low-level organic constituents in a sample are truly petroleum hydrocarbons or are related to other non-petroleum organic contaminants or naturally occurring biogenic materials (e.g. plant waxes, organic acids).




Figure 1 provides an example of a water sample with both petroleum hydrocarbons and naturally occurring plant waxes. In this example the EOC (DRO and RRO) measurements include impacts from both petroleum and naturally occurring chemicals and contain a high bias due to non-petroleum constituents. EPA Method 8015D analysis cannot differentiate between these classes of chemicals. Volatile POC (GRO) measurements, or semi-volatile EOC (DRO or RRO) measurements performed using a mass specific analysis like GC/MS can more readily differentiate between petroleum-and non-petroleum-related compounds.

#### Recommended Forensic Analysis for Low-Level TPH Characterization

Forensic methods are designed to characterize source materials and are optimized for low-level sample analysis. To maximize the extraction efficiency of both non-polar and polar hydrocarbons, samples should be prepared following USEPA Method 8270E's guidance for acid, base and neutral extraction with dichloromethane (DCM)(EPA Method 8270E, 1.4.8). It is important to note that solvents such as hexane have lower relative extraction efficiencies than DCM and may underrepresent polar and oxygenated hydrocarbons measured during sample analysis. Oxygenated hydrocarbon compounds are assumed to have the same toxicity as the parent hydrocarbons under HIDOH guidance (HIDOH 2024). When characterizing low level EOC (DRO or RRO) results it is recommended to follow a tiered analytical approach (Figure 2):

### **NewFields**

- ❖ Tier I: Modified EPA Method 8015D High Resolution GC/FID Fingerprint
  - High resolution GC/FID fingerprints provide greater separation between carbon ranges and allow for a more accurate assessment of potential petroleum source materials.
- Tier II: Confirmation Testing by GC/MS
  - Samples reporting low level POC (GRO), or EOC (DRO or RRO) results are further analyzed in Tier II by EPA Method 8260D for  $C_5$ - $C_{12}$  purgeable organics and Method 8270E  $C_8$ - $C_{44+}$  for extractable organics to screen for the presence of petroleum and other non-petroleum chemicals. This type of GC/MS analysis is used to perform both target and non-target analysis (NTA) and to detect tentatively identified compounds (TICs) that can be used to characterize the purgeable, and extractable constituents present in low level EOC (DRO or RRO) measurements. Tier II analysis will help determine if EOC (DRO or RRO) measurements are truly related to petroleum hydrocarbons or contain other non-petroleum-related constituents. Tier II GC/MS analysis must achieve sufficient instrument sensitivity and should target reporting limits between 1.0 and 5.0  $\mu$ g/L for  $C_5$ - $C_{12}$  purgeable organics and  $C_8$ - $C_{44+}$  extractable organics.
    - o <u>EICP Petroleum Hydrocarbon Screening</u>: Samples reporting low-level EOC (DRO or RRO) measurements are screened for the presence of petroleum hydrocarbons using GC/MS extracted ion current profiles (EICPs) that include petroleum specific diagnostic ions. EICPs provide a broad screening metric by which samples can be qualitatively evaluated for known chromatographic patterns of target and non-target petroleum hydrocarbon compounds. Samples should be screened for EICPs that monitor saturated hydrocarbons (m/z 43, 57, 85), alkylated benzenes (m/z 78, 92, 106, 120, 134), alkylated naphthalenes (m/z 128, 142, 156, 170, 184) and alkylated phenanthrenes and anthracenes (m/z 178, 192, 206, 220, 234). EICP screening can determine if petroleum hydrocarbons are present above the detection limit.
    - Non-Petroleum NTA and TIC Analysis: If GC/MS chromatograms contain NTA peaks arising from non-petroleum sources, the peaks are further analyzed using mass spectral analysis. The mass spectrum of NTAs is compared to a NIST library of mass spectrum and is assigned a tentatively identified compound name (TIC). TICs should be carefully reviewed for the quality of spectral matches between samples and the NIST library. A project specific threshold should be established for acceptable TIC quality scores (e.g. >50%) and only TICs with acceptable quality scores should be used in low-level TPH characterization.

#### ❖ Tier III: Petroleum Characterization

 If suspected petroleum-related compounds are present, samples can be further analyzed by modified forensic Methods 8260D-PIANO volatile organic compounds (paraffins, isoparaffins, aromatics, naphthenes and olefins) and 8270E-Alkylated PAHs. These methods are designed to chemically characterize petroleum hydrocarbon residues, determine source type, and evaluate the degree of environmental weathering. Consult HIDOH guidance for appropriate use of data for potential assessment of risk beyond initial forensic analysis (HIDOH 2024).

If petroleum-related compounds are identified during sample analysis, including the presence of parent and alkylated petroleum hydrocarbons and/or petroleum hydrocarbon-related degradation compounds, then HIDOH guidance should be reviewed to determine appropriate additional actions. This can include direct comparison of Method 8015 TPH data to risk-based action levels published by the agency. Additional consideration of data based on Non-Volatile Dissolved Organic Carbon (NVDOC) analysis or similar test methods might be required in some cases to more accurately estimate the total concentration of hydrocarbon-related metabolites present in a sample (USGS 2024).

#### References:


HIDOH, 2024, Evaluation of Environmental Hazards at Sites with Contaminated Soil and Groundwater – Hawaii Edition: Hawai'i Department of Health, Office of Hazard Evaluation and Emergency Response, Spring 2024.

USGS, 2024, Distribution of Ancient Carbon in Groundwater and Soil Gas from Degradation of Petroleum near the Red Hill Bulk Fuel Storage Facility, O'ahu, Hawai'i: U.S. Geological Survey, Scientific Investigations Report 2024–5034.

### **NewFields**

Figure 2. Tiered approach to Forensic Water Characterization (HIDOH 2024).

Follow this tiered approach for samples reporting positive TPH results and consult HIDOH for regulatory guidance.



### NewFields

#### Hawaii DOH 2024 Technical Notes:

- 1. **Tier I: (quantitative):** Petroleum hydrocarbon patterns are not generally discernable at concentrations below the laboratory Method Reporting Level (MRL) for GRO, DRO, and RRO methods (i.e. purgeable and extractable organic compounds). The HIDOH target MRL for petroleum-related GRO (Total Purgeable Organic Compounds,  $C_5$ - $C_{12}$ ) is 50 µg/L. The HIDOH target MRL for petroleum-related DRO and RRO (i.e. Total Extractable Organic Compounds,  $C_8$ - $C_{44}$ ) is 200 µg/L. High resolution GC/FID fingerprints provide greater separation between carbon ranges and allow for a more accurate assessment of potential source materials
- 2. **Total Petroleum Hydrocarbons (TPH)** concentrations are estimated by HIDOH as the sum of POC (GRO), and EOC (DRO and RRO) minus the concentration of organic compounds not related to petroleum hydrocarbon sources (HIDOH 2024). TPH results should be compared to the HIDOH petroleum hydrocarbon action level most appropriate for the type of fuel release.
- 3. **Tier II (qualitative):** Samples are analyzed by EPA Method 8260D for C<sub>5</sub>-C<sub>12</sub> purgeable organic compounds and Method 8270E C<sub>8</sub>-C<sub>44+</sub> for extractable organic compounds to characterize the chemical constituents present in POC (GRO), or EOC (DRO and RRO) measurements. EPA Methods 8260D and 8270E are used to screen samples for the presence of petroleum and other non-petroleum chemicals.
- 4. **Petroleum-Related Compounds:** Include identifiable petroleum-related hydrocarbon compounds as well as suspected petroleum-related degradation compounds, including partially oxidized aromatics and aliphatics.
- Non-Petroleum-Related Compounds: Consult with HIDOH to determine if identification of non-petroleumrelated compounds requires additional action, including other identified contaminants and/or naturally occurring biogenic matter.
- 6. Tier III (quantitative): According to HIDOH guidance, additional testing of a sample using PIANO-VOC and alkylated PAH analyses when petroleum-related compounds have been tentatively identified is optional. Toxicity factors and risk-based action/screening levels may be available for some compounds in addition to benzene, toluene, ethylbenzene, xylenes, naphthalene, and methylnaphthalene (BTEXNM). Note that non-BTEXNM, petroleum-related compounds are by default considered in bulk aromatic and aliphatic carbon range groupings used to develop weighted toxicity factors and risk-based action levels for TPH (refer to Appendix 1, Section 6 of the HIDOH EAL guidance). The individual assessment of petroleum-related compounds other than BTEXNN is not normally necessary since these compounds are included under the umbrella category of TPH. Proposals for separate assessment of individual chemicals and/or use of alternative methods to assess the weighted toxicity of TPH-related compounds should be presented to HIDOH for review and approval.